

Implementing an IBM b-type SAN with 8 Gbps Directors and Switches

Learn about the latest additions to the IBM b-type portfolio

Refresh and enhance your skills and awareness

Increase your SAN knowledge

> Jon Tate Uwe Dubberke Michael Engelbrecht Shanmuganthan Kumaravel Jose Rodriguez Ruibal

Redbooks

ibm.com/redbooks



International Technical Support Organization

Implementing an IBM b-type SAN with 8 Gbps Directors and Switches

March 2011

Note: Before using this information and the product it supports, read the information in "Notices" on page xvii.

Eleventh Edition (March 2011)

This edition applies to Data Center Fabric Manager v10.1.4 and Fabric Operating System v6.4.x.

© Copyright International Business Machines Corporation 2000-2011. All rights reserved. Note to U.S. Government Users Restricted Rights -- Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Notices xvii Trademarks xviii
Preface xix The team who wrote this book xix Now you can become a published author, too! xxii Comments welcome xxii Stay connected to IBM Redbooks xxiii
Summary of changes xxv March 2011, Eleventh Edition xxv
Chapter 1. Product introduction11.1 Overview of the product21.1.1 Hardware features21.1.2 Hardware naming convention: IBM and Brocade21.2 Product descriptions31.2.1 IBM System Storage SAN24B-4 switch31.2.2 IBM System Storage SAN24B-4 switch41.2.3 IBM System Storage SAN80-B4 switch61.2.4 IBM Converged Switch B3271.2.5 SAN32B-E4(2498-E32)81.2.6 IBM System Storage SAN84B Director91.2.7 IBM System Storage SAN34B Director91.2.8 IBM System Storage SAN768B Director111.2.9 Brocade 4 Gbps SAN Switch Modules151.2.11 Fabric Operating System161.2.12 Management tools161.2.13 Licensing171.2.14 Security171.2.15 Virtual Fabrics181.2.16 Support19
Chapter 2. Data Center Fabric212.1 Methodologies of current SAN design222.1.1 Availability considerations252.1.2 Benefits of a consolidated SAN design252.2 IBM/Brocade Data Center Fabric value enhanced25

2.3 IBM/Brocade backbone models	. 27
2.4 Scalability at the core	. 30
2.4.1 Scalability advantages	. 31
2.4.2 Moving a backbone-class switch from core to edge	. 33
2.5 Blade options	. 36
2.6 Advance Feature and Licensing	36
2.6.1 Advanced Feature summary	. 37
2.6.2 Fabric Operating Systems	. 37
	. 07
Chapter 3. Hardware features	. 39
3.1 The hardware	. 40
3.1.1 Entry level, midrange, and director models.	40
3.1.2 Switch and director model types	40
32 Generic features	41
3.2.1 Auto-sensing speed pegotiation	
3.2.2. Zoning	
3.2.2 Zohning	. 41
3.2.0 Traine intering	. 42
3.2.4 Roulling	. 42
	. 43
	. 43
	. 43
	. 45
3.3 Products and features	. 46
3.3.1 2499-384	. 46
3.3.2 2499-192	. 73
3.3.3 2109-M48	. 78
3.3.4 b-type top of rack switches	. 85
Chapter 4. Fabric Operating System	. 91
4.1 Fabric Operating System overview	. 92
4.2 Fabric Operating System v6.2.0 features	. 92
4.2.1 New features	. 92
4.2.2 Feature descriptions	. 94
4.3 Fabric OS v6.3.1 and v6.4.0 updates	. 98
4.3.1 Changes in Fabric OS version 6.3.1	. 99
4.3.2 Changes in Fabric OS version 6.4.0	101
4.4 Firmware upgrade considerations	109
4.4.1 Licensing changes	109
4.4.2 Fabric scalability	110
4.4.3 FICON support	112
4.5 Additional important notes and guidelines.	113
Chapter 5. Management tools	117
5.1 Web Tools	118

 5.2 Fabric Watch 5.3 SNMP 5.4 Data Center Fabric Manager 5.4.1 Time-saving tools 5.4.2 Exceeding service level agreements 	118 121 121 123 124
Chapter 6. Implementation 6.1 Implementation 6.1.1 Initial setup 6.1.2 The command-line interface initial setup. 6.1.3 SAN768B, SAN384B, and SAN256B configuration procedure 6.1.4 Connecting to the switch. 6.1.5 Setting the switch name 6.1.6 The Port Identifier format 6.1.7 Setting the date. 6.1.8 Firmware update. 6.1.9 SAN256B optional modem setup 6.2 SAN32B-3 implementation using EZSwitchSetup. 6.2.1 Implementing EZSwitchSetup. 6.2.3 Basic troubleshooting with EZSwitchSetup.	125 126 131 136 139 140 142 144 145 147 152 153 166 167
Chapter 7. License administration. 7.1 Licensed features 7.1.1 Ports on Demand 7.1.2 Full Fabric 7.1.3 8 Gbps. 7.1.4 Inter-Chassis Link (ICL) 7.1.5 Adaptive Networking. 7.1.6 Frame Based ISL Trunking 7.1.7 Fabric Watch 7.1.8 Advanced Performance Monitoring. 7.1.9 Extended Fabrics 7.1.10 ISL Trunking 7.1.11 Integrated Routing. 7.1.12 High Performance Extension over FCIP/FC 7.1.13 FICON Management Server 7.2.1 Using Web Tools to administer licenses 7.2.2 Installed licenses. 7.3 Tips on solving licensing issues	169 170 171 171 172 172 172 172 173 173 174 174 174 174 175 175 175 177 179
Chapter 8. Web Tools	181 182

8.1.1 Web Tools, the EGM license, and DCFM	. 182
8.1.2 System requirements	. 187
8.1.3 Java installation on the workstation	. 189
8.1.4 Java plug-in configuration	. 190
8.1.5 Value line licenses	. 193
8.1.6 Opening Web Tools	. 193
8.1.7 Requirements for the examples in this chapter	. 200
8.1.8 Overview of the Web Tools user interface	. 201
8.2 Web Tools buttons	. 204
8.2.1 Status button	. 205
8.2.2 Temp button	. 210
8.2.3 Power button	. 212
8.2.4 Fan button	. 212
8.2.5 HA button	. 213
8.2.6 Beacon button	. 215
8.2.7 Switch Status Policy button	. 216
8.2.8 Legend button	. 216
8.3 Name Server task	. 217
8.4 Zone Admin task	. 220
8.5 Admin Domain task	. 220
8.5.1 Requirements for Admin Domains	. 224
8.5.2 Creating an Admin Domain	. 225
8.6 Port Admin task	. 231
8.6.1 Renaming a port	. 237
8.6.2 Editing the configuration	. 237
8.6.3 Enabling and disabling a port	. 241
8.6.4 Persistent enable and persistent disable options for a port	. 241
8.6.5 Enabling or disabling trunking for a specific port	. 242
8.6.6 Enabling or disabling N_Port ID virtualization (NPIV)	. 242
8.6.7 Port swap	. 242
8.6.8 F_Port Trunking	. 242
8.6.9 Re-authenticating	. 245
8.6.10 F_Port BB credit	. 245
8.6.11 QoS Enable/Disable	. 245
8.6.12 Port beaconing	. 245
8.6.13 WWN to N_Port mapping	. 246
8.6.14 Port Administration window on the SAN256B and SAN768B	. 248
8.6.15 Port Administration for the FCOE switch	. 249
8.6.16 Port Administration for the IBM System Storage SAN06B-R	. 249
8.7 Switch Admin task	. 250
8.7.1 Switch Administration window layout	. 251
8.7.2 Switch tab	. 252
8.7.3 Network tab	. 255

8.7.4 Firmware Download tab	259
8.7.5 SNMP tab	263
8.7.6 License tab	268
8.7.7 User tab	276
8.7.8 Configure tab	281
8.7.9 Routing tab	286
8.7.10 Extended Fabric tab	286
8.7.11 AAA Service tab	287
8.7.12 Trace tab	290
8.7.13 Security Policies tab	291
8.7.14 FICON CUP tab	296
8.7.15 Trunking tab	296
8.8 Telnet/SSH Client task	296
8.9 Fabric Watch task	297
8.9.1 Alarm Notification tab	299
8.9.2 Threshold Configuration tab	300
8.9.3 Configuration Report tab	308
8.9.4 Memory and CPU Usage monitor with Fabric Watch	308
8.9.5 Modifying settings for switches with one power supply	310
8.9.6 Email Configuration.	314
8.10 IBM SAN ICL connectivity	314
8.10.1 Before you begin	315
8.10.2 ICL cabling	317
Chapter 9 IBM System Storage Data Center Fabric Manager	323
9.1 DCFM products	
9.1.1 DCFM Professional	324
9.1.2 DCFM Enterprise Edition	
9.1.3 Enhanced Group Management	326
9.1.4 DCFM Enterprise scalability	326
9.1.5 DCFM operating system support	327
9.2 DCFM installation	327
9.2.1 Installation of DCFM Enterprise Edition on Windows platform	328
9.2.2 DCFM server and client	336
9.3 DCFM GUI orientation	337
9.3.1 Front panel	337
9.3.2 Main toolbar	339
9.3.3 Product list	340
9.3.4 Connectivity Map	344
9.3.5 Master Log	349
9.3.6 Performance Legend.	350
9.3.7 Minimap	351
9.3.8 Status bar	352

9.3.9 Fabric tracking.	353
9.3.10 WWN display	355
9.3.11 Object naming	356
9.4 DCFM Fabric Discovery	356
9.4.1 Seed switch.	356
9.4.2 Setting up the discovery	358
9.4.3 DCFM Discovery Verification	362
9.5 DCFM reports	363
9.5.1 Fabric Summary Report and Port Report	364
9.5.2 Generating performance reports	367
9.5.3 Generating zoning reports.	367
9.6 Event logs	369
9.7 Performance management	373
9.7.1 Performance measures	375
9.7.2 Collecting performance data	375
9.7.3 Real time performance data	376
9.7.4 Historical performance data	378
9.7.5 Performance thresholds	381
9.7.6 Connection utilization	384
9.8 Encryption configuration	386
9.9 User management.	388
9.10 DCFM Server Management Console	390
9.10.1 Changing server port numbers	392
9.10.2 Restoring the database	393
9.10.3 Configuring authentication	395
9.10.4 Capturing technical support information	396
9.10.5 Gathering switch information for support	398
9.10.6 Viewing technical support information.	400
9.10.7 HMC upgrade	401
Chapter 10. Host Connectivity Manager	403
10.1 HCM features	404
10.1.1 Software features	404
10.1.2 Tree node pop-up menus	405
10.2 Getting started with HCM software	406
10.2.1 HCM software launch	407
10.2.2 Command line utility	408
10.2.3 HCM configuration data	408
10.2.4 Remembering the password	409
10.2.5 Skipping login	409
10.2.6 Changing an HCM application password	409
10.2.7 Changing an HCM agent password	410
10.2.8 Resetting a password or restoring a factory default password	411

10.2.9 Backing up data after an uninstall	. 412
10.2.10 Backing up HCM data using HCM	. 412
10.2.11 Restoring HCM data using HCM	. 413
10.2.12 HCM main window	. 414
10.2.13 HCM product icons	. 415
10.2.14 Discovery	. 416
10.2.15 Setting up out-of-band discovery for an adapter	. 416
10.2.16 Logging off HCM	. 418
10.3 Host configuration	. 418
10.3.1 Host security authentication	. 418
10.3.2 Configuring security authentication using the GUI	. 418
10.3.3 Configuring security authentication using the CLI	. 420
10.3.4 Buffer credits	. 421
10.3.5 Basic port configuration	. 422
10.3.6 Opening the Basic Port Configuration dialog box	. 422
10.3.7 Port logging level	. 423
10.3.8 Port speed	. 426
10.3.9 Frame data field size	. 428
10.3.10 Persistent binding	. 428
10.3.11 QoS (HBA only)	. 430
10.3.12 Path Time Out	. 433
10.3.13 Target rate limiting	. 435
10.3.14 Boot over SAN	. 437
10.3.15 Configuring Boot over SAN	. 438
10.3.16 Boot code image upload	. 439
10.3.17 Updating the boot code using the GUI	. 439
10.3.18 Virtual port configuration	. 440
10.3.19 Creating a virtual port	. 440
10.3.20 Deleting a virtual port	. 442
10.3.21 HCM logging levels	. 443
10.3.22 Advanced port configuration	. 444
10.3.23 Opening the Advanced Port Configuration dialog box	. 444
10.3.24 NPIV	. 446
10.3.25 Name configuration	. 446
10.3.26 Exporting the properties for a WWN	. 451
10.3.27 Importing the properties for a WWN	. 452
10.3.28 Importing properties in EFCM format	. 453
10.3.29 VLAN configuration	. 455
10.3.30 Adding a VLAN	. 456
10.3.31 Editing a VLAN	. 457
10.3.32 Removing a VLAN	. 458
10.4 Monitoring	. 459
10.4.1 Performance monitoring	. 459

10.4.2 Polling frequency rate	. 460
10.4.3 Resetting statistics	. 462
10.4.4 Master Log	. 463
10.4.5 Filtering event log entries	. 464
10.4.6 Application log.	. 465
10.4.7 Syslog support	. 466
10.4.8 Opening the Syslog Server Configuration dialog box	. 466
10.4.9 Removing a host server	. 467
Chapter 11. Virtual Fabrics	. 469
11.1 IBM/Brocade Virtual Fabric	. 470
11.1.1 Virtual Fabrics introduction	. 470
11.1.2 Logical switches and logical fabrics	. 470
11.2 What Virtual Fabrics are	. 472
11.2.1 Logical switch	. 473
11.2.2 Logical fabric	. 474
11.2.3 ISL sharing	. 474
11.2.4 Administrative Domains	. 474
11.2.5 User accounts	. 475
11.3 Configuring Virtual Fabrics	. 475
11.3.1 Changing the context to a different logical switch	. 476
11.3.2 Enabling Virtual Fabrics	. 476
11.3.3 Disabling Virtual Fabrics	. 479
11.3.4 Logical switch management	. 481
11.3.5 Modifying the base switch	. 482
11.3.6 Creating a logical switch	. 483
11.3.7 Deleting a logical switch	. 488
11.3.8 Displaying the logical switch configuration	. 489
11.3.9 Changing the fabric ID of a logical switch	. 490
11.3.10 Changing a logical switch to a base switch	. 491
11.3.11 Configuring a logical switch for XISL use	. 492
11.3.12 Creating a logical fabric using XISLs	. 494
11.4 A real life example of Virtual Fabrics	. 495
11.4.1 The scenario	. 496
11.4.2 Enabling Virtual Fabric on the switches	. 499
11.4.3 Creating logical switches.	. 502
11.4.4 Assigning ports to the newly created switch	. 504
11.4.5 Creating the base switch	. 507
11.4.6 Creating a user to manage the Virtual Fabric	. 509
Chanter 12 Basic zoning	512
12.1 Zoning in general	51/
12.1 2 Mixed fabrice	51/
	. 514

12.1.2 Zone configurations	515
12.2 Zoning using DCFM	516
12.2.1 Administrative Domains	519
12.2.2 Implementing Administrative Domains	520
12.3 Implementing zoning	521
12.3.1 Managing zoning	521
12.3.2 Creating an alias	523
12.3.3 Creating a zone	528
12.3.4 Creating a zone configuration	533
12.3.5 Enabling zone configurations	534
12.3.6 Adding a zone to a existing zone configuration	537
12.3.7 Analyzing a zone configuration	539
12.4 Basic zoning using Web Tools	543
12.4.1 To start zoning with Web Tools	544
12.4.2 Creating an alias	547
12.4.3 Creating a zone	550
12.4.4 Using Web Tools to create a zone	551
12.4.5 Creating a zone configuration	553
12.4.6 Enabling zone configurations	555
12.4.7 Analyzing a zone configuration	557
12.4.8 Zoning and E_Ports	559
12.4.9 Broadcast zone	561
12.5 Backing up a zone configuration	561
12.5.1 Backing up a zone configuration to an FTP server	562
12.5.2 Backing up a zone configuration to a Brocade USB device .	566
12.5.3 Downloading a zone configuration from a USB device	572
12.6 Zoning using CLI	576
12.6.1 Using CLI to create a zone	577
12.6.2 Using CLI to create a zone configuration	579
12.6.3 Backing up a zone configuration using the CLI	581
12.6.4 Backing up a zone configuration using a USB drive	582
12.6.5 Downloading a zone configuration from an FTP server	584
12.6.6 Downloading a zone configuration from a USB device	585
Chapter 13. Multiple switches and fabrics	587
13.1 Multiple switch environments	588
13.1.1 Gateway links	588
13.1.2 Buffer credit recovery	589
13.1.3 ISL Trunking	590
13.1.4 Connecting switches over distance	595
13.1.5 Routing policies	601
13.2 Merging fabrics	608
13.2.1 Duplicate domain IDs	610

13.2.2 Zoning configuration conflicts	. 611
13.2.3 Merging fabrics example	. 612
13.2.4 Merging with a configuration cleared switch	. 619
13.2.5 Operating parameter conflicts	. 620
13.2.6 InteropMode	. 621
Chapter 14. Security	. 623
	. 624
	. 624
14.1.2 Role-Based Access Control	. 625
14.1.3 Local database user accounts	. 626
14.2 Account management	. 627
14.2.1 Displaying account information	. 627
14.2.2 Creating an account	. 628
14.2.3 Modifying User and Account settings	. 631
14.3 Security protocols	. 635
14.3.1 Security protocol support	. 635
14.3.2 Secure file copy	. 637
14.4 Simple Network Management Protocol	. 638
14.4.1 SNMP and Virtual Fabrics	. 640
14.4.2 Security level	. 641
14.4.3 snmpConfig command	. 641
14.5 Secure Sockets Layer protocol	. 645
14.5.1 Browser and Java support	. 645
14.5.2 SSL configuration overview	. 646
14.5.3 Certificate authorities	. 647
14.6 Secure Shell protocol	. 653
14.6.1 SSH public key authentication	. 654
14.6.2 Configuring SSH authentication	. 655
14.7 Telnet protocol	. 658
14.7.1 Blocking Telnet	. 658
14.7.2 Unblocking Telnet	. 659
14.7.3 Listener applications	. 659
14.8 Ports and applications used by switches.	. 660
14.8.1 Access defaults	. 660
14.8.2 Port configuration	. 661
14.9 Security policies	. 662
14.9.1 ACL policies overview	. 662
14.9.2 ACL policy management	. 662
14.9.3 FCS policies	. 663
14.9.4 Overview of FCS policy management	. 665
14.9.5 Creating an FCS policy	. 665
14.9.6 Modifying the order of FCS switches	. 666

	14.9.7 FCS policy distribution	667
	14.9.8 DCC policies	669
	14.9.9 DCC policy restrictions	670
	14.9.10 Creating a DCC policy	670
	14.9.11 Creating a device policy	671
	14.9.12 Deleting a device policy	672
	14.9.13 Activating policy changes	673
	14.9.14 SCC policies	673
	14.9.15 Creating an SCC policy	674
	14.9.16 Authentication policy for fabric elements.	674
	14.9.17 E_Port authentication	676
	14.9.18 AUTH policy restrictions	679
	14.9.19 Viewing current authentication parameter settings for a switch .	681
	14.9.20 Setting authentication protocol used by the switch to DH-CHAP	681
	14.9.21 Re-authenticating E_Ports	682
	14.9.22 Secret key pairs	683
	14.9.23 Viewing a list of secret key pairs in the current switch database	683
	14.9.24 Setting a secret key pair	684
	14.9.25 Distributing the local ACL policies.	685
	14.9.26 IP Filter policy	686
	14.9.27 Creating an IP Filter policy	687
	14.9.28 Cloning an IP Filter policy	687
	14.9.29 Saving an IP Filter policy.	688
	14.9.30 Activating an IP Filter policy	688
	14.9.31 Deleting an IP Filter policy	688
	14.9.32 IP Filter policy rules	689
	14.9.33 IP Filter policy enforcement.	691
	14.9.34 Adding a rule to an IP Filter policy	692
	14.9.35 Deleting a rule in an IP Filter policy.	693
	14.9.36 Aborting a transaction associated with IP Filter	693
	14.9.37 IP Filter policy distributions	693
	14.9.38 IP Filter policy restrictions	694
Cł	anter 15 Adaptive Networking	695
15	1 Traffic Management	696
10	15.1.1 Committed rate considerations on FCIP	696
	15.1.2 Adaptive Bate Limiting considerations	697
	15.1.3 Trunking across multiple ECIP circuits	698
	15.1.4 Supported packet loss and delay	698
	15.1.5 Scalability considerations	699
15	.2 Ingress rate limiting	699
	15.2.1 Ingress Rate limiting with the CLI	701
	15.2.2 Ingress Rate Limiting with Web Tools.	703

15.3 Traffic Isolation	. 705
15.3.1 TI zone failover	. 707
15.3.2 FSPF routing rules and traffic isolation	. 709
15.3.3 TI zone misconfiguration example	. 711
15.3.4 Supported configurations	. 712
15.3.5 Virtual Fabric configuration	. 712
15.3.6 TI zones using CLI	. 713
15.3.7 Other zoning CLI commands	. 719
15.3.8 TI zones with DCFM	. 721
15.4 QoS: SID/BID traffic prioritization	. 724
15.4.1 QoS zones	. 726
15.4.2 QoS E_Ports	. 728
15.4.3 Supported configurations and limitations	. 729
15.4.4 QoS with CLI	. 730
15.4.5 Web Tools and QoS Zones	. 734
15.4.6 DCFM and QoS zones	. 736
Chapter 16. Performance monitoring	. 739
16.1 Performance monitoring with Web Tools	. 740
16.2 Basic Performance Monitoring	. 744
16.2.1 Basic Performance Monitoring with Web Tools	. 745
16.2.2 Throughput examples	. 745
16.3 Advanced Performance Monitoring.	. 753
16.3.1 Virtual Fabrics considerations	. 753
16.3.2 Performance Monitors	. 754
16.3.3 Displaying Performance Monitors with the CLI	. 755
16.3.4 SID/DID Performance Monitor	. 755
16.3.5 End-to-end monitoring with DCFM	. 761
16.3.6 Filter-based performance monitoring	. 762
	. 768
	. 769
16.3.9 Top Talkers monitors in port mode	. 771
16.3.10 Top Talkers monitors in fabric mode	. 774
16.3.11 Top Talkers monitoring considerations	. 776
16.3.12 Trunk monitoring	. ///
16.3.13 Saving and restoring the monitoring configuration	. ///
16.4 SCSI commands with Web Tools	. 778
16.4.1 SCSI versus IP traffic	. 780
16.4.2 ALPA error	. 781
16.5 Bottleneck detection	. 781
16.5.1 Latency bottleneck	. 782
16.5.2 Congestion bottleneck	. 782

Chapter 17. Health and troubleshooting
17.1 SAN Health
17.1.1 New features of SAN Health
17.1.2 Implementing SAN Health
17.2 Error logs
17.2.1 Capturing a trace dump
17.2.2 The supportsave command
17.2.3 DCFM support information
17.3 General troubleshooting
17.3.1 Troubleshooting device connectivity
17.3.2 Trace route
17.4 Port Fencing
17.4.1 Port Fencing using DCFM820
17.4.2 Port Fencing using CLI 828
17.4.3 Enabling Port Fencing for E_Port class link loss
17.4.4 Testing the configuration
17.4.5 Basic troubleshooting commands 835
- · · · · · · · · · · · · · · · · · · ·
Related publications
IBM Redbooks publications
Other resources
Referenced websites
Help from IBM
Index

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing, IBM Corporation, North Castle Drive, Armonk, NY 10504-1785 U.S.A.

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs.

Trademarks

IBM, the IBM logo, and ibm.com are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. These and other IBM trademarked terms are marked on their first occurrence in this information with the appropriate symbol (® or ™), indicating US registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at http://www.ibm.com/legal/copytrade.shtml

The following terms are trademarks of the International Business Machines Corporation in the United States, other countries, or both:

AIX®	FICON®
BladeCenter®	IBM®
DS4000®	Redbooks®
DS8000®	Redbooks (logo) 🧬 🛛
eServer™	System Storage®

System x® System z® TotalStorage®

The following terms are trademarks of other companies:

Snapshot, and the NetApp logo are trademarks or registered trademarks of NetApp, Inc. in the U.S. and other countries.

Java, and all Java-based trademarks are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Microsoft, Windows, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

Other company, product, or service names may be trademarks or service marks of others.

Preface

"Do everything that is necessary and absolutely nothing that is not."

This IBM® Redbooks® publication, written at a Data Center Fabric Manager v10.1.4 and Fabric Operating System v6.4.x level, consolidates critical information while also covering procedures and tasks that you are likely to encounter on a daily basis when implementing an IBM b-type SAN.

The products that we describe in this book have more functionality than we can possibly cover in a single book. A storage area network (SAN) is a powerful infrastructure for consolidation, distance solutions, and data sharing. The quality applications that the IBM SAN portfolio provides can help you take full advantage of the benefits of SAN.

In this book, we cover the latest additions to the IBM b-type SAN family and show how you can implement them in an open systems environment. In particular, we focus on the Fibre Channel Protocol (FCP) environment. We address the key concepts that these products bring to the market and, in each case, we provide an overview of the functions that are essential to building a robust SAN environment.

It is our intent to show *how* to implement the functions and features of the IBM b-type portfolio and, to get the best from this book, you must be familiar with SANs, basic SAN tasks, and the terminology associated with SANs. If not, we advise that you read the following IBM Redbooks publications before you start this one:

- ► Introduction to Storage Area Networks, SG24-5470
- IBM System Storage/Brocade Multiprotocol Routing: An Introduction and Implementation, SG24-7544

The team who wrote this book

This book was produced by a team of specialists from around the world working at the International Technical Support Organization, San Jose Center.

Jon Tate is a Project Manager for IBM System Storage® SAN Solutions at the International Technical Support Organization, San Jose Center. Before joining the ITSO in 1999, he worked in the IBM Technical Support Center, providing Level 2 support for IBM storage products. Jon has 24 years of experience in

storage software and management, services, and support, and is both an IBM Certified IT Specialist and an IBM SAN Certified Specialist. He is also the UK Chairman of the Storage Networking Industry Association.

Uwe Dubberke is an IBM Certified Specialist for High End Disk Solutions, working as a field specialist (RDS) for DASD and SAN products in IBM Germany. Since starting in 1990 at IBM he has been responsible for various high-end customers as an Account CE. He has also worked as an SE. Since 1999 he has been a virtual member of the EMEA Central Region Hardware Support Center in Mainz, and since 2005 he has also been a virtual member of the SAN Support Group, also in Mainz. He holds a degree in Electrical Engineering with a specialization in communications engineering from the University of Applied Sciences of Gelsenkirchen (Germany). Uwe has co-authored other Redbooks publications about the DS8000 and SSD.

Michael Engelbrecht is a Senior SSR in IBM Global Technical Services, MTS. He has worked with IBM for 29 years and for the last nine years he has worked for the Hardware Field Support team for SSA Sub Sahara Africa. Before that he was a Networking Specialist with many years of networking experience and a large range of networking equipment, specializing in ATM and Frame relay. He is currently a member of the VFE team for CEE and MEA on all RMSS products, as well as regional support for all SAN products for Sub Sahara Africa.

Shanmuganthan Kumaravel is an IBM Technical Services Specialist for the ITD-SSO MR Storage team of IBM India. He supports SAN, and disk products of both IBM and Hewlett Packard since August 2008. Prior to this he worked for HP product support providing remote support on HP SAN storage products, servers and operating systems including HP UNIX and Linux. Shan is a Brocade Certified SAN Designer (BCSD), Brocade Certified Fabric Professional (BCFP), and an HP Certified System Engineer (HPCSE).

Jose Rodriguez Ruibal is the Technical Sales Leader for the IBM System x® Networking team, based in Montpellier, France, and covering the southwest Europe region. He has more than 12 years of experience in IT, and has worked for IBM for more than eight years. His experience includes serving as Benchmark Manager in the IBM PSSC Benchmark Center in Montpellier, working as an IT Architect for Nokia while living in Finland for three years, and IT Architect and Team Leader for the IBM STG OEM and Next Generation Networks teams in EMEA. Prior to joining IBM, he worked for Red Hat and other consulting firms. He holds an MSC and a BSC in Computer Engineering and Computer Systems from Nebrija University, Madrid. His areas of expertise include Business Development, Strategic OEM Alliances and long-term IT projects in the Telecom, Media and Defense industries, high-level IT architecture and complex solutions design, Linux® and all x86 hardware. Jose has co-authored other Redbooks publications on Linux solutions, on IBM x86 servers and Performance Tuning for x86 servers.

Thanks to the following people for their contributions to this project:

Sangam Racherla Lori Bideaux International Technical Support Organization, San Jose Center

Doris Konieczny IBM Storage Systems Group

Khalid Ansari Jure Arzensek George DeBiasi Brian Cartwright Gareth Edwards Kerry Edwards Sven Eichelbaum Michael Engelbrecht Steve Garraway Joe Hew Cameron Hildebran Uwe Hofmann Thomas Jahn Kamalakkannan Jayaraman Mark Kornakiewicz Jin Su Kim Carsten Larsen Andy McManus Dariusz Myszka Jeannie Vangsness Sangam Racherla Pauli Ramo Simon Richardson **Glen Routley** Chris Seiwert Marcus Thordal Eric Wong The authors of previous versions of this book

A special mention must go to Brocade for their unparalleled support of this residency in terms of equipment and support in many areas throughout. Namely:

Jim Baldyga Yong Choi Silviano Gaona Jason Russo Brian Steffler Marcus Thordal Steven Tong Mansi Botadra *Brocade Communications Systems*

Now you can become a published author, too!

Here's an opportunity to spotlight your skills, grow your career, and become a published author—all at the same time! Join an ITSO residency project and help write a book in your area of expertise, while honing your experience using leading-edge technologies. Your efforts will help to increase product acceptance and customer satisfaction, as you expand your network of technical contacts and relationships. Residencies run from two to six weeks in length, and you can participate either in person or as a remote resident working from your home base.

Find out more about the residency program, browse the residency index, and apply online at:

ibm.com/redbooks/residencies.html

Comments welcome

Your comments are important to us!

We want our books to be as helpful as possible. Send us your comments about this book or other IBM Redbooks publications in one of the following ways:

Use the online Contact us review Redbooks form found at:

ibm.com/redbooks

Send your comments in an email to:

redbooks@us.ibm.com

Mail your comments to:

IBM Corporation, International Technical Support Organization Dept. HYTD Mail Station P099 2455 South Road Poughkeepsie, NY 12601-5400

Stay connected to IBM Redbooks

Find us on Facebook:

http://www.facebook.com/IBMRedbooks

Follow us on Twitter:

http://twitter.com/ibmredbooks

• Look for us on LinkedIn:

http://www.linkedin.com/groups?home=&gid=2130806

Explore new Redbooks publications, residencies, and workshops with the IBM Redbooks weekly newsletter:

https://www.redbooks.ibm.com/Redbooks.nsf/subscribe?OpenForm

► Stay current on recent Redbooks publications with RSS Feeds:

http://www.redbooks.ibm.com/rss.html

Summary of changes

This section describes the technical changes made in this edition of the book and in previous editions. This edition might also include minor corrections and editorial changes that are not identified.

Summary of Changes for SG24-6116-10 for Implementing an IBM b-type SAN with 8 Gbps Directors and Switches as created or updated on March 30, 2011.

March 2011, Eleventh Edition

This revision reflects the addition, deletion, or modification of new and changed information described here.

New information

- ► DCFM
- Virtual Fabrics
- Host Connectivity Manager
- Adaptive Networking
- ► Fabric OS v6.4.

Changed information

► Screen captures updated to reflect latest software available at time of writing

1

Product introduction

In this chapter we describe the IBM System Storage and TotalStorage® SAN b-type family, including the hardware naming conventions (IBM versus Brocade), as well as the various components involved.

1.1 Overview of the product

In this section, we describe the IBM System Storage and TotalStorage SAN b-type family. For the most up-to-date information, see the following website:

http://www-03.ibm.com/systems/storage/san/index.html

1.1.1 Hardware features

The b-type fabric directors and switches provide a flexible, intelligent platform for networking storage. With models ranging from entry-level 8-port fabric switches all the way up to 768-port backbones, this family addresses the requirements of both small departments and global enterprises. The 1, 2, 4, 8, and 10 Gbps solutions are available to support high-performance requirements. Express models that are pre-configured with Small Form-factor Pluggable (SFP) optical transceivers are available for several of the switches within the b-type family.

1.1.2 Hardware naming convention: IBM and Brocade

Table 1-1 lists the b-type family products, along with their equivalent Brocade names. Note that the table references the switches using their standard IBM names as well as the IBM type and model throughout this text.

IBM name	IBM machine type and model	Brocade name
IBM System Storage SAN24B-4	2498-B24	Brocade 300
IBM System Storage SAN40B-4	2498-B40	Brocade 5100
IBM System Storage SAN80B-4	2049-B80	Brocade 5300
IBM Converged Switch B32	3758-L32	Brocade 8000
IBM System Storage SAN06B-R	2498-R06	Brocade 7800
IBM System Storage SAN384B	2499-192	Brocade DCX-4S
IBM Encryption Switch SAN32B-E4	2498-E32	Brocade BES
IBM System Storage SAN768B	2499-384	Brocade DCX
Brocade 4 Gbps SAN Switch Modules for IBM eServer™ BladeCenter®	32R1813 32R1812	Brocade 4020

Table 1-1 IBM System Storage SAN b-type family products

IBM name	IBM machine type and model	Brocade name
Brocade 8 Gbps SAN Switch Modules for IBM eServer BladeCenter	42C1828 44X1920 44X1921	Brocade 5470

The b-type family includes the following switches, which will only be referenced in this book. These products include:

The entry level SAN06B-R multiprotocol routers as well as the SAN768B and SAN384B router blade. These components are discussed in depth in IBM System Storage b-type Multiprotocol Routing: An Introduction and Implementation, SG24-7544-03, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247544.html?Open

The Converged Switch B32. These components are discussed in depth in IBM Converged Switch B32, SG24-7935-00, available at this website:

http://www.redbooks.ibm.com/redpieces/abstracts/sg247935.html?Open

The Encryption switch SAN32B-E4 as well as the SAN768B and SAN384B encryption blade. These components are discussed in depth in *Implementing* the IBM System Storage SAN32B-E4 Encryption Switch, SG24-7922, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247922.html?Open

1.2 Product descriptions

In this section, we provide descriptions of the various product components.

1.2.1 IBM System Storage SAN24B-4 switch

The SAN24B-4 is a high performance scalable switch that provides 8, 16, or 24 fabric ports enabled. With auto-sensing link speeds at 1, 2, 4, and 8 Gbps and a flexible design to configure this switch as a fabric switch or an Access Gateway, it is suitable for small to mid-sized businesses.

Figure 1-1 shows the SAN24B-4 fabric switch.



Figure 1-1 SAN24-B fabric switch

The SAN24B-4 fabric switch requires Fabric OS v6.1.0 or later. The switch offers easy to use Web Tools, 8 Gb FC, Long Distance support, Advanced Zoning, Full-Fabric support, Fiber Watch, Advanced Performance Monitoring, Enhanced Group Management, and ISL Trunking. The base switch also offers eight default ports and Ports on Demand (POD) licenses are available in 8-port increments. With flexible architecture based on GoldenEye2 ASIC, the switch supports F, FL, E, and M Ports at 8 Gbps. The switch also has USB port support for firmware download, configuration upload and download, and supportsave.

It also supports NPIV and Access Gateway which is included in the base FOS.

The SAN24B-4 has a 1U form factor and is a single FRU with no field replaceable parts. The switch has one power supply and three integrated fans.

Important:

- Access Gateway mode is supported only in 24-port configurations, and only 2 GB Brocade branded USB drives are supported on the USB port.
- The 4 and 8 Gbps link speeds are supported *only* with Brocade branded SFPs.

1.2.2 IBM System Storage SAN40B-4 switch

The SAN40B-4 is a high performance enterprise fabric switch with 40 ports at 8 Gbps link speeds. This switch supports features such as Full-Fabric Support, Fabric Watch, Long Distance support, Advanced Performance Monitoring, Integrated Routing, FICON® CUP, and ISL Trunking. The switch requires Fabric OS v6.1, and port hardware is based on the Condor2 ASIC. One ASIC can support all 40 ports at 1, 2, 4, and 8 Gbps link speeds, and they can be configured as F, FL, E, M, and EX Ports.

It also supports NPIV and Access Gateway which is included in the base FOS.

Figure 1-2 shows the SAN40B-4 fabric switch.



Figure 1-2 SAN40B-4 fabric switch

The SAN40B-4 fabric switch requires Fabric OS v6.1.0 or later. The base model of the switch has 24 ports enabled, and the POD licenses are available in 8 port increments. Integrated Routing is a licensed feature which is supported on every port of the switch and requires a POD license for all 40 ports. The ports on the switch are grouped in 8-port groups matching the trunk group, and with ISL Trunking speeds of up to 64 Gbps can be achieved per trunk.

Dynamic Path selection can be used for optimizing the performance and load balancing, and the switch can be managed using Web Tools. The built-in USB port can be used for firmware download, configuration upload and download, and supportsave, and the switch supports non-disruptive firmware downloads.

New features in Fabric OS v6.2.0 make the switch Virtual Fabric capable. A single physical chassis can be subdivided into two or more logical switches creating a logical fabric with other switches.

Integrated Routing is a licensed feature that is supported on every port of the switch and requires the POD license for all 40 Ports.

Two hot-swappable, redundant 125W power supply and fan assemblies are included with the switch and these are field replaceable units (FRU). Each FRU has an ON/OFF switch AC plug and a power supply/fan status LED, and the switch has a 1U form factor.

Important:

- The USB port supports *only* 2 GB Brocade branded USB drives.
- The 4 and 8 Gbps link speeds are supported *only* with Brocade branded SFPs.

1.2.3 IBM System Storage SAN80-B4 switch

The SAN80-B4 is an 80-port, 8 Gbps enterprise fabric switch with 2U form factor. This switch supports features such Full-Fabric Support, Fabric Watch, Long Distance support, Advanced Performance Monitoring, Integrated Routing, FICON CUP and ISL Trunking.

It also supports NPIV and Access Gateway which is included in the base FOS.

Figure 1-3 shows the SAN80-B4 fabric switch.



Figure 1-3 SAN80-B4 fabric switch

The SAN80B-4 fabric switch requires Fabric OS v6.1.0 or later. Port hardware is based on the GoldenEye2 ASIC. Each ASIC can support 32 ports at 1, 2, 4, and 8 Gbps link speeds. The base model of the switch comes with 48 ports enabled, and the POD licenses are available in 16-port increments.

New features in Fabric OS v6.2.0 make the switch Virtual Fabric capable. A single physical chassis can be subdivided into two or more logical switches creating a logical fabric with other switches.

Integrated Routing is a licensed feature that is supported on every port of the switch and requires the POD license for all 80 Ports.

The ports on the switch are grouped in 8-port groups matching the trunk group, and with ISL Trunking speeds of up to 64 Gbps can be achieved per trunk. Dynamic Path selection can be used for optimizing the performance and load balancing, and the switch can be managed using Web Tools.

The built-in USB port can be used for firmware download, configuration upload and download, and supportsave, and the switch supports non-disruptive firmware downloads.

The switch has two hot-swappable, redundant 300 W power supplies and three hot-swappable fan assemblies. Both the power supplies and the fan assemblies are field replaceable units, and they have a status LED on them.

Important:

- ► The USB port supports *only* 2 GB Brocade branded USB drives.
- The 4 and 8 Gbps link speeds are supported *only* with Brocade branded SFPs.

1.2.4 IBM Converged Switch B32

The IBM Converged Switch B32 is a top-of-rack Fibre Channel over Ethernet (FCoE) switch in a compact 1U form factor. It features eight 8 Gbps Fibre Channel ports along with 24 Converged Enhanced Ethernet (CEE) ports with 10 Gigabit Ethernet capabilities. The CEE ports are capable of transporting both storage and LAN traffic eliminating the need for separate SAN and LAN adapters and cables.

The IBM Converged Switch B32 connects to servers through Converged Network Adapters (CNA). The consolidated SAN and LAN server ports and corresponding cables simplify configuration and cabling in server cabinets to reduce acquisition costs.



Figure 1-4 shows the IBM Converged Switch B32.

Figure 1-4 IBM Converged Switch B32

The IBM Converged Switch B32 requires Fabric Operating System v6.1.2_cee or later. The IBM Converged Switch B32 is designed to support Fibre Channel over Ethernet (FCoE), Fibre Channel, Converged Enhanced Ethernet (CEE), and traditional Ethernet protocol connectivity for servers and storage.

FCoE is a new protocol that can expand Fibre Channel into the Ethernet environment, and it helps to combine and leverage the advantages of two technologies, Fibre Channel protocol and Ethernet. The IBM Converged Switch B32 offer the following capabilities:

► A 32-port multiprotocol switch for server I/O consolidation

- ► Enterprise-class availability for business continuance
- Improved return of investment and investment protection
- Fabric security for mission-critical information
- The Converged Switch B32 components are discussed in depth in IBM Converged Switch B32, SG24-7935-00, available at this website:

http://www.redbooks.ibm.com/redpieces/abstracts/sg247935.html?Open

1.2.5 SAN32B-E4(2498-E32)

The IBM System Storage SAN32B-E4 Encryption Switch is a high performance 32 port auto-sensing 8 Gbps Fibre Channel switch with data encryption, decryption, and compression features.

This is a SAN fabric solution that has the capability of encrypting data-at-rest for heterogeneous disk LUNs, tape drives, and virtual tape libraries. The encrypting of the data is done using Advanced Encryption Standard (AES) 256-bit algorithms. The encryption and decryption engines provide in-line encryption services with up to 96 Gbps throughput for disk I/O (mix of ciphertext and clear text traffic) and up to 48 Gbps throughput for tape I/O (mix of ciphertext and clear text traffic).

The SAN32B-E4 shown in Figure 1-5 is a 2U form factor for standard 19-inch rack mount.

IBM System Storage SAN328-E	

Figure 1-5 SAN32B-E4

Management is provided by using the same integrated management tools as the rest of the IBM System Storage b-type family. This approach allows simple installation, configuration, and everyday administration.

The SAN32B-E4 offers 32 8 Gbps high-speed FC ports. In addition, it has hot swap redundant power supplies and fans to provide for high availability. The FC ports support universal (F/FL/E/EX/M) port configurations with full duplex, auto-sensing of 1, 2, 4, and 8 Gbps port speeds. This can be set to fixed port speed; speed matching between 1, 2, 4, and 8 Gbps ports. A number of
hot-pluggable 8 Gbps SFPs (small form-factor pluggable) are available for installation into the FC ports on the switch. These are 8 Gbps SW, 10 Km LW and 25 km ELW. Only Brocade branded SFPs will operate in this switch.

The Encryption switch SAN32B-E4 components are discussed in depth in *Implementing the IBM System Storage SAN32B-E4 Encryption Switch*, SG24-7922, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247922.html?Open

1.2.6 IBM System Storage SAN06B-R (2498-R06)

IBM System Storage SAN06B-R (2498-R06) is a rack based product with 8 Gbps FC routing, switching capabilities along with the Fibre Channel Over IP(FCIP) hardware feature. This has sixteen 8 Gbps FC ports and 6 GbE Ethernet ports. Figure 1-6 shows the IBM System Storage SAN06B-R (2498-R06).



Figure 1-6 IBM System Storage SAN06B-R

This model is available in 2 different configurations, as a Base Fabric Switch configuration which comes with 4 active 8 Gbps FC ports and 2 active 1 GbE ports. It can be upgraded with an additional 12 8 Gbps FC ports and 4 1GbE ports. Figure 1-6 shows the base ports and the upgrade license enabled ports.

1.2.7 IBM System Storage SAN384B Director

The IBM System Storage SAN384B fabric backbone is a core and edge network switching platform used to interconnect storage devices, hosts, and servers in Storage Area Networks (SANs). The SAN384B is a sixth generation platform, designed to facilitate server, SAN, and data center consolidation while helping to reduce infrastructure and administrative costs for IT environments.

Following the introduction of the industry-leading 384-port 8 Gbps SAN768B fabric backbone in 2008, the new SAN384B scales to 192 ports at up to full 8 Gbps speed through its four modular blade slots, and leverages the same breakthrough technology as the larger model to deliver industry-leading performance, scalability, and energy efficiency. The IBM b-type fabric backbone models were designed to address the data growth and application demands of evolving enterprise data centers.

Figure 1-7 shows the IBM System Storage SAN384B fabric backbone.

Figure 1-7 IBM System Storage SAN384B, no door

The IBM System Storage SAN384B requires Fabric OS v6.2.0. New features in Fabric OS v6.2.0 make the switch Virtual Fabric capable. A single physical chassis can be subdivided into two or more logical switches creating a logical fabric with other switches.

The SAN384B base model includes the following components enclosed in an 8U chassis with doors:

- Two vertical cable management combs
- Two control processor blades
- ► Two core blades
- Dual power supplies
- ► Two blower fans
- One exhaust duct kit
- ► Ship group
- Fabric Operating System (v6.2 or later)

Be aware of the following considerations:

- ► Fibre Channel (FC) switch blades are not included in the base.
- ► Fiber optic transceivers are not included in the base.
- Customers will need to order the 64-port, 48-port, 32-port, or 16-port 8 Gbps FC Switch blades and populate them with transceivers. The 64-port FC switch blade requires the new mini small form-factor pluggable (mSFP), which is of a reduced width to allow for 60 ports. The mSFP uses the standard SC connector type.

Integrated Routing is a licensed feature that is supported on every FC port of the switch.

Important:

- Only 2 GB Brocade branded USB drives are supported for use on the USB port.
- The SAN384B supports all features and functions as indicated and requires Fabric OS v6.2 or later. Blades that use the Condor2 ASIC *must* use Brocade branded SFPs.

You can find more information about the IBM System Storage Fabric Backbones at the following website:

http://www-03.ibm.com/systems/storage/san/b-type/san384b/

1.2.8 IBM System Storage SAN768B Director

The IBM System Storage SAN768B Fabric Backbone is a core switching platform that is used to interconnect storage devices, hosts, and servers in a storage area network (SAN). The SAN768B is a fifth generation platform, designed to meet the growing connectivity, virtualization, and the cost efficiency needs of enterprise data centers.

Figure 1-8 shows a view from the front, with no door.



Figure 1-8 Front, side angle, no door of SAN768B

The SAN768B is designed for the following tasks:

- ► Deliver breakthrough performance with 8 Gbps Fibre Channel connectivity.
- Provide long-term scalability to facilitate server and storage expansion by offering the highest density footprint with up to 768 Fibre Channel ports using two SAN768Bs that are connected with Inter-Chassis Links (ICL).
- Take advantage of proven reliability and new technology to deliver enterprise-class reliability, availability, and serviceability.
- Support multiprotocol infrastructure for both Fibre Channel and IP traffic.
- Improve energy efficiency by combining high bandwidth with low power consumption.

The SAN768B is designed to address key customer requirements while helping to protect investments already made by the deployment of existing SANs, servers, storage hardware, and advanced functions, as follows:

- It offers forward and backward compatibility with IBM System Storage SAN director, switch, and router models, 1, 2, 4, and 8 Gbps autosensing capability, as well as advanced fabric services and management tools.
- It enables interoperability between IBM System Storage and TotalStorage b-type and m-type SAN switches and directors.

Preferred for larger midrange to enterprise level SAN applications, the SAN768B Fabric Backbone integrates a new generation of hardware, including a minimum of two control processors, two core blades, four power supplies, and three fans in a 14U rack height, with the following advanced functions:

- Full Fabric operation and universal port operation on all ports (F_Port, E_Port, FL_Port, M_Port, EX_Port, and N_Port support on selected blades)
- ► ISL and ISL Trunking, Advanced Zoning, and FICON CUP
- Intelligent management and monitoring with Web Tools, Fabric Watch, and Performance Monitor
- USB port support for firmware download, configuration upload and download, and supportsave

Important: Only 2 GB Brocade branded USB drives are supported for use on the USB port.

Adaptive Networking Services with Quality of Service (QoS) is a licensed feature with Fabric Operating System v6.0 and later (Fabric OS) and uses network intelligence to anticipate congestion and to make adjustments in the fabric dynamically so that application traffic continues to flow

Important: The SAN768B supports all features and functions as indicated and requires Fabric OS v6.0 or later. Blades that use Condor2 ASIC *must* use Brocade branded SFPs.

New features in Fabric OS v6.2.0 make the switch Virtual Fabric Capable. A single physical chassis can be subdivided into two or more logical switches creating a logical fabric with other switches.

Integrated Routing is a licensed feature that is supported on every FC port of the switch.

You can find more information about the 768B at the following website: http://www-03.ibm.com/systems/storage/san/b-type/san768b/

1.2.9 Brocade 4 Gbps SAN Switch Modules

Figure 1-9 shows the Brocade 4 Gbps SAN Switch Module.



Figure 1-9 Brocade 4 Gbps SAN Switch Module

The Brocade Module supports 1, 2, and 4 Gbps. You can choose between the 10-port (part number 32R1813) or the 20-port module (part number 32R1812). The modules provide the ability to implement non-disruptive software upgrades. It includes Web Tools and Advanced Zoning, with optional features including Fabric Watch, Advanced ISL Trunking, Extended Fabric Activation, Advanced Security Activation, and Advanced Performance Monitoring.

Access Gateway is a standard feature that is available to all Brocade 4 Gbps SAN Switch Modules with Fabric OS v5.2.1 or later.

For more information about Access Gateway and its implementation, review *Implementing the Brocade Access Gateway for IBM BladeCenter*, REDP-4343, which is available at the following website:

http://www.redbooks.ibm.com/abstracts/redp4343.html?Open

1.2.10 Brocade 8 Gbps SAN Switch Modules

Figure 1-9 shows the Brocade 8 Gbps SAN Switch Module.



Figure 1-10 Brocade 8 Gbps SAN Switch Module

The Brocade Module supports 2,4, and 8 Gbps. You can choose between the 10-port (part number 44X1921), the 20-port module (part number 44X1920) or the 20-port enterprise model (part number 42C1828). The modules provide the ability to implement non-disruptive software upgrades. It includes Web Tools and Advanced Zoning, with optional features including Fabric Watch, Advanced ISL Trunking, Extended Fabric Activation, Advanced Security Activation, and Advanced Performance Monitoring.

The Enterprise 20-port model (42C1828) is a fully enabled switch with a complete set of licensed features that maximizes performance, ensures availability and simplifies management for the most demanding applications and expanding virtualization environments including Fabric Watch which monitors and creates alerts based on the health of switch and fabric elements.

For a complete list of all the Brocade 8 Gbps SAN switch module features and capabilities, see the following website:

http://www-03.ibm.com/systems/bladecenter/hardware/openfabric/fibrechan nel.html

For more information about Access Gateway and its implementation, review *Implementing the Brocade Access Gateway for IBM BladeCenter*, REDP-4343, which is available at the following website:

http://www.redbooks.ibm.com/abstracts/redp4343.html?Open

1.2.11 Fabric Operating System

Fabric Operating System (Fabric OS) provides enterprise-class, ultra-high availability, reliability, and security capabilities for a wide range of SAN environments. Fabric OS runs on the b-type family of Fibre Channel directors and switches, and provides transparent interoperability between 1, 2, 4, 8, and 10 Gbps devices as well as the reliable, high-performance data transport that is critical for scalable SAN fabrics interconnecting thousands of servers and storage devices. Fabric OS v6.x is common across all current members of the IBM System Storage and TotalStorage SAN b-type family.

Brocade Fabric OS v6.4.1 is supported for the following hardware platforms:

- IBM System Storage SAN24B-4
- IBM System Storage SAN40B-4
- IBM System Storage SAN80B-4
- ► IBM Converged Switch B32
- IBM System Storage SAN06B-R
- ► IBM Encryption Switch SAN32B-E4
- ► IBM System Storage SAN384B
- ► IBM System Storage SAN768B
- ► FC 8 Gbps, 16-port switch blade
- ► FC 8 Gbps, 32-port switch blade
- ► FC 8 Gbps, 48-port switch blade. FICON supported in FOS v6.2+
- ► FC 8 Gbps, 64-port switch blade
- FC 4 Gbps Routing blade 16x 4 Gbps FC ports, 2x GigE FCIP ports. Two max per 384. FC7887 required for optional FCIP
- ► FC 10 Gbps, 6-port switch blade. Requires FC2510 or FC2520
- FCoE 10GbE blade 24 x 10GbE CEE/FCoE ports. Two max per 384. Can not add any other intelligent blades.
- FC 8 Gbps Extension blade 12x 8 Gbps FC ports, 10x GigE FCIP ports. Optional 2x 10 GigE ports with FC7892. Two max per 384.
- ► FC Encryption Blade
- ► Brocade 4 Gbps SAN Switch Modules for IBM eServer BladeCenter
- ► Brocade 8Gb SAN Switch Module for IBM BladeCenter

1.2.12 Management tools

To ensure open fabric management, Fabric OS provides standard management interfaces, a full range of management tools, and an API that enables the development of third-party SAN management applications.

The following tools simplify SAN fabric management by centralizing control and enabling automation of repetitive administrative tasks:

- Web Tools: A built-in Web-based application that provides administration and management functions on a per switch basis
- Data Center Fabric Manager (DCFM): A client/server-based external application that centralizes management of IBM/Brocade multiprotocol fabrics within and across data centers, including support for FCoE and CEE
- ► Fabric Watch: A Fabric OS built-in tool that allows the monitoring of key switch elements: power supplies, fans, temperature, error counters, and so on
- SNMP: A feature that enables storage administrators to manage storage network performance, find and solve storage network problems, and plan for storage network growth

1.2.13 Licensing

Within the b-type family, licensing is performed at both a hardware and software level. The "pay-as-you-grow" flexibility with Ports On Demand allows scalability in 4-port, 8-port, or 16-port increments on the switch platforms.

Features such as ISL Trunking, Advanced Performance Monitoring (APM), Fabric Watch, and Extended Fabrics are software licensed and available across all platforms. CUP for FICON, Adaptive Networking, and Integrated Routing are additional licenses available on certain platforms.

Important: Secure Fabric OS features are now included in Fabric OS v6.0 and later, and Secure Fabric OS is no longer available as a licensed feature.

1.2.14 Security

Security within a SAN varies and can include external security, restricting physical access to directors and switches; software-based security where the use of zoning restricts which hosts and storage can communicate, and hardware-based security where the use of frame filtering monitors each frame and enforces its path through a SAN fabric.

Authentication, Authorization, and Accounting (AAA) services are available through the local switch user and password database or external RADIUS server. In Fabric OS v6.0 and later, the AAA services now support an external Lightweight Directory Access Protocol (LDAP) server running Microsoft® Active Directory Services, and the Fabric OS includes Active Directory/LDAP client. Fabric OS v6.0 and later also provides support for Federal Information Processing Standards (FIPS).

Standards: FIPS Standards Publication 140-2 was issued by the National Institute of Standards and Technology (NIST) and includes both software and hardware component requirements to handle sensitive, unclassified data. The FIPS standards are used by the departments and agencies of the United States federal government.

Secure Fabric OS

All the features of Secure Fabric OS are migrated to Fabric OS v6.0 and later, and Secure Fabric OS is no longer available as a licensed feature.

Role Based Access Control

Fabric OS v6.4.1 uses Role-Based Access Control (RBAC) to control access to all Fabric OS operations. Role-Based Access Control (RBAC) defines the capabilities that a user account has based on the role that the account is assigned. For each role, there is a set of predefined permissions on the jobs and tasks that can be performed on a fabric and its associated fabric elements.

For the Command Line Interface (CLI), you can display a list of all command help topics for a given login level, For example, if you are logged in as user and enter the **he1p** command, a list of all user-level commands that can be executed is displayed. The same rule applies to the admin, securityAdmin, and the switchAdmin roles.

1.2.15 Virtual Fabrics

With the release of Brocade Fabric OS (FOS) 6.2 and higher, customers have a new option, an ANSI standard based implementation of Virtual Fabrics. The Virtual Fabrics feature adds two new capabilities; Logical Switches and Logical Fabrics. Both are available in base FOS firmware.

With Virtual Fabrics, customers can partition a physical switch into multiple Logical Switches. Each Logical Switch belongs to a Logical Fabric, which has independent data paths, fabric configuration (zoning, Quality of Service (QoS), fabric mode, and so on) and management. With or without Virtual Fabrics, customers benefit from advanced Fabric OS (FOS) features, designed to deliver scalability, performance, and High Availability (HA), with simple management. The Virtual Fabrics feature is available on 8 Gbps platforms that are Virtual Fabric-capable (VF-capable), including these:

- IBM System Storage SAN768B Backbone
- ► IBM System Storage SAN384B Backbone
- IBM System Storage SAN80B Switch
- IBM System Storage SAN40B Switch

For investment protection, products that are not VF-capable, such as the Brocade 48000 Director, earlier 2 Gbps and 4 Gbps FOS and m-series platforms running M-Enterprise OS (M-EOS) software can seamlessly connect to Logical Switches in VF-capable products without any reconfiguration.

To simplify management, customers use the newest management platform, Brocade Data Center Fabric Manager (DCFM). After being created, Logical Switches and Logical Fabrics are managed in exactly the same way as their physical counterparts. Standard FOS Command-Line Interface (CLI) commands can be used to perform configuration and management functions for Virtual Fabrics or to script them.

The Virtual Fabrics feature is described in detail in Chapter 11, "Virtual Fabrics" on page 469.

1.2.16 Support

The IBM Resource Library website provides support for IBM users and is available at the following location:

http://www.ibm.com/systems/storage/san/b-type/library.html

2

Data Center Fabric

The data center is being transformed from a static physical infrastructure of dedicated servers and storage that hosts fixed applications, to a dynamic virtual infrastructure where applications run on virtual servers. In this chapter, we discuss the role of the Data Center Fabric in the evolution of the data center.

2.1 Methodologies of current SAN design

As SAN designs have evolved from 1 Gbps through 4 Gbps and now 8 Gbps, introducing next generation technology (such as the IBM System Storage 768B and 384B) has followed a pattern. To understand this pattern, it is useful to review some of the common methodologies of current SAN design.

Today, most SAN designs use a variant of what is known as a *core-to-edge* network design. In this design, the network elements, typically switches, are designated as either core or edge switches.



In Figure 2-1 we show a core-to-edge SAN design.

Figure 2-1 Core-to-edge SAN design with director type switches (SAN256B)

As we can see, the edge switches connect node devices such as servers and the core switches connect the storage devices and the edge switches. For this reason, core switches are sometimes called *backbone* switches. The core-to-edge, two-layer design has the following advantages:

- Storage: Because it is usually the most expensive component of the SAN, storage needs to be attached to the most powerful component of the FC network. The goal is to have fully utilized storage ports. The total bandwidth going through the inter-switch links (ISL) to the core switch depends on the bandwidth of the core switch to storage port connection.
- Server: Gathering servers connected to the edge switch allows many servers to be funneled into the core of the network.
- Separated SAN design: The use of a core switch for edge duty is appropriate for nodes that have a *one-to-many* relationship in the network, such as storage elements.
- Scalability: Rapid growth of the network infrastructure can be resolved by scaling by adding more switches, at the core and at the edge.
- High availability: Firstly, the two fabric design as described in Figure 2-1 on page 22 helps to address the requirement for high availability in the case of a single switch failure in the fabric, or a total fabric failure. Secondly, the core switches have built in high availability components.
- Reliability: Switches that are functioning as the core of the SAN network connecting storage are more reliable than the edge switches which connects node devices as servers. They use more sophisticated error detection and correction mechanisms to ensure reliability of data, for example:
 - Bus monitoring and control of blades and other field-replaceable units (FRUs).
 - Dual control processors that enable hot, non-disruptive fast firmware upgrades.

Because most SAN communications occur between servers and storage elements, the SAN design must provide the proper bandwidth to funnel communications for all server connections through to the storage elements.

The IBM technology of the new core SAN768B/SAN384B switches can enable the next *enterprise-class SAN design* by providing higher speeds and a denser fabric core, allowing a denser concentration of both server and storage connections to the fabric.

Similar to the design decisions that SAN architects made as Fibre Channel speeds moved from 2 Gbps to 4 Gbps, the transition from 4 Gbps to 8 Gbps will allow the most current FOS SAN infrastructure to use the IBM SAN768B/SAN384B at the core of the fabric and propagate directors, such as the SAN256B, towards the edge, as shown in Figure 2-2.



Figure 2-2 Core-to-edge design with IBM System Storage SAN768B/SAN384B as a core and SAN 256B as edge switches

2.1.1 Availability considerations

For high availability reasons, we keep the two fabric design. The IBM/Brocade backbone switch has been divided into two logical switches. Virtual fabrics and logical switches are described in Chapter 11, "Virtual Fabrics" on page 469.

2.1.2 Benefits of a consolidated SAN design

This type of consolidated SAN design has the following benefits:

- Ease of management by reducing the number of SAN switch elements in the fabric
- Use of fewer ISLs, as well as fewer optics for ISLs; 8 Gbps ISL provide improved performance
- Improved availability characteristics
- More connectivity with lower power and cooling profiles than the equivalent number of edge switches
- Improved data center space efficiencies
- Greater bandwidth on the core/storage edge of the SAN
- Reducing overhead and complexity
- Improving resource utilization
- Increasing performance
- Deploying long-term solutions

2.2 IBM/Brocade Data Center Fabric value enhanced

IBM/Brocade introduced the new class of 8 Gbps modular switching platform, which is designed for the next generation enterprise data centers. It supports open system and mainframe environments.

The building blocks for the IBM/Brocade Data Center Fabric are the IBM System Storage SAN768B and IBM System Storage SAN384B, and are called *backbones*.

IBM/Brocade backbones, a new class of fabric infrastructure, delivers the high-performance, non-disruptive scalability and continuous availability necessary for converged data center fabrics. The IBM/Brocade solution accelerates the transformation of today's physical data center into tomorrow's virtual data center.

The IBM/Brocade backbone delivers this performance at excellent value on an expandable technology platform designed to seamlessly add tomorrow's advanced technologies.

Here are the main advantages of the IBM/Brocade Backbone solution:

- Un-congested 8 Gbps throughput (up to 4 times more powerful than other offerings):
 - Offers greater server, storage, network, and data center consolidation
 - Broadens server virtualization with more virtual machines on fewer physical servers
 - Reduces equipment, facility, and overhead costs
 - Scales efficiently and non-disruptively to meet storage growth and application demands without increasing complexity
- A 10X energy efficiency advantage:
 - Provides lowest power consumption, cooling (BTU/hour), and carbon emissions
 - Frees limited power and cooling resources for more servers (physical/virtual) and storage arrays
 - Lowers energy costs and helps achieve "green" initiatives
- ► High-speed, highly secure fabric based encryption:
 - Prevents exposure to sensitive information
- Native b/m-series connectivity
- Adaptive Networking:
 - Optimizes fabric behavior and ensures ample bandwidth for critical applications
- Logical partitioning:
 - Provides ability to logically separate fabrics
- Future-built for FCoE/CEE:
 - Reduces and simplifies server network connections as new protocols emerge

2.3 IBM/Brocade backbone models

There are two IBM/Brocade backbone models:

- IBM System Storage SAN384B
- IBM System Storage SAN768B

Their features are described in Chapter 1, "Product introduction" on page 1.

In this and the following chapters, we introduce details of the backbone family of switches.

The differentiation between *director type* and *backbone* switches is as follows:

- Director:
 - Designed primarily to provide Layer 2 Fibre Channel/FICON connectivity
 - At the core of midsize enterprise data center SANs
 - At the edge of large data center fabrics
 - Requires high bandwidth (moderate 8 Gbps utilization), RAS, and energy efficiency
 - Has moderate virtual server demands (hundreds of virtual machines; less than 20 virtual machines per host; Tier 2 applications)
- Backbones:
 - Require the highest bandwidth (extensive 8 Gbps utilization)
 - Have extensive virtual server demands (several hundred to thousands of virtual machines; generally 15 or more virtual machines per host; Tier 1 applications in addition to Tier 2 applications)
 - Want integrated FC routing as opposed to using a special blade (and blade slot)
 - Have security/compliance requirements warranting encryption of data rest on a broad scale (as opposed to using/adding separate encryption switches)
 - Want the ability to logically partition a SAN fabric and manage by application, business group, customer, or traffic type
 - Want the flexibility to deploy direct CEE/FCoE network connections in the future as opposed to using a separate CEE/FCoE "top-of-rack" switch

In Figure 2-3 we show the smaller model of the family: the IBM System Storage SAN384B, which can be used as a mid-size enterprise fabric core or large enterprise edge/application engine.



Figure 2-3 IBM System Storage SAN384B

The following main features are included:

- ► Up to 256 FC/FICON ports
- An 8-slot horizontal card cage:
 - Two Active/Passive Control Processor (CP) Blades (same as the larger model)
 - Two Active/Active Core Switching (CR) Blades:
 - DCX can operate with one CR blade at half slot bandwidth.
 - Each CR blade has two ICL ports.



In Figure 2-4 we show the larger model of the backbone family.

Figure 2-4 IBM System Storage SAN768B

The following main features are included:

- A 12-slot vertical card cage:
 - Two Active/Passive Control Processor (CP) blades
 - Two Active/Active Core Switching (CR) blades:
 - DCX can operate with one CR blade at half slot bandwidth.
 - Each CR blade has two special Inter Chassis Link (ICL) ports.
- Up to 512 ports at full 8 Gbps speed
- ► 3.072 Tbps Chassis Bandwidth:
 - 256 Gbps bandwidth per slot

The backbone switches have separate (and redundant) control processor and core switching blades. If a control processor blade fails, the second control processor blade (in standby mode) takes over without any degradation in performance.

Consideration: However, the core switching blades are active/active: If a core switching blade fails, all ports will fully operate but with half the aggregate chassis and slot bandwidth.

2.4 Scalability at the core

If one backbone switch as the core is not sufficient to meet the needs of the fabric, there is a solution: Inter Chassis Links (ICLs), which are ISL connections between two CR (core) blades on the switch.

Inter-Chassis Links (ICLs): ICLs harness unused ports to connect the switching backplane of one SAN768B chassis directly with the switching backplane of another SAN768B or SAN384B chassis. This additional connection means that it does not consume usable ports. ICL connections operate as hardware trunked ISLs.

The connection means is through copper cables between each of the core switching blades on the SAN768B or SAN384B chassis. The copper cables are supplied by IBM and are 2 meters in length. Because of the short connectivity distance, chassis connected with ICLs will reside in the same cabinet or in adjacent cabinets. ICL cables can be connected in any fashion from one core blade in one chassis to the other core blade in the other chassis.

The best way to connect is using the same connector or blade in each chassis for simplicity. ICLs are an optional licensed feature of the SAN768B. Feature number 7870 provides two cables and feature numbers 7882 or 7885 provides a license. These features must be ordered for each of the chassis using ICL connections.

Use of ICLs does not collapse the switches domains into a single domain.

Both the SAN768B or SAN384B switches have the special Fibre Channel ICL ports to connect two or three backbone chassis, enabling the SAN768B and SAN384B switch to scale to the following capacity:

- ► Dual-chassis: Up to 1024 ports on a SAN768B or 512 ports on a SAN384B.
- ► Three chassis: Up to 1536 ports on a SAN768B or 768 ports on a SAN384B.

ICL: FOS V6.3 or higher is required for a three way ICL configuration.

2.4.1 Scalability advantages

The advantages of these connections are as follows:

- Port count is doubled at the core of the fabric without use of any user ports.
- Speed is locked at 8 Gbps and cannot be changed.

Attention: Configuration change is not allowed on ICL ports.

► No SFPs or FC ports are required.

For the IBM System Storage SAN768B:

- ► Each ICL port consists of sixteen 8Gbps FC connections.
- ► Four ICLs deliver 512 Gbps of bandwidth.

For the IBM System Storage SAN384B:

- ► Each ICL port consists of eight 8 Gbps FC connections.
- ► Four ICLs deliver 256 Gbps of bandwidth.

For both backbone models, it appears that each ICL is managed as:

- ► One (SAN384B) 8-port ISL trunk
- ► Two (SAN768B) 8-port ISL trunks

These models have the following features:

- ► Frame-based trunking is enabled across each ICL.
- ► DPS distributes exchanges across all frame trunks.
- ► If an ICL fails, traffic automatically flows over the remaining ICLs.

With the usage of ICL we can preserve E_Ports in the chassis for any other server/storage/switch connection:

- 64 x 8 Gbps E_Ports/per chassis for SAN768B (sixteen 8 Gbps per ICL * 4 ICLs)
- ► 32 x 8Gbps E_Ports/per chassis for SAN384B (eight 8 Gbps per ICL * 4 ICLs)

In Figure 2-5 there are four copper pin ICL ports per chassis which are used to connect two backbones with special 2m ICL cables.



Figure 2-5 ICL ports

Bear in mind that proper cable connections optimize load distribution across ICLs. Each ICL cable has a color coded connector (silver text/black background or black text/silver background). The connection can be done by matching ICL cable connector color with ICL port color on core blades. The multiple supported combinations of two chassis connection are outlined in SAN768B and SAN384B hardware guides (IBMSAN768B/DCX ICL Cable Replacement Procedure or IBM384B/DCX-4S ICL Cable Replacement Procedure).

Figure 2-6 shows a supported connection of two SAN384B switches.

Because the blades in the SAN384B are installed horizontally, the familiar top-to-bottom orientation for other products becomes a left-to-right orientation. Connect the cables from the left (top) connectors of theCR4S-8 blades in the first chassis to the right (bottom) connectors of the CR4S-8 blades in the second chassis. Similarly, connect the cables from the right (bottom) connectors of the CR4S-8 blades in the first CR4S-8 blades in the first chassis to the left (top) connectors of the CR4S-8 blades in the second chassis is to the left (top) connectors of the CR4S-8 blades in the first chassis to the left (top) connectors of the CR4S-8 blades in the second chassis.

Cables: It is also acceptable to attach the cables from slot 3 on one chassis to slot 3 on the second chassis (or slot 6 to slot 6) as long as the left-to-right (top-to-bottom) rule is followed.



Figure 2-6 ICL cable connection between two SAN384B backbone switches

2.4.2 Moving a backbone-class switch from core to edge

As we mentioned previously, the smaller backbone switch can act as a mid-size enterprise fabric core, or a large enterprise edge/application switch. So, it can be moved to the edge switch area and connected to the core switch.

In 2.2, "IBM/Brocade Data Center Fabric value enhanced" on page 25 we discussed moving the director class switch SAN256B to the edge. By moving this switch to the edge, and connecting it to the core we are forced to use the ports from the core and edge switch as well.

In this case we have not preserved the E_Ports for any other use. On the other hand, the same 8 Gbps, 10 Gbps, blades used in the SAN256B director are also utilized in the IBM/Brocade backbone switches. Backbones, however, deliver four times the slot bandwidth of the SAN256B (256 Gbps as opposed to 64 Gbps).

Figure 2-7 shows the ICL connection between core and edge switches, which includes the following characteristics:

- ► 256 Gbps of aggregate ICL bandwidth:
 - Based on ICL bandwidth of smaller backbone switch
- Moves the backbone-class from the core to the edge with:
 - Full 8 Gb
 - Integrated Routing
 - Virtual Fabrics
 - QoS
 - 2X CS and CP blades



Figure 2-7 ICL cable connections between 768B and 384B

As of FOS v6.3 and higher, the options to connect SAN384B and SAN768B switches have increased because there is now the possibility of connecting a three way ISL. All possible options can be found in the *IBM System Storage SAN768B Installation, Service, and User Guide*, GA32-0574-04.



Figure 2-8 shows an example of a three way ISL between three SAN768B switches.

Figure 2-8 Three way ISL

2.5 Blade options

For both switches in the family, we have the following blade options:

- Condor2 ASIC Port blades: 8 Gbps universal FC/FICON ports (E, F, FL, M, EX) up to a maximum of eight:
 - FC8-16: 16 x 8 Gbps FC ports
 - FC8-32: 32 x 8 Gbps FC ports
 - FC8-48: 48 x 8 Gbps
 - FC8-64: 64 x 8 Gbps
- ► The following other blades are supported:
 - FC10-6; up to eight
 - 6-port 10 Gbps blade for dark fiber connections
 - Encryption blade
 - 16 x 8 Gbps front-end user ports
 - 2 GbE ports for out-of-band cluster HA interconnect
 - Data cryptographic and data compression capabilities
 - 1:1 subscription at 16 ports
 - Auto-sensing Link Speeds at 1, 2, 4, and 8 Gbps
 - FR4-18i SAN Extension blade:
 - 16 x 4 Gbps FC ports, 2 GigE ports
 - FCIP and 4 Gbps FC Routing (alternative to integrated 8 Gbps FC Routing)
 - Up to 8 blades if FCIP only; up to 2 blades if FCIP and/or FCR

2.6 Advance Feature and Licensing

The Advanced Feature and License information is described in Table 2-1.

Feature	License
Integrated Routing	IR
Virtual Fabric	None (included in FOS 6.2+)
Top Talkers	Advanced Performance Monitoring
Ingress Rate Limiting	Adaptive Networking

Table 2-1 Advanced Features for SAN76bB/ SAN384B

Feature	License
Traffic Isolation Zones	None (included in FOS 6.0+)
Fabric QoS	Adaptive Networking
Native Interop with M-Series	None
Future 10GigE FCoE/CEE	Per future blade

2.6.1 Advanced Feature summary

Here we provide an Advanced Feature summary:

- Integrated Routing:
 - Up to 128 EX_ports
- Virtual Fabric (requires FOS v6.2)
- ► Logical Switch (Logical Fabric); maximum of eight per chassis:
 - Units that ship with FOS v6.2 are VF enabled by default
- Native interoperability with m-series switches (Interopmode 2, Interopmode 3):
 - SAN768B Model: FC and FICON
 - SAN384B Model: FC only (no FICON cascading with M-Series)
- ► 10 GigE FCoE/CEE future-built architecture:
 - Both models will utilize the same FCoE/CEE blade in the future

Licenses: Integrated Routing and ICL licenses are different for the SAN768B from the SAN384B. Otherwise, all other licenses are the same for both models.

2.6.2 Fabric Operating Systems

The following list shows which Fabric Operating Systems (FOS) are supported by the SAN768B and the SAN384B:

- SAN768B model requires FOS v6.0+
 - Virtual Fabric requires FOS v6.2+
- SAN384B model requires FOS v6.2+

3



Hardware features

In this chapter, we present the hardware features of the IBM System Storage and TotalStorage b-type family of products. We first discuss the generic features, then describe the features that are specific to the various models.

3.1 The hardware

The IBM System Storage and TotalStorage b-type family of products provide a range of entry and midrange switches and enterprise class directors.

3.1.1 Entry level, midrange, and director models

The entry level, midrange, and director models provide 1, 2, 4, and 8 Gbps port-to-port non-blocking throughput. With auto-sensing feature, they are capable of connecting to older 1 Gbps host servers, storage, and switches. Hub-based Fibre Channel Arbitrated Loop (FC-AL) solutions reduce performance as devices are added by sharing the bandwidth, but an IBM System Storage and TotalStorage SAN Fabric throughput continues to increase as additional ports are interconnected.

All of these models are fully interoperable with the previous IBM System Storage and TotalStorage SAN switches, and can be added to existing fabrics, enabling transition from existing Fibre Channel storage networks to the faster technology.

3.1.2 Switch and director model types

Table 3-1 lists the current and historic switch and director model types with speed and port capabilities, the current supported version of Fabric Operating System (Fabric OS), and the type of Application Specific Integrated Circuit (ASIC).

Switch type	# Ports	Port speed	Fabric OS version	ASIC type
2499-192	16 to 256	1, 2, 4 and 8 Gbps	6.4.1+	Condor2
2499-384	16 to 768	1, 2, 4, and 8 Gbps	6.4.1+	Condor2
2498-B80	80	1, 2, 4 and 8 Gbps	6.4.1+	GoldenEye2
2498-B80	48, 64, and 80	1, 2, 4, and 8 Gbps	6.4.1+	GoldenEye2
2498-B40	24, 32, and 40	1, 2, 4, and 8 Gbps	6.4.1+	Condor2
2498-E32	32	1, 2, 4, and 8 Gbps	6.4.1+	Condor2
2498-B24	8, 16, or 24	1, 2, 4, and 8 Gbps	6.4.1+	GoldenEye2
2498-R06	16 6	1, 2, 4, and 8 Gbps 6 x 1 GbE ports	6.4.1+	GoldenEye2

 Table 3-1
 Director and switch models

Switch type	# Ports	Port speed	Fabric OS version	ASIC type
3758-L32	8 24	1, 2, 4 and 8 Gbps 10Gig Converged Enhanced Ethernet (CEE)	6.4.1+	Condor2 Anvil
2005-B5K	16, 24, or 32	1, 2, and 4 Gbps	6.4.1+	Condor
2005-B64	32, 48, or 64	1, 2, and 4 Gbps	6.4.1+	Condor
2005-B32	16, 24, or 32	1, 2, and 4 Gbps	6.4.1+	Condor
2005-B16	8, 12, or 16	1, 2, and 4 Gbps	6.4.1+	GoldenEye
2005-H16	16	1 and 2 Gbps	5.3.x	Bloom II
2005-H08	8	1 and 2 Gbps	5.3.x	Bloom II
2109-M48	16 to 384	1, 2, 4 and 8 Gbps	6.4.1+	Condor
2109-M14	32 to 128	1 and 2 Gbps	5.3.x	Bloom II

3.2 Generic features

In this section, we describe the standard features that are available on all of the b-type family.

3.2.1 Auto-sensing speed negotiation

The IBM System Storage and TotalStorage SAN uses internal Application Specific Integrated Circuits that support link operation at either 8, 4, 2, or 1 Gbps. As a device is connected to a port, the link speed is negotiated to the highest speed that is supported by the device. This speed selection is auto-negotiated by the ASIC driver on a per-port basis. If multiple devices are connected to a port (for example, on an FL_Port), the driver auto-negotiates for the highest common speed and sets the transmitter and receiver accordingly. This *auto-sensing negotiation* allows easy configuration.

3.2.2 Zoning

You can use *zoning* to arrange fabric-connected devices into logical groups (zones) dynamically across the physical topology of the fabric.

Zones can include selected storage and hosts within a fabric restricting information access to only the member devices in the defined zone. Although zone members can access only other members in their zones, individual devices can be members of more than one zone. This approach enables the secure sharing of storage resources, a primary benefit of storage networks.

We discuss zoning further in Chapter 12, "Basic zoning" on page 513.

3.2.3 Frame filtering

Frame filtering enables another level of storage area network (SAN) fabric monitoring and management. Zoning is a fabric management service that you can use to create logical subsets of devices within a SAN and enable partitioning of resources for management and access control purposes. Frame filtering enables the switch to provide zoning functions with finer granularity. Frame filtering can be used to set up port level zoning, worldwide name zoning, device level zoning, protocol level zoning and filtering can be achieved at wire speed. Frame filtering is also used with performance monitoring, allowing you to monitor either "End to End" traffic flow or device-based I/O requirements.

3.2.4 Routing

The switch or director's control processor maintains two routing tables, one for *unicast* and one for *multicast*. The unicast routing tables are constructed during fabric initialization. The multicast tables are initially empty, except for broadcast addresses. When the tables have been constructed, they are loaded into each ASIC.

The unicast tables change if ports or links come online or go offline, or if some other topology changes occur. These updates are triggered by a Registered State Change Notification (RSCN). When new paths become available, the control processor can change the routing tables in order to share the traffic load.

The multicast tables change as ports register with the alias server to create, join, or leave a multicast group. Each time a table changes, it must be reloaded into the ASICs.

3.2.5 Service functions

The ASIC interrupts the embedded processor when a frame arrives that has an error (for example, incorrect source ID), when a frame times out, or when a frame arrives for a destination that is not in its routing tables. When a frame arrives for a destination that is not in its routing tables, the frame might be addressed to an illegal destination ID, or it might be addressed to one of the *service functions* that are provided by the embedded processor such as SNMP, name server, or alias server.

3.2.6 Port Fencing

Port Fencing is a feature that is added to the switches starting with Fabric OS v6.1. Using this feature, ports that operate outside the bounds of normal operation can be disabled. Port Fencing requires a Fabric Watch License and can be configured based on the Fabric Watch event monitoring. When the port is disabled, user intervention is required for the port to be enabled again. Port Fencing has to be configured using the command-line interface (CLI) and is not supported in Web Tools.

3.2.7 ISL Trunking

The current IBM System Storage and TotalStorage SAN b-type switches have an optional feature called *ISL Trunking*. ISL Trunking is ideal for optimizing performance and simplifying the management of a multi-switch SAN fabric.

When two to four or eight adjacent ISLs in the same trunking group, depending on switch models, are used to connect two switches, the switches automatically group the ISLs into a single logical ISL, or *trunk*. The throughput of the resulting trunk is the sum of the throughputs of the participating links.

ISL Trunking is designed to significantly reduce traffic congestion. As shown in Figure 3-1, four 4 Gbps ISLs are combined into a single logical ISL with a total bandwidth of 16 Gbps. The trunk can support any number of connections, although we only show five connections in our example. Be aware that prior to implementing the trunking, the four parallel ISLs result in a throughput of 10 Gb due to the fact that two of the connections are sharing the same ISL. Following the implementation of trunking, this throughput increases to 14 Gb, that is, full throughput.

To balance the load across all of the ISLs in the trunk, each incoming frame is sent across the first available physical ISL in the trunk. As a result, transient workload peaks for one system or application are much less likely to impact the performance of other devices of the SAN fabric.



Figure 3-1 SAN b-type ISL Trunking

Because the full bandwidth of each physical link is available with ISL Trunking, no bandwidth is wasted by inefficient load sharing. As a result, the entire fabric is used more efficiently. Fabric OS and management software, such as Fabric Watch, also view the group of physical ISLs as a single logical ISL. A failure of a single ISL in a trunk causes only a reduction of the available bandwidth and not a failure of the complete route. Therefore, no re-calculation of the routes at that time is required. Bandwidth is restored automatically when the ISL is repaired.

Trunk master: If an older 2 Gbps switch is involved in either end of a trunk, one of the links forming the trunk is chosen as the trunk master. If that trunk master link fails, the trunk must select a new master, causing a slight disruption to traffic. Trunks between the new 4 Gbps switches do not have this restriction.

ISL Trunking helps to simplify fabric design, lower provisioning time, enhance switch-to-switch performance, simplify management, and improve the reliability of the SAN fabrics. In-order delivery is still guaranteed by the switch ASICs.
Table 3-2 lists the maximum number of ISLs that a single trunk supports, as well as the maximum trunk speed for different IBM System Storage and TotalStorage b-type switch models. If you have to form an ISL trunk between two different switch models, the lower of the maximum values for both number of ports supported and port speed apply.

Device type	Ports/trunk	Port speed	Trunk speed
SAN24B-4	8	8 Gbps	64 Gbps
SAN40B-4	8	8 Gbps	64 Gbps
SAN80B-4	8	8 Gbps	64 Gbps
B32	8	8 Gbps	64 Gbps
SAN256B	8	8 Gbps	64 Gbps
SAN384B	8	8 Gbps	64 Gbps
SAN768B	8	8 Gbps	64 Gbps

Table 3-2 Maximum trunk capacity

3.2.8 Diagnostics

The switch supports a set of power-on self tests (POSTs), as well as tests that can be invoked using a CLI. These diagnostics are used during the manufacturing process as well as for fault isolation of the product in customer installations. The POST and diagnostic commands concentrate on the Fibre Channel ports and verify the functionality of the switch. Post diagnostics are written to run in the Fabric OS environment. However, as the Fabric OS does not run without a working SDRAM, a SDRAM/boot EEPROM test is run as part of the pre-Fabric OS startup code to verify that the basic processor connected memories are functioning properly.

Loop-back paths for frame traffic are provided in the hardware for diagnostic purposes. A loop-back path within the ASIC, at the final stages of the Fibre Channel interface, can be used to verify that the internal Fibre Channel port logic is functioning properly, as well as paths between the interface and the central memory.

Additionally, the Serial Link macro within the ASIC includes a serial data loop-back function that can be enabled through a register in the corresponding ASIC.

Diagnostics are provided to allow traffic to be circulated between two switch ports that are connected with an external cable. This allows the diagnostics to verify the integrity of the final stage of the SERDES interface, as well as the SFP module.

3.3 Products and features

In this section, we provide an overview of the products and features in the IBM/Brocade portfolio. For the latest information, see this website:

http://www-03.ibm.com/systems/storage/san/index.html

Both the Condor2 and GoldenEye2 ASICs now support 8 Gbps port throughput capability throughout the current product range from the 8-port B24 switch to the SAN768B Fabric Backbone. Additional functionality of these ASICs provides larger trunking capabilities and integrated SERDES.

We discuss the support for these new features in the following sections.

3.3.1 2499-384

The 2499-384, also known as the IBM System Storage SAN768B Fabric Backbone, is designed for larger mid-range to enterprise-level SAN applications and is a core switching platform used to interconnect storage devices, hosts, and servers in SANs. The SAN768B is designed to meet the growing connectivity, virtualization, and cost-efficiency needs of enterprise data centers. As the core of the Data Center Fabric (DCF) architecture, the SAN768B Fabric Backbone is highly robust and can support both open systems and mainframe environments. With breakthrough performance, scalability, and energy efficiency, the SAN768B is designed to meet a wide range of technology challenges for evolving enterprise data centers and provides long-term investment protection.

To support growing server and storage environments and to facilitate virtualization, the SAN768B delivers over four times the bandwidth of industry-leading SAN directors and perform at speeds of 1, 2, 4, 8, or 10 Gbps. Using 4 Gbps or 8 Gbps Fibre Channel SFPs, a single chassis provides up to 384 Fibre Channel ports. Four Inter-Chassis Link (ICL) ports are used to connect two or three SAN768B chassis, and preserve the equivalent of up to 128 8 Gbps E_Ports for server and storage connectivity.

As a member of the IBM System Storage and TotalStorage SAN b-type family products, the SAN768B is designed to participate in fabrics containing other b-type and m-type devices manufactured by Brocade. This versatile hardware can serve as a new top tier (or backbone) in a complex fabric and provide connections to other b-type and m-type directors, switches and routers.

Figure 3-2 shows the front view of the SAN 768B Fabric Backbone.

Figure 3-2 SAN768B Fabric Backbone

With the chassis size identical to the SAN256B, the SAN768B houses four 2000-watt power supplies and three 220 mm blower fans. Both the blowers and the power supplies plug directly into the backplane and are both individual FRUs. The power supplies are auto-sensing from 110 to 240 V single phase and frequency range 47 to 63 Hz. With a DC power consumption of 1515 watts when configured as a fully loaded system, the SAN768B is extremely energy efficient.

Power consumption: The 1515 watts power consumption is for a fully loaded system configured with two CP8 blades, two CR8 blades, eight FC8-48 blades with 384 SWL SFPs, and three blowers.

Table 3-3 shows the power consumption of each blade.

Blade	Power Consumption (Watts)
CP8(CP Blade)	38
CR8(Core Blade)	95
FC8-16(16 Port Blade)	50
FC8-32(32 Port Blade)	80
FC8-48(48 Port Blade)	115
FC8-64(64 Port Blade)	126
FR4-18i(FCIP Blade)	140
Encryption blade	235
FA4-18(Application Blade)	168
FC10-6(10 Gbps Blade)	120

 Table 3-3
 Blade power consumption

The SAN768B also has two world wide name (WWN) cards per chassis that are located between the power supplies and are covered with a plate. The WWN cards have one SEEPROM on each card to store the FRU S/N, runtime hours, OEM specific information and event/error logs on each. The data stored on the WWN cards is CRC checked when the data is written.

Figure 3-4 shows the WWN card status LEDs.



Figure 3-3 WWN card status LEDs

Inter-Chassis Link

The Inter-Chassis Link (ICL) allows three SAN768Bs or SAN384Bs to be connected together without sacrificing user ports (for more details, see 2.4, "Scalability at the core" on page 30). Each ICL is the equivalent of 16 x 8 Gbps of bandwidth. A total of four ICL connections can be made between two SAN768Bs, providing a total bandwidth of 64 x 8 Gbps and creating a dual core fabric with 768 user ports available.

Figure 3-4 shows an example of two SAN768Bs with the ICL connected and three SAN768Bs connected with ICL. An ICL kit that includes two ICL licenses, and four ICL cables, are required to establish an ICL.



Figure 3-4 SAN768B ICL connection

ICLs: Use of ICLs does not collapse two switch domains into a single domain.

Figure 3-5 shows the ICL cable connector.



Figure 3-5 SAN768B: ICL Cable Connector

Key features of the SAN768B include these:

- Operating on the Condor2 ASIC, the SAN768B supports full-line-rate performance with 8 Gbps ports.
- The high density blade architecture provides up to 512 8 Gbps Fibre Channel ports per single chassis or up to 1024 8 Gbps Fibre Channel ports in a dual chassis configuration and up to 1536 8 Gbps ports on a three chassis configuration.
- The SAN768B is designed to provide high performance with 4.6 Tbps per chassis (512 ports × 8 Gbps data rate + 512 Gbps ICL bandwidth).
- Multiprotocol capabilities and fabric interoperability features include support for Fibre Channel, FICON, FCIP, and IPFC. It also supports 10 Gbps Ethernet, Converged Enhanced Ethernet (CEE), Data at Rest Encryption, and Fibre Channel over Ethernet (FCoE) for future enhancements.
- The SAN768B supports fabric services and applications such as Adaptive Networking services, including Quality of Service (QoS), Ingress Rate Limiting, Traffic Isolation, N_Port ID Virtualization (NPIV), and Top Talkers.
- Special application blades designed for fabric based storage virtualization, continuous data protection, and replication and online data migration are supported on the SAN768B.
- High availability design of the SAN768B includes features such as the passive backplane, separate and redundant control processor and core switching blades, and redundant WWN cards. The high availability design also features four hot-pluggable redundant power supplies and three blower fans.
- Energy efficient design of the SAN768B makes it possible to use less than one-half watt per Gbps.

Blades on the SAN768B

The SAN786B architecture utilizes a wide variety of blades for increasing port density. The SAN768B is a 12-slot chassis consisting of 8-port blades, 2 control processor (CP8) blades, and 2 core (CR8) blades, and can provide 512 Gbps bi-directional bandwidth per slot.

The core frame routing functionality is handled by the CR8 blade, and the entire unit is capable of handling up to 16 000 hard zones. Port blades are available in 16, 32, and 48 port configurations and operate on the Condor2 ASIC. The 4 Gbps and 8 Gbps SFPs used on the blades that operate on the Condor2 ASIC must be Brocade branded.

Figure 3-6 shows the port side layout of SAN768B and slot numbers where the blades can be inserted. Slots 1 through 4 show 48 port blades; slots 5 and 8 have the core blades 0 and 1, respectively; slots 6 and 7 have the control processor blades 0 and 1, respectively; slots 9 and 10 show 32 port blades, and slots 11 and 12 show 16 port blades.



Figure 3-6 SAN768B: Port Side View

Control processor blade overview

The SAN768B has two control processor (CP8) blades in slots 6 and 7. Figure 3-7 shows the blade.

Each CP8 blade has a USB port, an RS-232 Console Port, two IP network ports, and dual processors. One of the processors and the service IP port are for future use. The USB port only supports Brocade branded USB drives and can be used for firmware download, supportsave, configuration upload, and configuration download.



Figure 3-7 CP8 blade

Table 3-4 describes the various LEDs located on the CP8 blade and the messages that can be interpreted from the status of these LEDs.

Table 3-4 LEDs on CP8 blade

LED	Color	Location	Description
Power	Green	Front Panel	On = CP power is operational. Off = CP power is failed.
Attention	Amber	Front Panel	On = If on for more than 5 seconds, board is defective or faulty.
Active	Blue	Front Panel	On = This CP is the active CP. Off = This CP is either booting, negotiating to be active or the standby CP.
Ethernet Link	Green	Front Panel RJ45 Top	On = Ethernet Port MAC link has been established at 100/1000 Mbps. Off = No Link or 10 Mbps.
Ethernet Activity	Green	Front Panel RJ45 Bottom	On Blinking = TX and RX Frames activity present. Off = No TX and RX activity.
USB Port	Green	External	On = USB port is enabled. Off = USB port is disabled.

Core blade

The CR8 blade provides the core routing of frames either from blade to blade or from SAN768B to SAN768B (or SAN384B) through an ICL cable. Each CR8 blade has four Condor2 ASICs and two ICL ports.



Figure 3-8 shows the CR8 blade with two ICL ports.

Figure 3-8 CR8 blade

The CR8 blade has two LEDs on the top, and their status can be interpreted as shown in Table 3-5.

Table 3-5 LEDs on CR8 Blade

LED	Color	Description
Power	Green	On = CP power is operational. Off = CP power has failed.
Attention	Amber	On = If on for more than 5 seconds, board is defective or faulty. Off = Normal operation.

The two ICL connectors have two LEDs each, and their status can be interpreted as shown in Table 3-6.

Table 3-6 LEDs on ICL connectors

Green	Amber	Condition
Off	Off	Cable is not present OR local end is not ready OR far end is not ready.
Off	On	N/A
On	Off	Cable is present AND local end is ready AND far end is ready.
On	On (Blinking)	Cable is present AND local end is ready AND far end is ready AND attention is required.

Condor2 ASIC port blades

The Condor2 ASIC is the next generation ASIC used on the port and the core blades, and provides all the functions that the Condor ASIC does but has more ports, higher speeds, and more buffer space. The SAN768B supports a variety of Condor2 ASIC port blades for increased port density.

FCOE10-24

This blade provides CEE/FCoE connectivity for server I/O consolidation (24 x 10 GbE CEE ports; up to two blades per chassis), shown in Figure 3-9.



Figure 3-9 FCOE10-24

Encryption Engine

The Encryption Blade provides plug-in encryption of data on disk or tape, supporting industry-standard AES-256 and DataFort-compatible encryption mode (16 8 Gbps Fibre Channel ports; up to four blades per chassis and requires DCFM management), shown in Figure 3-10.



Figure 3-10 Encryption Engine

FX8-24

This blade provides SAN extension over IP networks (12 8 Gbps Fibre Channel ports with license options providing up to 10 1 GbE ports, and up to two 10 GbE ports per blade; up to four blades), shown in Figure 3-11.



Figure 3-11 FX8-24 blade

FC 4 Gbps Routing blade

The Application Blade provides 16x 4 Gbps Fibre Channel ports and two Gigabit Ethernet ports per blade (up to four blades), shown in Figure 3-12.



Figure 3-12 FS4-16i

FC10-6

This blade provides six 10 Gbps Fibre Channel ports (up to eight blades)

References: These blades are described in detail in the following books:

- IBM Converged Switch B32, SG24-7935-00, available at this website: http://www.redbooks.ibm.com/redpieces/abstracts/sg247935.html?Ope n
- Implementing the IBM System Storage SAN32B-E4 Encryption Switch, SG24-7922, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247922.html?Open

 IBM System Storage b-type Multiprotocol Routing: An Introduction and Implementation, SG24-7544-03, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247544.html?Open

FC8-16

The FC8-16 is a 16 port blade that can operate on one Condor2 ASIC. Operating at speeds of 1, 2, 4, and 8 Gbps, this blade supports F/FL/E ports and provides a 1:1 subscription at all speeds.

Figure 3-13 shows the FC8-16 blade.



Figure 3-13 FC8-16 blade



Figure 3-14 shows the SAN768B architecture for an FC8-16 blade.

Figure 3-14 SAN768B architecture for a FC8-16 blade

Figure 3-15 shows the port area numbers when all the slots in the SAN768B are configured with FC8-16 port blades.



Figure 3-15 Port area numbers: FC8-16 blade

FC8-32

The FC8-32 is a 32-port blade that can operate on two Condor2 ASICs. Operating at speeds of 1, 2, 4, and 8 Gbps, this blade supports F/FL/E ports and provides a 1:1 subscription at all speeds. The FC8-32 is shown in Figure 3-16.



Figure 3-16 FC8-32 blade



The SAN768B architecture for an FC8-32 blade is shown in Figure 3-17.

Figure 3-17 SAN768B architecture for a FC8-32 blade

Figure 3-18 shows the port area numbers for the FC8-32 blade. Ports 0-7 and 16-23 are on one ASIC, and ports 8-15 and 24-31 are on the other ASIC.

								. r			 		 		L E		
15	143	31	159	47	175	63	191		79	207	95	223	111	239		127	255
14	142	30	158	46	174	62	190		78	206	94	222	110	238		126	254
13	141	29	157	45	173	61	189		77	205	93	221	109	237		125	253
12	140	28	156	44	172	60	188		76	204	92	220	108	236		124	252
11	139	27	155	43	171	59	187		75	203	91	219	107	235	•	123	251
10	138	26	154	42	170	58	186		74	202	90	218	106	234		122	250
9	137	25	153	41	169	57	185		73	201	89	217	105	233		121	249
8	136	24	152	40	168	56	184		72	200	88	216	104	232	-	120	248
7	135	23	151	39	167	55	183		71	199	87	215	103	231	•	119	247
6	134	22	150	38	166	54	182		70	198	86	214	102	230	•	118	246
5	133	21	149	37	165	53	181		69	197	85	213	101	229		117	245
4	132	20	148	36	164	52	180		68	196	84	212	100	228	•	116	244
3	131	19	147	35	163	51	179		67	195	83	211	99	227		115	243
2	130	18	146	34	162	50	178		66	194	82	210	98	226		114	242
1	129	17	145	33	161	49	177		65	193	81	209	97	225		113	241
0	128	16	144	32	160	48	176	I [64	192	80	208	96	224	-	112	240
1	1		2	2	3	4	L.Ca	rd Slot	s)	 	10	 1	1		1	2

Figure 3-18 Port area number: FC8-32 blade

FC8-48

The FC8-48 is a 48 port blade that can operate on two Condor2 ASICs. Operating at speeds of 1, 2, 4, and 8 Gbps, this blade supports F/E ports and provides a 24:16 subscription at 8 Gbps speeds. The FC8-48 is shown in Figure 3-19.



Figure 3-19 FC8-48 blade



Figure 3-20 shows the SAN768B architecture for an FC8-48 blade.

Figure 3-20 SAN768B architecture for a FC8-48 blade

The port area numbers for the FC8-48 blade are shown in Figure 3-21. Each ASIC supports 24 ports. Ports 0-7 and 24-39 are on one ASIC, and ports 8-23 and 40-47 are on the other ASIC.

		_		_							_	_	
135	271	161	287	167	303	183	319	199	336	216	351	231	367
34	270	160	286	166	302	182	318	198	334	214	350	230	366
133	269	149	285	165	301	181	317	197	333	213	349	229	365
132	268	148	284	164	300	180	316	196	332	212	348	228	364
131	267	147	283	163	299	179	315	195	331	211	347	227	363
130	286	148	282	162	298	178	314	194	330	210	346	228	362
129	285	146	281	161	297	177	313	193	329	209	345	225	361
128	284	144	280	160	298	178	312	192	328	208	344	224	360
16	283	31	279	47	295	63	311	79	327	96	343	111	369
14	282	30	278	48	294	62	310	78	326	94	342	110	368
13	281	29	277	46	293	61	309	77	326	93	341	109	367
12	280	28	278	44	292	60	308	76	324	92	340	108	356
11	269	27	276	43	291	69	307	76	323	91	339	107	365
10	268	28	274	42	290	68	306	74	322	90	338	108	354
9	267	26	273	41	289	67	305	73	321	89	337	105	353
8	256	24	272	40	288	68	304	72	320	88	336	104	352
7	143	23	169	39	176	66	191	71	207	87	223	103	239
e	142	22	168	38	174	63	190	70	206	88	222	102	238
6	141	21	167	37	173	63	189	69	206	86	221	101	237
4	140	20	168	38	172	62	188	68	204	84	220	100	236
3	139	19	166	36	171	61	187	87	203	83	219	89	235
2	138	18	164	34	170	60	188	66	202	82	218	98	234
1	137	17	163	33	169	49	185	85	201	81	217	97	233
0	136	18	162	32	168	48	184	64	200	80	216	96	232
	1		2		3	-	4	ote	9		10	1	1

Figure 3-21 Port area number: FC8-48 blade

FC8-64

The FC8-64 is a 64 port blade that can operate on four Condor2 ASICs. Operating at speeds of 2, 4, and 8 Gbps, this blade supports F/E ports and provides a 2:1 oversubscription at 8 Gbps speeds and 1:1 at 4 Gbps. FL ports are not supported on this blade. The FC8-48 is shown in Figure 3-22.

Attention: The 8-Gb 64-port blade (FC3864) cannot be installed in the same chassis as a FCOE10-24 blade (FC3880).



Figure 3-22

Figure 3-23 on page 67 shows the SAN768B architecture for an FC8-64 blade.



Figure 3-23 FC8-64 architecture

As shown there are four Condor2 ASICs on the FC8-64 blade. The port layout and port groups that share an ASIC are shown in Figure 3-24 on page 68.



Figure 3-24 Port assignments for FC8-64 blade.

The ports on the FC8-64 are assigned port numbers as shown in Figure 3-25 on page 69.

110		100					000
143 783	159 799	175 815	191 831	207 847	223 863	239 879	255 895
142 782	158 798	174 814	190 830	206 846	222 862	238 878	254 894
141 /81	157 797	173 813	189 829	205 845	221 861	237 877	253 893
140 780	156 796	1/2 812	188 829	204 844	220 860	236 876	252 892
139 //9	155 795	1/1 811	187 827	203 843	219 859	235 875	251 891
130 //0	104 /94	1/0 810	100 020	202 042	210 000	234 074	200 090
136 776	152 702	168 808	184 824	200 840	216 856	233 873	249 009
135 775	151 701	167 807	183 823	100 830	215 855	231 871	240 000
134 774	150 790	166 806	182 822	198 838	214 854	230 870	246 886
133 773	149 789	165 805	181 821	197 837	213 853	229 869	245 885
132 772	148 788	164 804	180 820	196 836	212 852	228 868	244 884
131 771	147 787	163 803	179 819	195 835	211 851	227 867	243 883
130 770	146 786	162 802	178 818	194 834	210 850	226 866	242 882
129 769	145 785	161 801	177 817	193 833	209 849	225 865	241 881
128 768	144 784	160 800	176 816	192 832	208 848	224 864	240 880
15 271	31 287	47 303	63 319	79 335	95 351	111 367	127 383
14 270	30 286	46 302	62 318	78 334	94 350	110 366	126 382
13 269	29 285	45 301	61 317	77 333	93 349	109 365	125 381
12 268	28 284	44 300	60 316	76 332	92 348	108 364	124 380
11 267	27 283	43 299	59 315	75 331	91 347	107 363	123 379
10 266	26 282	42 298	58 314	74 330	90 346	106 362	122 378
9 265	25 281	41 297	57 313	73 329	89 345	105 361	121 377
8 264	24 280	40 296	56 312	72 328	88 344	104 360	120 376
7 263	23 279	39 295	55 311	71 327	87 343	103 359	119 375
6 262	22 278	38 294	54 310	70 326	86 342	102 358	118 374
5 261	21 277	37 293	53 309	69 325	85 341	101 357	117 373
4 260	20 276	36 292	52 308	68 324	84 340	100 356	116 372
3 259	19 275	35 291	51 307	67 323	83 339	99 355	115 371
2 258	18 274	34 290	50 306	66 322	82 338	98 354	114 370
1 257	17 273	33 289	49 305	65 321	81 337	97 353	113 379
0 256	16 272	32 288	48 304	64 320	80 336	90 352	112 368
Slot 1	Slot 2	Slot 3	Slot	Slot	Slot	Slot	Slot 12

Figure 3-25 FC8-64 port numbering layout

Firmware upgrade requirements for FC8-64

Disable the ports inSAN768B or SAN384B Logical Switches that use 10 bit addressing mode that have 8 bit areas in the range 0x70-0x8F before upgrading to FOS v6.4.+. Otherwise the firmware upgrade will fail with an error message.

This step is necessary even if there is no plan to use FC8-64 blades after performing a firmware upgrade to FOS v6.4.0. However, if areas 0x70-0x8F are not in use this step is not necessary. Use the **portAddress** CLI command to find out the areas in use within a Logical Switch.

If there is a downgrade to a FOS below 6.4 then the FC8-64 blade must be removed or the process will fail.

mSFP Transceivers

The FC8-64 requires a mini Small Form-Factor Pluggable (mSFP). This is a smaller format SFP which has the same internal technology as a standard SFP.

The mSFP has a reduced width and gap between optics to cater for the increased number of ports on a single blade.

- 2mm less in width compared to a regular SFP
- ► Tx and Rx spacing decreased from 6.25mm to 5.25mm
- Cables with new Tx/Rx spacing connectors

The mSFP has a Pull/Push tab for easy insertion and removal as shown in Figure 3-26.



Figure 3-26 mSFP and SFP

Attention: An mSFP will fit into a standard SFP slot, but this is not a supported configuration, and the port will be faulted and taken offline.

Restriction: Only SWL optics are available for mSFP, and V6.1+ OS is required.

Port area numbers

You can also use Figure 3-21 as a reference for the port area numbers, as follows:

- ▶ Ports 0 through 15 on all blades are mapped to area numbers 0 through 127.
- Ports 16 through 31 on all the blades are mapped to area numbers 128 through 255.
- Ports 32 through 47 on all the blades are mapped to area numbers 256 through 383.
- Ports 48 through 61 on the FC8-64 blades are mapped to area numbers 768 through 895.

Figure 3-27 explains the port area numbers that are assigned, which depends on the slot in which the blade is installed.



Figure 3-27 SAN768B port area numbers with mixed blades

We further explain the port area numbers for the SAN768B using the following blade configuration:

- Slot 1 32 port blade
- Slot 2 16 port blade
- Slot 3 64 Port blade
- Slot 4 empty
- Slot 9 48 port blade
- ► Slot 10 32 port blade
- ► Slot 11 empty
- ► Slot 12 64 port blade

Figure 3-28 shows the blades installed in the SAN768B, and Figure 3-29 shows the actual port area numbers that are assigned for this setup.



Figure 3-28 SAN768B with different blades installed



Figure 3-29 SAN768B: Port area numbers for different blades

3.3.2 2499-192

The 2499-192, also known as the IBM System Storage SAN384B, is a fabric backbone product line extension offering 192x 8 Gbps ports (half the port count offered by the 2499-384, also known as the IBM System Storage SAN768B fabric backbone) in a horizontal chassis.

The SAN384B offers flexible deployment and investment protection in both new and existing storage networks. It can be deployed as a lower cost core backbone solution in midsize enterprise network environments that do not require the throughput and port density of the larger SAN768B fabric backbone. Large enterprise customers can also implement the SAN384B at the network edge to provide complete, scalable, and cost effective backbone-class capabilities throughout their data centers. The SAN384B can also connect natively to IBM b-type and m-type network environments without disruption. Figure 3-30 shows the front view of the SAN384B.



Figure 3-30 SAN384B front view

The mechanical chassis of the SAN384B is a horizontal chassis enclosure with 8 slots accessed from the front side and 2 blowers, 2 power supplies and dual WWN cards accessed from the non-port side.

Figure 3-31 shows the back view of the SAN384B.



Figure 3-31 SAN384B back view

The SAN384B is shipped with two 2000-watt power supplies and two 220 mm blower fans. Both the blowers and the power supplies plug directly into the backplane and are both individual FRUs. The power supplies are auto-sensing from 110 to 240 V single phase and frequency range 47 to 63 Hz, with a DC power consumption of 753 watts when configured as a fully loaded system.

For blade power consumption, see Table 3-3 on page 48.

Power consumption: The power consumption of the SAN384B is 753 watts when configured as a fully loaded system. This calculation is based on a system configuration with two CP8 control processors, two CR4S-8 core blades, four FC8-48 port blades with 192 SWL SFPs, and two blowers.

Key features of the SAN384B include these:

- 8 Gbps Fibre Channel interfaces supporting 1 Gbps, 2 Gbps, 4 Gbps, and 8 Gbps auto-sensing Fibre Channel ports, which self-configure as E, F, or FL ports.
- ► Four high-performance port blades (64 port, 48 port, 32 port, and 16 port).
- Dual redundant control processors and core switching blades designed to provide enhanced high availability and enable non-disruptive software upgrades.
- ► Up to 768 x 8 Gbps user ports in connected in a three core or 512 x 8 Gbps user ports connected in a dual core with the use of Inter Chassis Links (ICLs), and up to 256 ports in a single domain.
- The multiprotocol design of the SAN384B supports blades for Fibre Channel over IP (FCIP) and routing that are the cornerstone of highly intelligent fabrics.
- Inter-Switch Link (ISL) trunking allows up to eight ports between a pair of switches to be combined to form a single, logical ISL with an aggregate speed of up to 64 Gbps for optimal bandwidth utilization.
- Dynamic Path Selection can evenly balance up to eight equal cost paths, including trunks and ISLs, at speeds from 1 Gbps to 8 Gbps. With this function, two SAN384B chassis can have up to 256 Gbps of hardware load balanced paths.
- Frame filtering resources have been increased to provide expanded security for up to 16,000 hardware zones. Hardware zoning is accomplished at the port level of the switch or by world wide name (WWN).

Important: Only 2 GB Brocade branded USB drives are supported for use on the USB port.

Blades on the SAN384B

The SAN384B supports all the blades supported by the SAN768B: the FC8-16, FC8-32, FC8-48, and FC8-64 8 Gb port blades.

For more information, see "Blades on the SAN768B" on page 51.

Important:

- The SAN384B supports all features and functions as indicated and requires Fabric OS v6.4.1+.
- ► Blades that use Condor2 ASIC *must* use Brocade branded SFPs.

Figure 3-32 shows the CP, CR, and port blades.



Figure 3-32 Blades

Port assignment

Port numbering for the FC blades is as follows:

- ► FC8-16 port blade: Ports are numbered from 0 through 15 from right to left.
- FC8-32 port blade: Ports are numbered from 0 through 15 from right to left on the lower row of ports and 16 through 31 from right to left on the upper row of ports.
- FC8-48 port blade: Ports are numbered from 0 through 23 from right to left on the lower row of ports and 24 through 47 from right to left on the upper row of ports.
- FC8-64 port blade: Ports are numbered from 0 through 31 from right to left on the lower row of ports and 32 through 63 from right to left on the upper row of ports. Trunking groups are permitted with up to eight ports per group. Trunking groups are as follows: 0-7, 8-15, 16-23, 24-31, 32-39, 40-47, 48-55, and 56-63.

Figure 3-33 shows the port assignment on a SAN384B with 64 port layout. The FC port numbering is the same for all blades types in the different slots. For example, an FC8-16 blade in slot 7 will start with port number 123 and end on port number 143.



Figure 3-33 FC8-64 in a SABN384B

Inter-Chassis Link

The Inter-Chassis Link (ICL) allows up to three SAN384Bs (or SAN768Bs) to be connected together without sacrificing user ports. This is described in 2.4, "Scalability at the core" on page 30.

3.3.3 2109-M48

The IBM System Storage SAN256B (2109-M48) director is a single domain 384-port machine capable of running its ports at 1, 2, 4, 8, or 10 Gbps. The M48 includes support for FICON, FICON/Fibre Channel intermixing, FICON CUP, and FICON cascading, enabling it to address the demands for integrated System z® and open system server enterprise SANs. The chassis includes two control processor blades and, with improved port density, enables up to 384 ports in 14U space. Other standard software features include Web Tools, Zoning, Fabric Watch, Trunking, and Advanced Performance Monitoring. Optional software products include Extended Fabric Activation and FICON with CUP Activation.

The SAN256B is a 14U chassis with 10 slots for various blades. The CP4 control processor blades, which run on the Condor ASIC, are installed in slot 5 and slot 6 of the chassis, and the remainder are used for port blades.

The chassis has two power supplies installed as a standard and has room for four power supplies. Each of these power supplies can provide 1000 W of power. Two power supplies are required for normal operation. The SAN256B has three blower assemblies installed as a standard, and the blower side of the SAN256B also has the WWN card installed.

The WWN card retains important information about the chassis and switch identity data, chassis serial number, IP address assigned to each CP card slot, switch configuration, and FRU history logs.



Figure 3-34 shows the front view of the SAN256B SAN Director.

Figure 3-34 SAN256B SAN Director

Figure 3-35 shows the non-port side view.



Figure 3-35 SAN256B non-port side view

The SAN256B architecture utilizes a wide variety of blades for increasing port density. (We describe more about the FC4-16, FC4-32, and FC4-48 blades in the sections that follow.)

Important: Starting with Fabric OS v6.1, SAN256B can now support all the 8 Gbps Condor2 ASIC-based port blades. 8 Gbps speeds can be achieved only for local switching on the same 8 Gbps blade. We describe the FC8-16, FC8-32, and FC8-48 blades further in 3.3.1, "2499-384" on page 46.
The FC4-16 is a 16-port Fibre Channel blade that can support 1, 2, and 4 Gbps as shown in Figure 3-36.



Figure 3-36 FC4-16: 16 port blade

On the 16-port blade, all ports have 64 Gbps (128 Gbps full duplex) of possible external input, and the same internal bandwidth available. In other words, the blade has a 1:1 subscription ratio. It is useful for extremely high-performance servers, supercomputing environments, high-performance shared storage subsystems, and SANs with unpredictable traffic patterns.

The FC4-32 is a 32-port Fibre Channel blade that can support 1, 2, and 4 Gbps as shown in Figure 3-37.



Figure 3-37 FC4-32: 32 port blade

The 32-port blade is designed with a 16:8 subscription ratio at 4 Gbps for non-local traffic, and a 1:1 ratio at 2 Gbps for any traffic pattern. If some or all of the attached servers and storage devices run at 2 Gbps, or if I/O profiles are "bursty," the 32-port blade typically provides the same performance as the 16-port blade.

The FC4-48 is a 48-port Fibre Channel blade that can support 1, 2, and 4 Gbps as shown in Figure 3-38.



Figure 3-38 FC4-48: 48 port blade

At 24:8, the 48-port blade has a higher backplane over-subscription ratio but also has larger port groups. The backplane connectivity of this blade is identical to the 32-port blade. The only difference is that, rather than just 16 ports per ASIC, the 48-port blade exposes 24 outward-facing ports (96 Gbps or 192 Gbps full duplex of local switching per ASIC).

SAN256B applications

This blade is especially useful for high-density SAN deployments, in the following situations:

- ► Large numbers of servers have to be connected to the director.
- Some or all hosts are running below line rate much of the time.
- Potential localization of most traffic flows is achievable.

The SAN256B also supports the FC10-6 blade for 10 Gbps ISLs between two directors. This blade is designed to extend the value of the Fibre Channel infrastructure to include 10 Gbps FC and DWDM connected SANs. The blade provides the same high availability features that exist in the Brocade 48000 director today, satisfying the stringent requirements expected of an enterprise-class director. There are two local switch groups on the blade. Ports 0-2 and Ports 3-5 are locally switched with no data transferred over the backplane.

Support: ISL Trunking is not supported with the FC10-6 blade.

The control processor (CP4) cards are new by design, including faster processor units, and make use of two 32-port Condor ASICs as the switching core.

The 16, 32, and 48-port cards make use of cut-through routing, ensuring that frames destined for ports on the same card never leave the ASIC. This integrated feature called local switching provides significant performance benefits.

SAN256B numbering scheme

The SAN256B (2109-M48) uses a numbering scheme that progresses from left to right and bottom to top in numerical order. The reference location is from the cable side to chassis:

- ► Blade assemblies are numbered from 1 to 10, from left to right.
- Power supplies are numbered from 1 to 4, from bottom to top.
- ► Fans are numbered from 1 to 3, from left to right.
- The physical ports of the 16-port card are numbered 0 to 15, from bottom to top.
- ► The physical ports of the 32-port card are numbered 0 to 15 on the left column and 16 to 31 on the right column, from bottom to top.
- The physical ports of the 48 port blade are numbered 0 to 23 from bottom to top on the left set of ports and 24 to 47 from bottom to top on the right set of ports.

35.	27.1	1.150	287	11,87,1	30.3	183.	218	. 199 .	333	215	351	231	387	_2
34	276	1.50	28.6	1 66	39.2	18.2	318	1.	334	214	3 56	230	386	- 24
23	28.9	149	285	185	38.1	18.1	317	197	333	213	349	2.29	385	243
32	255	148	284	164	30.0	. 188	316	. 198 .	332	212	348	2.28	384	.244
31	267	147	285	165	29.9	17.9	315	195	331	211	347	227	363	240
30	255	148	282	1.62	238	178	314	194	330	210	3.45	2.28	382	243
22 .	265	145	281	11.81, 1	227	. 177 .	212	. 193 .	358	2091	345	2,25	36.1	. 24,3
28	284	144	280	160	296	17.6	312	1 922	328	208	344	2.24	360	240
5	263	31	279	.47	22.5	83	311	79	327	3 3	343	1111	359	327
4	28.2	30	275	48	224	82	310	78	326	94	342	1.10	358	126
2	261	29	277	43	29.3	8 1	30.0	77.	325	99	341	109	357	325
2	260	28	276	.44	29.2	80	308	7.6	324	92	340	1.08	356	324
1	259	- 27	275	43	22.1	34	317	75	323	93	3.39	107	355	323
U .	258	28	274	.42	220	-	306	74	322	- 98	338	108	354	122
4	257	25	273	43	28.9	37	30.5	7.5	32.1	89	3.37	100	353	321
۱.	256	24	272	40	288	38	304	72	320		3 36	104	352	120
7	143	23	1 59		17.5	38	191	71	207		225	105	23.9	319
	142	22	1.58	38	174	38	190	7.0	20.6	88	222	1054	238	313
1	141	21	. 157 .	. 37	173	55	189.	82	205	83	221	101	237	217
•	.140	20	1.56	38	372	32		88	204	84	228	1.44	236	310
4	139	19	1.55		171	33	187	67	20.3	83	219	.99	235	315
2000	158	18	154	34	170	-	186	86	20.2	82	218		234	214
,	137	17	1.53	33	169	49	18.5	65	201	81	217	37	233	313
	136	18	152	32	1681		184	64	200	80	216	35	232	312
1		2	2	3	3	4	ł	Card Slote 7		8	3		9	

Figure 3-39 shows the logical decimal port numbering for the SAN256B with 48-port cards.

Figure 3-39 IBM System Storage SAN256B director 384-port numbering scheme

3.3.4 b-type top of rack switches

Here we describe the current B-Type rack mounted FC switches. The following advanced function switches are also available:

 3758-L32 converged switch, full details, and functionality, described in IBM Converged Switch B32, SG24-7935-00, available at this website:

http://www.redbooks.ibm.com/redpieces/abstracts/sg247935.html?Open

2005-R04 and 2498-R06 multi protocol routers and extension switches, full details, and functionality, which can be found in IBM System Storage b-type Multiprotocol Routing: An Introduction and Implementation, SG24-7544-03, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247544.html?Open

 2498-E32 encryption switch, full details and functionality, which can be found in *Implementing the IBM System Storage SAN32B-E4 Encryption Switch*, SG24-7922, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247922.html?Open

2498-B24

The 2498-B24 (also known as the SAN24B-4) is designed for medium-sized SAN environments. It can be used to create a wide range of high-performance SAN solutions, from simple, single-switch configurations to larger, multi-switch configurations. As an entry-level eight-port storage consolidation solution, it can support up to seven servers with a single path to either disk or tape. The Ports on Demand feature is designed to enable a base switch to grow to 16 and 24 ports to support more servers and more storage devices without taking the switch offline.

Figure 3-40 shows the SAN24B-4 fabric switch.



Figure 3-40 SAN24B-4

The switch requires Fabric OS v6.1+,and port hardware is based on the GoldenEye2 ASIC. One ASIC can support all 24 ports at 1, 2, 4, and 8 Gbps link speeds and they can be configured as F, FL, E, M and EX Ports. This switch provides a 1:1 subscription on all 24 ports.

The switch supports non-blocking architecture designed to provide up to 284 Gbps aggregate throughput with a 24-port configuration.

Standard configuration includes 8-port activation and capability to attach to hosts and storage device. Capability to attach to other SAN devices is standard on 2498-B24 and optional on 249824E.

Frame-based trunking with up to eight 8 Gbit/sec ports per ISL trunk with optional license; up to 64 Gbit/sec per ISL trunk (8 ports × 8 Gbit/sec [data rate]) Exchange-based load balancing across ISLs with DPS included in Fabric OS.

The switch also has a built-in USB port that can be used for firmware download, configuration upload and download, and supportsave.

Figure 3-41 shows the SAN24B-4 fabric switch port layout and trunk groups.



Figure 3-41 SAN24B-4 port layout

2498-B40

The 2498-B40 (also known as the SAN40B-4) is a high performance enterprise fabric switch with 40 ports at 8 Gbps link speeds. This switch supports features such as Web Tools, Advanced Zoning, Full-Fabric support, Fabric Watch, and Enhanced Group Management standard. Optional features include ISL Trunking, Extended Fabrics, Advanced Performance Monitoring, Adaptive Networking, FICON CUP, and Integrated Routing.

The switch requires Fabric OS v6.1+, and port hardware is based on the Condor2 ASIC. One ASIC can support all 40 ports at 1, 2, 4 and 8 Gbps link speeds and they can be configured as F, FL, E, M and EX Ports. This switch provides a 1:1 subscription on all 40 ports.

Figure 3-42 shows the SAN40B-4 fabric switch.



Figure 3-42 SAN40B-4 fabric switch

The base model of the switch has 24 ports enabled, and the POD licenses are available in 8-port increments. The ports on the switch are grouped in 8-port groups matching the trunk group, and ISL Trunking speeds of up to 64 Gbps can be achieved per trunk. Integrated Routing is a licensed feature that is supported on every port of the switch and requires the POD license for all 40 ports.

The switch also has a built-in USB port that can be used for firmware download, configuration upload and download, and supportsave.

Figure 3-43 shows the port numbering scheme on the SAN40B-4.



Figure 3-43 SAN40B-4 ports

Two hot-swappable, redundant 125 W power supply and fan assemblies are included with the switch. These are field replaceable units (FRU). Each FRU has an ON/OFF switch AC plug and a power supply and fan status LED, and the switch has a 1U form factor.

Important: The USB port supports *only* a 2 GB Brocade branded USB drive. The 4 Gbps and 8 Gbps link speeds are supported *only* with Brocade branded SFPs.

2498-B80

The 2498-B80 (also know as SAN80B-4) is an 80-port, 8 Gbps enterprise fabric switch with 2U form factor. This switch supports features such as Web Tools, Advanced Zoning, Full-Fabric support, Fabric Watch, and Enhanced Group Management standard. Optional features include ISL Trunking, Extended Fabrics, Advanced Performance Monitoring, Adaptive Networking, FICON CUP, and Integrated Routing.

Figure 3-44 shows the SAN80-B4 fabric switch.



Figure 3-44 SAN80-B4 fabric switch

The switch requires Fabric OS v6.1 and port hardware is based on the GoldenEye2 ASIC. Each ASIC can support 32 ports at 1, 2, 4, and 8 Gbps link speeds and the switch has 9 ASICs. Ports can be configured as F, FL, E, M, and EX Ports.

The base model of the switch comes with 48 ports enabled and offers a 1:1 subscription at all 80 ports that can be activated with the POD licenses that are available in 16 port increments. Integrated Routing is a licensed feature that is supported on every port of the switch and requires the POD license for all 80 ports.

The ports on the switch are grouped in 8-port groups matching the trunk group. Figure 3-45 shows the port numbering scheme.



Figure 3-45 SAN80B-4 ports

ISL trunk speeds of up to 64 Gbps can be achieved per trunk. Dynamic Path Selection can be used for optimizing the performance and load balancing, and the switch can be managed using Web Tools. The built-in USB port can be used for firmware download, configuration upload and download, and supportsave. The switch supports non-disruptive firmware downloads.

Important: The USB port supports *only* 2 GB Brocade branded USB drives. The 4 Gbps and 8 Gbps link speeds are supported *only* with Brocade branded SFPs.

The switch has two hot-swappable, redundant 300 W power supplies and three hot-swappable fan assemblies. Both the power supplies and the fan assemblies are FRUs, and they have a status LED. With a nominal power consumption of 260 W, this switch is extremely energy efficient.

Figure 3-46 shows the non-port side view of the switch and illustrates how the power supplies and the fans are identified in the Fabric OS.



Figure 3-46 SAN80B-4 non-port side view

4

Fabric Operating System

In this chapter, we provide an overview of the Fabric Operating System (FOS) software for the switches, including the firmware that initializes and manages the switch hardware and the diagnostics. We also introduce Fabric OS v6.4.0 and explain its new features and the changes introduced.

4.1 Fabric Operating System overview

The Fabric OS manages the operation of the switch and delivers the same, and compatible, functionality to all the different models of switches and directors. The switch firmware is designed to make the switches easy to install and use while retaining the flexibility that is required to accommodate user requirements.

The Fabric OS includes all the basic switch and fabric support software as well as optionally licensed software that you enable using license keys. It is composed of two major software components:

- Firmware that initializes and manages the switch hardware
- Diagnostics

Fabric OS v5.x and v6.x are Linux-based operating systems, while Fabric OS v3.x and prior were based on the VxWorks operating system.

In this chapter we also introduce the changes in versions 6.3.1 and 6.4.0, to help you understand the differences between versions, and understand the upgrades from one version to the next one.

4.2 Fabric Operating System v6.2.0 features

Releases: In this section you can find information about Fabric OS v6.2.0, which is here for legacy and compatibility reasons. This information is mainly for your reference, but it is important to understand the main changes between releases. We strongly advise you to update to the newer version of the Fabric OS to ensure that you have all the latest features available and bugs fixed.

4.2.1 New features

In addition to the support for the new hardware platform that was introduced with this release, many new features were introduced in Fabric OS v6.2.0:

- Virtual Fabrics:
 - Full VF feature support on SAN768B, SAN384B, SAN80B-4, SAN40B-4
 - Single physical chassis can be subdivided into two or more logical switches creating a logical fabric with other switches
 - Per-port assignment of ports to logical switches
 - Shared ISLs provide connectivity for multiple logical fabrics

- ► FCR and FCIP enhancements:
 - FCIP (SCSI) Read Tape Pipelining
 - Enhancements to SoTCP
 - LSAN Tagging
 - Support for Pathinfo over MetaSAN
 - Use FSPF cost in FCR backbone fabric to find shortest path to edge fabric
 - In-band management link over FCIP connections for the IBM SAN18B-R
 - TCP Byte Streaming for FCIP connections used with WAN optimization hardware
 - Improved FCIP statistics support, including TCP connection history, high water mark information and connection snapshot capability
- Support temporary licenses for Adaptive Networking, Integrated Routing, and Fabric Watch.
- Security enhancements:
 - IPv6 Auto-configuration
 - IPSec with IPv6 (for management port)
 - Configurable switch-wide policy requiring authentication of all HBAs
 - RADIUS enhancements allowing password expiration and source IP address information
 - LDAP enhancement allowing for alternate domain UPN
 - IPv6 certified for JITC Approved Product List
- ► FICON enhancements:
 - RNID support for CUP
 - New FC addressing modes for support with Virtual Fabrics
 - Support for FC8-48 blade with VF-enabled SAN768B/SAN384B for FICON environments
- Access gateway enhancements:
 - AG mode supported on IBM SAN40B-4
- Encryption enhancements:
 - Data encryption support in Virtual Fabrics environments
 - Support for tape encryption and compression.
 - Support for up to four FS8-18 Encryption blades in a single SAN768B or SAN384B chassis
- Brocade HBA feature support:
 - Beacon adjacent switch port from HCM
 - Fabric based boot LUN discovery
 - QoS nameserver support allowing query for QoS zone information
 - Support for FC Ping

- Miscellaneous features:
 - FC ping support between switches (ping switch WWN)
 - Provide path information through the CLI
 - Frame Redirection support in interopmode 3 (McDATA Open Fabric Mode)
 - Support for M-EOSn 239 Domain ID mode through FCR in interopmode 3
 - System-wide RASLOG
 - Port Auto-Disable support
 - Ethernet Port Bonding for management ports
 - New CLI command to configure F_Port receive buffer credits

4.2.2 Feature descriptions

In the topics that follow we describe some of the features introduced with Fabric OS v6.2.0 in greater depth.

Virtual Fabrics

In this section we describe the Virtual Fabrics capability:

- Virtual Fabrics (VF) is a new capability supported on the IBM SAN768B, SAN384B, SAN80B-4, and SAN40B-4 switches, and newer models. After being enabled, VF allows the user to divide a single physical chassis or switch into multiple "logical switches" by assigning individual ports to a logical switch. Each of these logical switches is managed as a completely independent layer 2 Fibre Channel switch, and can be deployed in independent fabrics known as "logical fabrics."
- VF also allows the user to create a special logical switch known as the "base switch," used for connectivity to other base switches and also as a backbone fabric for Fibre Channel Routing. Individual logical fabrics can utilize this shared base fabric for connectivity to other switches, providing efficient use of resources by sharing common ISL and ICL connections among multiple logical fabrics.
- The Virtual Fabrics feature is part of the base Fabric OS and does not require a license. Virtual Fabrics is fully compatible with legacy IBM b-series products as well as m-series switches and directors.

FCR and FCIP enhancements

In this section we describe various FCR and FCIP enhancements:

- FCIP (SCSI) Read Tape Pipelining: Anticipates host read operations and buffers data to reduce latency from the FCIP WAN.
- LSAN tagging: Provides special behavior for designated LSAN zones using either a new "speed" tag or "enforce" tag. The enforce tag allows individual FCRs to be configured to only import devices in specific LSAN zones,

increasing scalability. The speed tag allows designated targets to remain imported, allowing sensitive hosts to discover targets much faster. This is useful when performing boot over LSAN operations.

- SoTCP enhancements: Improved network congestion management in Slow Start Mode helps to prevent host I/O from timing out.
- Support for Pathinfo over MetaSAN: The Pathinfo command has been enhanced to provide path information across routed fabrics, especially useful when troubleshooting connectivity problems across routed fabrics.
- Use of FSPF cost in FCR backbone fabric: Uses the most efficient route to reach a destination fabric, preventing the use of an FCIP link when an ISL is available.
- In-band management link over FCIP connections for the IBM SAN18B-R: Allows a management station to communicate with a remote SAN18B-R through the GE ports. This allows a single management station located on the WAN side of the SAB18B-R to communicate with the management interface on the CP for management tasks such as firmware downloads, SNMP polling, SNMP traps, troubleshooting, and configuration.

Enhanced native connectivity with McDATA products

In this section we describe enhanced native connectivity with McDATA:

- Frame Redirection: Fabric OS v6.2.0 and M-EOS v9.9 now support Frame Redirection in McDATA Open Fabric Mode (interopmode 3) fabrics. Frame Redirection zones must be created and activated from FOS platforms.
- FCR Support for M-EOSn 239 DID mode: FOS platforms now support EX_Port connections to McDATA Open Fabric Mode Mi10ks using the 239 DID setting.

Security enhancements

In this section we describe several security enhancements:

- IPv6 auto-configuration: Configurable stateless IPv6 auto-configuration support.
- IPSec with IPv6: Supports greater security for management ports by providing configurable security policies for IPv4/6 addresses.
- Switch-wide policy requiring HBA authentication: New configurable switch-wide setting requires the FC-SP bit to be set in FLOGI. If bit is not set, the FLOGI is rejected and the port will be disabled.
- RADIUS enhancements: New warning for RADIUS login allows users to configure how many days in advance they need to be notified of password expiration.

 LDAP enhancements: Added ability to provide an alternate UPN (userPrincipalName) to domain authentication.

Encryption enhancements

Additional support for application based tape encryption and compression, or tape encryption on its own, has been included with FOS 6.2.0

Contact your application vendor regarding their implementation of tape encryption.

Optionally licensed software

The Fabric OS v6.2.0 release includes all basic switch and fabric support software, as well as the following optionally licensed software that is enabled using license keys:

- Ports on Demand: Allows customers to instantly scale the fabric by provisioning additional ports through license key upgrade (applies to select models of switches).
- Extended Fabrics: Provides greater than 10km of switched fabric connectivity at full bandwidth over long distances (depending on platform this can be up to 3000km). Contact IBM or your vendor for the latest supported distances.
- ISL Trunking: Provides the ability to aggregate multiple physical links into one logical link for enhanced network performance and fault tolerance. Also includes Access Gateway ISL Trunking on those products that support Access Gateway deployment.
- Advanced Performance Monitoring: Enables performance monitoring of networked storage resources. This license includes the TopTalkers feature.

Top Talkers: The Top Talkers feature was introduced in Fabric OS v6.0.0 and is part of the optional Advanced Performance Monitoring license. This feature provides real-time information about the top n bandwidth consuming flows that pass through a specific point in the network. You can enable Top Talkers on individual F_Ports to provide information about top consumers of bandwidth for all E_Port connections on a switch.

- High Performance Extension over FCIP/FC: Formerly known as FC-IP Services, (available for the FR4-18i blade, IBM SAN18B-R, and SAN04B-R): This license key also includes the FC-Fastwrite feature and IPsec capabilities.
- Accelerator for FICON: This license enables unique FICON emulation support for IBM's Global Mirror application as well as Tape Pipelining for all FICON tape and virtual tape systems to significantly improve XRC and tape backup/recovery performance over virtually unlimited distance for SAN18B-R, upgraded SAN04B-R and FR4-18i.

- Fabric Watch: Monitors mission-critical switch operations. Fabric Watch now includes new Port Fencing capabilities.
- FICON Management Server: Also known as "CUP" (Control Unit Port), enables host-control of switches in Mainframe environments.
- ICLs, or Inter Chassis Links: Provide dedicated high-bandwidth links between two IBM SAN768B or SAN384B chassis, without consuming valuable front-end 8Gbps ports. Each SAN768B/SAN384B must have the ICL license installed in order to enable the ICL connections. (Available on the SAN768B/SAN384B only).
- Enhanced Group Management: This license, available only on the SAN768B, SAN384B, and other 8 Gbps platforms, enables full management of the device in a datacenter fabric with deeper element management functionality and greater management task aggregation throughout the environment. This license is used in conjunction with IBM's Data Center Fabric Manager (DCFM) application software.
- Adaptive Networking: Adaptive Networking provides a rich framework of capability allowing a user to ensure high priority connections obtain the network resources necessary for optimum performance, even in congested environments. The QoS SID/DID Prioritization and Ingress Rate Limiting features are the first components of this license, and are fully available on all 8 Gbps platforms.

Ingress: Ingress Rate Limiting was introduced with Fabric OS v6.0.0, and this feature allows the Application Specific Integrated Circuit (ASIC) to delay the return of BB_Credits to the external device. By doing so, a user can limit the throughput on the ingress side of a port, thereby removing potential congestion scenarios within a fabric caused by heavy bandwidth consumption by low priority applications. Ingress rate limiting is only supported on F/FL ports, and is only available on 8 Gbps capable ports.

QoS feature was also introduced with Fabric OS v6.0.0 and is available on all 8 Gbps capable ports on the 8 Gbps platforms. When congestion is detected, QoS allocates the largest portion of available bandwidth to high priority traffic and the smallest amount to low priority traffic. SID/DID flow pairs not explicitly set as having high or low priority automatically default to medium priority.

Integrated Routing: This license allows ports in a SAN768B, SAN384B, SAN80B-4 or SAN40B-4 to be configured as EX_ports supporting Fibre Channel Routing. This eliminates the need to add an FR4-18i blade or use a SAN Router for FCR purposes, and also provides double the bandwidth for each FCR connection when connected to another 8 Gbps capable port.

- SAN04B-R Upgrade (For the IBM SAN04B-R only): This license allows customers to upgrade a 4- port (2 FC ports and 2 GE ports) SAN04B-R base to a full 18-port (16 FC ports and 2 GE ports) SAN18B-R configuration and feature capability. The upgraded SAN04B-R includes the complete High Performance Extension license feature set.
- Server Application Optimization: This new license introduced with FOS v6.2, when deployed with Brocade Server Adapters, optimizes overall application performance for physical servers and virtual machines by extending virtual channels to the server infrastructure. Application specific traffic flows can be configured, prioritized, and optimized throughout the entire data center infrastructure.

Temporary license support

The following licenses are available for 45-day temporary use, with a maximum of two temporary license per feature and per switch (90 days maximum):

- ► Fabric (E_port) license
- Extended Fabric license
- ► Trunking license
- ► High Performance Extension license
- Advanced Performance Monitoring license
- Adaptive Networking license (introduced in FOS v6.2)
- Fabric Watch license (introduced in FOS v6.2)
- Integrated Routing license (introduced in FOS v6.2)

4.3 Fabric OS v6.3.1 and v6.4.0 updates

Since the last edition of this book, two versions of Fabric OS have been released, and in this section we discuss the changes in versions 6.3.1 and 6.4.0. In terms of the CLI, the implementation is the same, but here we introduce the changes, and make sure that all the new features or differences from previous versions are documented. Additionally, we show screen captures of the changed DCFM interface.

Clarification of basic concepts: Before getting into details, let us review some important terms related to FCIP that you need to be familiar with, and that will help in the understanding of the new features in the two last releases:

- Circuit: A communication that is established between a source IP address to destination IP address.
- Tunnel: A collection of one or more circuits between two switches. Note that in the case of two or more circuits in the tunnel, the tunnel is trunked.

 VE Port: Virtual_E port that is behind one or more physical ports on each side of the tunnel.



In Figure 4-1 we can see a graphical representation of these terms.

Figure 4-1 FCIP terms explanation

We now list the main changes in the two latest releases of the firmware that concern FCIP implementation. These changes do not affect the commands and the way to proceed or execute one FCIP configuration, but might have an impact on how to plan your infrastructure and how to deploy it. These changes can also explain why certain features will work after you update the firmware, but you cannot modify them afterwards, because the Fabric OS requires compliance with certain values. If this is the case in the latest release, we explain it.

4.3.1 Changes in Fabric OS version 6.3.1

Fabric OS 6.3.1 provides the following general enhancements:

- Virtual Fabrics with the 24 ports 8 Gbps blade's VE_Ports as XISLs; the VE_Ports on a blade can be assigned to a base switch for XISL use
- 10 GbE to 1 GbE tunnel and circuit connectivity configuration on the 24 ports blade, which allows connection between 10 GbE ports and 1 GbE ports on another Ethernet switch of the family
- Access Gateway support on the IBM Converged switch B32
- Added support for FCoE Initialization Protocol (FIP) v1.0 (equivalent to the FC-BB-5 version 2.0 standards, dated June 4 2009)
- VLAN tagging/802.1p
- ► IPSec (only for the IBM System Storage SAN06B-R)
- ► Port Beaconing
- DCFM v10.4 support for all the foregoing features

In the rest of this section we explain some of these changes, and describe what has been introduced.

IPSec on the IBM SAN06B-R

Internet Protocol Security (IPSec) uses cryptographic security to ensure private, secure communications over IP networks. The IPSec protocol is used to secure the FCIP tunnel over a public IP WAN by using encryption.

IPSec feature capabilities

With the latest release of the firmware, all the b-type products will be able to handle IPSec. This was already possible in release 6.3.1 with the IBM System Storage SAN06B-R, and now it is supported in the FC routing blade.

There is no longer any need for an external IPSec appliance.

IPSec feature attributes

The FC routing switches will use the following IPSec attributes:

- The SAN06B-R and the FC routing blade will use the internal FPGA for hardware encryption operations.
- ► IPSec is configured using a pre-configured policy:
 - Internet Key Exchange (IKE) v2 for key negotiation
 - Encapsulating Security Payload (ESP) transport mode for IPSec (only the payload is encrypted)
 - Advanced Encryption Standard (AES) with 256 bit keys of encryption; AES-CGM-ESP is the mode AES uses
 - Security Association (SA) lifetime is roughly 2 GB of data sent through the SA
- IPSec will *only* support IPv4 for the Fabric OS release 6.4.0, and IPv6 is not supported at this time.

VLAN Tagging (IEEE 802.1p) / DSCP

This feature allows for differentiation of Fabric OS QoS levels across FCIP links. The L2CoS and Differentiated Services Code Point (DSCP) are used to assign QoS across the IP WAN. L2CoS refers to the Class of Service field defined by the IEEE 802.1p s

The L2COS and DSCP are configured on a per circuit basic. The values are configured per Fabric OS QoS priority basis within a circuit, and each fabric QoS can even be defined to have its own L2CoS bits and DSCP value.

Port beaconing

The port beaconing feature is enabled using the command **portbeacon** --enable [slot/]port. The normal LED output is suppressed, and the LEDs will flash amber and green in a 2.5 second pattern.

The beaconing will remain enabled until disabled using the command **portbeacon** --disable [slot/]port, and this is not persistent across reboots.

4.3.2 Changes in Fabric OS version 6.4.0

In this latest version (at the time of writing) of Fabric OS, there are more changes:

- IPv6 (IPv6 support for IPSec is not supported)
- ► IPSec (for FCoE 10GbE blade, already supported on SAN06B-R)
- Virtual EX_Port (for FCoE 10GbE blade, and already supported on SAN06B-R)
- Software compression for maximum compression ratio (for FCoE 10GbE blade, and already supported on SAN06B-R)
- DSCP
- Scalability increase (4 blades per chassis for FCoE 10GbE blade)
- Lossless DLS on FC ports
- TPerf enhancements
- Supports up to 100 ms with 0.1% packet loss for FCIP tunnels with one or both ends on 10 GbE
- DCFM v10.4 support for all the foregoing features

DCFM screen captures of the previously listed enhancements

In the following set of screen captures, you will see the enhancements in the DCFM software. This section is intended to show you how it looks in the DCFM interface in order to have a clear overview of the changes.

As you can see in Figure 4-2, DCFM now supports the configuration of FCIP tunnel advanced settings. You can reach this menu when creating or editing a tunnel, under the "Advanced Settings" button.

Transmission	Security FIGON Emulation
Ensure connect	cting peer switches have known VW/Ns
Remote VW/N	
Enable IPSec PreShared Key	

Figure 4-2 TCIP tunnel configuration on DCFM

In Figure 4-3, we can see also how DCFM is now able to help us configure the VLAN tagging options for FCIP, and DCFM will be able to discover both fabrics for the VLAN.

	Circuit Number 2		
Switch One Settin	ngs	Switch Two Settin	ngs
Switch	RSL1-ST07-DCX4S	Switch	RSL1-ST07-7800
Fabric	FCIP	Fabric	FCIP
Tunnel	12	Tunnel	16
GigE Port	8/ge0 🔻	GigE Port	ge0 💌
	the second		
MTU Size	(1200	MTU Size	Same as Switch Orie
Metric	0	Metric	Same as Switch One
VLAN ID		VLAN ID	Same as Switch One
Bandwidth (Mb/s)	(Blank or 1 - 4094, Fabric OS Version >= 6.0.0) Uncommitted Committed (10-1000 Mb/s)	Bandwidth (Mb/s)	Same as Switch One

Figure 4-3 VLAN tagging configuration on DCFM

Figure 4-4 shows how to configure DSCP and L2CoS using DCFM, in the "FCIP circuit Advanced Settings" page for the circuit.

Selective Ack			
Keep Alive Time Out (ms)	10000	(500-7200000)	
Min. Retransmission Time (ms)	100		
Max. Retransmits	8	(1-8)	
L2Cos F-Class 0 - DSCP	F-Class 0	(0-63)	
L2Cos Low 0 V DSCP	Low 0	(0-63)	
L2Cos Medium 0 🗸 DSCP	Medium 0	(0-63)	
L2Cos High 0 🗸 DSCP	High 0	(0-63)	

Figure 4-4 DSCP and L2CoS options

Figure 4-5 illustrates the configuration panel for the VEX_Port options, using DCFM.

witch	RSL1-ST07-DCX4S	Switch		
abric unnel	FCIP (Requires Circuit Configuration)	Fabric	Y	
ort Type	VE Port VEX Port Fabric ID Interop Mode Brocade ▼	Port Type	VE Port VEX Port Fabric ID Interop Mode	Brocade V

Figure 4-5 VEX_Port configuration panel

IPv6 support will be added in the configuration panel, when available, as shown in Figure 4-6.

	Circuit Number 2		
Switch One Setti	ngs	Switch Two Sett	lings
Switch	RSL1-ST07-DCX4S	Switch	RSL1-ST07-7800
Fabric	FCIP	Fabric	FCIP
funnel	12	Tunnel	16
GigE Port	8/ge0 👻	GigE Port	ge0 🗸
P Address Type	○ IPv4 ● IPv6	IP Address Type	● IPv4 ○ IPv6
P Address	·	IP Address	· · · · · · · · · · · · · · · · · · ·
Prefix Length		Subnet Mask	

Figure 4-6 IPv6 support

There is a new "Delete" button in the FCIP tunnel configuration panel that will let us delete a tunnel from DCFM. This is shown in Figure 4-7.

roducts	Switch One	Switch Two	Total Circuits	Tunnel Operational Status	Administrative Status	Description	
E B RSL1-ST07-DCX4S							Add Tunnel
Tunnel 8/12 (VE)	RSL1-ST07-DC	RSL1-ST07-7800	2	Up	Enabled		Edit Tunnel
E SL1-ST07-7800							
Tunnel 16 (VE)	RSL1-ST07-7800	RSL1-ST07-DC	2	Up	Enabled		Delete Tunnel
							Enable Tunnel
							Disable Tunnel
							Performance

Figure 4-7 Delete button for FCIP tunnel on DCFM

There is a new "metric" field in DCFM that can be configured when adding a new FCIP circuit from the GUI. This is shown in Figure 4-8.

	Circuit Number 2		
Switch One Setti	ngs	Switch Two Sett	ings
Switch	RSL1-ST07-DCX4S	Switch	RSL1-ST07-7800
abric	FCIP	Fabric	FCIP
funnel	12	Tunnel	16
SigE Port	8/ge0 💌	GigE Port	ge0
P Address Type	● IPv4 ○ IPv6	IP Address Type	● IPv4 ○ IPv6
P Address	· · · · · · · · · · · · · · · · · · ·	IP Address	
Subnet Mask		Subnet Mask	
Default route will g	et created using the above IP address. :fault Route	Default route will g	et created using the above IP address. efault Route
Gateway	~	Gateway	-
MTU Size	(1260 - 1500) Suggest	MTU Size	Same as Switch One
Metric	0 👻	Metric	Same as Switch One
	· · · · · · · · · · · · · · · · · · ·	VLAN ID	Same as Switch One

Figure 4-8 Metric field when adding an FCIP circuit on DCFM

Changes on the Traffic Isolation Zones with Fabric OS v6.4.0

With the latest 6.4.0 firmware of Fabric OS, there have been changes to Traffic Isolation (TI) Zones. These changes are listed here:

- Device ports can now be in multiple Traffic Isolation Zones at the same time.
- Devices in a *failover disabled* TI zone are able to communicate with local devices that are not part of the same TI zone.

- Prior to Fabric OS v6.4.0, devices would need to be in a failover enabled TI zone in order to communicate with local devices.
- There is an enhancement that ensures that the Domain Controller connectivity between the switches will never affect the TI zones.

Support: These new features are supported in Condor2 and GoldenEye2 ASICs. They are not supported on the 8 Gbps blades for DCX.

In the following sections we will describe the changes made in the latest release at the time of writing.

Overlapping TI Zones with failover disabled

Even with failover disabled, now it is possible to have devices in more than one zone. By enabling this feature, a link failure will not affect the alternative path.

The best way to illustrate this new change is with an example. As we can see in Figure 4-9, in the diagram we have a Channel Device that is a member of both the green and red zones with failover disabled. We also have two Control Units (CU), A and B, that are members of the two zones.



Figure 4-9 Link failure on TI Zone with failover disabled

This example illustrates how devices can now be members of multiple TI zones. The Channel is a member of both the green and the red TI zones, which have failover disabled. CU A is a member of the red and blue zones, and CU B is a member of the green and blue zones.

In the event of an ISL failure, which in this example would be in the ISL between the Channel and CU A, and the ISL goes offline, the communication with CU B will be maintained. However, the traffic between the Channel and CU A will be halted because failover is disabled.

Local device communication

The devices that are members of a TI zone can now communicate with local devices that are not members of the failover disabled TI zone. In versions prior to 6.4, this communication was blocked.

In Figure 4-10, we can see that now it is possible that a host can communicate with a local device even in a TI zone. In this example the host needs access to the tape library using a dedicated, failover disabled TI zone (in blue), and also to the local storage. The green zone in the figure represents this new capability to access local devices, even when the host is connected to a failover disabled zone.



Figure 4-10 Example of local device communication

Domain controller only routes

Suppose that we have three Domain Controller links between three switches and they are installed in serial in such a way that switch 2 is between the other two switches. In our case the links between the two first switches are failover enabled, and the link between the two others is not. In the case of a link failure between one of the two links in the communication of the first two switches, we would have a situation.

Prior to version 6.4, in the case of a link failure between more than two switches, if the main ISL between two switches was down, the first switch was not able to connect to the third switch through the second switch. Now, even in the case of a link failure between the first two controllers, the communication will reach the third controller.

Switch-to-switch management: Domain Controller refers to switch-to-switch communication coming from the embedded port PID 0xFFFFxx (where xx is the domain ID). This traffic is for switch-to-switch management. The traffic information will be updated on all the elements of the fabric that are connected to the management port.

Lossless DLS overview

With Fabric OS v6.4.0, there are improvements with respect to Lossless DLS. The Lossless Dynamic Load Sharing (DLS) allows for rebalancing of port paths without causing I/O failures. The Lossless mode means that no frame will be lost during rebalancing and only takes effect if DLS is enabled. If the end device also requires the order of frames to be maintained during the rebalancing operations, then In Order Delivery (IOD) can be enabled.

The combination of Lossless DLS and IOD is supported only in specific topologies, such as in a FICON environment.

Lossless DLS works by:

- Pausing ingress traffic (by not returning credits) with no impact on frames already in flight
- If IOD is enabled, giving sufficient time for frames already received on the original path to be transmitted
- Rebalancing the traffic to use all available paths
- Resuming traffic on the new path

Fabric OS v6.4.0 now allows Lossless DLS to be used with exchange-based routing. The IOD option can now be enabled or disabled, when in previous versions of Fabric OS, it was only supported on port-based routing.

Dynamic Path Sharing: Lossless DLS with exchange-based routing is also known as Dynamic Path Sharing (DPS).

This enhancement has some limitations:

- Lossless DLS cannot use XISLs in FICON environments.
- The entire data path in the switch fabric must be Condor2/GoldenEye2 ASICs.
- It is not supported on switches or blades that do not comply with the previous statements.

4.4 Firmware upgrade considerations

In this section we cover the considerations to upgrade the firmware to version 6.4.0 or higher.

In the IBM SAN768B with Virtual Fabrics enabled, the addressing mode defaults to 10-bit addressing. The 10-bit addressing works by borrowing the top two bits from the ALPA field of a 24-bit Fibre Channel address. 10-bit addressing is required in order to support the 512 user FC ports plus ICL ports in a single chassis. As a result of the additional ports provided by the 8 ports blade, the area numbers between 0x70 and 0x0F are no longer unique.

The following considerations apply when upgrading the firmware:

- Disable the ports on the IBM SAN768B logical switches that use 10-bit addressing mode and that have 8-bit areas in the range 0x70-0x8F.
 - Otherwise the firmware upgrade will fail with an error message.
 - Additional areas 0x70-0x8F are needed to support the 8 port blades.
 This is necessary even if users do not plan to use those blades.
 - If the areas are not in use, this step is not necessary.
- ► An 8-bit area is assigned to a port in the following scenario:
 - A port is connected to a switch in Access Gateway mode.
 - A port is connected to a Brocade HBA.
 - A user has explicitly bound an 8-bit area to a port (as in the case of FICON)
- ► Use the command **portaddress** --show to find areas in use.

This situation only applies to the IBM SAN768B when Virtual Fabrics are in use, not to the IBM SAN384B, which has no shared areas and therefore would not be a problem in this case.

4.4.1 Licensing changes

In Fabric OS v6.4.0, the slot-based licenses are automatically assigned to an appropriate slot when they are installed. The licenses can be unassigned and reassigned to different slots as needed using the **licenseslotconfig** command.

The slot-based licensing was first introduced with Fabric OS version 6.3.0. When a license is added, it is applied to the lowest slot number containing a blade that uses that license. With the old model, if the license needed to be moved to another slot, it had to be removed from the assigned slot and then added to the desired slot.

4.4.2 Fabric scalability

Scalability limits for Fabric OS v6.2.0 are essentially the same as those limits supported by Fabric OS v6.1.0. Fabrics of up to 6000 virtual or physical connections (WWNs logged into a single fabric) and 56 domains (domain support is the same as on previous Fabric OS releases) can be supported on the SAN768B, SAN384B and the SAN80B-4. Other products running Fabric OS v6.1.0 retain the same fabric limits as Fabric OS v5.3.x for non-routed fabrics (Layer 2 only, 56 domains and 2560-ports).

When operating in Native Connectivity modes (InteropMode 2 or 3), different scalability limits are supported. For both InteropMode 2 and 3, fabrics of up to 2048 virtual or physical connections (WWNs logged into a single fabric) and 31 domains are supported. This is an increase from Fabric OS v6.0.0 for InteropMode 3, which only supported up to 800 connections and 15 domains in a fabric.

The Virtual Fabrics capabilities supported in FOS v6.2.0 or later introduce additional factors to consider when assessing scalability. Specifically, when looking at a the limits that an individual chassis or switch can support, it is no longer just a factor of the size of the Layer 2 fabric or the number of devices imported from edge fabrics. Virtual Fabrics allows a single physical chassis to participate in up to 8 separate Layer 2 fabrics, not including additional impacts from imported devices from FC Routing.

To account for this, each physical switch has limits which are supported for the aggregate environment. This means that if a single physical switch has three individual Logical Switches, each participating in an independent Logical Fabric, the total number of domains and participating host/storage devices in all three Logical Fabrics must be counted and compared against the physical switch limits.

The individual Logical Fabric limits are the same as those noted for a traditional Layer 2 fabric.

Table 4-1 lists supported limits specific to Virtual Fabrics enabled environments.

Table 4-1 Supported limits

	SAN40B/ SAN80B/ SAN384B and SAN768B
Max # of Logical Switches per Chassis/switch (including default and base switch)	3/4/8
Total # of participating devices (all Logical Fabrics) per chassis	6000
Total # of fabrics (Logical Switches and FCR-connected edge fabrics) per chassis	32/32/48
Total # of base switches creating a single base fabric	12
Total # of Logical Fabrics utilizing a single base fabric	48

Supported FCR scalability limits have increased in a few select areas and some new limits are included to reflect the new Integrated Routing support. Table 4-2 lists the Supported Routing scalability limits.

Table 4-2 Fibre Channel Routing scalability limits

Maximum number of edge fabrics per metaSAN	48
Maximum number of edge fabrics per chassis	16 (SAN18B-R and FR4-18i in SAN256B, SAN768B or SAN384B) 32 (SAN40B-4 and SAN80B-4) 48 (SAN768B and SAN384B)
Maximum number of local switches per edge fabric	26
Maximum number of WWNs per edge fabric	1500
Maximum number of local switches per edge fabric (M-EOS fabric) ^a	16
Maximum number of WWNs per edge fabric (M-EOS fabric) ^a	1500
Maximum number of imported devices per fabric (M-EOS fabric) ^a	1000
Maximum number of L2 switches per backbone fabric	12
Maximum number of FCRs per backbone fabric	12
Maximum number of WWNs per backbone fabric	1024
Maximum number of imported devices per fabric	1000
Maximum number of devices per metaSAN	10000

Maximum number of LSAN zones per metaSAN	5000 ^b
Maximum number of devices per LSAN zone	64
Maximum number of hops between edge switches	19
Ex_Ports per FCR (SAN256B/SAN768B with FR4-18i)	32
Ex_Ports per FCR (SAN768B with Integrated Routing)	64
Ex_Ports per chassis with Integrated Routing (SAN768B and SAN384B/SAN80B-4/ SAN40B-4)	128/80/40

a. M-EOS fabrics must be running M-EOS 9.6.2 firmware or later.

b. All BB FCRs with Fabric OS v6.0.0 and above. For M-EOS edge fabrics prior to v9.6, the limit is 1024 zones. For M-EOS edge fabrics operating with v9.6.x or later, the limit is 2048 zones.

Other important considerations include these:

- ► IPFC over FCR is only supported for edge to edge.
- ► FC Fast Write is only supported for edge to edge.
- The backbone cannot run in InteropMode 2 (McDATA Native Interop) or mode 3 (Open mode). It must be in Fabric OS native mode.
- All limits apply to Integrated Routing as well as FCR on SAN18B-R/FR4-18i unless otherwise noted.

4.4.3 FICON support

Fabric OS v6.1.0b provides FICON CUP support in Fabric OS/MEOS mixed fabrics operating in InteropMode 2. This support is available in fabrics with SAN768B, SAN40B-4,SAN80B-4, and SAN256M. Fabric OS v6.1.0b also adds support for configuring the MIHPTO (Missing Interrupt Handler Primary Time-out) value.

Fabric OS v6.1.0b includes enhanced CUP statistics counters comparable to those supported in M-EOS.

The FC4-48 and FC8-48 Fibre Channel port blades are *not* supported to connect to System z environments using FICON channels or using FCP zLinux on System z. To attach the SAN256B or SAN768B to the System z environment, use an FC4-16, FC4-32, FC8-16, or FC8-32 Fibre Channel port blade.

The SAN384B is not supported for FICON Cascading in interopmode 2 or 3 for use in mixed fabrics with M-EOS platforms.

4.5 Additional important notes and guidelines

Here we provide other important notes and guidelines:

- ► Virtual Fabrics:
 - On Virtual Fabrics capable platforms, the Virtual Fabrics feature must be enabled after upgrading to FOS v6.2.0 in order to utilize the related capabilities, including Logical Switches and Logical Fabrics. On units that ship with FOS v6.2.0 or later installed, the Virtual Fabrics feature is enabled by default on capable platforms.
 - When creating Logical Fabrics that include switches that are not Virtual Fabrics capable, it is possible to have two Logical Switches with different FIDs in the same fabric. Use extra caution to verify that the FIDs match for all switches in the same Logical Fabric.
 - The **aptpolicy** can be configured per logical switch. The Admin Guide indicates that it is a chassis level setting.
 - In order to support non-disruptive Hot Code Load on a Brocade 5100 with VF enabled, the total zoning DB size for the entire chassis must not exceed 1 MB.
 - A switch with Virtual Fabrics enabled cannot use Port Mirroring or participate in a fabric that is using IP Filter or Password Database distribution or Administrative Domains. The Virtual Fabrics feature must be disabled prior to deploying in a fabric using these features.
- ► Licensing Behavior:
 - When operating a switch with Fabric OS v6.2, some licenses might display as "Unknown."
 - This is due to changes in licensing requirements for some features that no longer require a license key that might still be installed on a switch.
- ► Frame Redirection
 - In v6.2.0, Frame Redirection zoning is not allowed with Default Zoning ("all access" in IMO and default zone in IM2).
 - This was allowed in prior releases. There is no SW enforcement to block the upgrade.

- ► Adaptive Networking/Flow-Based QoS Prioritization:
 - When using QoS in a fabric with 4G ports or switches, FOS v6.0 or later must be installed on all products in order to pass QoS info. E_Ports from the DCX to other switches must come up *after* 6.0 is running on those switches.
 - Flow based QoS is *not* supported on FC8 blades in the Brocade 48000.
 - Any products that are not capable of operating with FOS v6.0 *cannot* exist in a fabric with Flow based QoS. Major problems will occur if previous generation 2G products exist in the fabric.
- ► FCR switches:
 - All FCR switches need to be running FOS v6.2.0.
 - This is done in order to support M-EOS 239 Domain Mode on the i10K.
- ► FCR Backbone Fabric ID change:
 - With FC8 blades, the switch must be disabled to change the backbone fabric ID.
 - With routing and dual backbone fabrics, the backbone fabric ID must be changed to keep the IDs unique.
- ► Traffic Isolation over FCR:
 - All switches and Fibre Channel Routers both in edge and backbone fabrics must be running FOS v6.1.0 or later in order to support this feature.
 - In order for Traffic Isolation over FCR to function properly, the associated TI zones in each fabric (edge and backbone) need to have failover *enabled*.
- Integrated Routing:
 - To allow Hot Code Load on a Brocade 5100 when using Integrated Routing, the edge switch connected to the 5100 must be running Fabric OS v6.1 or later code.
 - Integrated Routing EX_Ports are only supported in the base switch on a switch with VF enabled.
 - Integrated Routing and TopTalkers are not concurrently supported in FOS v6.2. To use Integrated Routing, be sure to first disable TopTalkers prior to configuring EX_Ports.
 - Ports 16-47 on the FC8-48 blade cannot be used as Ex_Ports. Use only ports 0-15 for FCR on the 48-port blade.

- ► FCS Automatic Distribution:
 - When using the FCS Automatic Distribution feature in Fabric OS v6.0 or later, all switches in the fabric must be running Fabric OS v6.0 or later. If any switches are running Fabric OS v5.x or earlier, only manual distribution can be used.
 - Fabric OS v6.0 or later will allow only FCS automatic distribution when in strict mode, requiring only switches with Fabric OS v6.0 or later.
- Access Gateway:
 - When in Access Gateway mode, the Automatic Port Configuration policy might not work when attached to M-EOS switches. M-EOS ports must be set to G_Port to prevent problems with port type discovery.
 - Ports 16-47 on the FC8-48 blade cannot be used for Access Gateway F_Port Trunking connections.
- ► 10 Gbps Interoperability:
 - 10 Gbps interoperability between FC10-6 and McDATA blades is not supported.
 - However, the FC10-6 blade is supported in a chassis running in InteropMode 2 or 3 (FC10-6 to FC10-6 connections only).
 - An FC10-6 blade will not synchronize with a McDATA 10 Gbps blade, but this will not impact the system negatively.
- ► Traffic Isolation over FCR:
 - All switches and Fibre Channel Routers both in edge and backbone fabrics must be running Fabric OS v6.1.0 in order to support this feature.
 - It is essential to have "fail-over" policy *enabled* in all edge fabrics that are part of the traffic isolation zones, in order for the proper functioning of Traffic Isolation over FCR.
- ► FICON:
 - For the DCX, FICON CUP is not allowed with a 48-port blade in the Default Logical Switch.
 - All ports on a 48 port blade must be assigned to a user-defined Logical Switch to use them in a FICON CUP enabled switch.
- ► FICON CUP Cascading:
 - All switches must be running Fabric OS v6.1.0b in order to support this feature.

- Port Fencing:
 - The default settings for port fencing have very low thresholds and can fence ports that experience a small number of errors. It is best to increase these threshold values for use in production environments. Different platforms might require different threshold settings for optimum behavior. Port Fencing is only available with the optional Fabric Watch license.
 - When the port fencing feature is enabled for ITW or CRC errors, the first set of errors detected on an active link that meet the custom high threshold level set by the user (or the default threshold level) is always ignored to account for expected link transition errors. The port is only disabled upon detection of a second set of errors, i.e. the next time the user-set threshold level (or default threshold level) is reached. This prevents a port from being disabled due to normal link transition behaviors.
 - When using the Port Fencing feature, you must first run the fwalarmsfilterset command. This command enables the port and allows you to receive Port Fencing messages.
 - Port Fencing can be inadvertently disabled from Web Tools. This happens when you do the following operations:
 - i. Open the Fabric Watch configuration window.
 - ii. Check the SNMP Trap check box in the Above row.
 - This change in WebTools disables Port Fencing. If this happens, you must re-enable the Port Fencing bit from the command line interface. See 8.9.2, "Threshold Configuration tab" on page 300.
- ► Port Mirroring:
 - Proper behavior of Port Mirroring functionality requires that the entire frame path must contain either only 4 Gbps ASICs or 8 Gbps ASICs. If a frame path contains a mix of 4 Gbps and 8 Gbps ASICs, then this functionality will not work as intended.
 - On the SAN80B-4, the port mirroring feature has a limitation where all port mirror resources must stay within the same ASIC port group. The resources are the configure mirror port, Source Device, and Destination Device or ISL, if the Destination Device is located on another switch. The ASIC port groups are 0-15, 16-31, 32-47, 48-63, and 64-79. The routes will be broken if the port mirror resources are spread across multiple port groups.
 - Port Mirroring is not supported on a switch with the Virtual Fabrics feature enabled.
5



In this chapter, we briefly discuss the various built-in and external management tools available to IBM/Brocade SAN-switch users. Examples of these include Fabric OS v6.4 Web Tools and the latest management software, Data Center Fabric Manager (DCFM).

5.1 Web Tools

Web Tools is an easy-to-use, graphical user interface (GUI) that you can use to monitor and manage single or small fabrics, switches, and ports from a standard workstation. You perform tasks using a Java[™]-capable Web browser from a workstation anywhere on the same network. Web Tools provide the administrative control point for Advanced Fabric Services, including Advanced Zoning, ISL Trunking, Advanced Performance Monitoring, and Fabric Watch.

Web Tools also provide an interface to Telnet commands to perform special switch functions and diagnostics that are available only through the Telnet interface. For some switch models, Web Tools provide a simplified interface, EZSwitchSetup, that allows less-experienced users to perform basic management tasks.

Highlights of the Web Tools features include these:

- Simplified management with a single interface for viewing all switches in the fabric and their current status, including Registered State Change Notification (RSCN) filtering
- Centralized administration and configuration tasks for the entire fabric, specific switches, or even individual ports
- Increased flexibility by performing administrative and configuration tasks from any remote location through a Web browser and Internet connection
- Ability to view real-time performance data for monitoring and tuning
- Ability to take advantage of an easy-to-use shortcut panel for commonly performed administrative functions

Beginning with Fabric Operating System v6.1 (Fabric OS), the Web Tools license is no longer required. Web Tools is enabled automatically on all the devices that are running Fabric OS v6.1 or later.

We discuss the current functionality that is available in Web Tools in Chapter 8, "Web Tools" on page 181.

5.2 Fabric Watch

Fabric Watch is a storage area network (SAN) health monitor for switches and was an optional licensed feature that is supported on Fabric OS v2.2 or higher, and it comes with no cost in the current versions of the Enterprise switches. Fabric Watch enables each switch to monitor its SAN fabric constantly for potential faults and to provide an alert automatically to any problems long before they become costly failures.

Fabric Watch tracks a variety of SAN fabric elements, events, and counters. It monitors fabric-wide events, ports, SFPs, environmental parameters, and enables early fault detection and isolation as well as performance measurement. Fabric Watch is easy to configure and can be used to select custom fabric elements and alert thresholds or choose from a selection of preconfigured settings. Fabric Watch can also be integrated easily with enterprise systems management solutions.

By implementing Fabric Watch, you can improve SAN availability rapidly and improve performance without installing new software or system administration tools.

For a growing number of organizations, SAN fabrics are a mission-critical part of their systems architecture. These fabrics can include hundreds of elements, such as hosts, storage devices, switches, and interswitch links (ISLs). A flexible solution like Fabric Watch can optimize SAN value by tracking a wide spectrum of fabric events.

For example, Fabric Watch monitors the following situations:

- Fabric resources, including fabric reconfiguration, zoning changes, and new logins
- Switch environmental functions such as temperature, power supply, and fan status, along with security violations
- Port state transitions, errors, and traffic information for multiple port classes as well as operational values for supported models of "smart" GBICs/SFPs
- ► Performance information for AL_PA and end-to-end metrics

Fabric Watch allows you to define how often to measure each switch and fabric element, and to specify notification thresholds. Whenever fabric elements exceed these thresholds, Fabric Watch automatically provides notification using several methods, including email messages, SNMP traps, and log entries.

Fabric Watch provides the following types of automatic notifications:

- A continuous alarm provides a warning message whenever a threshold is breached; it continues to send alerts until the condition is corrected. For example, if a switch exceeds its temperature threshold, Fabric Watch activates an alarm at every measurement interval until the temperature returns to an acceptable level.
- A triggered alarm generates the first warning when a threshold condition is reached and a second alarm when the threshold condition is cleared.

Fabric Watch provides event notifications in several different formats to ensure that event details are accessible from all platforms and operating systems. In response to an event, Fabric Watch can record event data as any (or all) of the following types:

- Simple Network Management Protocol (SNMP) trap: The SNMP performs an operation called a *trap* that notifies a management station (a workstation that runs network management applications using SNMP protocol) when events occur. The software has to be configured to receive trap information from the network device and the SNMP agent on the switch has to be configured to send the trap to the management station. An SNMP trap forwards the following information to an SNMP management station:
 - Name of the element whose counter registered an event
 - Class, area, and index number of the threshold that the counter crossed
 - Event type
 - Value of the counter that exceeded the threshold
 - State of the element that triggered the alarm
 - Source of the trap

The trap stores event information but does not actively send alerts. Port changes do not generate SNMP traps. Support for SNMP makes Fabric Watch readily compatible with both network and enterprise management solutions.

- Switch Event log: Following an event, Fabric Watch adds an entry to the internal event log of an individual switch and can store up to 1024 error messages. The error log stores the event information but does not actively send alerts.
- Port Log Lock: The port log locks to retain detailed information about an event, preventing the information from being overwritten as the log becomes full. This alarm stores event information but does not actively send alerts, which is done automatically when some thresholds are exceeded and an alert is triggered.
- RAPI Trap: This Fabric Watch alarm actively alerts you to events by forwarding all event information to a designated proxy switch. The host API configures the proxy switch automatically based on firmware version. The switch forwards the information to a server and alerts the SAN manager to event activity.
- Email notification: Following an event, Fabric Watch sends email alerts to a specified email address with information about a switch event. An email alert can send information about any error from any element, area, and class. The email specifies the threshold and describes the event, much like an error message.

Fabric Watch is designed for rapid deployment: Simply enabling Fabric Watch permits immediate fabric monitoring, and is also designed for rapid custom configuration. You can create and modify configuration files easily using a text editor and then distribute configurations to all the switches in the SAN through the Fabric OS configuration management utility. Fabric Watch also comes with preconfigured profiles for rapid implementation.

5.3 SNMP

Simple Network Management Protocol (SNMP) is an industry-standard method of monitoring and managing network devices. This protocol promotes interoperability, because SNMP-capable systems must adhere to a common set of framework and language rules.

Understanding the components of SNMP makes it possible to use third-party tools to view, browse, and manipulate switch variables (MIBs) remotely as well as to set up an enterprise-level management process. Every switch and director supports SNMP.

5.4 Data Center Fabric Manager

Data Center Fabric Manager (DCFM) Enterprise is a comprehensive network management application that enables end-to-end management of data center fabrics. Data Center Fabric Manager Enterprise manages and secures the flow of data across multiple fabrics—empowering organizations to achieve their goals related to Service Level Agreements (SLA), security, and compliance while containing their operating expenses.

To account for the enormous growth in data moving within and across data centers, Data Center Fabric Manager Enterprise provides unprecedented scalability and performance that helps maximize data availability. In addition, it features easy-to-use administration tools that streamline or automate repetitive tasks so organizations can achieve unprecedented levels of productivity and efficiency.

As a key component of the IBM/Brocade Data Center Fabric (DCF) architecture, Data Center Fabric Manager Enterprise is designed for unified management of data center fabrics—from storage ports all the way to the Host Bus Adapters (HBA), both physical and virtual. It configures and manages the IBM/Brocade Backbone product family along with IBM/Brocade directors, routers, and switches. Moreover, it supports encryption capabilities for data-at-rest and HBA products, as well as new storage networking technologies such as Virtual Fabrics and emerging protocols such as FCoE and CEE.

DCFM: Organizations that need to manage smaller SAN environments can utilize DCFM Professional, an application included with IBM/Brocade switches that contains a subset of DCFM Enterprise features.

DCFM provides the following benefits:

- Centralizes management of IBM/Brocade multiprotocol fabrics within and across data centers, including support for FCoE and CEE as they become available
- Supports data center virtualization, including visualizing and setting QoS levels for applications running on virtual machines and support for Virtual Fabrics
- Reduces expenses and maximizes productivity by automating tasks and providing easy-to-use, wizard-driven operations
- Helps organizations meet SLAs through industry-leading monitoring, troubleshooting, diagnostics, and event notification capabilities
- Secures data flow from applications to storage across data center fabrics by managing user access controls and ensuring consistent security settings
- Delivers real-time and historical performance monitoring to enable proactive problem diagnosis, maximize resource utilization, and facilitate capacity planning
- Integrates seamlessly with leading third-party automation solutions to provide a holistic approach to data center management

Figure 5-1 shows a sample DCFM main window.



Figure 5-1 DCFM main window

5.4.1 Time-saving tools

As the demand for IT administrator resources continues to increase, Data Center Fabric Manager Enterprise provides time-saving tools that automate repetitive tasks through an intuitive wizard-driven approach. As a result, Data Center Fabric Manager Enterprise offers these capabilities:

- Streamlines firmware downloads, switch configuration backups/restores, and the collection of supportSave diagnostics data across groups of switches
- Enables organizations to edit zone information and preview the impact of proposed changes without affecting the production fabric
- Provides a configurable fabric snapshot/compare capability to track changes to fabric objects and membership
- Generates reports for status changes, port usage, zoning activation, and more—either on-demand, automatically, on a scheduled basis, or in response to a fabric event
- Configures and manages FICON and cascaded FICON environments while providing powerful analysis and diagnostic facilities

- Configures, monitors, and optimizes Fibre Channel over IP (FCIP) tunnels across WAN links
- Provides comprehensive support for Fibre Channel Routing, including configuration, zoning, visualization, analysis, and troubleshooting tools

5.4.2 Exceeding service level agreements

In order to gain a competitive advantage, organizations must meet or exceed established SLAs with their internal and external stakeholders. These SLAs depend on an efficient data center fabric that provides critical connectivity from servers (and their applications) to corresponding storage.

Data Center Fabric Manager Enterprise seamlessly manages multiple data center fabrics to help optimize performance and maximize the availability of data and networked resources. It does so by utilizing industry-leading capabilities for monitoring, troubleshooting, diagnostics, and proactive event notification.

Data Center Fabric Manager Enterprise also includes these functions:

- > Proactively monitors critical fabric health information at varying levels of detail
- Configures Quality of Service (QoS) priorities for applications running on both physical and virtual servers to optimize performance for high-priority applications
- Collects and displays performance statistics in real-time and historical views for proactive problem determination
- Enables organizations to capture, back up, and compare switch configuration profiles through advanced replication capabilities
- Performs automatic data collection and triggers Call Home notification for easier fault isolation, diagnosis, and remote support
- Provides proactive alerts with real-time logging, diagnostic, and fault isolation capabilities to resolve issues before they impact SLAs

Upgrades: Previous versions of IBM/Brocade management software Fabric Manager (FM) or Enterprise Fabric Connectivity Manager (EFCM) can be upgraded to DCFM. An automatic migration facility will migrate most of the data and configurations from EFCM or Fabric Manager to DCFM as long as the minimum versions levels are met (EFCM 9.6 or higher or Fabric Manager 5.4 or higher).

DCFM Installation, configuration, and management are covered in depth in Chapter 9, "IBM System Storage Data Center Fabric Manager" on page 323.

6



Implementation

In this chapter, we discuss the initial setup to implement the switches. We then describe the EZSwitchSetup, a starter kit that greatly simplifies the setup and implementation of storage area network (SAN) switches.

6.1 Implementation

In the topics that follow, we show how to implement the switches initially.

6.1.1 Initial setup

Prior to configuring the IBM System Storage SAN switch, it must be physically mounted and connected to the appropriate electrical outlets. The amount of planning and preparation that is required for the installation is dependent upon the SAN product that is installed. See the Brocade hardware reference guide for the model that you plan to install, because this guide highlights the key aspects for consideration. You must arrange for your IBM service representative to install the chassis or rack physically in the location that you have planned.

After the switch is installed and turned on, it requires some initial configuration parameters to be set. All of the b-type switches require the same initial setup. The fundamental steps have not changed from the earlier switch models.

Sequence to turn on a switch

Timing: These steps take a minimum of three minutes to complete.

When you turn on or restart the switch, the following sequence of steps occurs:

- 1. Early power-on self-test (POST) diagnostics run. POST runs before Fabric Operating System (Fabric OS) starts.
- 2. The Fabric OS initializes.
- 3. The hardware initializes. The switch resets, the internal addresses are assigned, the Ethernet port initializes, the serial port initializes, and the front panel initializes.
- 4. A full POST runs.
- 5. The links initialize. Receiver and transmitter negotiation runs to bring the connected ports online.
- 6. During the Fabric Login (FLOGI), link parameters exchange to determine whether any ports are connected to other switches. If so, FLOGI negotiates which switch becomes the principal switch.
- 7. Domain addresses are assigned. After the principal switch is identified, port addresses are assigned. Each switch tries to keep the same domain ID that it used previously. Previous IDs are stored in the configuration Flash memory.
- 8. The routing table is constructed. After the addresses are assigned, the unicast routing tables are constructed.

9. Normal Nx_Port operation is enabled.

The chart in Figure 6-1 describes the initialization sequence of a port when a device is connected to it.



Figure 6-1 Flowchart showing device initialization

Basic setup functions

After you install the switch or director into a rack, and it has passed successfully through the POST tests, you need to perform some basic setup functions.

By connecting to the switch using a terminal emulator, you can see the switch POST tests as they progress.

Example 6-1 shows the startup of a SAN80B switch.

Example 6-1 SAN80B startup

```
The system is coming up, please wait...
U-Boot 1.1.3 (Apr 13 2009 - 21:30:54)
CPU:
      8548 E, Version: 2.0, (0x80390020)
Core: E500, Version: 2.0, (0x80210020)
Clock Configuration:
      CPU:1199 MHz, CCB: 399 MHz,
      DDR: 199 MHz, LBC: 49 MHz
L1:
      D-cache 32 kB enabled
      I-cache 32 kB enabled
Board: Thor
CPU Board Revision 255.198 (Oxffc6)
    PCI2: disabled
I2C:
      ready
DRAM: Initializing DDRSDRAM
memsize = 400
   DDR: 1024 MB
Now running in RAM - U-Boot at: 3fb8e000
trap init : 0x0
system inventory subsystem initialized
FLASH: 4 MB
L2 cache 512KB: enabled
ATA interface setup: io base=0xf8f00000, port=0x1f0, ctl=0x3f6
PCI:
Skip our host bridge
       00 11 1657 0011 0280 1a
       00 12 1657 0011 0280 1a
       00 13 1657 0011 0280 1a
       01 01 1657 0011 0280 1a
       01 02 1657 0011 0280 1a
       01 03 1657 0011 0280 1a
       01 04 1657 0011 0280 32
       00 14 12d8 8150 0604 3b
```

```
02 01 1657 0011 0280 1a
       02 02 1657 0011 0280 1a
       02 03 1131 1561 0c03 1a
       02 03 1131 1562 0c03 1a
       00 15 12d8 8150 0604 1a
In:
      serial
Out:
      serial
Frr:
      serial
Net:
ENETO: PHY is Broadcom BCM5241 10/100 BaseT PHY (143bc31)
ENET1: PHY is not applicable
ENET2: PHY is not applicable
ENET3: PHY is not applicable
Checking system RAM - press any key to stop test
Checking memory address: 00100000
System RAM test using Default POST RAM Test succeeded.
set bootstatus: BS LOAD OS, platform idx = 6
Hit ESC to stop autoboot: 0
Map file at LBA sector 0x9dbff
## Booting image at 00400000 ...
   Image Name: Linux-2.6.14.2
   Image Type: PowerPC Linux Multi-File Image (gzip compressed)
   Data Size: 2890659 Bytes = 2.8 MB
   Load Address: 00000000
   Entry Point: 00000000
   Contents:
   Image 0: 1814143 Bytes = 1.7 MB
   Image 1: 1076503 Bytes = 1 MB
   Uncompressing Multi-File Image ... ## Current stack ends at
Ox3FB6CBC0 => set upper limit to 0x00800000
## initrd at 0x005BAECC ... 0x006C1BE2 (len=1076503=0x106D17)
   Loading Ramdisk to 1fef9000, end 1ffffd17 ... OK
 initrd start = 1fef9000, initrd end = 1ffffd17
## Transferring control to Linux (at address 00000000) ...
tlbcam index=11
mpc85xx setup: Doing Pcie bridge setup
SILKWORM HWSEM: This BD 64 is not supported
PCI: Cannot allocate resource region 2 of PCI bridge 1
PCI: Cannot allocate resource region 2 of PCI bridge 2
Installing Linux 2.6 Kernel
Attempting to find a root file system on hda1...
```

```
INIT: version 2.78 booting
Bypassing firmware validation.
INIT: Entering runlevel: 3
uptime: 4293888564; sup gid: 0
Fabric OS (IBM SAN80B 217)
IBM SAN80B 217 console login:
2009/07/17-22:51:22, [HAM-1004], 565, CHASSIS, INFO, SAN80B 182,
Processor rebooted - Reboot
SNMP Research EMANATE/Lite Agent Version 16.2.0.9
Copyright 1989-2006 SNMP Research, Inc.
ki state set: redundant ACTIVATE for instance 1
2009/07/17-22:51:33, [FCR-1069], 566, FID 128, INFO, IBM SAN80B 217,
The FC Routing service is enabled.
2009/07/17-22:51:33, [FCR-1068], 567, FID 128, INFO, IBM SAN80B 217,
The FC Routing service is disabled.
All service instances on Active
POST1: Started running Fri Jul 17 22:51:53 GMT 2009
POST1: Test #1 - Running turboramtest
POST1: Script PASSED with exit status of 0 Fri Jul 17 22:52:03 GMT 2009
took (0:0:10)
POST2: Started running Fri Jul 17 22:52:03 GMT 2009
POST2: Test #1 - Running portloopbacktest (SERDES)
POST2: Test #2 - Running portloopbacktest (BI LINKS FE BI->CORE BI)
POST2: Running diagshow
POST2: Script PASSED with exit status of 0 Fri Jul 17 22:52:40 GMT 2009
took (0:0:37)
2009/07/17-22:52:41, [BL-1000], 568, CHASSIS, INFO, SAN80B 182,
Initializing ports...
2009/07/17-22:52:51, [BL-1021], 569, CHASSIS, INFO, SAN80B 182, Retry
1, internal port retry initialization, ports: 3 188 .
2009/07/17-22:52:52, [BL-1001], 570, CHASSIS, INFO, SAN80B 182, Port
initialization completed.
2009/07/17-22:53:08, [SNMP-1008], 571, FID 128, INFO, IBM SAN80B 217,
The last device change happened at : Fri Jul 17 22:53:06 2009
Fabric OS (IBM SAN80B 217)
```

IBM_SAN80B_217 console login:

To get to the console login prompt, you must press the Enter key. It is useful to be aware of the standard boot up sequence for your switch so that, if a problem occurs, it is easy to distinguish between standard and abnormal behavior.

6.1.2 The command-line interface initial setup

To manage a switch, director, or a SAN768B backbone from a remote workstation on a network, you have to set the IP address, subnet mask, and gateway address for the Ethernet management interface on the switch. On SAN768B, SAN384B, and SAN256B, set the networking parameters for the following three entities:

- Logical switch
- CP 0
- CP 1

You can modify these settings using the **ipAddrSet** command. (We show the steps to modify the settings in 6.1.3, "SAN768B, SAN384B, and SAN256B configuration procedure" on page 136.)

The default IP address and subnet mask for the SAN24B-4, SAN40B-4, and SAN80B-4 switches are 10.77.77.77 and 255.255.255.0.

The default IP addresses and subnet masks for a SAN768B, SAN384B, or SAN256B are as follows:

- ► CP 0: 10.77.77.75 and 255.255.255.0 (CP 0 is the CP Card in slot 6)
- CP 1: 10.77.77.74 and 255.255.255.0 (CP 1 is the CP Card in slot 7)

There is no default IP address for logical switch SW 0 on SAN768B, SAN384B, or SAN256B.

For successful implementation, set the following parameters as well:

- Domain ID: For switches to be connected together within a fabric, each switch must have a unique domain ID. The default domain ID for a switch is 1. If two switches are connected through an ISL and if they both have the same Domain ID, they become segmented. You can modify domain IDs using the configure command. We show an example of how to use this command in "Connecting to the switch" on page 139.
- Switch names: Set a switch name to identify different switches within a site. This name is very helpful in easily identifying a switch to which you are connected. Using the switchName command, you can assign your own switch names, which can be up to 15 characters long, must begin with an alpha character, and can include alpha, numeric, and underscore characters.

Configuration examples

We describe the steps to configure these settings in the sections that follow, using two examples:

- SAN32B-3
- ► SAN768B

To configure these settings will take approximately 15 minutes. The following items are required:

- ► SAN switch installed physically and connected to a power source.
- ► A workstation that has a terminal emulator application. In our examples, we used **putty.exe** for both serial and telnet connections.
- The serial cable that is provided with the switch for connecting the switch to the workstation. If your workstation does not have a 9-pin serial port, you might require an adapter. We used a USB serial adapter to connect.
- Unused IP address or addresses plus gateway IP address and subnet mask. SAN256B, SAN384B and SAN768B requires three IP addresses (SW 0, CP 0, and CP 1), while SAN24B-4, SAN40B-4, and SAN80B-4 need one IP address.
- Ethernet cable for connecting the switch to the workstation or to a network that contains the workstation.
- ► SWL or LWL SFPs and fiber optic cables as required.

Attention: Do not connect the switch to your LAN until the IP settings are configured properly and they do not conflict with any other devices in your network.

It is important to leave at least 3.28 ft (1 m) of slack for each port cable. This extra length provides room to remove and replace the switch, allows for inadvertent movement of the rack, and helps prevent the cables from being bent to less than the minimum bend radius.

Use hook-and-loop straps to secure and to organize fiber optic cables. Do not use tie wraps on fiber optic cables, because these wraps are easily overtightened and can damage the optic fibers.

Setting the IP address using the serial port

In this section, we describe the steps necessary to set the IP address using the serial port on an IBM SAN32B-3. The procedure is the same for all IBM/Brocade switches except for the SAN256B, SAN384B and SAN768B. (We show the steps for these two products in 6.1.3, "SAN768B, SAN384B, and SAN256B configuration procedure" on page 136.)

Follow these steps to set the IP address:

- 1. Remove the shipping plug from the serial port and insert the serial cable that is provided with the switch.
- 2. Connect the other end of the serial cable to an RS-232 serial port on the workstation. If you do not have a male DB-9 serial port connector on your workstation, you can use a USB serial adapter.

Tip: The serial cable shipped with the switch is a straight-through cable, not a cross-over cable. Label the cable as such to minimize confusion at a later date.

- 3. Verify that the switch is on and initialization has completed by confirming that the system and power status LEDs are both on and green.
- 4. Disable any serial communication programs running on the workstation, such as PDA synchronization.
- 5. Open a terminal emulator application (such as HyperTerminal or **putty.exe** on a Windows® workstation or TERM in a UNIX® environment), and configure as follows:
 - a. In Microsoft Windows environment, adjust the following parameters and values if necessary:
 - Bits per second: 9600
 - Databits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: None

Category: Session Logging Terminal Keyboard Bell Features Window Speed (baud) 9600 Appearance Behaviour Translation Stop bits Stop bits None 	Rutty Configuration		×
Image: Session Options controlling local serial lines Image: Logging Select a serial line Image: Terminal Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line Image: Region of the serial line Select a serial line	Category:		
E Connection → Data → Proxy → Telnet → Rlogin → SSH	Category: 	Options controll Select a serial line Serial line to connect to Configure the serial line Speed (baud) Data bits Stop bits Parity Flow control	ing local serial lines COM1 9600 8 1 None None Vone
	About		Open Cancel

Figure 6-2 shows the PuTTY serial connection configuration options.

Figure 6-2 PuTTY connection options

b. In a UNIX environment, enter the following string at the prompt:

tip /dev/ttyb -9600

From the terminal emulator application, log on to the switch through the serial connection. The default administrative logon is **admin** and the default password is **password**. If you have just turned on the switch, you might have to press Enter to display the login prompt following the message: Port Initialization Completed.

When logging into a new switch, you are requested to change the password. To skip this request, press Ctrl+C. You are prompted to change the password again at your next login. If you choose to change the password at this stage, you are prompted to change the password for each of the generic user accounts (root, factory, admin, and user). When all the passwords are changed, they are saved to stable storage. Change the password prior to connecting the switch to your network.

6. Enter the **ipAddrSet** command at the prompt.

Then, enter the appropriate values at the corresponding prompts, as shown in Example 6-2.

Example 6-2 Entering network settings with ipAddrSet command

```
IBM_SAN80B_4_217:admin> ipAddrSet
Ethernet IP Address [10.64.210.217]: Enter new IP address
Ethernet Subnetmask [255.255.240.0]: Enter new subnet mask
Gateway IP Address [10.64.208.1]: Enter new gateway ip address
DHCP [Off]:
```

7. Verify that the address was set correctly by entering the **ipAddrShow** command.

Example 6-3 displays the values that you entered in the previous step.

Example 6-3 ipAddrShow command output

```
IBM_SAN80B_4_217:admin> ipAddrShow
SWITCH
Ethernet IP Address: 10.64.210.217
Ethernet Subnetmask: 255.255.240.0
Gateway IP Address: 10.64.208.1
DHCP: Off
IBM_SAN80B_4_217:admin>
```

8. After verifying that the IP address is correct, remove the serial cable, and replace the shipping plug in the serial port.

Serial Port: The serial port is intended only for use during the initial setting of the IP address and for service purposes. Do not use the serial port for day-to-day management and monitoring operations.

9. Record the IP address for future reference.

After the IP address is set, you can connect the switch to the managing workstation by Ethernet cable (this can be a direct cross-over connection or through a network) by following these steps:

- 1. Remove the shipping cover from the Ethernet port.
- 2. Insert one end of an Ethernet cable in the Ethernet port.
- 3. Connect the other end of the Ethernet cable to the workstation or to an Ethernet network that contains the workstation.

Important: The switch can now be accessed remotely, using Telnet or Web Tools. As a result, it is important to ensure that the switch is not modified simultaneously from any other connections during the remaining steps.

6.1.3 SAN768B, SAN384B, and SAN256B configuration procedure

The initial configuration of a SAN768B, SAN384B, or SAN256B requires a serial connection. (Note that the following examples were carried out on a SAN768B; however, the procedure is identical for a SAN384B and a SAN256B.)

Follow these steps to establish a serial connection and log in to the director:

- 1. Make sure that the SAN768B is turned on and that POST is complete by verifying that all power LED indicators on the port blades and CP blades display a steady green light.
- 2. Use the serial cable that is provided with the SAN768B to connect the serial console port on the active CP blade to a workstation.

Attention: The active CP blade is indicated by an illuminated blue LED. The LED on the standby CP blade must be off. The serial port is intended primarily for use during the initial setting of the IP addresses and for service purposes.

- 3. Access the SAN768B using a terminal emulator application (such as HyperTerminal or **putty.exe** on Windows or TERM in a UNIX environment).
- 4. Disable any serial communication programs running on the workstation (such as synchronization programs).
- 5. Open the terminal emulator application and configure as follows:
 - Bits per second: 9600
 - Databits: 8
 - Parity: None
 - Stop bits: 1
 - Flow control: None

For most UNIX systems, enter the following string at the prompt:

tip /dev/ttyb -9600

When the terminal emulator application stops reporting information, press Enter. You receive the following login prompt:

Fabric OS (IBM_SAN768B) IBM_SAN768 console login: 6. Log in to the SAN768B as admin. The default password is password.

Passwords: At the initial login, you are prompted to enter new admin and user passwords.

7. Change the passwords. Passwords can be 8 to 40 characters long. They must begin with an alphabetic character and can include numeric characters, the period (.), and the underscore (_). Passwords are case-sensitive, and they are not displayed when you enter them on the command line. To skip modifying the password, press Ctrl+C, as shown in Example 6-4.

Example 6-4 Chassis console login

```
Fabric OS (IBM_SAN768B)
IBM_SAN768B console login: admin
Password:
Please change passwords for switch default accounts now.
Use Control-C to exit or press 'Enter' key to proceed.
Password was not changed. Will prompt again at next login
until password is changed.
IBM_SAN768B:admin>
```

8. View the active CP LED on the CP blades in slots 6 and 7 or enter the **haShow** command to verify which CP blade is active. Example 6-5 shows the output for the **haShow** command. You can modify the configuration only through a login session to the active CP blade.

Example 6-5 hashow command

```
IBM_SAN768:admin> hashow
Local CP (Slot 7, CP1): Active, Cold Recovered
Remote CP (Slot 6, CP0): Standby, Healthy
HA enabled, Heartbeat Up, HA State synchronized
IBM_SAN768:admin>
```

To configure the IP addresses for the logical switch and both CP blades (from the active CP blade), follow these steps:

- 1. Log in to the active CP as admin using the serial cable connection.
- 2. Set up the logical switch IP address and subnet mask by entering the **ipAddrSet -sw 0** command at the command prompt. Enter the requested information at the prompts, which are shown in Example 6-6.

Example 6-6 Setting the logical switch IP address

```
IBM_SAN768:admin> ipAddrSet -chassis
Ethernet IP Address [10.64.210.210]: Enter the IP address
Ethernet Subnetmask [255.255.240.0]: Enter the subnet mask
IBM SAN768:admin>
```

Reserved addresses: The addresses 10.0.0.0 through 10.0.0.255 are reserved and used internally by the Brocade DCX. External IP addresses must not use this range.

3. Set up the CP0 blade IP address by entering the **ipAddrSet** -cp 0 command at the prompt. This is the CP blade in slot 6. Enter the requested information at the prompts, as shown in Example 6-7.

Example 6-7 Setting the CP 0 IP address

```
IBM_SAN768_210:admin> ipAddrSet -cp 0
Host Name [IBM_SAN768_210_cp0]: Enter the hostname
Ethernet IP Address [10.64.210.211]: Enter the new IP address
Ethernet Subnetmask [255.255.240.0]: Enter the new IP subnet mask
Gateway IP Address [10.64.208.1]: Enter the gateway IP address
IBM_SAN768_210:admin>
```

4. Set up the CP1 blade IP address by entering the **ipAddrSet** -cp 1 command at the prompt, as shown in Example 6-8. This is the CP blade in slot 6.

Example 6-8 Setting the CP 1 IP address

```
IBM_SAN768_210:admin> ipAddrSet -cp 1
Host Name [IBM_SAN768_210_cp1]: Enter the hostname
Ethernet IP Address [10.64.210.212]: Enter the new IP address
Ethernet Subnetmask [255.255.240.0]: Enter the new IP subnet mask
Gateway IP Address [10.64.208.1]: Enter the gateway IP address
IBM_SAN768_210:admin>
```

After entering all the IP addresses, you can use the **ipAddrShow** command to verify the settings. Example 6-9 shows the output of this command on our SAN768B.

Example 6-9 The ipAddrShow command output

IBM_SAN768_210:admin> ipAddrShow

CHASSIS Ethernet IP Address: 10.64.210.210 Ethernet Subnetmask: 255.255.240.0

CPO Ethernet IP Address: 10.64.210.211

Ethernet Subnetmask: 255.255.240.0 Host Name: IBM_SAN768_210_cp0 Gateway IP Address: 10.64.208.1

CP1

Ethernet IP Address: 10.64.210.212 Ethernet Subnetmask: 255.255.240.0 Host Name: IBM_SAN768_210_cp1 Gateway IP Address: 10.64.208.1

```
Backplane IP address of CPO : 10.0.0.5
Backplane IP address of CP1 : 10.0.0.6
IPv6 Autoconfiguration Enabled: Yes
Local IPv6 Addresses:
IPv6 Gateways:
IBM_SAN768_210:admin>
```

Reboot not needed: Although the SAN768B hardware reference manual suggests that a reboot is required when changing the IP address, this reboot is not necessary. You can change the IP address online without rebooting the director.

The terminal serial port can be used to monitor error messages through a serial connection. It is not intended for use as a command interface during normal operations. If this port is not going to be in ongoing use, remove the serial cable and protect the port from dust by replacing the shipping cap. This completes the initial configuration.

6.1.4 Connecting to the switch

After using a serial connection to configure the IP addresses for the SAN768B, you have to connect both the active and the standby CP blade to the local area network (LAN). Connect the CP blades to a private network/VLAN to provide additional security to your SAN as well as to protect it from network broadcast storms or other problems.

By establishing an Ethernet connection, you can complete the configuration using either the serial session or a Telnet session or through the graphical management interfaces (Web Tools and Data Center Fabric Manager). However, you must ensure that the SAN768B configuration is not modified from other connections at the same time.

To establish an Ethernet connection, follow these steps:

- 1. Remove the shipping plug from the Ethernet port on the active CP blade.
- 2. Insert one end of an Ethernet cable into the Ethernet port.
- 3. Connect the other end to an Ethernet 10/100 Base-T LAN.

The SAN768B can now be accessed by remote connection using any of the available management tools, such as Telnet, Web Tools, or Data Center Fabric Manager.

- 4. Repeat steps 1 through 3 for the standby CP blade.
- To complete any additional configuration procedures through a Telnet session, log in to the SAN768B using Telnet with the admin login. The default password is password.

Important: When managing the SAN768B backbone, use the **-chassis** IP address for management GUI and Telnet access. Unless you are carrying out activities to a specific CP, this address prevents unpredictable results.

6.1.5 Setting the switch name

The switch name of the SAN768B can be up to 15 characters long, can include alpha, numeric, and underscore characters, and must begin with an alpha character. Setting meaningful names for your switches simplifies the management of your SAN. Ideally, you need to define an appropriate naming convention and use this naming convention to provide standardized names for your switches.

Customizing the name

To customize the name, follow these steps:

1. Enter the **switchName** command with the new name in quotes (see Example 6-10). The change will be committed but the prompt will not change until the telnet session is reconnected.

Example 6-10 Changing the SAN768B name

```
switch:admin> switchName "IBM_SAN768B_210"
Committing configuration...
Done.
switch:admin>
```

2. Record the new name for future reference.

Setting the Domain ID

Each switch in the fabric must have a unique Domain ID. The Domain ID can be set using the **configure** command. You can also allow the Domain ID to be set automatically. The default Domain ID for the SAN768B is **1**.

To set the Domain ID, follow these steps:

- 1. Enter the **fabricShow** command to determine the current Domain IDs available.
- 2. Enter the switchDisable command to disable the SAN768B.
- 3. Enter the configure command. Enter y at the Fabric parameters prompt:

```
Fabric parameters (yes, y, no, n): [no] y
```

4. Then, enter a unique Domain ID:

Domain: (1..239) [1] 3

- 5. Complete the remaining prompts or press Ctrl+D to accept the other settings and to exit.
- 6. Enter the switchEnable command to re-enable the SAN768B.
- 7. Add SFPs and fiber optic cables to the ports as required.

Cables: The ports and cables that are used in trunking groups must meet specific requirements.

8. Remove the shipping plug from the ports to be used.

 Position the SFP so that the key (the tab near the cable-end of the SFP) is on top, and insert the SFP into the port until it is firmly seated and the latching mechanism makes a clicking sound. For specific instructions, see the SFP manufacturer's documentation.

Attention: The SFP module is keyed so that it can only be inserted correctly into the port. If the module does not slide in easily, make sure it is not upside down.

10. Connect the fiber optic cables to the SFPs as appropriate to the fabric topology by positioning each cable so that the key (the ridge on one side of the cable connector) is aligned with the slot in the SFP, then inserting the cable into the SFP until it is firmly seated and the latching mechanism makes a clicking sound.

Attention: The cable is keyed so that it can only be inserted correctly into the SFP. If the cable does not slide in easily, try turning it over.

- 11. Verify the correct operation of the switch.
- 12. Enter the following command at the Telnet prompt to verify the switch and port status:

switchShow

Backups: This command provides information about the status of the switch and the ports. Always back up the configuration after any initial configuration changes and then perform backups periodically thereafter. This ensures that a complete configuration is available if ever required for uploading to a replacement switch. Switch configuration is backed up by issuing a **configUpload** to the FTP server.

6.1.6 The Port Identifier format

The Port Identifier (PID) format is a fabric wide parameter that must be set to the same value on all switches in the fabric. SAN devices use PID for routing and zoning services. Historically, the IBM/Brocade SAN products support the following PID format types:

- VC encoded
- Native (PID format 0)
- Core (PID format 1)
- Extended edge (PID format 2)

In Fabric OS v6.2.0, the PID format is set to 1 (Core PID). You cannot modify this value, which means that the PID format must be set correctly on existing switches for port addressing capability with newer switches.

Changing this parameter is normally disruptive to switch and fabric operation; however, with careful planning, it is possible to update the PID format parameter in a live production environment. This change requires redundant fabrics with multipathing software, which is normally the case in mission-critical environments that require the highest possible uptime.

Do not perform backups during the update process, because the tape drives are very sensitive to I/O interruption.

If your SAN architecture is not redundant, you need to schedule downtime to change the PID format parameter. Before attempting to set the switch PID format, check to see if it is already set. To check the switch PID format value, open a Telnet session to the switch and use the **configShow -pattern "fabric"** command. As shown in Example 6-11, SAN384B running Fabric OS v6.2.0e has the PID format value set to **1**.

Example 6-11 Checking the PID format using configshow

```
IBM SAN384B 213:admin> configshow -pattern "fabric"
fabric.domain:1
fabric.ididmode:0
fabric.ops.BBCredit:16
fabric.ops.E D TOV:2000
fabric.ops.R A TOV:10000
fabric.ops.bladeFault on hwErrlevel:0
fabric.ops.dataFieldSize:2112
fabric.ops.max hops:7
fabric.ops.mode.fcpProbeDisable:0
fabric.ops.mode.isolate:0
fabric.ops.mode.longDistance:0
fabric.ops.mode.noClassF:0
fabric.ops.mode.pidFormat:1<<<<<<<
fabric.ops.mode.tachyonCompat:0
fabric.ops.mode.unicastOnly:0
fabric.ops.mode.useCsCt1:0
fabric.ops.vc.class.2:2
fabric.ops.vc.class.3:3
fabric.ops.vc.config:0xc0
fabric.ops.vc.linkCtrl:0
fabric.ops.vc.multicast:7
fabric.ops.wan tov:0
fabric.principalSwSelMode:0
```

Remember: Changing the switch PID format might require a reboot of UNIX servers that bind by port ID.

If the switch PID format is set to a value other than 1 on existing switches, you can change it by following these steps:

- Disable the switch with the switchDisable command: switchDisable
- 2. Then, run the **configure** command: configure
- 3. Enter y when prompted to set Fabric parameters:

Fabric parameters (yes, y, no, n): [no] y

- 4. Press Enter to use default parameters for settings until you are prompted for the switch PID format setting. Set the parameter to 1:
 Core Switch PID Format: (0..1) [0] 1
 Switch PID Format: (1..2) [1] 1
- 5. Continue to press Enter to skip other settings. You receive the following message:

Committing configuration...done.

- 6. Enable the switch using the switchenable command.
- 7. Fastboot the switch using the fastboot command.

6.1.7 Setting the date

Now is also a good opportunity to set the date and time in the switch. Although a switch with the incorrect date and time will function properly, it is best to make these values realistic, because they are used for time stamping during logging of events. We suggest that you set these parameters prior to any further operations, because you might find this information very helpful if you have to troubleshoot at a later date.

Set the day and time using the date MMDDhhmmYY command, where:

- MM Month
- DD Day
- hh hour
- mm minutes
- YY Year

See Example 6-12 showing the use of this command.

Example 6-12 Setting the date and time

```
IBM_SAN384B_213:admin> date 0714164509
Tue Jul 14 16:45:00 UTC 2009
```

Time: Use an NTP server to ensure that all switches in your environment are on the same time.

The steps for the installation are now complete, although it is best to upgrade to the latest level of firmware that is available before making the switch available for use.

6.1.8 Firmware update

When the switch is delivered, it might not have the latest firmware installed. It is a good practice to update the firmware to the latest version (or to the version in line with other switches in your SAN) before putting it in production. In this section, we show an example of firmware update using a Telnet session. Other possible ways to update the code are as follows:

Web Tools:

We explain how to do a SAN switch firmware update with Web Tools in 8.7.4, "Firmware Download tab" on page 259.

Data Center Fabric Manager

Set the Telnet session timeout value to **0**. This effectively disables the timeout (so that your session will not time out during the firmware upgrade procedure). Use the following command:

timeout O

Because the new timeout value takes effect with the next login, you now need to log out and log back in.

Normally, the next steps are to configure the switch upload (with the **configUpload** command) and to save the support information (with the **supportSave** command). However, because you are performing the initial setup and have not yet configured the switch, you do not perform these steps now.

Therefore, continue with the actual firmware update, using the **firmwareDownload** command. Example 6-13 uses the FTP server with IP address 10.64.210.103 and logs in as **IBM** with password **password**. The Fabric OS v6.2.0e files are stored on this FTP server.

Example 6-13 Firmware update with firmwareDownload command

SAN32B 3 146:admin> firmwaredownload -p ftp 10.64.210.103, ibm, /, password Server IP: 10.64.210.103, Protocol IPv4 Checking system settings for firmwaredownload... System settings check passed. You can run firmwaredownloadstatus to get the status of this command. This command will cause a warm/non-disruptive boot on the switch, but will require that existing telnet, secure telnet or SSH sessions be restarted. Do you want to continue [Y]: y Firmware is being downloaded to the switch. This step may take up to 30 minutes. Preparing for firmwaredownload... Start to install packages... dir ldconfia alibc glibc-linuxthreads bash readline terminfo termcap . . . Lines deleted for clarity . . . tz mtracer-tool sysstat ipv6 awk ipsec kernel-module-ipsec Writing kernel image into flash.

```
Finished writing kernel image.
Removing unneeded files, please wait ...
Finished removing unneeded files.
All packages have been downloaded successfully.
Firmware has been downloaded to the secondary partition of the switch.
HA Rebooting ...
```

To verify that the switch firmware was updated properly, you can use the **firmwareShow** and **version** commands. Example 6-14 shows the output of these two commands. The switch now runs Fabric OS v6.1.0.

Example 6-14 Verifying the switch firmware version

6.1.9 SAN256B optional modem setup

Each CP blade in the SAN256B contains a modem serial port for connection to a Hayes-compatible modem. The modem serial ports are wired as standard DTE ports and have the same commands, log in capabilities, and operational behavior as the terminal serial ports. However, asynchronous informational messages and other unsolicited text are not sent to the modem ports. No additional software is required to use modems with the director.

Modems: The director detects modems only during power-on, reboot, or a CP blade failover sequence. Set up the modems before powering on the director. For increased security, any active modem sessions are disconnected automatically if the modem cable is disconnected. For optimal security, disconnect the modem cable when it is not in use.

You can ensure high availability of the modem connection by connecting a separate modem to each CP blade and then connecting both modems to a shared telephone line. This connection ensures an available telephone connection to the active CP blade even if a failover occurs; however, it is necessary to log in again after a failover. When both CP blades are connected to a shared telephone line, callers are dialed in to the active CP blade automatically, which answers on the first ring. If the active CP blade cannot answer for any reason, the standby CP blade answers on the seventh ring and allows login to proceed.

Connection: If a modem connection is set up, connect a modem to each CP blade, as shown in Figure 6-3.



Figure 6-3 Optional modem line and data connections

Connecting modems

Attention: Set up the modems before turning on the director and connect it to the fabric.

The following items are required to set up two modems to work with the director:

- Two Hayes-compatible modems, such as the Zoom/Modem V.92 EXT Model 3049
- ► Two standard modem cables, DB25 (male) to DB9 (female)
- One RJ–11 "Y" adapter for standard Telco wiring or equivalent circuitry (three total connections)
- One analog telephone line

Attention: Turn off the director before connecting cables to the modem ports.

Complete the following steps to connect the modems to the director:

- 1. Set up the two modem units and corresponding power connections, but do not turn on the modems until all cables are attached.
- 2. Connect the modem cables to the modems and to the director RS–232 modem ports.
- 3. Connect the telephone line inputs on the modems to the RJ–11 Y connector. This effectively places both modems on a single telephone line.
- 4. Optionally connect a telephone handset to one of the phone connections on the modems.
- 5. Connect the "Y" adapter to an appropriate analog telephone line and document the dial-in number for later use.
- 6. Turn on the modems and verify that the Modem Ready indicator illuminates on both units.
- 7. Turn on the director, to allow the director to recognize the modems.

When the modems are connected, you can use a Telco system to dial in to the modems and verify that they answer and communicate as expected. If a dial-out modem facility is not available, you can use a terminal emulation program on a computer workstation (or mobile computer) that has an attached modem.

This procedure is only required if a dial-out modem facility is not already available for testing the director modem connections.

Perform the following steps to set up the optional remote modem:

- 1. Connect the remote modem to the workstation, as shown in Figure 6-4.
- 2. Disable any serial communication programs running on the workstation (such as a synchronization program for a PDA).



Figure 6-4 Remote modem setup

3. Launch the terminal emulator application and configure it as shown in Table 6-1.

Table 6-1 Configuration parameters

Parameter	Value
Port Speed	115200 ^a
Data Protocol	Standard EC
Compression	Enabled
Flow Control	Hardware
Databits	8
Parity	None
Stop Bits	1
Modulation	Standard

a. Port usually defaults to the highest speed that the modem supports but might negotiate at a slower speed.

4. Follow the instructions from the modem manufacturer to set up and verify modem operation.

Verifying the modem connection

This section provides information about how to verify that the modems are connected correctly.

Equipment: This procedure requires either a Telco system to dial in to the modems or a terminal emulation program on a mobile computer or workstation that has an attached modem.

Complete the following steps to verify the modem connection:

- 1. Verify that both modem cables are connected firmly.
- 2. Turn on the modems, if they are not already on.

Boot: The modems must be turned on and operational before the director is turned on, to allow the director to detect the modems during boot.

- 3. Verify that both modems indicate that they are ready by illuminating their Clear to Send (CS), Terminal Ready (TR), and Modem Ready (MR) indicators. If this illumination does not occur, ensure that the modems are connected to a power source and are turned on. Check all modem cable connections.
- 4. Verify that POST is complete on the director (a minimum of 3 minutes).
- 5. Dial in to the telephone number that is assigned to the director, using a Telco system to dial in to the modems.
- 6. Observe the modem lamps. The Ring indicator will flash briefly as the telephone rings. If the Ring indicator does not flash on both units, check the incoming telephone lines to the modems again.
- 7. Verify that after one ring, the modem that is associated with the active CP blade (usually in slot 5), illuminates the Off Hook (OH) indicator on the modem and a login prompt is presented to the remote client.
- 8. Log in to the switch from the remote client as admin. The default password is **password**.

Cable: If the OH indicator illuminates on the standby CP blade modem, recheck the modem cable connection to the active CP blade.

9. Log out of the modem session.

 Remove the Telco connector from the active CP blade modem, leaving the Telco line from the standby CP blade connected to the "Y" connector. See Figure 6-3 on page 148.

Cable: The modem session is disconnected automatically if the modem cable is detached while a session is active.

- 11. Dial in to the telephone number that is assigned to the director.
- 12.Observe the modem lamps. The Ring indicator will flash only on the modem that is connected to the standby CP blade.
- 13. Verify that after seven rings, the OH indicator on the standby CP blade modem is illuminated. A login prompt is presented to the remote client, and a message confirms that the standby CP blade is being logged in to. You can log in or disconnect the session, as desired.
- 14. Reconnect the Telco connector to the active CP blade modem. The director modems are ready for use.

6.2 SAN32B-3 implementation using EZSwitchSetup

The EZSwitchSetup starter kit greatly simplifies the setup and implementation of supported switches. The kit ships with the switch and includes a serial cable and a CD that contains the setup software. It makes the switch setup as simple as a "click-and-go" solution. It runs only in a single switch fabric.

If you follow the standard switch configuration practice, you implement a new switch by connecting a serial cable, setting up a tool such as Hyperterm to communicate, and implementing the **ipaddrset** command to configure the IP address. Then, you can then connect to the network using an Ethernet cable, using a Web browser to access Web Tools, or alternatively using Telnet to enter CLI mode and to configure the switch further. From here, you can set up zoning, assuming that all devices are connected and also that switch status monitoring uses Web Tools, SNMP, or an external application.

EZSwitchSetup greatly simplifies this process by walking you through all the steps automatically using a GUI-based interface.

In this section, we explain how to use EZSwitchSetup to configure a SAN32B-3 switch.
6.2.1 Implementing EZSwitchSetup

Before you begin, you need to obtain an IP address, subnet mask, and default gateway address for the switch. Then, follow these steps:

1. Using either a Windows system that is located physically close to the switch or a mobile computer, insert the CD, which starts the EZSwitchSetup program automatically, as shown in Figure 6-5. Click **OK** to start the installation.



Figure 6-5 EZSwitchSetup - startup panel

InstallAnywhere guides you through the simple installation. The EZSwitchSetup program runs automatically when the installation is complete.

2. Following the instructions, as shown in Figure 6-6 and Figure 6-7, connect the power cord to the switch, the Ethernet cable between the mobile computer and switch, and the serial cable from your mobile computer to the switch. Wait for the switch to turn on fully before continuing. It can take up to 3 minutes for the switch to be in a ready state with both the System Status and Power LEDs green.

뺥 EZSwitchSetup	
Steps	Introduction
Introduction	Welcome to FZSwitchSetun.
Assign IP Address	There are two parts to setting up your switch.
- Connect Cables	
- Discover Switch	1. Assigning an IP address to the switch 2. Logging into the switch and configuring basic parameters
- Confirm IP Address	To begin, select a method for assigning the switch's IP address:
	 Use an Ethernet connection to the LAN on the same sub-net as the switch Use a Serial cable to connect directly to the switch
	Once you assign an IP address to the switch, you can continue setting up your switch in the second part: Configure the Switch.
Help <u>C</u> ancel	Next 🕨

Figure 6-6 EZSwitchSetup - Introduction

非 EZSwitchSetup	
Steps	Connect Cables
Introduction	Connect the switch
Assign IP Address	-To a power source using the power cord -To the LAN using an Ethernet cable
- Connect Cables	
- Discover Switch	Connect the setur
- Confirm ID Address	-To the LAN on the same subnet as the switch, using an Ethernet cable
	Ethernet Ethernet
	Wait at least 2 minutes to ensure that the switch is powered on. Make sure that both the System Status and Power LEDs are green. Also, make sure that Link Activity LED of Ethernet Port is blinking and its status LED is green, then click Next.
Help <u>C</u> ancel	<u>Previous</u> <u>Next </u>

Figure 6-7 EZSwitchSetup - Connect Cables

3. Click **Next**, and the software starts a discovery by entering the switch WWN as shown in Figure 6-8. When the switch is found, you can move to the next panel by clicking **Next** again.

恭 EZSwitchSetup	
Steps	Discover Switch
Introduction	
Assign IP Address	Select the first five bytes from the dropdown that matches the VWVN of your switch and enter the remaining three bytes in the text field. To learn more about VWVN click Help.
- Connect Cables	
- Discover Switch	
- Confirm IP Address	Select first 5 bytes Witch WWW 10:00:00:05:1E: 34:81:74 The wizard will try to discover the switch based on WWN. It will be successful only if the wizard is running on the computer connected to the same sub-net as that of the switch.
Help Cancel	

Figure 6-8 EZSwitchSetup - Discover Switch

4. EZSwitchSetup logs in to the switch using the admin ID. If, for whatever reason, the default password has changed, EZSwitchSetup prompts you for the new password.

5. At the next panel (shown in Figure 6-9), to accept the IP address, select the **No** radio button and click **Next**.

쁥 EZSwitchSetup			
Steps	Discover Sw	vitch	
Introduction			
Assign ID Address	Following is the IP add	ess configuration of the swite	h
Assign II Anness	World Wide Name	10:00:00:05:1E:34:81:74	
- Connect Cables	IPV4 Address	10.64.210.146	
- Discover Switch	IPV4 Subnet Mask	255.255.240.0	
	IPV4 Default Gateway	10.64.208.1	
- Confirm IP Address	IPV6 Address		
	DHCP	Off	
	Do you want to assign a s	tatic IP to the Switch?	
	Yes		
<u>H</u> elp <u>C</u> ancel			<u> P</u> revious <u> N</u> ext ▶

Figure 6-9 EZSwitchSetup - Set Switch IP Address

6. Now, the switch IP settings are complete, see Figure 6-10. Click **Continue** to spawn the second part of configuration, which is a Java plug-in for your existing browser. If you have a firewall enabled, you might have to permit access to the Internet in order to continue.

恭 EZSwitchSetup			
Steps	Confirm IP	Address	
Introduction	You have ented t	e retain the quisting ID addre	an of the quitch If you
Assign IP Address	wish to change it	o retain the existing IP addre t, click Previous.	ss of the switch. If you
- Connect Cables	The switch can now k	e reached at this IP address through ti	ne network.
- Discover Switch	World Wide Name	10:00:00:05:1E:34:81:74	
	IP Address	10.64.210.146	
- Confirm IP Address	Subnet Mask	255.255.240.0	
	Default Gateway	10.64.208.1	
	To begin with switch o take up to 2 minutes.	configuration, click Continue. Loading th	ne configuration wizard may
Help Cancel			◀ Previous Continue

Figure 6-10 EZSwitchSetup - Confirm IP Address

7. This part of the configuration is controlled by the switch setup wizard. First, the Welcome window displays (Figure 6-11). Click **Next**.

EZSwitchSetup	
Steps	Welcome to Switch Configuration
Switch Configuration	
1. Set Parameters	This wizard will guide you as you configure your switch. Click Next to begin.
2. Select Zoning	
3. Specify Devices	
4. Configure Ports and Connect Devices	
5. Finish	
Links Comparis	
<u>H</u> elp <u>C</u> ancel	Previous Next P

Figure 6-11 EZSwitchSetup - Welcome window

8. Now, set the switch parameters, as shown in Figure 6-12. In this step, you can change the Admin password, the switch name, and the date and time.

SezSwitchSetup			
Steps I	Set Parameter	rs	
Switch Configuration			
1. Set Parameters	The default user name the first time, you mus	e of this account is "admin".If you are sett st change the password for the admin acc	ing up the switch for ount.
2. Select Zoning	*IMPORTANT* Save th	e new admin account password in a safe	place, it will be
3. Specify Devices	required to update ac	count settings in the future.	
4. Configure Borts	New Password	•••••	
and Connect Devices	Re-enter New Password	•••••	
5. Finish	You can also change	the switch name and time if you wish.	
	Switch Name	IBM_SAN32B_146	
	Switch Time	Jul 16, 2009 🔹 17 : 15 : 16 Etc/GMT-0	
	IP Address	10.64.210.146	
	Subnet Mask	255.255.240.0	
	Default Gateway	10.64.208.1	
	Firmware Version	v6.2.0e	
	:		
Help Cancel			<u> P</u> revious <u> N</u> ext ▶

Figure 6-12 EZSwitchSetup - Set Parameters

You can access EZSwitchSetup again later by entering *switchIP*/EZsetup.html as the address field in a Web browser or, alternatively, by selecting the setup option from the switch manager.

9. After you set up these values, click **Next** to open the zoning configuration panel, as shown in Figure 6-13.

& EZSwitchSetup		
Steps	Select Zoni	ng
Switch Configuration	Zone configuration with each other. To	specifies which devices connected to the switch can communicate Dearn more about zoning options, click Help.
2. Select Zoning	Typical Zoning	(Recommended): Uses preset zones for a single switch, best suited for a basic SAN user.
3. Specify Devices	Custom Zoning	Allows you to customize zoning for a single switch using a device accessibility matrix.
4. Configure Ports and Connect Devices	Advanced Zoning	Allows you to customize zoning for a more complex fabric.
5. Finish		
Help <u>C</u> ancel	1	Previous

Figure 6-13 EZSwitchSetup - Select Zoning

Here you are presented with three options:

- Typical Zoning
- Custom Zoning
- Advanced Zoning

In our example, we select Typical Zoning and then click Next.

10. Figure 6-14 shows the next step. In typical zoning scenario, we simply need to specify the number of switch ports for HBA and for storage connections.

🌲 EZSwitchSetup	×□-
Steps	Specify Devices
Switch Configuration	Select the number of HBA and storage connections you are attaching to the switch.
1. Set Parameters	Make sure the devices are powered on and have appropriate drivers installed. Click Next to continue.
2. Select Zoning	Total Number of HBA Connections 4
3. Specify Devices	Total Number of Storage Connections 2
4. Configure Ports and Connect Devices	
5. Finish	
Help Cancel	

Figure 6-14 EZSwitchSetup - Specify Devices

11.EZSwitchSetup wizard then displays the device connection window (see Figure 6-15), which suggests the ports that you need to use for the requested connections. Here, you need to connect the hosts and storage physically as suggested by the software.



Figure 6-15 EZSwitchSetup - Configure Ports and Connect Devices

Because we have no devices connected to the switch yet, Figure 6-16 shows this situation. Valid connections would be shown with a solid green line. Invalid connections would be highlighted with the color red.



Figure 6-16 EZSwitchSetup - showing that all devices are connected

12. The final setup panel (shown in Figure 6-17) displays a summary of the switch configuration. At this point, the process is complete.

& EZSwitchSetup			
Steps	Finish		
Switch Configuration			
1. Set Parameters	You have completed th the settings, click Print.	e switch setup and the swi	tch is ready to use as configured. To print a summary of
2. Select Zoning			
2 Specify Devices	Parameter	Setting	
5. specify Devices	Switch Name	IBM_SAN32B_146	
4. Configure Ports	IP Address	10.64.210.146	
and Connect Devices	Subnet Mask	255.255.240.0	
5. Finish	Default Gateway	10.64.208.1	
	This switch is configured	l with Typical Zoning.	
	Total Number of HBA Conn	ections 0	
	Total Number of Storage Co	onnections 0	
		7	
1			
Help Print			

Figure 6-17 EZSwitchSetup - Finish

6.2.2 Using Switch Manager to manage a switch

If you have set up a switch with EZSwitchSetup and if it is not connected to other switches, then you use the Switch Manager utility to manage it (instead of Web Tools). Figure 6-18 shows an example of the Switch Manager user interface.

IBM_SAN32B_146 - Switch Manage	er							
Tasks	0.500	Ton		agond				
Switch	Switch View			egena				
View	888888	10000	000000000000000000000000000000000000000			100000(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		
Setup	<u></u>					ם איניסים די		
Enable Inactive Ports	2 0	• • •					UUUUUUUUUU 16. 01. 01. 01. 02. 02. 02. 02. 02. 00. 00. 00. 00.	
Devices								
View								
Display Connections	Port informati	on, Sv	vitch Information					
Modify Alias	Port Informa	ation	Switch Information					
	Number 🔺	Nan	ne State	Туре	Health	Licensed		
Zoning	0		No Light	U-Port	Offline	Yes	-	
View	1		No_Module	U-Port	Offline	Yes		1000
, ion	2		No_Module	U-Port	Offline	Yes		
Edit	3		No_Module	U-Port	Offline	Yes		
Validate	4		No_Module	U-Port	Offline	Yes		
	5		No_Module	U-Port	Offline	Yes		
Restore Detault Typical Zoning	6		No_Module	U-Port	Offline	Yes		
	7		No_Module	U-Port	Offline	Yes		
Miscellaneous	8		No_Module	U-Port	Offline	Yes		
Defearb	9		No_Module	U-Port	Offline	Yes		
kerresn	10		No_Module	U-Port	Offline	Yes		
Advanced Management	11		No_Module	U-Port	Offline	Yes		
Log Out	12		No_Module	U-Port	Offline	Yes		
Log out	13		No_Module	U-Port	Offline	Yes		
	14		No_Module	U-Port	Offline	Yes		
	15		No_Module	U-Port	Offline	Yes		
	16		No_Module	U-Port	Offline	Yes		
	17		No_Module	U-Port	Offline	Yes		
	18		No_Module	U-Port	Offline	Yes		ſ
	19		No_Module	U-Port	Offline	Yes		
	20		No_Module	U-Port	Offline	Yes		
	21		No_Module	U-Port	Offline	Yes		- 1
	22		No_Module	U-Port	Offline	Yes		
	23		No_Module	U-Port	Offline	Yes		

Figure 6-18 Switch Manager user interface

In comparison with Web Tools, the Switch Manager is a simple utility that is designed to manage stand-alone SAN switches. You launch the Switch Manager the same way that you launch Web Tools by specifying the switch IP address in the Web browser address field.

6.2.3 Basic troubleshooting with EZSwitchSetup

If reinstalling or upgrading EZSwitchSetup fails, you need to uninstall the previous version first, and then reinstall.

If EZSwitchSetup encounters a launch problem, check whether there is already a copy of EZSwitchSetup running on another user's system. Only one copy of the program is allowed to run at any given time.

If during the EZSwitchSetup process, you encounter an operation failure, check the serial and Ethernet connection and fix it if necessary, and then launch EZSwitchSetup again.

EZSwitchSetup does not fully recognize storage that is presented to the SAN in initiator and target mode. This issue can occur, for example, if a DS4000® with remote mirroring enabled is connected. Usually, a simple SAN will not involve this type of configuration, and as such it is unlikely that you will experience this issue. However, if it occurs, you can circumvent the issue by adding only the hosts in the initial setup. You can then add the storage when you have proceeded past the Switch Setup Complete window.

After you add the switch to a fabric, you can no longer access the EZSwitchSetup wizard, as shown in the error message in Figure 6-19.

Address 💩 http://10.64.210.251/EZManager.html

EZSwitchSetup cannot be used if your switch is part of a fabric. To manage switches in a multi-switch fabric using Web Tools, click here.

Figure 6-19 Web Tools EZ error message

7

License administration

In this chapter, we discuss the licensed features that are available on IBM/Brocade SAN products. We also describe how to use Web Tools and CLI for license administration (as explained in 8.7.6, "License tab" on page 268).

7.1 Licensed features

IBM/Brocade SAN products normally ship with the basic set of features enabled. Numerous advanced features are available as add-ons and can be enabled by applying appropriate license keys. This ability to add-on features allows "pay-as-you-grow" flexibility so that customers with basic requirements do not have to pay for features that they do not need, while customers who need additional functionality can purchase the exact set of features they require.

Fabric OS v6.1.0 introduces some changes to the licensing scheme. Web Tools and zoning are no longer licensed features. They are now part of the basic Fabric OS, and there are a number of new licenses, such as Integrated Routing, Inter-Chassis Link (ICL), and Adaptive Networking and for the IBM Converged Switch B32 Frame-Based ISL Trunking.

7.1.1 Ports on Demand

Storage area network (SAN) switches typically ship with lower than the maximum number of ports enabled. You can enable additional Ports on Demand in increments of 8 or 16 ports.

Additional Ports On Demand

For example, the SAN24B-4 ships with eight ports activated (ports 0 through 7). You can enable additional eight ports (8 through 15) by purchasing the Ports on Demand (PoD) license. You can enable another eight ports (16 through 23) with an additional PoD license.

The SAN40B-4 is delivered with 24 enabled ports. The first increment of eight ports brings the number of enabled ports to 32, and the second increment allows you to use the total number of 40 ports.

Finally, the SAN80B-4 ships with 48 activated ports. You can increase the number of ports to 64 ports with the first PoD license and to a total of 80 ports with a second PoD license.

On the previous generation of IBM/Brocade SAN products, a simple rule of thumb was that switches with the PoD capability are shipped with 50% of the ports configured and that PoD upgrades are available in 25% increments. For example:

- SAN16B (16 physical ports) ships with eight ports activated initially. A PoD license is available in increments of four ports.
- SAN32B (32 physical ports) ships with 16 ports activated and, with a PoD license, can be upgraded in 8-port blocks.
- SAN64B (64 physical ports) ships with 32 ports activated and, with a PoD license, can be upgraded in 16-port blocks.

Enabling these licenses using Web Tools or the CLI (using licenseAdd and **portEnable**) are both non-disruptive. If you remove a PoD license by mistake, the affected ports continue to operate until the switch is disabled or rebooted.

Dynamic Ports On Demand

You can use Dynamic Ports on Demand on Brocade SAN switch modules for the BladeCenter. If some Blade servers do not have the Fibre Channel expansion card installed, then the corresponding port on the SAN switch module is never needed. So, you only need to enable a subset of all the switch module ports. With Dynamic Ports on Demand, you can use a particular subset of ports, according to which Blade servers actually require SAN connectivity. You can create the subset dynamically (ports are assigned as they come online, until the number of licensed ports is reached) or statically (you specify a PoD ports subset that is used for ports enablement).

7.1.2 Full Fabric

Base switches act as single-switch fabrics without E_Port capability. Some older switches had to upgrade with the Full Fabric license to get this function. When this license is applied, the switch can connect to other switches through E_Ports to join a multi-domain fabric. With newer products this function is already included in the base switch.

7.1.3 8 Gbps

This license is a pre-installed license. You can see the license using **licenseshow** on the 8 Gbps platforms, and it must never be removed. This license is for informational purposes only.

7.1.4 Inter-Chassis Link (ICL)

Two SAN768B chassis, two SAN384B (or one SAN768B and one SAN384B) can be interconnected using four ICL cables.

The ICL license enables ICL ports and is, therefore, a mandatory requirement before any ICL connections can be made. You must enable this license on both SAN768B or SAN384B chassis.

7.1.5 Adaptive Networking

Use the Adaptive Networking feature to introduce SAN traffic control in congested environments. The feature is available on 8 Gbps capable switches and provides the following features:

Quality of Service (QoS) SID/DID prioritization:

This technique utilizes virtual channels (VC) across an ISL connection. The VCs are assigned high, medium, or low priority. High priority VCs get 60% of bandwidth, medium priority VCs get 30%, and low priority VCs get 10%.

SID/DID traffic priority assignment is done by means of zoning. Special zone name prefixes are used for assigning source and destination device worldwide names (WWNs):

- QOSH_ for high priority traffic
- QOSL_ for low priority traffic

Medium priority is the default. The SID/DID pairs not assigned into any of the QoS zones will be set to this priority level.

Ingress rate limiting:

You can use this feature to throttle down the ingress port speeds, which can be useful in case of congested ISLs. Only the F and FL_ports support ingress rate limiting. In addition, this feature can only be used on 8 Gbps capable ports. Ingress rate limiting is unidirectional. It limits only the data transfer rate from the device to the switch port. The transfer rate from the switch port to the device is not affected.

7.1.6 Frame Based ISL Trunking

This feature enables the IBM Converged Switch B32 to have up to 8 ports between a pair of switches to be combined into a logical ISL with speeds of up to 64 Gbps (128 Gbps full duplex) for optimal bandwidth utilization and load balancing, and exchange-based load balancing across ISLs with DPS (included in Fabric OS).

7.1.7 Fabric Watch

Fabric Watch provides real-time monitoring of switch health, performance, and security. The information it provides enables the SAN administrator to act proactively and, therefore, to avoid unnecessary downtime. Numerous operational parameters of the switches in the fabric are tracked, and automatic alerting takes place whenever switches operate outside acceptable thresholds.

Fabric OS v6.1 also introduces Port Fencing in Fabric Watch, which disables automatically a port that operates outside of the defined thresholds.

7.1.8 Advanced Performance Monitoring

This licensed feature provides a comprehensive set of technologies for tracking performance and bandwidth usage in the SAN. It is based on Brocade Frame Filtering technology and performance counter engine. You can use the information that is gathered for performance bottleneck identification and capacity planning.

The Advanced Performance Monitoring feature provides these capabilities:

- End-to-end monitors that you can use to monitor the traffic between host/target pairs. Host and target are specified with Source ID (SID) and Destination ID (DID). This performance monitor counts the number of received (RX_COUNT) and transmitted (TX_COUNT) words in frames.
- Filter-based monitors can measure the amount of particular subset of total traffic. You use filters to specify the traffic type in which you are interested. There is a set of standard filters, such as SCSI Read commands, SCSI Write commands, SCSI traffic frames, and IP traffic frames. In addition, you can set up custom filters to gather the specific statistics suitable to your needs.
- ISL monitors measure the traffic across an inter-switch link (ISL) to all reachable destination domains. Then, you can see easily which destination domain consumes the highest amount of bandwidth.
- Top Talkers monitoring is a feature that was introduced in Fabric OS v6.0.0. These monitors can identify the SID/DID pairs that consume the most bandwidth. You can use the Top Talkers data to re-route the traffic to less busy ports, in case the original ports are becoming overloaded. You can also use the Top Talkers information to identify the SID/DID pairs that might require higher priority in order to have the adequate Quality of Service (QoS).

Attention: ISL monitors cannot be used when Top Talkers monitoring is installed. In addition, the new 8 Gbps products (SAN24B-4, SAN40B-4, SAN80B-4, SAN384B, SAN768B and 3758-B32) do not support ISL monitors.

7.1.9 Extended Fabrics

Normally, Fibre Channel standard allows up to 10 km Fibre Channel cable lengths in the fabric. The Extended Fabrics licensed feature provides SAN fabric extension to much longer distances. By optimally utilizing the internal switch buffers, it is possible to achieve ISLs at distances up to 500 km. Check with the vendor as to the exact distances that are supported.

7.1.10 ISL Trunking

You use this feature to enable configuration of multiple ISL connections into trunks, providing a much increased bandwidth level. You can establish the ISL trunk between any two supported 2, 4, or 8 Gbps switches, provided that both switches have this license installed. If an 8 Gbps capable switch is connected to a 2 or 4 Gbps switch, the ISL trunk operates at the lower speed. With 8 Gbps capable switches on both ends, you can establish trunks with up to eight ports, and the maximum bandwidth is up to 64 Gbps.

7.1.11 Integrated Routing

You can install this licensed feature on the new 8 Gbps capable products SAN384B, SAN768B, SAN80B-4, and SAN40B-4. It adds Fibre Channel Routing (FCR) support. You can configure the 8 Gbps ports as native EX_ports, thus you do not need to add a routing blade or use the SAN18B-R if you want to set up FCR. Additionally, this feature provides twice the bandwidth of existing FCR solutions when using 8 Gbps ports on both sides.

In the case of a SAN768B or SAN384B with a routing blade, you cannot use both the native EX_ports (available through the Integrated Routing licensed feature) and EX_ports on the routing blade. Only the VEX_ports can be used in conjunction with Integrated Routing EX_ports.

7.1.12 High Performance Extension over FCIP/FC

This feature contains the capabilities formerly included in FCIP Services license. It also provides additional features, such as FC-Fastwrite and IPSec. The license can be applied to the products supporting FCIP:

- ► SAN04B-R
- SAN18B-R
- SAN06B-R
- ► FCR Blade (FR4-18i)
- ► FCR Blade (FX8-24)

7.1.13 FICON Management Server

The FICON Management Server license is required to set up FICON CUP function. IBM/Brocade switches that support FICON CUP can appear as control units to IBM System z servers. FICON CUP is the protocol used by the management software on IBM System z to perform in-band management of the switches.

7.2 Using Web Tools to administer licenses

Web Tools provides all the functions that are required to administer licensed features. You can display a list of installed licenses, install additional licenses, and remove those licenses that are no longer required. In this section, we show only some basic tasks, such as verification of licensed ports, and a list of installed licenses.

7.2.1 Using Web Tools to check licensed ports

The Web Tools Port Administration window contains a column to tell whether a port is licensed. To display the Port Administration window, click **Port Admin**, as shown in Figure 7-1.

¹¹ IBM_SAN80B_217 - We	b Tools
<u>Manage R</u> eports Monitor	Tools
Tasks 🔷 🎗	Status O Temp O Power O Fan Reacon
Manage	Logical Switch 128 💌
🖪 Switch Admin	Switch View
Port Admin	
🙀 Fabric Watch	
Monitor	
Marken Performance Monit	
III Name Server	Switch Events, Information

Figure 7-1 Web Tools: Launching the Port Administration window

IBM_SAN80B_217 - Port	t Administratic	n				_ 🗆 ×
					Show Bas	sic Mode
FC Ports						
FC Ports Explorer	View Details	Rename	Edit Confid	uration Ena	ble Disable	
1(IBM_SAN80B_217)	:					
— 🖲 Port 0	Persistent E	nable Pers	istent Disable	Enable <u>T</u> run	king	
- 🖲 Port 1	Diochlo Trur				Bort Susion	
— 🖲 Port 2	E Disable trui				Port Swap	
— 🕑 Port 3	Re-Authenti	cate <u>Q</u> oS	Enable G	oS Disable F-	Port Trunking	
Port 4						
- 🕑 Port 5	.QOS Status	Controllable	Licensed	Trunking Ena	NPIV Enabled	Additic
Port 6	Enabled	Yes	Yes	true	true	-
Port /	Enabled	Yes	Yes	true	true	
Port 8	Enabled	Yes	Yes	true	true	100
Port 9	Enabled	Yes	Yes	true	true	
Port 10	Enabled	Yes	Yes	true	true	
- 🕑 Port 11	Enabled	Yes	Yes	true	true	
- Port 12	Enabled	Yes	Yes	true	true	
- 🕑 Port 13	Enabled	Yes	Yes	true	true	
- 🖲 Port 14	Enabled	Yes	Yes	true	true	(Trunk
- 🕑 Port 15	Enabled	Yes	Yes	true	true	(upstri
- 🕑 Port 16	Enabled	Yes	Yes	true	true	
📃 🕘 Port 17	Enabled	Yes	Yes	true	true	
Port 18	Enabled	Yes	Ver	true	true	_
			1000000			
Mode: Advanced Fre	e Professional M	anagement Too	10.64.210	.217 FID 128	User: admin	Role: admin

The column that shows the licensed ports displays in advanced mode (see Figure 7-2).

Figure 7-2 Port Administration window showing licensed ports

7.2.2 Installed licenses

To see the licenses that are installed on the switch, open the Switch Administration window by clicking **Switch Admin** task, as shown in Figure 7-3.

¹⁴ TIBM_SAN80B_217 - We	b Tools
<u>M</u> anage <u>R</u> eports M <u>o</u> nitor	Tools
Tasks 🔷 🌋	🖡 🔾 Status 📔 🔿 Temp 🔷 Power 🔷 Fan 📗 🦹 Beacon
Manage	
Zone Admin	Logical Switch 128 🔻
Switch Admin	Switch View
Port Admin	
BB Fabric Wetch	
www.Fabric watch	* 🗖 🗖 🚔 👋 🖞 🖞 🖓
www.rabric.watch	
Monitor	
Monitor Image: Second constraints	

Figure 7-3 Web Tools - launching Switch Administration window

When the Switch Administration window displays, click the **License** tab, as shown in Figure 7-4.

CONAME: IBM_SAN80B_217	DomainID: 1(0x1) WWN: 10:00:00:05:1e:09:97:01	Mon Aug 03 2009 01:42:24 GMT+
ritch Network Firmware Download	License User Trunking	
cense Administration		
icense Key	Feature(s)	Expiry Date
R9SceSRdRTSATds	Extended Fabric	NA
CYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGE	B7BNH Performance Monitor,Trunking,Adaptive Network	king NA
SMN49m7ATRVVZEXXZEY9NM4N7atTY4rHE	3SBLN 8 Gig FC	NA
QezcSebScRf0dk	Fabric	NA
cS9QzbR99cdVARs	Integrated Routing	NA
cS9QzbR99cdXARu	Second Ports on Demand license - additional 16	port upgrade NA
cS9QzbR99cfTARs	FICON_CUP	NA
cS9QzbR99ctTAR6	First Ports on Demand license - additional 16 port	t upgrade NA
cS9QzbR99edTARs	Fabric Watch	NA
AXQF94VVtFYXF1ZfgVVmPLBR7HP9GFVVfKB	A7NJ Enhanced Group Management	NA

Figure 7-4 Installed licenses on this switch

In our example, we see the list of licenses installed on our switch.

7.3 Tips on solving licensing issues

Various things can go wrong with licensing keys. Switch or mainboard replacement, key mismatches, and typographical errors are the most common issues.

There are some simple steps you can take to solve issues with licensing keys:

1. A Switch/Mainboard was replaced, then the new Switch/Mainboard is missing licenses because licenses are bound to a switch's WWN.

Note the old and the new Switch/Mainboard WWN and use the following website to generate the keys:

https://www-912.ibm.com/FruLicenseRequestClient/

If this does not work, you will have to ask a Brocade authorized representative to open a ticket at Brocade.

Brocade will then transfer the license key from the old WWN to the new WWN.

2. You have received a transaction key and you made a typographical error when generating the license key.

Note the correct WWN and the incorrect WWN and ask a Brocade representative to open a ticket at Brocade.

Brocade will transfer the license key from the incorrect WWN to the correct one.

3. You received a transaction key and successfully generated the license key but lost the license key before you activated it on the switch.

Note the switch type and WWN and ask a Brocade representative to open a ticket at Brocade.

Brocade can check their database and see which licenses were activated for this switch WWN.

8



Web Tools

In this chapter, we discuss the features of Web Tools in greater detail. Although the Web Tools display has changed over time, the tools still have the same basic look and feel to them as they had in previous versions.

8.1 Web Tools walk-through

In this chapter, we describe the features of Web Tools in detail. However, before we begin that discussion, in this section we provide some basic information about getting started with Web Tools.

8.1.1 Web Tools, the EGM license, and DCFM

Beginning with Fabric OS version 6.1.1, Web Tools functionality is tiered and integrated with DCFM. If you are migrating from a Web Tools release prior to Fabric OS version 6.1.1, this might impact how you use Web Tools.

A Web Tools license is not required, and a basic version of Web Tools is available for free. Additional functionality can be added by obtaining the Enhanced Group Management (EGM) license. Table 8-1 compares Basic Web Tools features to Web Tools with the EGM license. The EGM license is only for 8 Gbps platforms, such as the IBM SAN768B, SAN384B enterprise-class platforms, and the IBM SAN80B-4, SAN40B-4 and SAN24B-4 switches. For non-8 Gbps platforms, all functions are available without the EGM license.

Feature	Basic Web Tools	Web Tools with EGM license
Active Directory Support	Yes	Yes
AD Context Switching	No	Yes
AD Filtered Views	Yes	Yes
Admin Domain Management	No	Yes
AG Management	Yes	Yes
Analyze Zone Config	No	No
Basic Zoning and TI Zoning	Yes	Yes
Blade Management	Yes	Yes
Cloning a Zone	No	Yes
Config Upload/Download	Yes	Yes
Convenience Function from Tools Menu	No	No

Table 8-1 Web Tools features enabled by the EGM license

Feature	Basic Web Tools	Web Tools with EGM license
Device Accessibility Matrix	No	No
Easy to configure iSCSI Wizard	Yes	Yes
Extended Fabric Management	No	Yes
F_Port Trunk Management	No	Yes
Fabric Events	No	No
Fabric Summary	No	No
Fabric Tree	Yes	Yes
FCIP Tunnel Configuration	No	No
FCIP Tunnel Display	Yes	Yes
FCR Management	Yes	Yes
FCR Port Configuration	Yes	Yes
FICON CUP Tab	No	Yes
FRU Monitoring	Yes	Yes
High Availability	Yes	Yes
IP Sec Policies	Yes	Yes
ISL Trunk Management	No	Yes
ISL Trunking Information	Yes	Yes
License Management	Yes	Yes
Long Distance	No	Yes
Logical Switch Context Switching	No	Yes
PDCM Matrix	No	Yes
Port Administration	Yes	Yes
Print Zone Database Summary	No	No
RBAC	Yes	Yes

Feature	Basic Web Tools	Web Tools with EGM license
Routing and DLS Configuration	No	Yes
Security Policies Tab (such as ACL)	Yes	Yes
Switch Info Tab	Yes	Yes
Switch Status	Yes	Yes
Switch View right-click options	Yes	Yes
Trace Dump	Yes	Yes
USB Management	Yes	Yes
User Management	Yes	Yes
Verify and troubleshoot accessibility between devices	Yes	Yes

Also beginning with Fabric OS version 6.1.1, some Web Tools capabilities are moved from Web Tools to DCFM. Table 8-2 summarizes these changes.

The functionality that was moved from Web Tools into DCFM is applicable to both DCFM Professional and DCFM Enterprise.

Function	Web Tools 6.1.0	DCFM	Comments
Add Un-Zoned Devices	Zone Admin	Configure → Zoning Reverse Find in the Zoning dialog provides the view of the zoned and unzoned devices in the fabric if all zone members are selected for Find.	

Table 8-2 Web Tools functionality moved to DCFM

Function	Web Tools 6.1.0	DCFM	Comments
Analyze Zone Config	Zone Admin	 Configure → Zoning Reverse Find in the Zoning dialog provides the view of the zoned and unzoned devices in the fabric if all zone members are selected for Find. Device Tree and Topology: Connected End Devices - Custom Display from the top level in the main frame provides the device tree and topology view for all the zoned devices if all zones are selected in the active zone configuration. 	
Define Device Alias	Zone Admin	Configure → Zoning	
Device Accessibility Matrix	Zone Admin	Configure → Zoning The Compare dialog provides the Storage-Host and Host-Storage view in a tree representation that is comparable to the Device Accessibility Matrix when all devices are selected.	

Function	Web Tools 6.1.0	DCFM	Comments
Fabric Events	Monitor → Fabric Events	Monitor \rightarrow Logs \rightarrow Events?	
Fabric Summary	Reports → Fabric Summary	Monitor → Reports → Fabric Summary Report?	
FCIP Tunnel Configuration	Port Admin Module; GigE Tab	Configure → FCIP Tunnel	Viewing FCIP tunnels is still supported in Web Tools 6.1.1, but New, Edit Config, and delete are only available in DCFM.
GigE Ports Interface	Port Admin Module; GigE Tab	Configure → FCIP Tunnel	
GigE Ports Route	Port Admin Module; GigE Tab	Configure → FCIP Tunnel	
Non-local switch ports display in zoning tree	Zone Admin Admin Domain Switch Admin → DCC Policies Performance Monitoring	Configure → Zoning	In Web Tools, non-local switch port id/WWN can be added using text box.
Remove Offline or Inaccessible Devices	Zone Admin	Configure → Zoning Replace/Replace All zone members by selecting the offline devices from the zone tree. Offline devices have an unknown overlay badge with good visibility.	
Zone database summary print	Zone Admin	Configure → Zoning Zoning report for both online and offline database.	

8.1.2 System requirements

Web Tools requires that your browser conform to HTML v4.0, JavaScript v1.0, and Java plug-in v1.6.0_16 or higher.

Brocade has certified and tested Web Tools on the platforms shown in Table 8-3.

Operating system	Browser
Windows 7	Internet Explorer 7.0/8.0
Windows Server 2008 Standard	Internet Explorer 7.0/8.0
Windows Vista Business	Internet Explorer 7.0/8.0
RedHat Enterprise Server 5 Advanced Platform	Firefox 2.0
SUSE Linux Enterprise Server 10	Firefox 2.0/3.0
Linux Red Hat AS 3.0	Firefox 2.0
Linux Red Hat AS 4.0	Firefox 2.0/3.0
Windows 2000	Firefox 2.0, Internet Explorer 6.0
Windows 2003 Server, SP2	Firefox 2.0/3.0, Internet Explorer 7.0/8.0
Windows XP, SP3	Firefox 2.0/3.0, Internet Explorer 7.0/8.0
Windows XP, SP2	Firefox 2.0, Internet Explorer 7.0/8.0
Solaris 10 (SPARC only)	Firefox 2.0
Solaris 9 (SPARC only)	Firefox 2.0

Table 8-3 Supported Operating Systems and Browsers

For Windows systems, a minimum of 256 MB of RAM for fabrics comprising up to 15 switches, 512 MB of RAM for fabrics comprising more than 15 switches, and a minimum of 8 MB of video RAM are preferable. A DCX with a fully populated FC8-64 blade requires a minimum of 512MB RAM.

Setting the refresh frequency for Internet Explorer

Correct operation of Web Tools with Internet Explorer requires specifying the appropriate settings for browser refresh frequency and process model. Refresh the browser pages frequently to ensure the correct operation of Web Tools:

- 1. Click **Tools** \rightarrow **Internet Options** in the browser.
- 2. Click the General tab and click Settings under "Temporary Internet Files."
- 3. Click **Every time I visit the webpage** under "Check for newer versions of stored pages," as shown in Figure 8-1.

Internet Options	
Connecte a fear fear of a strengt	
Temporary Internet Files and History Settings	
Temporary Internet Files Internet Explorer stores copies of webpages, images, and media for faster viewing later. Check for newer versions of stored pages:	Configure your browser to
C Every time I start Internet Explore	of stored pages every visit
C Automatically	to the page
C Never	
Disk space to use (8 - 1024MB): 50 - 50 - 50	
Current location:	
C:\Users\Administrator\AppData\Local\Microsoft\Windows\Tempo Internet Files\	
Move folder View objects View files	
History Specify how many days Internet Explorer should save the list of websites you have visited. Days to keep pages in history: 20 🛓	
OK Cancel	

Figure 8-1 Configuring Internet Explorer

Deleting temporary Internet files used by Java applications

For Web Tools to operate correctly, you must delete the temporary Internet files used by Java applications:

- 1. From the Control Panel, open Java.
- 2. Click the General tab and click Settings.
- 3. Click **Delete Files** to remove the temporary files used by Java applications (see Figure 8-2).
4. Click **OK** on the confirmation dialog box.

You can clear the Trace and Log files check box if you want to keep those files.

- 5. Click OK.
- 6. On the Java Control Panel, click **View** to review the files that are in the Java cache. (If you have deleted all the temporary files, the list is empty).

Temporary Files Settings X
Veen temporary files on my computer
Vecp comparary nes on my comparenz
Location
Select the location where temporary files are kept:
Administrator\AppData\LocalLow\Sun\Java\Deployment\cache Change
Disk Space Select the compression level for JAR files: None Set the amount of disk space for storing temporary files: MB
Delete Files Restore Defaults
OK Cancel

Figure 8-2 Temporary Internet Settings dialog box

8.1.3 Java installation on the workstation

The Java Plug-in must be installed on the workstation. If you attempt to open Web Tools without any Java Plug-in installed:

- Internet Explorer automatically prompts and downloads the proper Java Plug-in.
- ► Firefox downloads the most recently released Java Plug-in.

If you attempt to open Web Tools with an earlier version Java Plug-in installed:

- Internet Explorer might prompt for an upgrade, depending on the existing Java Plug-in version.
- ► Firefox uses the existing Java Plug-in.

Installing the JRE on your Linux client workstation

Follow these steps:

1. Locate the JRE on the Internet, at the following URL:

http://java.sun.com/products/archive/j2se/5.0_13/index.html

Attention: This URL points to a non-IBM website and is subject to change without notice.

- 2. Select JRE 5.0 Update 13.
- 3. Follow the instructions to install the JRE.
- 4. Create a symbolic link: From this location:

\$FIREFOX/plugins/libjavaplugin_oji.so

To this location:

\$JRE/plugin/\$ARCH/ns600/libjavaplugin_oji.so

Installing the Java plug-in on Windows

Follow these steps:

- 1. Click Start Menu \rightarrow Control Panel and select the Java Plug-in Control Panel.
- 2. Click the About tab.
- 3. Determine whether the correct Java Plug-in version is installed:
 - If the correct version is installed, Web Tools is ready to use.
 - If no Java Plug-in is installed, point the browser to a switch running Fabric OS v5.2.0 or later to install JRE 1.6.0. Web Tools guides you through the steps to download the proper Java Plug-in.
 - If an outdated version is currently installed, uninstall it, reboot your computer, re-open the browser, and enter the address of a switch running Fabric OS v5.2.0 or later to install JRE 1.6.0. update16. Web Tools guides you through the steps to download the proper Java Plug-in.

8.1.4 Java plug-in configuration

If you are managing fabrics with more than 10 switches or 1000 ports, or if you are using the iSCSI Gateway module extensively, increase the default heap size to 256 MB to avoid out-of-memory errors.

If you are using a Mozilla family browser (Firefox, Netscape, and so on), set the default browser in the Java control panel.

The following procedures instruct you in increasing the default heap size in the Java Control Panel and in setting the default browser.

Configuring the Java plug-in for Windows

Follow these steps:

- 1. From the Start menu, select **Control Panel** \rightarrow **Java**.
- 2. Click the Java tab (see Figure 8-3).



Figure 8-3 Java Control Panel

3. In the section Java Applet Runtime Settings, click View.

The Java Applet Runtime Settings dialog box displays (Figure 8-4).

Java Runtime version:	,		1
Product Name	Version	Location	Java Runtime Parame
JRE	1.6.0_05	C:\Program Files (x86)	
JRE	1.6.0_07	C:\Program Files (x86)	
JRE	1.6.0_13	C:\Program Files (x86)	
J			

Figure 8-4 Java Runtime Settings

4. Double-click in the Java Runtime Parameters field and type the following information to set the minimum and maximum heap size:

-Xms256m -Xmx256m

In this example, the minimum and maximum sizes are both 256 MB.

- 5. Click OK.
- 6. Click Apply to apply your settings and close the Java Control Panel.

Configuring the Java plug-in for Mozilla family browsers

Follow these steps:

- 1. From the Start menu, select **Control Panel** \rightarrow **Java**.
- 2. Click the **Advanced** tab and expand the **Default Java for browsers** option (Figure 8-5).

🛃 Java Control Panel	. 🗆 🗙
General Update Java Security Advanced	
Settings Default Java for browsers Default Java for browsers Microsoft Internet Explorer Mozilla family District Creation JNLP File/MIME Association DISTRE Auto-Download Security Miscellaneous	
OK Cancel A	pply

Figure 8-5 Default Java for browsers option

- 3. Select Mozilla family and click OK.
- 4. Click Apply to apply your settings and close the Java Control Panel.

8.1.5 Value line licenses

If your fabric includes a switch with a limited switch license and you are opening Web Tools using that switch, if the fabric exceeds the switch limit indicated in the license, Web Tools allows a 30-day "grace period" in which you can still monitor the switch through Web Tools. However, Web Tools will display warning messages periodically.

These messages warn you that your fabric size exceeds the supported switch configuration limit and tells you how long you have before Web Tools will be disabled. After the 30-day grace period, you will no longer be able to open Web Tools from the switch with the limited switch license if that switch is still exceeding the switch limit.

Web Tools is part of the Fabric OS of a switch. When you open Web Tools on a switch, you can manage other switches in the fabric that have lower or higher firmware versions. It is important to note that when accessing these switches you are opening the remote switch's version of Web Tools, and the functionality available for those switches might vary.

8.1.6 Opening Web Tools

You can open Web Tools on any workstation with a compatible Web browser installed. For a list of Web browsers compatible with Fabric OS v6.4.0, see Table 8-3 on page 187 Table 3. Web Tools supports both HTTP and HTTPS protocol.

1. Open the Web browser and type the IP address of the device in the Address field:

```
http://10.77.77.77
```

or

https://10.77.77.77

2. Press Enter.

A browser window opens to open Web Tools. A Login dialog box opens. See "Logging in" on page 194, for more information. If you are using Firefox, the browser window is left open. You can close it anytime after the Login dialog box displays. If you are using Internet Explorer, the browser window automatically closes when the login dialog box displays. When you have successfully logged in the Web Tools interface opens (see Figure 8-6). If you have installed EZSwitchSetup on your workstation, the EZSwitchSetup Switch Manager displays the first time you access the device. EZSwitchSetup provides an easy to use wizard interface that can be used to simplify the initial setup procedure for smaller switches. See the EZSwitchSetup Administrator's Guide for information about the EZSwitchSetup interface.

If you want to use Web Tools instead of EZSwitchSetup, click **Advanced Management** in the lower-left corner of the window to open the Web Tools interface. This section describes only the Web Tools interface.

witch - Web Tools							
Manage Reports Monitor Tools							
Tasks 👘 🖄 🖉 🗛 👘							
Vienne Vienne	Power Fan A Beacon Each Legend Fan A Beacon						
Admin Domain ADD	Admin Domain ADD						
Zone Admin							
Switch Admin Switch View	Switch View						
Port Admin							
🖳 Admin Domain							
WY Fabric Watch							
Monitor 🛪							
22 Derfermanes Meniter							
Switch Events, Information	- @						
Name Server Switch Events Switch	Information						
Other 🌣 Last updated at	Wed Nov 03 2010 00:37:14 GMT+00:00						
Telpet/SSH Client							
Name	switch						
Status	Healthy						
Fabric OS version	v6.4.1						
Domain ID	5(0x5)						
VWWN	10:00:00:05:1e:b0:81:80						
Type	76.7						
Fabric Tree Role	Subordinate						
E Ethernet							
View by: Name Ethernet IPv4	10.18.228.18						
Ethernet IPv4 netmask	255.255.255.0						
Ethernet IPv4 gateway	10.18.228.1						
B5000 76 Ethernet IPv6	None						
- 📼 IBM 2498 R06 📄 FC							
BM SAN384B 27 IPFC IPv4	None						
SAN32B-E4-1 IPFC IPv4 netmask	None						
SAN32B-E4-2							
switch Effective configuration	IEM RB						
Segmented Switches							
Number of switches: 7							
	Free Professional Management Tool 10.18.228.18 AD0 User: admin Role: admin						

Figure 8-6 Web Tools interface

Logging in

When you use Web Tools, you must log in before you can view or modify any switch information. This section describes the login process.

Prior to displaying the login window, Web Tools displays a security banner (if one is configured for your switch), which you must accept before logging in. The security banner displays every time you access the switch.

When you are presented with the login window, you must provide a user name and a password. Your home Admin Domain is automatically selected. You can choose to log into an Admin Domain other than your home domain:

1. Click Run on the signed certificate applet.

If you select the check box **Always trust content from this publisher**, the dialog box is not displayed when you open Web Tools again, as shown in Figure 8-7.

Warning - Secu	rity	×
The applic Do you wa	ation's digital signature has been verified. nt to run the application?	Java"
Name:	com.brocade.web.secsan.LoginApplet	
Publisher: From:	Brocade Communications Systems, Inc. http://10.32.151.116	
🔽 Always tr	rust content from this publisher.	
	Run	Cancel
The o	digital signature has been validated by a trusted source. More 1	information

Figure 8-7 Signed applet certificate

- 2. Click **OK** in the security banner window, if one displays.
- 3. In the login dialog box, as shown in Figure 8-8, type your user name.
- 4. Type the password.

If your current password has expired, you must also provide a new password and confirm the new password.

5. Click **OK**.

Please Login
Please enter user name and password.
Resource 10.64.210.130
User Name
Password
QK Cancel Options >>

Figure 8-8 Login dialog box

Logging in to a Virtual Fabric

If you are logging in to a platform that is capable of supporting Virtual Fabrics, the log in dialog box provides the option of logging in to a virtual fabric. The following platforms support virtual fabrics:

- IBM SAN768B and IBM SAN387B
- IBM SAN80B
- IBM SAN40B
- 1. Select **Options** to display the Virtual Fabric options.

You are given a choice between **Home Logical Fabric** and **User Specified Virtual Fabric** as shown in Figure 8-9. Home Logical Fabric is the default. This option logs in to the physical switch, and displays the physical switch configuration. It is given a default fabric ID number of 128.

Please Login
Please enter user name and password.
Resource 10.64.210.210
User Name
Password
Virtual Fabric
O Home Logical Fabric
User Specified Logical Fabric
QK Cancel Options <<

Figure 8-9 Virtual Fabric login option

- 2. Log in to a logical fabric:
- ► To log in to the home logical fabric, select the **Home Logical Fabric** radio button and click **OK**.
- To log in to a logical fabric other than the home logical fabric, select the User Specified Logical Fabric radio button, type in the fabric ID number, and click OK.

Logging in to an Admin Domain

If you are logging in to a platform that is capable of supporting Admin Domains, the log in dialog box provides the option of logging in to an Admin Domain.

You do not have an Admin Domain option if the Access Gateway or Interoperability mode is enabled. Admin Domains and Virtual Fabrics are mutually exclusive. Follow these steps:

1. Select **Options** to select an Admin Domain other than your default home domain.

You are given a choice of **Home Domain** (the default), or **User Specified Domain**, as shown in Figure 8-10.

Please Login
\sum Please enter user name and password.
Resource 10.64.210.130
User Name
Password
Admin Domain
Home Domain
O User Specified Domain
QK Cancel Options <<

Figure 8-10 Login dialog box with Admin Domain options

- 2. Log in to an Admin Domain:
- To log in to the home domain, select the Home Domain radio button and click OK.
- To log in to an Admin Domain other than the home domain, select the User Specified Domain radio button, type in the Admin Domain name or number, and click OK.

If the user name or password is incorrect, a dialog box displays indicating an authentication failure.

If you entered valid credentials, but specified an invalid Admin Domain, a dialog box displays from which you can choose a valid Admin Domain or click **Cancel** to log in to your home domain, as shown in Figure 8-11.

nvalid Admin Domain 🔰 🚺	<
You have entered an invalid admin domain. Please select one of the domains listed below. If you click Cancel, you will login to HOME Domain.	
AD0 👻	
AD0	
Physical Fabric	

Figure 8-11 Invalid Admin Domain dialog box

Logging out

You can end a Web Tools session either by logging out or by closing the **Switch Explorer** window. You might be logged out of a session involuntarily, without explicitly clicking the **Logout** button, under the following conditions:

- A physical fabric administrator changes the contents of your currently selected Admin Domain.
- ► Your currently selected Admin Domain is removed or invalidated.
- Your currently selected Admin Domain is removed from your Admin Domain list.
- You initiate a firmware download from the Web Tools Switch Administration window. In this case, you are logged out a few minutes later when the switch reboots.
- Your session times out.

Role-Based Access Control

Role-Based Access Control (RBAC) defines the capabilities that a user account has based on the role the account is assigned. For each role, there is a set of pre-defined permissions on the jobs and tasks that can be performed on a fabric and its associated fabric elements.

When you log in to a switch, your user account is associated with a pre-defined role. The role that your account is associated with determines the level of access you have on that switch and in the fabric. Following is a description of each of the roles:

► admin:

You have full access to all of the Web Tools features.

► operator:

You can perform any actions on the switch that do not affect the stored configuration.

► securityadmin:

You can perform actions that do not affect the stored configuration.

► switchadmin:

You can perform all actions on the switch, with the following exceptions:

- You cannot modify zoning configurations.
- You cannot create new accounts.
- You cannot view or change account information for any accounts. You can only view your own account and change your account password.

zoneadmin:

You can only create and modify zones.

► fabricadmin:

You can do everything the Admin role can do except create new users.

basicswitchadmin:

You have a subset of Admin level access.

► user:

You have non-administrative access and can perform tasks such as monitoring system activity.

Session management

A Web Tools session is the connection between the Web Tools client and its managed switch. A session is established when you log in to a switch through Web Tools. When you close Switch Explorer, Web Tools ends the session.

A session remains in effect until one of the following conditions happens:

- You log out.
- ► You close the Switch Explorer window.
- The session ends due to inactivity (time out).

A session automatically ends if no information was sent to the switch for more than two hours. Because user key strokes are not sent to the switch until you apply or save the information, it is possible for your session to end while you are entering information in the interface. For example, entering a zoning scheme in the Zoning module does not require you to send information to the switch until you save the scheme.

Web Tools does not display a warning when the session is about to time out. If your session ends due to inactivity, all Web Tools windows become invalid and you must restart Web Tools and log in again.

Web Tools enables sessions to both secure and non-secure switches.

Access rights for your session are determined by your role-based access rights and by the contents of your selected Admin Domain. After you log in, you can change to a different Admin Domain at any time; however, you cannot change your role-based permissions.

Ending a Web Tools session

To end a Web Tools session, perform one of the following actions:

• Click Logout in Switch Explorer.

- ► Click the X in the upper-right corner of Switch Explorer window to close it.
- Close all open Web Tools windows.

Attention: If you click Logout in Switch Explorer, and Web Tools leaves the Temperature, Fan, Power, and the Switch status windows open, you must manually close them.

Requirements for IPv6 support

The following list provides requirements for Web Tools IPv6 support:

- In a pure IPv6 environment, you must configure DNS maps to the IPv6 address of the switch.
- The switch name is required to match the DNS name that is mapped to the IPv6 address.
- If both IPv4 and IPv6 addresses are configured, Web Tools uses the IPv4 address to launch the switch.
- Use a switch with v5.3.0 or higher firmware to manage a mixed fabric of IPv4 and IPv6 switches.
- Switches running on version 5.2.0 do not discover IPv6 address-only switches in the same fabric until the IPv4 address is configured.

Web Tools system logs

The log4J framework is used to write Web Tools log files.

Web Tools automatically creates the log directories the first time in this directory:

- <webtools> directory
- Web Tools switch support save directory with name format as <core switch name-IP address- Switch WWN>, which has the following files:
 - Log4j.XML This configuration file can be edited with a compatible XML editor if data at startup is to be collected.
 - webtools.log This log file for Web Tools is maintained at 2 MB size limit.
 - switchinfo.txt This file contains basic switch information such as switch name, FOS version, switch type, Ethernet configuration with IP, subnet mask, and gateway.

8.1.7 Requirements for the examples in this chapter

In the examples in this chapter, we use the SAN80B switch, SAN256B director, and SAN384B backbone to describe the Web Tools graphical user interface (GUI), although the functions are identical on any of the IBM System Storage SAN switch family. We use Fabric Operating System v6.4.1 (Fabric OS).

8.1.8 Overview of the Web Tools user interface

In this section, we provide a brief overview of the Web Tools GUI. To open the interface, start the Web browser if it is not already active and enter the switch name or IP address in the Location/Address field. Enter login credentials when prompted.

Tip: When managing a multi-switch fabric, enter the switch name or IP address of the switch with the largest port count and the highest firmware level.

The first thing you see when you log in to a switch with Web Tools is Switch Explorer, shown in Figure 8-12. Switch Explorer is divided into areas that provide access to, and information about, the switch and fabric.



Figure 8-12 Web Tools Switch Explorer window

As highlighted in Figure 8-12, the Web Tools window includes the following panels:

- Tasks panel: Includes shortcuts to the tasks that are available in the Web Tools interface. These tasks are also accessible through pull-down menu bar options.
- Fabric Tree panel: Lists the switches in the fabric. In our examples, we have two switches in the fabric. You can launch Web Tools for another switch by selecting its icon.
- Switch View panel: Displays a picture of the switch. You can click any of the switch ports to launch the Port Administration window.
- Switch Events, Information panel: Contains two tabs:
 - Switch Information tab, which displays basic information about the switch.
 - Switch Events tab, which shows the event log.

The window also includes an area with buttons, which we discuss in detail in 8.2, "Web Tools buttons" on page 204.

The information that is displayed in these panels differs depending on the switch that is accessed and the licenses that are applied. For example, Figure 8-13 shows the Tasks panel on a SAN80B (left), a SAN256B (center) and a SAN384B (right).



Figure 8-13 Tasks panel on SAN32B-3, SAN256B and SAN768B

The Switch View panel differs significantly between storage area network (SAN) switches (such as SAN80B-3) and SAN directors or backbones (SAN256B or SAN384B). For example, Figure 8-14 shows the Switch View panel for the SAN80B-3, and Figure 8-15 shows a very different panel for the SAN384B.



Figure 8-14 Switch View panel for a SAN80B



Figure 8-15 Switch View panel for the SAN384B

You access the Web Tools functions by clicking various items in the Web Tools window, such as:

- Web Tools buttons
- Tasks in the Tasks panel
- ► Ports in Switch View panel
- Elements in the Fabric View panel

In the remaining sections of this chapter, we describe the functions of Web Tools buttons and tasks in detail.

8.2 Web Tools buttons

Web Tools buttons display above the Switch View panel and provide quick access to hardware status and environmental information. The buttons use the following color coding:

- A green mark indicates an optimal state of components or parameters.
- A yellow mark is a sign of a degraded state.
- A red mark means that the monitored component is down.

Figure 8-16 shows the Web Tools buttons, which we explain in the sections that follow.



Figure 8-16 Web Tools buttons

8.2.1 Status button

The Status button is available on all IBM System Storage SAN Switch models. Clicking **Status** opens the Switch Health Report window, as shown in Figure 8-17, which shows the health of the switch.

Action								
2	Switch Health Repo	rt R	leport Tin	ne: Fri Jul 17 2009 10:32:28 GMT -				
🗁 Report								
• <u>Switch Health</u> 🗁 Port Detail	Switch Name:	ВM	_SAN38	4B_213				
• <u>Healthy</u>	IP Address:	10.64	4.210.213	3				
• <u>Marginal</u>	Switch State:	HEA	LTHY					
• <u>Faulty</u> • <u>All</u>	Duration (H:M): 17:44							
• <u>SAM</u>	Switch State Contribution	ntors	State	1				
	Power supplies monitor		HEALTHY					
	Temperatures monitor		HEALTHY					
	Fans monitor		HEALTHY					
	VWVN servers monitor		HEALTHY					
	Standby CP monitor		HEALTHY					
	Blades monitor		HEALTHY					
	Core Blades monitor		HEALTHY					
	Flash monitor		HEALTHY					
	Marginal ports monitor		HEALTHY					
	Faulty ports monitor		HEALTHY					
	Missing SFPs monitor		HEALTHY					
	All ports are healthy.							

Figure 8-17 SAN384B switch status view from Web Tools

From here, you can navigate to obtain information about the health of different ports on the switch. Under Port Detail, you can view the ports in *HEALTHY*, *MARGINAL*, and *FAULTY* status. Clicking **All** displays details about all the ports.

Figure 8-18 shows the details for just the healthy ports on a SABN80B, which is helpful information in understanding the port states.

Action Report Switch Health South Health Healthy	Port Detail Report Report Time: Fri Jul 17 2009 23:50:59 GMT Switch Name: IBM_SAN80B_217 IP Address: 10.64.210.217 Search Criteria: Healthy																	
• <u>All</u> • SAM	Port #	Туре	State	State Dur(H:M)			Port Errors						SFP Errors					
·					LFA	LSY	LSI	PER	INW	CRC	PSC	BLP	<u>STM</u>	SRX	<u>STX</u>	<u>SCU</u>	SVO	
	000 [0/0]	F_PORT	HEALTHY	0:57		-	-		-	-	-	-	-	-	-	-	-	
	008 [0/8]	F_PORT	HEALTHY	0:57	-	-	-		-	-	-	-	-	-	-	-	-	
	048 [0/48]	F_PORT	HEALTHY	0:57	-	-	-	-	-	-	-	-	-	-	-	-	-	
	056 [0/56]	F_PORT	HEALTHY	0:57	-	-	-	-	-	-	-	-	-	-	-	-	-	
	064 [0/64]	L_PORT	HEALTHY	0:57	-	-	-	-	-	-	-	-	-	-	-	-	-	
																		-

Figure 8-18 SAN80B Healthy Port Detail Report

The report view provides a full description of each of the columns. Information about this report is detailed in Table 8-4 for reference.

Error	Description and suggested action					
LFA (Link Loss)	Description: Number of link loss occurrences exceeded range for time period.					
	Action: Troubleshoot transmitters, receivers, and fibers, and verify that all cables connect properly.					
LSY (Sync Loss)	Description: Number of sync loss occurrences exceeded range for time period.					
	Action: Check for problems with the appropriate SFP and cable. If you continue to experience sync loss errors, troubleshoot your HBA and contact your support representative.					
LSI (Signal Loss)	Description: Number of signal loss occurrences exceeded range for time period.					
	Action: Troubleshoot transmitters, receivers, and fibers, and verify that all cables connect properly.					
PER (Protocol Error)	Description: Number of protocol errors exceeded range for time period.					
	Action: Check both ends of your connection, and verify that your cable and SFP are not faulty.					

Table 8-4 Port Detail Report: Error interpretation

Error	Description and suggested action
INW (Invalid Word)	Description: Number of invalid words exceeded range for time period.
	Action: Verify that your cable is not faulty and check both ends of your connection. Troubleshoot your SFP to verify that it is not faulty.
CRC (Invalid CRC)	Description: Number of invalid CRC errors exceeded range for time period.
	Action: Check your SFPs, cables, and connections for faulty hardware. Clean all optical hardware.
PSC (Port State)	Description: Port hardware state changed too often due to fabric reconfiguration.
	Action: All State Changes messages are informational. Respond to this message as is appropriate to the particular policy of the user installation.
BLP (Buffer Limited Port)	Description: Port buffer credit was not large enough.
	Action: Reset the buffer credit.
STM (SFP Temperature)	Description: SFP temperature is out of specifications.
	Action: Temperature-related messages usually indicate that you must replace the SFP.
SRX (SFP RX)	Description: SFP receive power is out of specification.
	Action: Replace the SFP.
STX (SFP TX)	Description: SFP transmit power is out of specifications.
	Action: If the current rises above the high boundary, you must replace the SFP.
SCU (SFP Current)	Description: SFP current is out of specifications.
	Action: If the current rises above the high boundary, you must replace the SFP.
SVO (SFP Voltage)	Description: SFP voltage is out of specifications.
	Action: Frequent messages indicate that you must replace the SFP.
-	Meaning: Monitoring value is within the threshold.
X	Meaning: Monitoring value is over the threshold.

You can display the same information at the Telnet prompt by entering the switchStatusShow command, as shown in Example 8-1.

IBM SAN384B 27:admin> switchstatusshow Switch Health Report Report time: 11/03/2010 11:33:05 AM Switch Name: IBM SAN384B 27 IP address: 10.18.228.27 SwitchState: HEALTHY Duration: 17:44 Power supplies monitor HEALTHY Temperatures monitor HEALTHY Fans monitor HEALTHY WWN servers monitor HEALTHY CP monitor HEALTHY Blades monitor HEALTHY Core Blades monitor HEALTHY Flash monitor HEALTHY Marginal ports monitor HEALTHY Faulty ports monitor HEALTHY Missing SFPs monitor HEALTHY All ports are healthy IBM SAN384B 27:admin>

Example 8-1 The switchStatusShow command output

Selecting **SAM** from the menu displays the SAM (Switch Availability Monitoring Report), as shown in Figure 8-19.

Action Report Switch Health Port Detail I Healthy I Marginal	SAM Re Switch N IP Addre	eport Fame: ess:	Report Ti IBM_SA 10.64.21	ime: Fri Jul 17 20 .N80B_217 0.217	009 17:47:35 GM	Т
• <u>Faulty</u> • <u>All</u> • SAM	Port #	Туре	<u>Total Up Time</u> (Percent)	<u>Total Down</u> <u>Time (Percent)</u>	<u>Down</u> <u>Occurrence</u> <u>(Times)</u>	<u>Total Offline</u> <u>Time (Percent)</u>
·	001 [0/1]	U	0	0	0	100
	002 [0/2]	U	0	0	0	100
	003 [0/3]	U	0	0	0	100
	004 [0/4]	U	0	0	0	100
	005 [0/5]	U	0	0	0	100
	006 [0/6]	U	0	0	0	100
	007 [0/7]	U	0	0	0	100
	009 [0/9]	U	0	0	0	100
	010 [0/10]	U	0	0	0	100

Figure 8-19 Extract from the SAM Report

8.2.2 Temp button

The Temp button changes color from green to show that all temperatures are within the defined limits or changes to yellow or red, depending on the policy thresholds.

Clicking **Temp** displays detailed temperature information. Figure 8-20 shows an example for a SAN384B chassis.

Thermal Concer Me	Clat	Otata	Continuedo	Febreelseit
mermai sensor No.		State	Centigrade	ranrennen
	1	Absent	22	04
2	2	OK	33	91
ა •	2	Ok	40	104
4	2	OK	28	82
5	2	OK	26	/8
6	2	Ok	28	82
7	2	Ok	40 ' V	104
8	2	Ok	26	78
9	4	Ok	28	82
10	4	Ok	35	95
11	4	Ok	36	96
12	4	Ok	39	102
13	5	Ok	28	82
14	5	Ok	36	96
15	5	Ok	35	95
16	5	Ok	38	100
17	3	Ok	31	87
18	3	Ok	27	80
19	3	Ok	32	89
20	3	Ok	28	82
21	6	Ok	32	89
22	6	Ok	27	80
23	6	Ok	32	89
24	6	Ok	29	84
25	7	Ok	35	95
	7	Ok	41	105
20	7	Ok	28	82
21	7	OK	20	80
20	7	Ok	42	100
23	ر ٥	OK	43	103
30	0	Ok	30	90
31	0	OK	39	102
32	8	OK	31	87
33	8	Ok	29	84
34	8	Ok	30	86
35	8	Ok	40	104
36	8	Ok	28	82

Figure 8-20 SAN384B Temperature status window

To display similar information at a Telnet command line, issue the **tempShow** command as shown in Example 8-2.

Example 8-2 SAN384B tempShow output

IBM_SAN	384B_21	3:admin>	tempShow	
Sensor	Slot	State	Centigrade	Fahrenheit
ID				
	======	=======		
1	1	Absent		
2	2	0k	33	91
3	2	0k	40	104
4	2	0k	28	82
5	2	0k	26	78
6	2	0k	28	82
7	2	0k	40	104
8	2	0k	26	78
9	4	0k	28	82
10	4	0k	35	95
11	4	0k	36	96
12	4	0k	39	102
13	5	0k	28	82
14	5	0k	36	96
15	5	0k	35	95
16	5	0k	38	100
17	3	0k	31	87
18	3	0k	27	80
19	3	0k	32	89
20	3	0k	28	82
21	6	0k	32	89
22	6	0k	27	80
23	6	0k	32	89
24	6	0k	29	84
25	7	0k	35	95
26	7	0k	41	105
27	7	0k	28	82
28	7	0k	27	80
29	7	0k	43	109
30	8	0k	36	96
31	8	0k	39	102
32	8	0k	31	87
33	8	0k	29	84
34	8	0k	30	86
35	8	0k	40	104
36	8	0k	29	84

8.2.3 Power button

The color of the Power button indicates the overall health of the power supply status. Clicking **Power** displays the window shown in Figure 8-21.

Power Sup	oply States fo	r Chassis	_ 🗆 ×
Power Suppl	State		
1	Ok		
2	Ok		

Figure 8-21 SAN348B power status

8.2.4 Fan button

If all conditions are normal according to the switch policy settings, the Fan button is green. Clicking **Fan** displays an informational window that describes the state of each fan, as shown in Figure 8-22.

Fan No. State Speed (RPM) 1 Ok 1818 2 Ok 1791				
1 Ok 1818 2 Ok 1791	Fan No.	State	Speed (RPM)	
2 Ok 1791	1	Ok	1818	
	2	Ok	1791	

Figure 8-22 SAN384B fan status

You can gather the same information from a Telnet command line by entering the **fanShow** command as shown in Example 8-3.

Example 8-3 SAN384B fanShow command

IBM_	Sł	1038	34B_2	213 : adm	nin>	> fanS	Show
Fan	1	is	0k,	speed	is	1846	RPM
Fan	2	is	0k,	speed	is	1818	RPM

8.2.5 HA button

The SAN768B, SAN384B and SAN256B support High Availability (HA) features. The color of the HA button indicates the overall high availability status of the switch. This button enables you to perform tasks such as CP failover or synchronization services on the CP.

Clicking **HA** launches the High Availability window shown in Figure 8-23. The first tab shows the status of the services for the switch. Notice that in the upper, right corner, the HA Status field is green and displays the message Non-Disruptive Failover Ready. If the HA Status field was not green, then you need to synchronize the services before attempting to initiate failover. When the HA Status field shows Non-disruptive Failover Ready, a failover can be initiated without disrupting the fabric.

IBM_SAN384B_213 - High Avail	ability					
Chassis: ibm_dcx4s_213		HA Status: Non-Dis	ruptive Failover f	Ready		
Service CP						
E SwitchCP0 -S Ro Lo	witchCP0 ole: ocation:	Act	ive)			
St EV	tatus: vent: vent Time:	Hes Arb	althy itration			
-S Ra LLC	witchCP1 ole: position:	Star CP1	ndby			
St La Ev	tatus: ast Sync Time: vent Time:	Nor	1-Disruptive Failo	ver Ready		Detail
		Synchronize Ser	rvices Initiate	e Failover	Close	Refresh
[HA Admin started: Fri Jul 17 2009 11:1	16:54 GMT+00:00]					
High Availability	Free Professional	Management Tool	10.64.210.213	ADO U	lser: admin	Role: admin

Figure 8-23 SAN384B High Availability status

When you select **Synchronize Services** (shown in Figure 8-23), you are prompted with a warning to confirm your actions (as shown in Figure 8-24). Click **Yes**.

Warning	×	×
?	You are about to make the following change(s):	
	Synchronize Services	
	WARNING: All standby services will be synchronized with their active services.	
	Yes No Cancel	

Figure 8-24 Synchronize services warning

From the same panel in Figure 8-23, you can initiate the failover and monitor the status by clicking **Initiate Failover**. A warning displays, as shown in Figure 8-25.

Warning		×
?	You are about to make the following change(s):	
	Initiate Failover	
	WARNING: Initiate Failover will change the active CP. The current session will be invalidated. Do you want to proceed?	
	Yes No Cancel	

Figure 8-25 Initiate failover warning

After clicking **Yes**, failover is initiated. The HA status field changes to red with the message Non-Redundant Failover to indicate that failover is taking place. Just before it completes the failover, HA status shows yellow and indicates Disruptive Failover Ready. When failover is complete, the CPs have changed as shown in Figure 8-26, and the HA status returns to Non-Disruptive Failover Ready.

💽 IBM_SAN384B_213 - High Availabili	у _ 🗆 🗙
Chassis: ibm_dcx4s_213	HA Status: Non-Disruptive Failover Ready
Service CP	
SwitchCP1 SwitchCP1 SwitchCP1 SwitchCP1 Status Event: Event Status Locati Status Locat Status Locati Status Locat Statu	CP1 Active CP1 Heatiny Arbitration ime: CP0 Standby n: CP0 Non-Disruptive Failover Ready Detail ime: ime:
	Synchronize Services Initiate Failover Close Refresh
[HA Admin started: Fri Jul 17 2009 11:31:49	GMT+00:00]
High Availability	Free Professional Management Tool 10.64.210.213 AD0 User: admin Role: admin

Figure 8-26 SAN384B: Failover complete

Failover: A non-disruptive failover can take a few minutes to complete. It is possible that the connection to the switch might be lost during that time.

8.2.6 Beacon button

The beaconing function allows you to locate a switch physically by sending a signal to the specified switch, which causes a yellow LED pattern to flash from side to side on the switch. This flashing pattern makes the switch very easy to find.

To activate beaconing, click **Beacon** as shown in Figure 8-27.



Figure 8-27 SAN384B showing the Beacon button

You can toggle this function on and off when the switch is identified.

8.2.7 Switch Status Policy button

This enhancement in Web Tools 6.4.0 and later defines the policy for switch status notifications, and is used to define what constitutes a healthy switch status and also the parameters to define for marginal/down state of a switch. The entire switch status changes if any one of the parameter values changes. Figure 8-28 shows the Web Tools options available to define the switch status policy of a SAN384B.

	Down	Marginal
Power Supplies (02)	3	1
Femperature (032)	2	. 1
Fans (02)	2	1
Flash (01)	0	1
Marginal Ports (01800)	112	44
Faulty Ports (01800)	112	44
Missing SFPs (0288)	0	0
AWN (02)	0	1
CP (02)	0	0
Blades (08)	0	0
Core Blades (02)	0	0

Figure 8-28 Switch status policy

This is similar to defining the policy with command switchstatuspolicyset.

8.2.8 Legend button

Clicking **Legend** displays the explanation of color-coded status icons, as shown in Figure 8-29.

0	Healthy					
\triangle	Marginal					
•	Critical					
	Unmonitored					
	Close					

Figure 8-29 Web Tools legend

8.3 Name Server task

Select this task to display the Name Server table, as shown in Figure 8-30. The table includes all name server entries for the fabric, not just those name server entries that are local to the host domain. Each row in the table represents a different device that has logged in to the fabric. The Name Server table provides a good cross reference of WWPN/WWN and the port position on the switch. It also lists the zones of which the port is a member and, therefore, can be a very useful problem determination tool.

IBM_SAN256B_130 - Name Server										
Auto Refresh Auto-Refresh Interval: 15 seconds Number of Devices: 8										
Domain	Port #	Port ID	Port Type	Device Port WWN	Device Node WWN	Device Name	Capability	FDMI Host Name	WWN Company ID	
1(0x1)	111(0x6F)	016f00	N	50:06:06:98:04:50:c7:38	50:06:06:98:04:50:c7:39	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	105(0×69)	016900	N	50:06:06:98:04:50:c7:08	50:06:06:98:04:50:c7:09	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	109(0×6D)	016d00	N	50:06:06:98:04:50:c7:28	50:06:06:98:04:50:c7:29	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	107(0×6B)	016b00	N	50:06:06:98:04:50:c7:18	50:06:06:98:04:50:c7:19	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	110(0×6E)	016e00	N	50:06:06:98:04:50:c7:30	50:06:06:98:04:50:c7:31	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	106(0×6A)	016a00	N	50:06:06:98:04:50:c7:10	50:06:06:98:04:50:c7:11	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	104(0×68)	016800	N	50:06:06:98:04:50:c7:00	50:06:06:98:04:50:c7:01	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
1(0x1)	108(0×6C)	016c00	N	50:06:06:98:04:50:c7:20	50:06:06:98:04:50:c7:21	IPAddr: 0.0.0	NS		Brocade Communications Systems, Inc.	
	Detail View Accessible Devices Refresh Print Close									
Refreshin	Refreshing Name Server Information done Free Professional Management Tool 10.64.210.130 AD0 User: admin Role: admin									

Figure 8-30 SAN256B Name Server table (part 1 of 3)

The Name Server table contains the following parameters:

Domain	Domain ID of the switch to which the device is connected
Port #	Port number of the switch to which the device is connected
Port ID	The Fibre Channel Port address of the device (basically, a 24-bit hexadecimal number)

Port Type	Shows whether the port is a public loop port (NL) or a switch fabric port (N)
Device Port WWN	Worldwide name for the device port (WWPN)
Device Node WWN	Worldwide name of the device node (WWNN)
Device Name	Name of the device according to the SCSI INQUIRY, such as FCP or \ensuremath{IP}
Capability	The Name Server Capability
FDMI Host Name	Displays the FDMI host name of the device
WWN Company ID	Displays vendor company based on device WWN

Scroll to the right to see the remaining parameters in the Name Server table. Figure 8-31 displays the next set.

IBM_SAN256B_130 - Name Server										
Auto-Refresh Interval: 15 seconds Number of Devices: 8										
NPIV(or)Virtual(or)Physical	Host vs. Target	Member Of Zones	Member Of Aliases	FC4 Type	Class Of Service	Fabric Port Name	Fabric Port WWN	Port IP Address		
Virtual	Unknown(initiator/target)			FCP	3		20:6f:00:60:69:80:45:0c	N/A		
Virtual	Unknown(initiator/target)			FCP	3		20:69:00:60:69:80:45:0c	N/A		
Virtual	al Unknown(initiator/target) FCP 3 20:6d:00:60:69:80:45:0c N/A									
Virtual	Unknown(initiator/target)			FCP	3		20:6b:00:60:69:80:45:0c	N/A		
Virtual	Unknown(initiator/target)			FCP	3		20:6e:00:60:69:80:45:0c	N/A		
Virtual	Unknown(initiator/target)			FCP	3		20:6a:00:60:69:80:45:0c	N/A		
Virtual	Unknown(initiator/target)			FCP	3		20:68:00:60:69:80:45:0c	N/A		
Virtual	Unknown(initiator/target)			FCP	3		20:6c:00:60:69:80:45:0c	N/A		
					Detail Viev	Accessible [Devices Refresh	Print Close		
Refreshing Name Server Informationdone Free Professional Management Tool 10.64.210.130 AD0 User: admin Role: admin										

Figure 8-31 SAN256B Name Server table (part 2 of 3)

The remaining parameters include these:

NPIV or Virtual or Physical	Identifies type of device, virtual or physical
Host versus Target	Identifies type of device, host, or target
Member of Zones	List of zones to which the device belongs
Member of Aliases	List of aliases for this device
FC4 Туре	Fibre Channel FC4 layer types supported by device, such as FCP or IP
Class of Service	Class of service that the device supports
Fabric Port Name	Displays the name of the port
Fabric Port WWN	The worldwide name of the fabric port
Port IP Address	IP address of the fabric port

Figure 8-32 shows the final set of Name Server table parameters.

	I OIL II Made 000	Hard Address	Portinuex	Snareu Area	Device	Unit Type	woulder	nag -	 Sequence N 	wanuracturer	wanuracture
20:6f:00:60:69:80:45:0c	N/A	N/A	111(0×6F)	No							
20:69:00:60:69:80:45:0c	N/A	N/A	105(0×69)	No							
20:6d:00:60:69:80:45:0c	N/A	N/A	109(0×6D)	No							
20:6b:00:60:69:80:45:0c	N/A	N/A	107(0×6B)	No							
20:6e:00:60:69:80:45:0c	N/A	N/A	110(0×6E)	No							
20:6a:00:60:69:80:45:0c	N/A	N/A	106(0×6A)	No							
20:68:00:60:69:80:45:0c	N/A	N/A	104(0×68)	No							
20:6c:00:60:69:80:45:0c	N/A	N/A	108(0x6C)	No							

Figure 8-32 SAN256B Name Server table (part 3 of 3)

To view all of the details for a given device in the Name Server table, highlight the device in which you are interested and click **Detail View** to open the detailed view window as shown in Figure 8-33.

III Name Server Information f	or 016f00		×							
Detail View for Device 016f00										
Device Port WWN:	50:06:06:98:04:50:c7:38	Domain:	1(0x1)							
Device Node VWVN:	50:06:06:98:04:50:c7:39	Port #:	111(0×6F)							
Port Type:	N	Port ID:	016f00							
Device Name:	[48] "IPAddr: 0.0.0.0 Slot/Port: 9/	Fabric Port VWVN:	20:6f:00:60:69:80:45:0c							
Capability:	NS	Device Type:	N/A							
Unit Type:	N/A	Model:	N/A							
Tag:	N/A	Sequence Number:	N/A							
Manufacturer:	N/A	Manufacturer Plant:	N/A							
FDMI Host Name:	N/A	Fabric Port Name:	N/A							
WWWN Company ID:	Brocade Communications Syste	Class Of Service:	3							
NPIV(or)Virtual(or)Physical:	Virtual	Port IP Address:	N/A							
Host vs. Target:	Unknown(initiator/target)	Hard Address:	N/A							
FC4 Type:	FCP	Port Index:	111							
Shared Area:	No									
Member of Zones:	None	Member of Aliases:	None							
(*: Effective Zones)		(including aliases								
		level and port level)								
·	·		1							
			Close							

Figure 8-33 Name Server table entry - detailed view

8.4 Zone Admin task

Selecting this task launches the Zone Administration window. We describe zone administration in detail in Chapter 12, "Basic zoning" on page 513.

8.5 Admin Domain task

An Administrative Domain (*Admin Domain* or *AD*) is a logical grouping of fabric elements that defines what switches, ports, and devices you can view and modify. An Admin Domain is a filtered administrative view of the fabric.

Admin Domains: If you do not implement Admin Domains, the feature has no impact on users, and you do not need to learn how to use this functionality.

Admin Domains permit access to a configured set of users. Using Admin Domains, you can partition the fabric into logical groups and allocate administration of these groups to different user accounts so that these accounts manage only the Admin Domains assigned to them and do not make changes to the rest of the fabric.

For example, you can put all the devices in a particular department in the same Admin Domain for ease of managing those devices. If you have remote sites, you can put the resources in the remote site in an Admin Domain and assign the remote site administrator to manage those resources.

Admin Domains and Virtual Fabrics are mutually exclusive and are not supported at the same time on a switch.

Do not confuse Admin Domains with zones:

- Zones define which devices and hosts can communicate with each other.
- Admin Domains define which users can manage which devices, hosts, and switches.

Attention: You do not use the Admin Domain window to assign Admin Domains to particular user accounts. These assignments are performed in the Switch Administration window User tab.

You can have up to 256 Admin Domains in a fabric (254 user-defined and 2 system-defined), numbered from 0 through 255. Admin Domains are designated by a name and a number. This document refers to specific Admin Domains using the format "ADn" where n is a number between 0 and 255.

The two predefined Admin Domains have the following meanings:

- AD0 is a system-defined Admin Domain that contains all online devices, switches, and ports that have not been assigned manually to any user-defined Admin Domain. However, you can assign members manually to AD0. In addition, AD0 contains devices from switches running Fabric OS earlier than v5.2.0.
- AD255 (physical fabric) contains all devices, switches, and ports in the fabric. It provides a full, unfiltered view of the fabric. You can manage other Admin Domains within AD255, but you cannot manage zones. AD255 is not associated with any zone database.

Domain: Do not confuse an Admin Domain number with the domain ID of a switch. They are two different identifiers. The Admin Domain number identifies the Admin Domain and has a range of 0 through 255. The domain ID identifies a switch in the fabric and has a range of 1 through 239.

An "AD-capable switch" is a switch that meets the following requirements:

- ► Runs Fabric OS v5.2.0 or later (on both CPs, if a dual CP switch)
- ► Has a valid Advanced Zoning license, for switches running Fabric OS v5.2.x through 6.2.x.

Zoning: Switches running Fabric OS v6.1.0 or later do not need an Advanced Zoning license because zoning is bundled with the Fabric OS.

A "non-AD-capable switch" is a switch that is running one of these possibilities:

- ► Fabric OS v5.1.x or earlier.
- Fabric OS v5.2.x through Fabric OS v6.0.x, but does not have an Advanced Zoning license.
- ► Fabric OS v5.2.0 or later on one CP but Fabric OS v5.1.x or earlier on the other (for dual-CP switches) and the HA state is "synchronized".

An AD-aware switch is a switch that runs Fabric OS v5.2.0 or later (on both CPs, if a dual CP switch) and that has a valid Advanced Zoning license.

Admin Domains allow you to do the following actions:

- Define the scope of an Admin Domain to encompass ports and devices within a switch or a fabric.
- Share resources across multiple Admin Domains. For example, you can share array ports and tape drives between multiple departments.
- ► Have a separate zone database for each Admin Domain.
- Move devices from one Admin Domain to another without traffic disruption, cable reconnects, or discontinuity in zone enforcement.
- ► Provide strong fault and event isolation between Admin Domains.
- Have visibility of all physical fabric resources. All switches, E_Ports, and FRUs (including blade information) are visible.
- Implement Admin Domains in a fabric with some switches running AD-unaware firmware versions (that is, firmware versions earlier than Fabric OS v5.2.0).
- Continue to run existing third-party management applications. Prior and existing versions of third-party management applications continue to work with admin and user IDs.



Figure 8-34 shows a fabric with two Admin Domains: AD1 and AD2.

Figure 8-34 Fabric with two Admin Domains

Figure 8-35 shows how users get a filtered view of this fabric, depending on which Admin Domain they are in. As depicted in this diagram, users can see all switches and E_Ports in the fabric, regardless of their Admin Domain; however, the switch ports and end devices are filtered based on Admin Domain membership.



Figure 8-35 Filtered fabric views when using Admin Domains

8.5.1 Requirements for Admin Domains

This section lists the requirements for implementing Admin Domains in a fabric:

- Admin Domains are supported only on fabrics with one or more switches running Fabric OS v5.2.0 and later.
- If a switch runs Fabric OS earlier than v6.1.0, you must install Advanced Zoning license on it. On Fabric OS v6.1.0 or later, this license is no longer required (zoning became a part of base Fabric OS features).
- ► The default zone mode setting must be set to *No Access* before you create Admin Domains.
- ► Virtual Fabrics must be disabled before you create Admin Domains.
- To use Admin Domains and the FC-FC Routing Service in the same fabric, the switches connecting to the FC Router must be running Fabric OS v5.2.0 or later.
- If you are using LSAN zones:
 - Do not use LSAN zone names ending with _ADn (where n is the Admin Domain number).
 - Do not use LSAN zone names longer than 57 characters.
- You must be in the native operating mode to use Admin Domains because Admin Domains are not supported in interoperability mode.
- ► Gigabit Ethernet (GigE) ports cannot be members of an Admin Domain.
8.5.2 Creating an Admin Domain

The first step in creating an Admin Domain is to set the AD context to the physical fabric (AD255) this is done by selecting **Physical Fabric** in the Admin Domain drop-down menu as shown in Figure 8-36.



Figure 8-36 Admin Domain Selection menu

Click **Yes** in the confirmation dialog box (Figure 8-37).



Figure 8-37 Switch Admin Domain Context Dialog Box

To launch the Admin Domain window, click **Admin Domain** in the Web Tools Tasks panel. Figure 8-38 shows an example of the Admin Domain window.

BM_SAN256B_130 - Admin Doma	ain				
File View Actions					
🕂 New 🗟 Print 🔹 🗞 Ref	resh 🔹 📲	Apply 💼	<u>S</u> ave 🛃 🤮	Jear Fabric last updated at: Fri Jul 17 2009 20:	40:09 GMT+00:00 🛛 🤣
E- 🖪 Admin Domains	Admin Domains	;			
AD0	New	View Details	Rename	Modify Delete Activate Deactivate	
	Name 🔺	ID	State	Number of	
			State	Switches A Ports A Devices A	
	ADO	0	Active	0 0 0	
				Free Professional Management Tool 10.64.210.130 Physical Fabric U	Jser: admin Role: admin

Figure 8-38 Admin Domain window

Only the system-defined AD0 is listed in the Admin Domain window. For this example, we want to create another Admin Domain and name it AD2 using the following steps:

1. Click the **New** icon to launch the Admin Domain creation wizard. You need to provide basic information about the new Admin Domain (name and ID) as shown in Figure 8-39.

Ereate Admin Domain		×
Create Admin Domain Steps 1. Basic Information 2. Membership 3. Summary	Basic Information Name Image: Uger Specified Augo Assigned (Based on numeric ID) Image: Description Image: User Specified Image: User Specified Image: Augo Assigned (Next available ID: 1)	
	State	
Cancel		

Figure 8-39 Create Admin Domain: Basic information

- 2. To add AD2 and, therefore, to populate the fields accordingly, continue by clicking **Next**.
- 3. Next, you select the membership. Select the switches, ports, and devices to form the new Admin Domain. As shown in Figure 8-40, we add ports 0-7 on Blade1 of the SAN256B to AD2 for this example. You need to highlight the members in the **Available Members** panel, hold down *Ctrl* to select multiple members, and then add these members to the **Selected Members** panel by clicking the **Add**> button.



Figure 8-40 Create Admin Domain - membership selection

As shown in Figure 8-41, we can see that the members we chose have now been added to the Selected Members panel.



Figure 8-41 Create Admin Domain: Selected members

4. Click **Next** to proceed to the Summary window, shown in Figure 8-42. You can now review the selections and go back to make corrections. When everything is correct, click **Finish**.

🚦 Create Admin Domain						E
Steps	Summary					
1. Basic Information				AD2		
2. Membership	AD Name Al	D2 ID	2 State	Active		
3. Summary	Switches 0	Ports	8 Devices	: 0		
	Port Members (B)				
	Domain	Slot	Port	Port Index	Port Type	Port Name
	1	1	0	0	U-Port	
	1	1	1	1	U-Port	
	1	1	2	2	U-Port	
	1	1	3	3	U-Port	
	1	1	4	4	U-Port	
	1	1	5	5	U-Port	
	1	1	6	6	U-Port	
	1	1	7	7	U-Port	
		·	·		·	
]
<u>C</u> ancel Print						vious <u>F</u> inish

Figure 8-42 Create Admin Domain: Summary

5. The new Admin Domain AD2 is created and displays in the Admin Domain window (Figure 8-43). However, you need apply the AD configuration by clicking **Apply** icon to make the new Admin Domain effective.

EIBM_SAN256B_130 - Admin Don	nain						_	
File View Actions								
👫 New 🔮 Print 🔹 🧇 R	efresh 🔹 🔒	🖬 Apply) 📾	Save 🔬 🖸	lear		Fa	bric last updated at: Fri Jul 17 2009 20:40:09 GMT+00:00	99
E- 🗟 Admin Domains	Admin Domains							
ADU	New	View Details	Rename	Modify Delet	e Acti <u>v</u> a	ate <u>D</u> eactiva	te	
	blama A	ID	Chata		Number of			
	Name -	IU .	State	Switches 🔿	Ports 🗠	Devices 🛆		
	ADO	0	Active	0	() 0		
	AD2	2	Active	0	8	3 0		
				Free Pr	ofessional Man	agement Tool	10.64.210.130 Physical Fabric User: admin Role	admin

Figure 8-43 New Admin Domain AD2

6. Click Yes in the Apply AD Confirmation dialog box, Figure 8-44.



Figure 8-44 Apply AD Confirmation

7. When done, you can close the Admin Domain window to return to the main Web Tools window. The new Admin Domain AD2 is now available for selection in the Admin Domain pull-down menu, as shown in Figure 8-45.

Admin Domain	Physical Fabric 💌
	AD0
	AD2
	Physical Fabric

Figure 8-45 Web Tools: Admin Domain selection for AD2

Admin Domains are used in Switch Administration User tab settings. See 8.7.7, "User tab" on page 276 for more details.

8.6 Port Admin task

To access the detailed port information, select the appropriate port on the switch (Switch View panel) or the Port Admin task (Tasks panel), as in Figure 8-46. This launches the Port Administration window Figure 8-47). From this window, you can select any of the switch ports to display the details.

Tasks	
Manage	*
🛃 Zone Admin	
K Switch Admin	
Port Admin	
Fabric Watch	

Figure 8-46 Port Admin task

BM_SAN80B_217 - Port Ac	Iministration					_ 🗆 🗡
					Show Advar	nced Mode
FC Ports						
FC Ports Explorer	General SEP Po	rt Statistics				
2(IBM SAN80B 217)						
- 🖸 Port 1	Rename Edit Conf	iguration Enable	Disable Persistent Enable	Persistent Disable	е	
- 🕑 Port 2	General					
- • Port 3	Port Number	1(0x1)				
Port 4	Port Name					
Port 5	Port protocol	FC				
Port 6 Port 7	Port WWN	20:01:00:05:1e:09:97	01			
Port 9	Port Media					
- Port 10	Port Type	U-Port				
- • Port 11	Allowed Port Type	E-Port,F-Port,L-Port				
- 🖲 Port 12	Speed (Gb/s)	N8				
- 🖲 Port 13	Port Status	No_Module				
- • Port 14						
📃 🖲 Port 15						
Port 17						
- 🕑 Port 18						
Port 19						
Port 20						
Port 21						
Port 22						
Port 23						
Port 25						
Port 26						
Port 28						
- • Port 29						
- 🕑 Port 30						
- 🔍 Port 31						
		Mode:Basic	Free Professional Management Tool	10.64.210.217	FID 128 User: admin	Role: admin

Figure 8-47 SAN80B Port Administration window

The window contains three tabs:

- ► General
- ► SFP
- Port Statistics

When the window opens, it displays the General tab. This tab shows basic information about the selected port. It also contains a set of buttons that you can use to perform a certain action on selected port. Buttons that are not applicable to the selected port are disabled. When multiple ports are selected, only the tasks that can be performed on all of the selected ports are displayed and the others are disabled.

Use the SFP tab to see detailed information about the SFP that is installed, as shown in Figure 8-48. This will not be visible if there is no SFP installed with the port in an empty state.

IBM_SAN80B_217 - Port	Administration				_ 🗆 ×
					Show Advanced Mode
FC Ports					
FC Ports Explorer	General SFP	Port Statistics			
2(IBM_SAN80B_217)	Basic				\$
Port 0	Vendor Name :	BROCADE			
Port 1	Vendor OUI :	00:05:1e			
Port 2	FC Speed :	200,400,800_MB/s			
Port 3	Distance :	Short_dist			
Port 4					
Port 6					
Port 7					
Port 8					
- O Port 9					
- • Port 10					
- 🗩 Port 11					
Port 12					
Port 13					
- 🗩 Port 14					
- 🖲 Port 15					
- • Port 16					
- 🖲 Port 17					
- 🖲 Port 18					
- 🕑 Port 19					
- • Port 20					
Port 21					
		Mode:Basic	Free Professional Management Tool	10.64.210.217 AD0	User: admin Role: admin

Figure 8-48 SAN32B-3 Port Administration SFP tab

Figure 8-49 shows the Port Statistics tab.

IBM_SAN80B_217 -	Port Administration				
					Show Advanced Mo
C Ports					
Ports Explorer	Connect CED D	ut Chatiatian			
Dort 17	General SPP PU	on statistics			
Port 18	Port Information				
Port 10	Port Number 0(0	0×0)			
Port 19	Speed (Gb/s) N2				
Port 20	Port Trunked : No				
Port 21					
Port 22					
PUR 23 Pur 24					
Devt 25					
Port 25					
Purt 20					
Purt 27	Port Statistics				
Port 20	- Port Statistics Config	uration			
Port 29					
Port 30	Show: 🖲 Absolute	Values ု 🔿 Detta Values	Clear Counters		
Port 20					
Port 32	Update Interval in Sec	s 30 🔻			
Port 33					
Port 34 Port 35	Last Updated: Fri Jul 1	7 2009 23:29:36 GMT+00:0)		
Port 35	Rasia				
Port 36	Dasic				
Port 39	Basic Port Statistics				
Port 30	In Bytes(MB):	0.186968			
Port 39	Out Bytes(MB):	0.658848			
Port 40	In Frames :	2348			
Dovt 43	Out Frames :	4084			
Devt 42	Frames Busied :	0			
Port 43	Frames Rejected :	0			
PUL 44	Total Errors:	116236			
PUR 45	▼ :				
· · · · · · · · · · · · · · · · · · ·					
		Mode: Basic	Free Professional Management Tool	10.64.210.217 AD0	Liser admin Role:

Figure 8-49 SAN32B-3 Port Administration - Port Statistics tab

You can view the port statistics for a specific port in the Basic or Advanced tabs, and all the errors display on the Error Details tab. Figure 8-50 shows these different tabs.

Basic Advanced	Error Details				
Basic Port Statistics	Error Potonio				
In Bytes(MB):	0.186968				
Out Bytes(MB):	0.658848				
In Frames :	2348				
Out Frames :	4084				
Frames Busied :	0				
Frames Rejected :	0				
Total Errors:	116236				
Basic Advanced	Error Details				
Advanced Port Statistics	3				
C2 Frames Received		0			
C3 Frames Received		2348			
C3 Frames Discarded		0			
Link Control Frames Re	eceived	0			
Mcast Frames Receive	d	0			
Mcast Timeouts		0			
Mcast Frames Transm	itted	0			
Time R_RDY Priority		0			
Time BB_Credit Zero		0			
Encd Errs Inside Frame	es	0			
Encd Errs Outside Fra	nes	116236			
Frames with CRC Errs		0			
Short Frames		0			
Long Frames		0			
Bad End-of-Frames		0			
Basic Advanced	Error Deteile	1			
Error Details	En or Details				
	Ω	1			
Loss of Sync :	2				
Loss of Signal	4				
Protocol Error	0				
Invalid Transmitted Word 14		6236			
I II IYaliu Transmitteu oon					
Invalid CRC	Π				
Invalid CRC Delimiter Error	0				
Invalid Transmitted vvoi Invalid CRC Delimiter Error Address Error	0				
Invalid Transmitted Wor Invalid CRC Delimiter Error Address Error Inbound Link Reset	0				
Invalid Transmitted Wor Invalid CRC Delimiter Error Address Error Inbound Link Reset	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0				
Invalid Transmitted woo Invalid CRC Delimiter Error Address Error Inbound Link Reset Outbound Link Reset	0 0 2 0 0				
Invalid Transmitted woo Invalid CRC Delimiter Error Address Error Inbound Link Reset Outbound Offline Sequer Outbound Offline Sequer	0 0 2 0 10 0				

Figure 8-50 Port Statistics Basic, Advanced, and Error Details tabs

The SAN256B, SAN384B, and SAN768B have a slightly different display in which you can choose to see either the FC or the GigE ports. Figure 8-51 shows the Port Administration window on a SAN256B.

orts GigE Ports								Show Advanced	A K
rts Explore <mark>r</mark>	View Deta	ills <u>R</u> ename	Edit Configuration	Enable Dis	able <u>P</u> ersist	ent Enable Persis	tent Disable		
(IBM_SAN256B_130 Slot 1(24)	Slot#	Port#	Port Id	Port Name	Port Type	Speed (Gb/s)	Port Status	Health	
Slot 2(18)	3	0(0x0)	0x012000		U-Port	N4	No_Module	Offline	_
Slot 3(17)	3	1(0x1)	0×012100		U-Port	N4	No_Light	Offline	
Slot 4(17)	3	2(0×2)	0×012200		E-Port	N2	Online	Healthy	
Slot 9(31)	3	3(0×3)	0x012300		U-Port	N4	No_Module	Offline	
	3	4(0×4)	0x012400		U-Port	N4	No_Module	Offline	
	3	5(0x5)	0x012500		U-Port	N4	No_Module	Offline	
	3	6(0×6)	0×012600		U-Port	N4	No_Module	Offline	
	3	7(0×7)	0x012700		U-Port	N4	No_Module	Offline	
	3	8(0x8)	0x012800		U-Port	N4	No_Module	Offline	
	3	9(0×9)	0×012900		U-Port	N4	No_Module	Offline	
	3	10(0xA)	0x012A00		U-Port	N4	No_Module	Offline	
	3	11(0xB)	0x012B00		U-Port	N4	No_Module	Offline	
	3	12(0xC)	0x012C00		U-Port	N4	No_Module	Offline	
	3	13(0xD)	0x012D00		U-Port	N4	No_Module	Offline	
	3	14(0×E)	0x012E00		U-Port	N4	No_Module	Offline	
	3	15(0xF)	0×012F00		U-Port	N4	No_Module	Offline	
	4	0(0x0)	0x013000		U-Port	N4	No_Module	Offline	
	4	1(0x1)	0x013100		U-Port	N4	No_Module	Offline	
	4	2(0x2)	0×013200		LI-Port	N4	No. Module	Offline	

Figure 8-51 SAN256B Port Administration window

From the Port Administration window including the basic and advanced mode, you can perform the following functions:

- Rename a port
- ► Edit Configuration
- Enable or disable a specific port
- Persistent enable or persistent disable a port
- ► Enable or disable trunking for a specific port (default value is enabled)
- Enable or disable N_Port ID virtualization (NPIV)
- Port swap
- ► F_Port Trunking
- ► Re-Authenticate
- ► F_Port BB Credit
- ► QoS Enable/Disable
- ► Port Beacon enable /Disable
- WWN to N_Port mapping (Access Gateway)

(We explain the Configuration function in more detail in 8.6.2, "Editing the configuration" on page 237.)

Figure 8-52 shows the view of the General tab in advanced mode.

General SFP Port St	atistics
217) A Rename Edit Configura	tion Enable Disable Persistent Enable Persistent Disable Enable Trunking Disable Trunk
Epoble NDV Disable N	DV Dot Swan Re Authenticate Device Datalle OoS Ecolus OoS Disable E Port Trupkin
Chable land	
General	
Port Number	0(0×0)
Port Name	
Port WWN	20:00:05:1e:09:97:01
Port Media	sw
Port Type	F-Port
Port protocol	FC
Allowed Port Type	E-Port,F-Port,L-Port
Speed (Gb/s)	N2
Speed Configured	Auto-Negotiate
Ingress Rate Limit (Gb/s)	Not Initialized
QOS Status	Enabled
Long Distance Mode	L0:Normal
Desired Distance (km)	N/A.
Port Status	Online
Controllable	Yes
Licensed	Yes
Health	Healthy
Port Index	0(0×0)
Trunking Enabled	true
FC Fast Write Enabled	false
Trunk Port State	
Master Port	
Trunk Index	
Logical Port VW/N	
NPIV Enabled	true
Authentication	None
Additional Port Info	
Port Id	0×020000

Figure 8-52 Advanced mode

Table 8-5 describes the fields for a specific port on the General Tab of the Port Administration window.

Table 8-5Fields on the General Tab for a port

Field	Description
Port Number	The port number.
Port Name	Symbolic name assigned to the port.
Port Protocol	Type of protocol used on the port.
Port WWN	Port worldwide name.
Port Media	Type of Media connected to the port (sw or lw).
Port Type	Displays the current type of port.
Allowed Port Type	Configurable port types for the specific port.
Speed (Gbps)	Displays the actual speed at which the port is connected.
Speed Configured	Displays Speed the speed at which the port is configured.

Field	Description
Long Distance Mode	Shows the long distance mode selected for the port.
Desired Distance (km)	Shows the desired distance set for this port.
Port Status	Displays the current status of the port.
Controllable	Yes, if we can change port configuration settings.
Licensed	Shows whether the port is licensed, or requires POD license before it can be enabled and used.
Health	Displays the port health status.
Port Index	Shows whether the port has been swapped with another port.
Trunking Enabled	Displays trunking status.
FC Fast Write Enabled	Shows FC Fast Write status.
NPIV Enabled	Displays status of NPIV capability.
Additional Port Info	More information about the port.

Depending on the SAN switch type, additional fields might be present that contain information about Ingress Rate Limit (only supported on SAN768B and SAN384B), QoS, trunking attributes, and so on.

8.6.1 Renaming a port

Port naming is an optional feature to enable easier port management and identification. This option is available only for the FC and FCIP virtual ports and is not available for GE ports. From Port Admin Tasks, we can rename the port by clicking the **Rename** button. It can also be done by right-clicking the port from the switch view of Web Tools and clicking **Configure** \rightarrow **Rename**, where we can enter a name for the port.

8.6.2 Editing the configuration

This function allows you to view and change various port parameters. Follow these steps:

1. Select the port in the left pane of the Port Administration window and then click **Edit Configuration**.

When editing the configuration of a port that is online, you are presented with a confirmation dialog box as shown in Figure 8-53.



Figure 8-53 Online Port Edit Configuration Confirmation

2. Click **Yes** to accept the confirmation, and you see the FC Port Configuration Wizard, shown in Figure 8-54. The first step is to configure the Allowed Port Types.

FC Port Configuration Wizard	×
Steps	Specify Ports Parameters
1. Specify Ports Parameters	Select Allowed Port Types -
2. Specify FC Parameters	E Port
	🗹 F Port
3. Confirmation	🗹 L Port
1 Poport	O EX-Port
4. Report	Fabric ID: 1
	Interop Mode
	Brocade Native Mode
	O McDATA Fabric Mode
	O Open Mode
	O McDATA Fabric Legacy
Cancel	

Figure 8-54 FC Port Configuration Wizard Port Parameters

3. Set the allowed port types as required, and click **Next** to continue.

- 4. Now, you set FC parameters. As shown in Figure 8-55, there are four parameters that can be set:
 - Speed: Port speed can be set the speed to Auto, 1G, 2G, 4G, and 8G.
 - Ingress Rate Limit, Ingress rate limiting is a licensed feature that requires the Adaptive Networking license. Ingress rate limiting restricts the speed of traffic from a particular device to the switch port. The valid values measured in megabits per second (Mbps) are: 200, 400, 600, 800, 1000, 1500, 2000, 2500, 3000, 3500, 4000, 5000, 6000, 7000, and 8000.
 - Long Distance Mode: This sets the mode for long distance ports. The following values are valid:
 - L0: Normal
 - LE: <=10KM
 - LD: Auto
 - LS: Static
 - Desired Distance: This is used if the Long Distance mode is set to LD.
 LD calculates buffer credits based on the distance measured during port initialization. An upper limit is placed on the calculation by providing a desired distance value. If the measured distance is more than the desired distance, the desired distance is used in the calculation; otherwise, the measured distance is used.

FC Port Configuration Wizard			×
Steps	Specify FC Parameters		
1. Specify Ports Parameters			
2. Specify FC Parameters			
3. Confirmation	Speed	Auto 💌	
4. Report	Ingress Rate Limit(Mb/s)	Not Initialized	
	Long Distance Mode	L0:Normal	
	Desired Distance (km)	N/A	
Cancel			

Figure 8-55 FC Port Configuration Wizard FC Parameters

5. After changing the appropriate fields, click **Next** to display the Confirmation window, as shown in Figure 8-56.

FC Port Configuration Wizard			×
Steps	Confirmation		
1. Specify Ports Parameters	Allowed Port Type:	E_Port,F_Port,L_Port	
2. Guardiffe EC Demonstrate	Selected Port:	0	
2. Specify FC Parameters	FC Parameters:		
3. Confirmation	Speed:	Auto	
	Ingress Rate Limit:	Not Initialized	
4. Report	Long Distance Mode:	L0:Normal	
	Click Save to complete the Port Configu	ration	
Cancel			

Figure 8-56 FC Port Configuration Wizard Confirmation

 Review the configuration changes and click Save to complete the port configuration. You are presented with a success page, as shown in Figure 8-57. Click Close.

FC Port Configuration Wizard	×
Steps	Report
1. Specify Ports Parameters	Configurations are completed successfully
2. Specify FC Parameters	
3. Confirmation	
4. Report	
Cancel	Previous Close

Figure 8-57 FC Port Configuration Wizard Success

8.6.3 Enabling and disabling a port

From port admin tasks we can enable or disable a port by clicking the **Port** enable or **Port disable** buttons. Some configuration changes, such as port swapping, require that you disable and enable the port. This can also be done from the switch view in Web Tools by right-clicking the port and then **Configure** \rightarrow **Enable/Disable**.

8.6.4 Persistent enable and persistent disable options for a port

The Persistent disable and enable option makes it possible to have ports in an enabled or disabled state across restarts. This can be done from the switch view of Web Tools by right-clicking the port, then selecting **Configure** \rightarrow **Persistent Enable/Disable**. From the Port Admin Tasks view, we can also do this by clicking the **Persistent enable** or **Persistent disable** button.

8.6.5 Enabling or disabling trunking for a specific port

Trunking is enabled by default for a port, which enables an ISL connected from the same port group to form a trunk. This is described more detail in Chapter 13, "Multiple switches and fabrics" on page 587. If required, we can manually either enable or disable the trunking feature on a port from the port admin tasks advanced mode view by clicking **Enable Trunking** or **Disable Trunking**.

8.6.6 Enabling or disabling N_Port ID virtualization (NPIV)

This feature is available when the NPIV license is installed. From Web Tools, you can either enable or disable NPIV for a port by clicking the **Enable NPIV** or **Disable NPIV** button in the port admin task in advanced mode. This is a mandatory feature when Access Gateway mode is enabled.

8.6.7 Port swap

We might need to perform a port swap without affecting the host end device configurations. In such cases this port swap option allows us to maintain the same port index or port ID in the new port so that we can change the connectivity to the new port without having to change the port ID. While doing this in a backbone or director, we need to input the new slot number along with the new port number. Figure 8-58 shows the option to input the new port number when we click **Port Swap** from the port administration window.

Port Swap		×
Clathhumhan	Selected	New
 Port # 	0	1
O Port Address (Hex)	_00_	
	Sw	/ap <u>C</u> ancel

Figure 8-58 Port swap task

8.6.8 F_Port Trunking

This is a preferred option used for Nodes and targets connected by switches in Access Gateway mode. F_Port trunking requires the following criteria to be met:

- ► The Enhanced Group Management (EGM) license is installed.
- Trunking needs to be enabled in the port.

- Access gateway switch must have a trunking license.
- The port must not be configured for Long distance connection.
- The port must not be swapped.

When we create an F_Port trunk, a logical unit called a Trunk Index (TI) is formed that represents the physical ports in the trunk. From Advanced mode, when we select **F_Port trunking**, it will prompt us to select the ports as shown in Figure 8-59.

F-Port Trunking Adding ports fr Removing ports Selected Slot : 8	om LHS to R \$ from RHS \	सेंS will enable trunk area will disable trunk area on	on these ports. these ports.	×
Ports for trunking]	Trunk Groups	
	A Search	1	Trunk Groups	
Port 0				
Port 1				
Port 4				
Port 7		Create Trunk Group, Add Members>> < <remove members<="" td=""><td></td><td></td></remove>		
			Ōĸ	<u>C</u> ancel

Figure 8-59 F_Port Trunk group creation

Then click **OK** to Create Trunk Group and select the **Trunk Index** as shown in Figure 8-60.

Select Trunk Index		×
Select Trunk Index	192	-
	<u>0</u> K	<u>C</u> ancel

Figure 8-60 F_Port Trunk Index

By selecting the **Trunk Index** and clicking **OK**, we get the trunk group as shown in Figure 8-61. From here we click **OK** and then **Yes** to confirm it.

Selected Slot : 8		
Ports for trunking		Trunk Groups
Port 4 Port 7	im <u>Search</u>	ITURIK Groups ITURIK
		Create Trunk Group
		Add Members>>
		< <remove members<="" td=""></remove>

Figure 8-61 F_Port trunking

8.6.9 Re-authenticating

Devices or switches connected by F_Port or E_Port can be re-authenticated from the Port Admin Tasks view if DH-CHAP secrets or PKI certificates are set with switch level security policy. If the security features are not defined and available, this test of authentication will fail and the port will be disabled. This is described more in Chapter 14, "Security" on page 623

8.6.10 F_Port BB credit

BB credit for an F_Port can be defined from this advanced mode option. The default value is 8. This option allows us to change the default value if required for an F_Port by clicking the **F port BB credit** button, and it will prompt for a new value.

8.6.11 QoS Enable/Disable

This option requires the Adaptive Networking licensed feature. We can enable or disable QoS for a port by clicking **Qos Enable** or **Qos Disable** from Port Admin Advanced mode. More details are provided in Chapter 15, "Adaptive Networking" on page 695.

8.6.12 Port beaconing

Port beaconing enables easy port identification and can be enabled or disabled from the port admin task by clicking **Port Beacon Enable** or **Port Beacon Disable**. When enabled, the port blinks amber and green for 2.5 seconds each, which will be visible from the switch view.

8.6.13 WWN to N_Port mapping

In Access Gateway mode, the facility to map a WWN to an N_Port has been introduced. When a switch is in Access Gateway mode, the port admin task has two options to "Configure N-Port groups" and "Configure F-N port mappings." For this feature of WWN to an N_Port, we click **Configure F-N port mappings** as shown in Figure 8-62. All other port configuration options in Port Admin are disabled because the switch is in Access Gateway mode.

switch - Port Admini	stration	opfiguration Policy	Advanced			Charry	Advenced Martin
	Port C	oringuration Policy	Auvanceu			Show	Advanced Mode
C Ports CEE Interfac	es FCoE Ports						
- Ports Explorer	▶ <u>V</u> iew Deta	ils <u>R</u> ename	Edit Configurat	ion E <u>n</u> able	Disable Pe	r <u>s</u> istent Enable	
Port 0	Persistent	Disable Config	ure N-Port Group	os Configur	e F-N Port Mapping		
Port 1 Port 2	Port# 🔺	Port Id	Port Name	Port Type	Speed (Gb/s)	Port Status	Health
Port 2	0(0×0)	0×050000		N-Port	N8	No Module	Offline
Port 3	1(0x1)	0×050100		N-Port	N8	No Module	Offline
Port 5	2(0×2)	0×050200		N-Port	N8	No_Module	Offline
Port 6	3(0x3)	0×050300		N-Port	N8	No_Module	Offline
Port 7	4(0×4)	0×050400		N-Port	N8	Online	Healthy
E Port?	5(0x5)	0×050500		N-Port	N8	No_Module	Offline
	6(0×6)	0×050600		N-Port	N8	Online	Healthy
	7(0×7)	0×050700		N-Port	N8	No_Module	Offline

Figure 8-62 Port admin tasks for Access Gateway mode

When we click **Configure F-N port Mappings**, it gives us the N_Port mapping configuration with a list of the mapping groups defined as shown in Figure 8-63.

r mar y wappe ga-	
Available VWWVs	Primary Mappings
4 10:00:00:05:1e8e:c8:60 4 10:00:00:00:c64ate.a2 4 10:00:00:06:1e57.78.78	Croup 0 Coup
Add Add	
econdary Fallover Mappings	
Available VMN's	Failover Mappings
Available / Fallower Magpings Available WMN's	Fallover Mappings

Figure 8-63 WWN N_Port mapping

Here we can enable WWN mapping by selecting a WWN and then click **Configure WWN**, which gives us the option to select **Enable Rule for WWN configuration** as shown in Figure 8-64.

www.connguratio	n	
Selected VWVN: 20:00:0	0:05:1e:12:34	4:58
P Enable Rule		
	ОК	<u>C</u> ancel

Figure 8-64 WWN config enable

8.6.14 Port Administration window on the SAN256B and SAN768B

While most of the buttons in the Port Administration window perform the same function on all switches, the SAN256B, SAN384B, and SAN768B have two tabs on the left pane. Figure 8-65 shows the first tab, which is for FC ports.

BM_SAN256B_130 - Port	Administration	× □_
		Show Basic Mode
FC Ports GigE Ports		
FC Ports Explorer	General SFP Port Statis	stics
1(IBM_SAN256B_13 -		
🖻 🚺 Slot 1(24)	Rename Edit Configuration	In Enable Disable Persistent Enable Persistent Disable
Port 0	Enable Trunking Disable	Trunking Enable NPIV Disable NPIV Port Swap Re-Authenticate
Port 1		
Port 2	QoS Enable QoS Disable	F-Port Trunking
Port 3	Ceperal	
Port 4	Ceneral .	
Port 5	Port Number	1/U(UXU)
Port 6	Port Name	20:00:00:00:00:00:46:0-
Port 7	Port WWWN	20:00:00:50:59:80:45:00
Port 8	Port Media	
Port 9	Port Type	
Port 10	Alleria al Dert Trans	
Bost 12	Allowed Port Type	
Port 12	Speed (GD/S)	Neto Monstinto
Port 14	Ingrees Rate Limit (Ch/s)	Auto-negoliate
Port 14	OOS Status	Foohlad
Port 16 (cel	Long Distance Mode	L () Normal
Port 17 (get	Desired Distance (km)	N/A
Port 18 (get	Port Status	Persistent Disabled
Port 19 (gef	Controllable	Yes
	Mode: Advance	ad Free Professional Management Tool 10.64.210.130 AD0 User: admin Role: admin

Figure 8-65 SAN256B Port Administration FC Ports tab

Figure 8-66 shows the GigE ports tab in the Port Administration window of SAN256B.

C Ports GigE Ports								
E Ports Explorer	GigE Ports	Configuration a	nd Management					
1(IBM_SAN256B_130) - [] Slot 1(24)	View De	etails <u>E</u> na	ble Port Disable	Port P	ersistent Enable	Persisten	t Disable	
— 🖾 ge0	Slot#	Port#	MAC Address	Port Type	Status	State	Speed	
- 🚾 ge1	1	ge0	00:05:1e:37:	GigE-Port	Disabled	Offline	1	
- 🚺 Slot 9(31)	1	ge1	00:05:1e:37:	GigE-Port	Disabled	Offline	1	
ge0	9	ge0	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
_ III ge1	9	ge1	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
_ Los ge2	9	ge2	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
e le ge3	9	ge3	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
_ LEE ge4	9	ge4	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
i i ges	9	ge5	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
geb	9	ge6	00:05:1e:38:	GigE-Port	Enabled	Offline	1	
— 💷 ge/	9	ge7	00:05:1e:38:	GigE-Port	Enabled	Offline	1	

Figure 8-66 SAN256B Port Administration GigE Ports tab

8.6.15 Port Administration for the FCOE switch

This topic is described in the book, *IBM Converged Switch B32*, SG24-7935-00, available at this website:

http://www.redbooks.ibm.com/redpieces/abstracts/sg247935.html?Open

8.6.16 Port Administration for the IBM System Storage SAN06B-R

This topic is described in the book, *IBM System Storage b-type Multiprotocol Routing: An Introduction and Implementation*, SG24-7544-03, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247544.html?Open

8.7 Switch Admin task

The Switch Admin task on the Tasks panel (Figure 8-67) is used to launch the Switch Administration window.



Figure 8-67 Switch Admin task

In this section, we discuss the Switch Administration in detail.

8.7.1 Switch Administration window layout

In this example, we explore the Switch Administration on a SAN80B. When the administration window opens, it is composed of five areas (labeled A, B, C, D, and E), as shown in Figure 8-68.

Tip: If you hover the mouse over buttons and other areas of the window, information displays about their function.

BM_SAN80B_217 - Switch Administration		
		Show Basic Mode
SwitchName: IBM_SAN80B_217 D	omainID: 2(0×2) VWVN: 10:00:00:05:1e:09:97:01 Mon Jul	20 2009 17:02:07 GMT+00:00
SNMP Configure Routing Extended Fabric AAA Servi	e Trace FICON CUP Security Policies	В
Switch Network	Firmware Download License User	Trunking
Switch Name and Domain ID		
Name IBM_SAN80B_217	Manufacturer Serial # AHX0617D001	
Domain ID 2	Supplier Serial # 107700H	c
Switch Status	DNS Configuration	
Enable Disable	DNS Server 1	
	DNS Server 2	
Report	Domain Name	
View Report	Remove All	
Reboot/Fastboot		
Reboot Fastboot		
	Apply	Close Refresh
A 7		
[Switch Administration opened]: Mon Jul 20 2009 16:58:27 GMT+00:00)	
' Change current switch settings	Mode: Advanced Free Professional Management Tool 10.64.210.217 AD0 Use	er: admin Role: admin 📔 🖌

Figure 8-68 SAN80B administration window layout

Here we describe the five areas of the window:

- Area A: Displays summary information, switch name, domain ID, date, and time. You can use the button on the right side to switch between Basic and Advanced Mode display.
- Area B: Allows navigation through the different management panels (by clicking the desired tab). The content of this area depends on the licenses installed on the switch. In addition, content also depends on switch administration mode:
 - In basic mode, you see only the seven most commonly used tabs (Switch, Network, Firmware Download, License, User, Blade (on chassis based systems), and Trunking).
 - Advanced mode displays all available tabs.
- ► Area C: Contains parameters to be set in the current panel.
- Area D: Contains the button bar.
- Area E: Contains the report window that allows viewing of the switch report upon operation completion.

We describe the Switch Administration tabs in the sections that follow.

8.7.2 Switch tab

When the administration window first opens, the Switch tab displays by default, as shown in Figure 8-68 on page 251.

On the first tab, you can define the switch name and the domain ID, set the DNS configuration, enable or disable the entire switch, and view a detailed report of the switch.

You can also perform the following actions:

- Reboot switch
- Fastboot switch

Table 8-6 describes the fields on the Switch tab.

Table 8-6 Switch Information tab

Field	Description
Name	Enter data for the switch name. Enter a new name to change a name in this field.
Domain ID	Displays or sets switch domain ID. Domain IDs must be unique within a fabric. To change domain ID, enter new domain ID in this field. Use a number from 1 to 239 for normal operating mode (FCSW compatible) and a number from 0 to 31 for VC encoded address format mode (backward compatible to SilkWorm 1000 series). Note: The switch needs to be disabled to change this value.
Manufacturer Serial #	Physical serial number of the switch.
Supplier Serial #	Supplier serial number of switch for display only.
(Status) Enable	Click the radio button to enable the switch.
(Status) Disable	Click the radio button to disable the switch.
DNS Server 1	Enter the primary DNS server in this field.
DNS Server 2	This is the field for secondary DNS server.
Domain Name	Enter the Domain Name.
Reboot	Click to reboot the switch.
Fastboot	Use this button to perform fastboot.
Apply	Click to save any changes made to this tab and remain in the current tab. You can make additional changes and click Apply when making changes incrementally.
Close	Click to exit the Switch Admin view. If you make changes but do not commit them by clicking Apply , a dialog box is presented to allow you to commit or delete the changes.
Refresh	Click to retrieve current values from the switch.

Click **View Report** to display a window as shown in Figure 8-69. The detailed report includes a list of all the types of switches connected to the local switch, the inter-switch links (ISLs), list of ports, the Name Server information, details on the configured zones, and SFP serial ID information.

			Switch I	nformation Report for IBM	_SAN80B_217
List of Swite	hes				
Switch ID 1	Jorldwide Name	Enet IP Addr	FC IP Addr	Name	
2: fffc02 :	l0:00:00:05:1e:09:97:	01 10.64.210.217	0.0.0.0	>"IBM_SAN80B_217"	
Current Swit	ch Information				
Ethernet IP . Ethernet Subs Fibre Channe. Fibre Channe. Gateway Addre Ethernet IPv	Address: 10.64.210.21 hetmask: 255.255.240. L IP Address: 0.0.0.0 L Subnetmask: 0.0.0.0 ss: 10.64.208.1 5 Addresses:	7 0			
Kernel: 2 Fabric OS: 7 Made on: 7 Flash: 1 BootProm: 2	2.6.14.2 76.2.0e Fue Apr 14 21:34:25 2 Mon Jul 13 22:56:26 2 0.14	009 009			
List of Inter-	Switch Links				
Local Domain	ID: 2				
Local Port	Domain Remote	Port State			
List of Ports					
switchName: switchType: switchState: switchRole: switchDomain switchId: switchWwn: toning: switchBeacon FC Router: FC Router BB	IBM_SAN80B_217 64.3 Online Native Principal 2 fffc02 10:00:00:05:1e:09 OFF OFF Fabric ID: 120	:97:01			

Figure 8-69 SAN80B Switch report

8.7.3 Network tab

Use the Network tab to modify the IP settings of the switch. Figure 8-70 displays the network tab for the SAN80B switch.

	_c.r. Jinten	Administrat	ion							Show I dupped M
abbiene IDM	CANOD 247				Damair	ID: 2/0-2) . WARAN 40-00	00.05.4 - 00.07.0	24	Man Ind	310W Advanced W
ICTINAME. IDW	:hName: IBM_SAN80B_217			Domaii	=	.00.05.18.09.97.0	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	WOIT JUI.	20 2009 17:31:07 GMT+	
vitch Netw	ork Firmwar	e Download	License	User	Trunking					
thernet and Fi	ore Channel IP (Configuration								
IPv4 Address										
Ethernet IP	10.64.210.21	7				Fibre Channel Net IP	0.0.0.0			
Ethernet Masi	255.255.240	0				Fibre Channel Net Mask	0.0.0.0			
Gateway IP	10.64.208.1					DHCP : Disabled				
IPv6 Address										
Ethernet IPv6							1	State :		
Enable IPv6	Auto Configura	tion								
Auto Config	red IPv6 Addre	sses								
Address	Prefix	State								
- IPv6 Gatew	ays									
IPv6 Gatew	ays									
Address										
yslog IP's Con	figuration									
Syslog IP	- Current Value								_	
1	10.64.223.12								New IP	
2	10.64.210.36									لداده
3	10.64.210.35									Add
4	10.64.210.101									Remove
5	10.64.210.102									Clear All
6	10.64.210.100									
									Apply	Close Refresh

Figure 8-70 SAN80B Network tab

Table 8-7 describes the fields in the Network tab (which is shown in Figure 8-71 on page 258).

Table 8-7 Network tab

Field	Description
Ethernet IP	Display or set the Ethernet IP address.
Ethernet Mask	Display or set the Ethernet IP Subnet Mask.
Gateway IP	Display or set the Gateway IP address.
Fibre Channel Net IP	Display or set the Fibre Channel IP address.
Fibre Channel Net Mask	Display the Fibre Channel Subnet Mask.
IPv6 Address	Set the IPv6 address, if required.
Enable IPv6 Auto Configuration Check box	When IPv6 auto-configuration is enabled, the platform will engage in stateless IPv6 auto-configuration. When IPv6 auto-configuration is disabled, the platform will relinquish usage of any auto-configured IPv6 addresses that it might have acquired while it was enabled.
Syslog IPs	Display the six syslog IP addresses for a user to configure.
Add	Add syslog IP address entered in field.
Remove	Remove syslog IP address.
Clear All	Remove all previous syslog IP entries.
Apply	Click to save the changes made to this tab and to stay in the current tab. You can make additional changes and click Apply when making changes incrementally.
Close	Click to exit the Admin window. If you make changes but do not commit them by clicking Apply , a dialog box displays to allow you to commit or delete the changes.
Refresh	Click to retrieve current values from the switch.

Upgrades: An upgrade from Fabric OS v6.1 or earlier, which does not support IPv6 auto-configuration, to a platform that does support IPv6 auto-configuration, such as Fabric OS v6.2 or later, will cause IPv6 auto-configuration to be enabled on the upgraded platform. In upgrades or downgrades between versions of Fabric OS that support auto-configuration, the enabled state of IPv6 auto-configuration will not be changed.

Overview of syslogd

The Fabric OS maintains an internal log of all error messages. However, the internal log buffers are limited in capacity. When they are full, new messages overwrite old messages.

You can configure the switch to send error log messages to a UNIX host system that supports **syslogd**. You can configure this host system to receive error or event messages from the switch and then store them in its file system, overcoming the size limitations of the internal log buffers on the switch.

The host system can be running UNIX, Linux, or any other operating system as long as it supports standard **syslogd** functionality. The switch by itself does not assume any particular operating system to be running on the host system.

To configure the syslog function, simply put the IP address of the host running the syslogd in the Syslog IP field, and click Add. After adding all logging host IP addresses to the list, you must click Apply to save the changes.

Network tab: SAN256B and SAN768B

The network configuration panel on a SAN256B director or SAN768B backbone looks slightly different. As shown in Figure 8-71, the panel contains an additional section called *Advanced IP Configuration*. This section allows you to configure the Ethernet management ports on each CP.

			Show Advanced Mod
itchName: IB	M_SAN256B_130	DomainID: 1(0×1) VWVN: 10:00:00:60:69:80:45:0c	Mon Jul 20 2009 17:40:03 GMT+0
witch Net	work Firmware Download L	icense User Blade Trunking	
Ethernet and	Fibre Channel IP Configuration		
IPv4 Addres	s		
Ethernet IP	10.64.210.130	Fibre Channel Net IP 0.0.0.0	
Ethernet Ma	ask 255.255.240.0	Fibre Channel Net Mask 0.0.0.0	
Gateway IF	10.64.208.1		
IPv6 Addres	s		
Ethernet IPv	6	/ Sta	ate :
Advanced	IP Configuration		*
-IPv4 Addre:	38		_
CP0 Ethern	et IPv4 10.64.210.131	CP1 Ethernet IPv4 10.64.210.132	
CP0 IPv4 S	ubnet Mask 255.255.240.0	CP1 IPv4 Subnet Mask 255.255.240.0	
IPv6 Addre:	38		
CP0 Ethern	et IPv6	/State	:
CP1 Ethern	et IPv6	/ State	:
Enable IP	6 Auto Configuration		
– Auto Confi – IPv6 Gatev	gured IPv6 Addresses		
Syslog IP's C	onfiguration		
Syslog IP	Current Value		
1	10.64.210.105		New IP
2	10.64.210.100		
3	10.64.210.45		Add
4	10.64.210.103		Remove
			Clear All
			Annha Class Defect
			Apply Close Refresh

Figure 8-71 Network tab of the SAN256B

8.7.4 Firmware Download tab

We use the Firmware Download tab to upgrade the Fabric OS. The firmware upgrade procedure normally requires an FTP server that stores the Fabric OS files. Additionally, if the switch is equipped with a USB port, you can use a Brocade-branded USB memory key as the source for firmware download. Figure 8-72 shows an example of the Firmware Download panel on a IBM Converged B32 switch.

🔄 swit	ch - Switch A	dministrati	ion							
									She	ow Basic Mode
Switch	Name: switch		C	omainID: 5(0×5) V	WWN: 10:0	00:00:05:1e:b	0:81:80		Mon Nov 08 2010 (23:55:56 GMT+00:0
SNMP	Configure	Routing	Extended Fabric	AAA Service	Trace	FICON CUP	Security Pol	icies		
S	witch	Netw	ork	Firmware Dov	vnload		License	User	Trunking	CEE
Curr	ent Firmware Ir Primary partition Secondary part	iformation n: iition:	6.4.0b 6.4.0b							
Firm	ware Key Inform	nation								*
	Select Sourc Provide *Passwo	e of image Host Detai ord is optione	Network ils *, Transfer Pro al, if user name is "	USB Ditocol and Path fo	r Firmwa	re Downloa	d			
	Host Name o	r IP	10.18.228.37							
	User Name		admin							
	Password		•••••	1 (777)						
	Protocol Type	B North	File Transfer Prot	0C0I (F IP)						
	Specity Firm	ware Path	rirmware/Switche	55/6.X/6.4.X/6.4.1/						-
									Download Close	e Refresh
[Switch	Administration	opened): Mo	n Nov 08 2010 23:	33:53 GMT+00:00						
[Switch [Switch	Administration Administration	closed]: Mor closed]: Mor	Nov 08 2010 23:3 Nov 08 2010 23:3	4:53 GMT+00:00 4:53 GMT+00:00						
Switch	Administration	openedj: Mo	n Nov U8 2010 23:	53:56 GMT+UU:00						
Firmwar	e download			Mode: Advanced	Free Pr	ofessional Ma	nagement Tool	10.18.228.18	AD0 User: admin	Role: admin •

Figure 8-72 Firmware Download tab

Uploading switch configuration before changing firmware

The IBM Converged B32 switch has a USB port, therefore, the USB radio button is active. Fabric OS v6.4.0 allows you to download either the actual firmware or the public firmware key.

Always upload a copy of the switch configuration before performing any firmware change. The configuration upload function is available in the **Configure** tab (described in 8.7.8, "Configure tab" on page 281).

Upgrading the firmware using Web Tools

In this section, we show the firmware upgrade procedure with Web Tools. In our example, we upgrade the firmware of IBM Converged B32 switch from v6.4.0b to v6.4.1.The firmware versions are stored on an FTP server.

To upgrade the firmware, proceed as follows:

1. Launch Web Tools for IBM Converged B32 switch and select **Switch Admin** as shown in Figure 8-73.

[₩] T switch - Web Tools			
Manage Reports Monitor Tools			
Tasks	Status O Temp O Power	C Fan	Beacon Read Switch Status Policy
Manage			
Zone Admin	Admin Domain AD0 💌		
Switch Admin	Switch View		
Port Admin			
		8-8-8-8-8-8	
E Admin Domain	🗢 10101 🖵 USB 🛶 °	۵ ¹ 0 ² 0 ³ 0	
🙌 Fabric Watch			
Markey A		TE TE TE	
Monitor			
Performance Monitor	Cuileb Events Information		
Name Server	Switch Events, Information		
	Switch Events Switch Information		
Other <	All Events Last Updated: Mon Nov 08 201	0 23:49:56 GMT	+00:00 (Auto-Refresh interval is 15 seconds)
Telnet/SSH Client			FiterSho
	Time	Level	Message
	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	InterfaceMode changed from None to L2 for interface az0.0.5
	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	OperationalEndpointMode changed from None to trunk for interface az0.0.5
	Mon Nov 01 2010 08:28:13 GMT+00:00	 Information 	InterfaceMode changed from None to L2 for interface az0.1.4
	Mon Nov 01 2010 08:28:13 GMT+00:00	()Information	OperationalEndpointMode changed from None to trunk for interface az0.1.4
	Mon Nov 01 2010 08:28:13 GMT+00:00	()Information	InterfaceMode changed from None to L2 for interface az0.1.5
Fabric Tree	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	OperationalEndpointMode changed from None to trunk for interface az0.1.5
View by: Name 👻	Mon Nov 01 2010 08:28:13 GMT+00:00	 Information 	InterfaceMode changed from None to L2 for interface az0.2.4
El 🌲 Fabric	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	OperationalEndpointMode changed from None to trunk for interface az0.2.4
B 85000 75	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	InterfaceMode changed from None to L2 for interface az0.2.5
B5000_76	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	OperationalEndpointMode changed from None to trunk for interface az0.2.5
BM 2498 806	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	Interface Port-channel 1 is created
IBM SAN384B 27 VF	Mon Nov 01 2010 08:28:13 GMT+00:00	Information	Interface TenGigabitEthernet 0/0 is added on interface Port-channel 1
SAN32B-E4-1	Mon Nov 01 2010 08:28:13 GMT+00:00	(1) Information	Interface TenGigabitEthernet 0/0 is administratively up
SAN32B-E4-2	Mon Nov 01 2010 08:28:13 GMT+00:00	(1) Information	Interface TenGigabitEthernet 0/1 is added on interface Port-channel 1
switch	Mon Nov 01 2010 08:28:13 GMT+00:00	 Information 	Interface TenGigabitEthernet 0/1 is administratively up
Segmented Switches	Mon Nov 01 2010 08:28:13 GMT+00:00	 Information 	InterfaceMode changed from None to L2 for interface TenGigabitEthernet 0/2
	Mon Nov 01 2010 08:28:13 GMT+00:00	(1) Information	OperationalEndpointMode changed from None to access for interface TenGigabitEthernet 0/2
	Mon Nov 01 2010 08:28:13 GMT+00:00	(1) Information	OperationalEndpointMode changed from access to converged for interface TenGigabitEthernet
	Mon Nov 01 2010 08:28:13 GMT+00:00	(1) Information	Interface TenGigabitEthernet 0/2 is administratively up
	Map Nov.01 2010 09:29:12 CMT:00:00	Information	CEEMan datauit assigned to interface TanCinshiEthernat 0/0
Number of switches: 7	Getting events from switchdone.		

Figure 8-73 IBM Converged SAN B32 switch Web Tools
2. From the Switch Administration window. Select the **Firmware Download** tab, as shown in Figure 8-74.

💐 switch - Switch Administrat	on				
				\$	Show Advanced Mode
SwitchName: switch	DomainID: 5(0×5) VWVN: 10:	00:00:05:1e:b0:81:80		Tue Nov 09 2	010 00:36:56 GMT+00:0
Switch Network Firmware	Download License User Trunking	CEE			
Current Firmware Information					
Duinensentäises	0.4.05				
Secondary partition:	6.4.0b				
Firmware Key Information					×
Download	Eirmware Firmware Key				-
Select Source of image	Network USB				
Provide Host Deta	s *, Transfer Protocol and Path for Firmwa	re Download			
*Password is option	I, if user name is "anonymous"				
Host Name or IP	10.18.228.37				
User Name	admin				
Password	•••••				
Protocol Type	File Transfer Protocol (FTP)		•		
Specify Firmware Path	Firmware/Switches/6.x/6.4.x/6.4.1/v6.4.1		•		
					•
				Download	Close Refrech
				Download	close Reliesh
n Trivare uownioau raileu, rue w	▼ 05 2010 00.33.30 9WIT+00.00				
[Firmware download started]: Tue Initiating firmware download	lov 09 2010 00:35:56 GMT+00:00				l l
From Host: 10.18.228.37					
File Path: /Firmware/Switches/6.x/t [Frror]: The server is inaccessible.	.4.x/6.4.1/ r firmware path is invalid. Please make sure the	server name or IP address th	e user/bassword	and the firmware	e path are valid
[Firmware download failed]: Tue N	v 09 2010 00:35:56 GMT+00:00				part are raild.
Start transport	Mode: Basic Free Pr	ofessional Management Tool	10.18.228.18	AD0 User: ac	lmin Role: admin 🛛

Figure 8-74 Switch Administration Firmware Download tab

3. Complete the fields as appropriate. Enter the IP address of FTP server, the user name and password, and the directory that contains the firmware files (in our case, the directory is Firmware/Switches/6.x/6.4.x/6.4.1/v6.4.1/).

4. Then, click **Download** to initiate the firmware upgrade process.

A confirmation window displays, see Figure 8-75. The information displayed in the window reminds you that the switch will reboot after the download is done. Note that on the Converged Switch (Elara) this will cause a cold/disruptive boot. This means that the management network connection to the switch will be lost and will need to be re-established.

Confirm Firmware Download
Firmware download may take a while This operation will cause the system reboot during the process. This will cause disruption to attached devices and temporary loss of Network Connection to the system. All other operations will be disabled during the download. Please do not power cycle the switch. On Elara this command will cause a cold/disruptive boot. Do you want to proceed? Yes No

Figure 8-75 Firmware download confirmation

- 5. Continue by clicking Yes.
- The firmware download and upgrade process takes a while (up to 30 minutes). When it completes, you have to close and reopen Web Tools and reconnect to the switch. As shown in Figure 8-76, the switch now runs Fabric OS v6.4.1 (Figure 8-76).

🗤 switch - Web Tools			_ 🗆 >
Manage Reports Monitor Tools	2		
Tasks			
	🖡 💛 Status 🛛 💛 Temp	Power Fan A Beacon Emilegend X Switch Status Policy	
Manage ×	Admin Domain ADD	-	.og Out
🔊 Zone Admin	Admin Domain AD0		
Switch Admin	Switch View		
Port Admin			
Admin Domain	S .		
CD Admin Domain			4
💱 Fabric Watch			
[14-3-3		TE TE TE TE SE TE TE TE TE TE TE TE TE TE SE LE U LE U SESS	
Monitor			
🖾 Performance Monitor			
Name Server	Switch Events, Information		
	Switch Events Switch Infor	mation	
Other 🔶	Last updated at	Tue Nov 09 2010 01:06:18 GMT+00:00	-
Telpet/SSH Client	Switch		
	Name	switch	
	Status	Heathy	
	Fabric OS version	v6.4.1	
	Domain ID	5(0x5)	
	VWWN	10:00:00:05:1e:b0:81:80	
	Type	76.7	
abric Tree	Role	Subordinate	
	Ethernet		
flew by: Name	Ethernet IPv4	10.18.228.18	
- 🐟 Fabric	Ethernet IPv4 netmask	255.255.255.0	
B5000_75	Ethernet IPv4 gateway	10.18.228.1	
- E B5000 76	Ethernet IPv6	None	
IBM_2498_R06	E FC		
IBM_SAN384B_27_VF	IPFC IPv4	None	
SAN32B-E4-1	IPFC IPv4 netmask	None	
- SAN32B-E4-2	E Zone		
switch	Effective configuration	IBM RB	
 Segmented Switches 	E Other		12
	Mapufacturer serial number	AV\$0639E01A	
	Supplier serial number	1095077	_
	License ID	10:00:05:1e;b0:81:80	
	E RNID	003758	-
Jumber of switches. 7	Type	003758	•

Figure 8-76 IBM Converged SAN B32 running Fabric OS v6.4.1

8.7.5 SNMP tab

We use the SNMP tab to administer the SNMP subsystem. From the SNMP tab, you specify the switch community string, location, trap level, and trap recipients. SNMPv3 is available from Fabric OS v4.4 onwards, as well as SNMPv1. As shown in Figure 8-77, you can set traps using either SNMPv1 or SNMPv3.

Apart from using Web Tools, SNMP parameters can also be set with Telnet commands or Data Center Fabric Manager (Figure 8-77).

IBM_SAN80B	_217 - Switch	Administr	ation									- Show Basic Mod
vitchName: IBM_	SAN80B_217			Domainll	D: 2(0×2)	WWN: '	10:00:00:05:	1e:09:97:01			Mon Jul 20 20	009 18:52:25 GMT
SNMP Config	ure Routing	Extende	d Fabric	AAA Service	Trace	FICO		ecurity Policies				
Switch		Network		Fir	mware Dov	wnload		Lic	ense	User		Trunking
ChiMD Informati							Enchle Die	able Authoritadi	n Tron			
Contact Name	Field Summert						Enable/Disa	able Autrienticati	Jiiirap			
Contact Name	Field Support.	0						0.40				
Description	Fibre Channel	Switch.						Authentication	rap			
Location	End User Prem	ilse.										
- SNMPv3 Info	rm / Trap Recipi	ent	L			-				L		
UserName		_	Recipient	t IP		Po	ort Number			Trap Level		_
somnadmip?	F1A/		10.64.21	0.104		16	92 20			4 - Informational		
sninpauninz -	ENA/		0.0.0.0			162			0 - None			
Commu	unity String	cipient	Recip	pient		Port Nur	nber	Act	ess Contro	ol	Trap L	evel
Secret C0de		10.64.21	10.74		162			Read Write		4 - 1	nformational	•
OrigEquipMfr		dell-stor	agex-074		162			Read Write		4 - 1	nformational	•
private		127.0.0.	1		162			Read Write		1 - 0	lone	-
oublic		10.64.21	0.72		162			Read Only		4 - 1	nformational	•
- Access Con	trol List											
Access Host						R	ccess Contr lead Write	OI LIST				T
0.0.0.0						R	ead Write					-
0.0.0					R	Read Write						
0.0.0.0						R	ead Write					•
											Apply (Close Refres

Figure 8-77 SNMP tab

Creating a new SNMPv1 trap

To create a new trap, proceed as follows:

- 1. Double-click a community string in the SNMPv1 section, and enter a new community string.
- 2. Double-click a recipient IP address in the SNMPv1 section, and enter a new IP address.
- 3. Click Apply.

Creating a new SNMPv3 trap

To create a new trap, proceed as follows:

- 1. Select a user name from the User Name drop-down list in the SNMPv3 section.
- 2. Double-click a recipient IP address in the SNMP v3 section, and enter a new IP address.
- 3. Select a trap level from the Trap Level drop-down list.
- 4. Click Apply.

Table 8-8 describes the fields on the SNMP tab.

Table 8-8 SNMP tab

SNMP Basic Inform	nation				
Contact Name	Displays or sets contact information for switch. Default is Field Support.				
Description	Displays or sets system description. Default is Fibre Channel Switch.				
Location	Displays or sets the location of switch. Default is End User Premise.				
Enable Authentication Trap	Check to enable authentication traps; uncheck to disable (preferable).				
SNMPv1 Community/Trap Recipient					
Community String	Displays the community strings that are available to use. A community refers to a relationship between a group of SNMP managers and an SNMP agent, in which authentication, access control, and proxy characteristics are defined. A maximum of six community strings can be saved to the switch.				
Recipient	Displays the IP address of the Trap Recipient. A trap recipient receives the message sent by an SNMP agent to inform the SNMP management station of a critical error.				
Access Control	Displays the Read/Write access of a particular community string. Read only access means that a member of a community string has the right to view, but cannot be changed. Read/Write access means that a member of a community string can be both viewed and changed.				
Trap Level	Sets severity level of switch events that prompt SNMP traps. Default is 0.				

SNMPv3 Trap Rec	ipient
User Name	Displays user names that are available to use. The user names are predefined with different Read/Write or Read Only access. The predefined user names are snmpadmin1, snmpadmin2, snmpadmin3 with Read/Write access and snmpuser1, snmpuser2, snmpuser3 with Read Only access.
Recipient IP	Displays the IP address of the Trap Recipient. A trap recipient receives the message sent by an SNMP agent to inform the SNMP management station of a critical error.
Trap Level	Sets severity level of switch events that prompt SNMP traps. Default is 0
Access Control Li	st Configuration
Access Host	Displays the IP address of the host of the access list.
Access Control List	Displays the Read/Write access of a particular access list. Read only access means that a member of an access list has the right to view but cannot make changes. Read/Write access means
	that a member of an access list can both view and make changes.
Apply	that a member of an access list can both view and make changes. Click to save the changes made to this tab. You can make additional changes and click Apply when making changes incrementally.
Apply Close	 that a member of an access list can both view and make changes. Click to save the changes made to this tab. You can make additional changes and click Apply when making changes incrementally. Click to exit the Admin window. If you have made changes but did not commit them clicking Apply, a dialog box displays.

You can also set SNMP parameters with Telnet using the **snmpConfig** command. In older Fabric OS releases, the following set of commands was used to set and view SNMP settings:

- ▶ agtcfgSet
- ► agtcfgShow
- ▶ agtcfgDefault

The functionality of these commands is now available through the snmpConfig command. You also use the snmpConfig command to view or set the MIB capability, instead of older commands snmpMibCapSet and snmpMibCapShow. Example 8-4 shows current MIB capability settings for the SAN80B switch.

Example 8-4 Using the snmpConfig command to verify MIB capability settings

IBM SAN80B 217:admin> snmpConfig --show mibCapability FE-MIB:YES SW-MIB: YES FA-MIB: YES FICON-MIB: YES HA-MIB: YES FCIP-MIB: NO ISCSI-MIB: YES SW-TRAP: YES swFCPortScn: YES swEventTrap: YES swFabricWatchTrap: YES swTrackChangesTrap: YES FA-TRAP: YES connUnitStatusChange: YES connUnitEventTrap: YES connUnitSensorStatusChange: YES connUnitPortStatusChange: YES SW-EXTTRAP: NO FICON-TRAP: YES linkRNIDDeviceRegistration: YES linkRNIDDeviceDeRegistration: YES linkLIRRListenerAdded: YES linkLIRRListenerRemoved: YES linkRLIRFailureIncident: YES HA-TRAP: YES fruStatusChanged: YES cpStatusChanged: YES fruHistoryTrap: YES

8.7.6 License tab

We use the License tab to install the license keys that you have purchased. You use license keys to enable additional features on a switch. You can also use the table within the License tab to remove a listed license from the switch. Figure 8-78 displays the License tab for a SAN80B switch.

IBM_SAN80B_217 - Switch Administration			
		Show Basic Mode	
SwitchName: IBM_SAN80B_217 Dor	nainID: 2(0x2) VWVN: 10:00:00:05:1e:09:97:01	Mon Jul 20 2009 19:08:26 GMT+00:00	
Trunking SNMP Configure Routing Extended Fabric AA	A Service Trace FICON CUP Security Policies		
Switch Network	Firmware Download License	User	
License Administration			
License Key	Feature(s)	Expiry Date	
SR9SceSRdRTSATds	Extended Fabric	NA	
aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH	Performance Monitor, Trunking, Adaptive Networking	NA	
aSMN49m7ATRWZEXXZEY9NM4N7atTY4rHBSBLN	8 Gig FC	NA	
bQezcSebScRf0dk	Fabric	NA	
bcS9QzbR99cdVARs	Integrated Routing	NA	
bcS9QzbR99cdXARu	Second Ports on Demand license - additional 16 port upgrade	NA	
bcS9GzbR99cfTARs	FICON_CUP	NA	
bcS9QzbR99ctTAR6	First Ports on Demand license - additional 16 port upgrade	NA	
bcS9QzbR99edTARs	Fabric Watch	NA	
rAXQF94WtFYXFfZfgWmPLBR7HP9GFWtKBA7NJ	Enhanced Group Management	NA	
	Add	Remove Close Refresh	
Add or remove feature licenses.	Mode: Advanced Free Professional Management Tool 10.64.210.217 AD	0 User:admin Role:admin 🗸	

Figure 8-78 Switch Administration License tab

The following licenses are currently enabled on this switch:

- Extended Fabric
- Performance Monitor, Trunking, Adaptive Networking
- ▶ 8 Gig FC
- ► Fabric
- Integrated Routing
- Second Ports on Demand licence additional 16 port upgrade
- ► FICON_CUP
- First Ports on Demand licence additional 16 port upgrade
- ► Fabric Watch
- Enhanced Group Management

Certain licenses might be available only for a limited time as indicated, in the Expiry Date column. In our example, all currently enabled licenses never expire.

To enable additional licenses, you need the following items:

- A license transaction key, which is supplied in the documentation when purchasing a license.
- A license ID of the switch. You can obtain this ID in two ways:
 - In the Switch Information panel on main Web Tools window as shown in Figure 8-79.

vitch Events, Information	
witch Events Switch Inform	ation
Last updated at	Mon Jul 20 2009 19:15:26 GMT+00:00
Switch	
Name	IBM_SAN80B_217
Status	Healthy
Fabric OS version	v6.2.0e
Domain ID	2(0×2)
WWW	10:00:00:05:1e:09:97:01
Туре	64.3
Role	Principal
Ethernet	
Ethernet IPv4	10.64.210.217
Ethernet IPv4 netmask	255.255.240.0
Ethernet IPv4 gateway	10.64.208.1
Ethernet IPv6	None
FC	
FC IPv4	None
FC IPv4 netmask	None
Zone	
Effective configuration	no configuration in effect
Other	
Manufacturer serial number	AHV0617D001
License ID	1011001010510-009701
Durp Durp	10.00.00.00.10.00.01.01
True	000400
Madal	002486
Ter	00
Tag Comunication of market	
Sequence number	Displicat
Mapufacturer	IBM
manuracturer	

Figure 8-79 License ID field

- Using the licenseIdShow command, as shown in Example 8-5.

Example 8-5 The licenseldShow command

```
IBM_SAN80B_217:admin> licenseIdShow
10:00:00:05:1e:09:97:01
```

Our SAN80B switch license ID is 10:00:00:05:1e:09:97:01, which is actually the same license ID as switch WWN.

You need the license ID and the transaction key from the documentation to obtain the *license activation key* on the Feature activation keys Web page, as discussed in the next section.

Obtaining the license activation keys

The Feature activation keys Web page is available at the following URL:

http://www.ibm.com/storage/key

Figure 8-80 displays the Web page. To obtain the license activation key:

1. Read the instructions carefully, then click **Generate one or more activation** keys.



Figure 8-80 Feature activation keys Web page

2. Enter your email address, switch WWN/License ID, and transaction keys as shown in Figure 8-81. Complete the fields as appropriate, then click **Continue**.

Email Notification						
* Email address	itso@us.ibm.com					
* Verify email address	itso@us.ibm.com					
Installation Site Information * World Wide Names/License ID's and Transaction Keys						
World Wide Name/License ID	Transaction Key					
10:00:00:05:1e:09:73:fd	6848c56b06f9f7fb22a247					
10:00:00:						
10:00:00:						
10:00:00:						
10:00:00:						
	Add more rows					
This data may be used by IBM or se you with information about other of below. Alternatively, if you would pr check the second box.	elected organizations, such as Lenovo, to provide ferings. To receive this via email, check the first box efer not to receive such information by any means,					
Please use e-mail to	send me information about other offerings.					
 Please do not use this data to send me information about other offerings. 						
By clicking Continue you agree tha above and as described in Privacy.	t IBM may process your data in the manner indicated					
Continue						

Figure 8-81 Feature activation keys: Enter email address, WWN/License ID, and transaction keys

3. Next, verify the entries (see Figure 8-82).

IBM Systems > Systems Support > network (SAN) >	Storage support > Storage area
SAN Switch featur	e activation
Activate a SAN Switch feature	
Please verify the following informat activation key(s).	ion, then click Submit to create feat
Email Notification	
Email address itso@us.i	bm.com
Installation Site Information	
World Wide Name/License ID	Transaction Key
10:00:00:05:1e:09:73:fd	6848c56b06f9f7fb22a247
Submit Sack	Cancel

Figure 8-82 Feature activation keys: Verify entered information

- 4. Click **Submit** to create license activation keys for the selected features.
- 5. Finally, the license activation keys are generated and presented to you, as shown in Figure 8-83. The license keys are also sent to your email address.

Activate a SAN Switch feature

Activation keys:	
------------------	--

World Wide Name	Transaction Key	License Key	Feature Name
10:00:00:05:1E:09:73:FD	6848C56B06F9F7FB22A247	TFfSD7HPXgNCmCtZ4W4tZGrXXgmGK7ABBJRFL	Enterprise Bundle: ISL Trunking, Advanced Performance Monitoring & Adaptive Networking

Installation Guide

Note: The following instructions assume the switch has been attached to a network and is accessible from your PC or workstation.

Via telnet

- Connect to the switch via telnet session from a terminal emulation program initiated on a PC or workstation on your network.
- Type the command: telnet [switch IP address]. When prompted, enter Administrator User name and password.
- After login, enter the command: licenseAdd "license-key" (quotes are needed for this command). Be sure to enter the license key value exactly as received.
- Check the status of installed license features by entering the command: licenseShow. This command displays a list of all licensed features enabled on the switch.

From a web browser (via GUI)

- 1. Connect to the switch with your browser. From the Switch view, select the Admin button.
- 2. When prompted, enter administrator user name and password.
- 3. On successful login, you will be presented the Admin screen, select the License Admin tab,
- Enter the new License Key. Be sure to enter the license key value exactly as received.
- 4. Select the Add License button.

To validate that this LicenseKey has been installed

From front panel display - if your switch is a model with a front panel display, the WWN can be shown on the display. Select the following command sequence: Status Menu > WorldWide Menu.

Figure 8-83 Feature activation keys: Generated license keys

In addition to the license keys, this Web page also displays installation steps that you need to take to enable the licenses on the switch.

Removing a license key

To remove a license key, follow these steps:

1. Highlight the license key to remove and click **Remove**, as shown in Figure 8-84.

- 2. Click Yes to confirm that you are removing the license.
- 3. Click **Refresh** to show that the license was removed.

WitchName: IBM_SAN80B_217 DomainID: 2(0x2) WWN: 10:00:000:51e:09:97:01 Mon Jul 20:2009 1 Trunking SNMP Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies Switch Network Firmware Download License License License Key Feature(s) Expiry Date SR9SceSRdRTSATds Extended Fabric NA aCYP7ZBLgXrGJrMmgYOLaC3XEDMaQQHG87BNH Performance Monitor,Trunking,Adeptive Networking NA aSNMY9m/ATRWZEXZEYSNM4N7atTY4rHBSBLN 8 Gig FC NA NA bgezoebScRf0dk Fabric NA NA	9:45:27 GMT+I User	
SNMP Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies Switch Network Firmware Download License Icense Icense	User	
Switch Network Firmware Download License License Administration License Administration Expiry Date License Administration Feature(s) Expiry Date SR9SceSRdRTSATds Extended Fabric NA aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH Performance Monitor,Trunking,Adaptive Networking NA aSMN49m7ATR/WZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA bQezcSebScRft0dk Fabric NA	User	
License Administration Expiry Date License Key Feature(s) Expiry Date SR9SceSRdRTSATds Extended Fabric NA aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH Performance Monitor,Trunking,Adaptive Networking NA aSMN49m7ATRWZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA opezcSebScRft0k Fabric NA		
Elicense Key Feature(s) Expiry Date License Key Feature(s) Extended Fabric NA aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH Performance Monitor,Trunking,Adaptive Networking NA aSMN49m7ATR/VZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA vgezcSebScRfddk Fabric NA		
SR9SceSRdRTSATds Extended Fabric NA icCYP7ZBLgXrGJrMmgYQLac3XEDMaQQHGB7BNH Performance Monitor,Trunking,Adaptive Networking NA isMN49m7ATRVZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA vQezcSebScRf0dk Fabric NA	Expiry Date	
ICYP7ZBLgXrGJrMmgYQLaC3XEDMaQQH0B7BNH Performance Monitor,Trunking,Adaptive Networking NA ISMN49m7ATRV/ZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA GezcSebScRf0dk Fabric NA CSC0cbP80exUABc Idearated Routing	NA	
SMN49m7ATRWZEXXZEY9NM4N7atTY4rHBSBLN 8 Gig FC NA vgezcSebScRf0dk Fabric NA	NA	
QezcSebScRf0dk Fabric NA	NA	
Integrated Routing NA	NA	
Integrated Hotaling	NA	
cS9QzbR99cdXARu Second Ports on Demand license - additional 16 port upgrade NA	NA	
cS9gzbr99cfTARs FICON_CUP NA	NA	
bcS9QzbR99ctTAR6 First Ports on Demand license - additional 16 port upgrade NA	NA	
pcS9QzbR99edTARs Fabric Watch NA		
AXQF94VMFYXF1ZfgWmPLBR7HP9GFVVfKBA7NJ Enhanced Group Management NA	NA	

Figure 8-84 Removing a license

Installing a license key through the CLI

To install a license key feature using the CLI, perform the following steps:

1. From a command prompt, use the Telnet command to log in to the switch using an account that has administrative privileges. In the following example, we replace *address* with the switch IP address:

C:\telnet address

2. To determine which licenses are already installed on the switch, run the **licenseShow** command. A list displays of all the licenses currently installed on the switch, as shown in Example 8-6.

Example 8-6 The licenseshow CLI output from SAN40B-4

```
IBM_SAN80B_217:admin> licenseShow
bQezcSebScRfOdk:
    Fabric license
bcS9QzbR99edTARs:
    Fabric Watch license
SR9SceSRdRTSATds:
    Extended Fabric license
```

```
bcS9QzbR99cdVARs:
    Integrated Routing license
bcS9QzbR99ctTAR6:
    First Ports on Demand license - additional 16 port upgrade license
bcS9QzbR99cdXARu:
    Second Ports on Demand license - additional 16 port upgrade license
rAXQF94WtFYXFfZfgWmPLBR7HP9GFWfKBA7NJ:
    Enhanced Group Management license
aSMN49m7ATRWZEXXZEY9NM4N7atTY4rHBSBLN:
    & Gig FC license
aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH:
    Performance Monitor license
    Trunking license
    Adaptive Networking license
```

3. To install a license key, enter the following command on the command line:

licenseAdd "key"

In this command, "*key*" is the license key that is provided to you, enclosed in double quotation marks. The license key is case sensitive, so you must enter it exactly as given as shown in Example 8-7.

Example 8-7 Adding a License Key

```
IBM_SAN80B_217:admin> licenseAdd "bcS9QzbR99cfTARs"
adding license-key [bcS9QzbR99cfTARs]
```

4. Use licenseShow again to verify that the license was added.

If the license is listed, the feature is installed and available. Otherwise, repeat step 3.

Example 8-8 adds the FICON_CUP license to the SAN80B switch.

Example 8-8 Adding licenses

```
IBM_SAN80B_217:admin> licenseShow
bQezcSebScRfOdk:
    Fabric license
bcS9QzbR99edTARs:
    Fabric Watch license
SR9SceSRdRTSATds:
    Extended Fabric license
bcS9QzbR99cdVARs:
    Integrated Routing license
bcS9QzbR99ctTAR6:
    First Ports on Demand license - additional 16 port upgrade license
```

```
bcS9QzbR99cdXARu:
    Second Ports on Demand license - additional 16 port upgrade license
bcS9QzbR99cfTARs:
    FICON_CUP license <-----New License
rAXQF94WtFYXFfZfgWmPLBR7HP9GFWfKBA7NJ:
    Enhanced Group Management license
aSMN49m7ATRWZEXXZEY9NM4N7atTY4rHBSBLN:
    8 Gig FC license
aCYP7ZBLgXrGJrMmgYQLaC3XEDMaQQHGB7BNH:
    Performance Monitor license
    Trunking license
    Adaptive Networking license
```

8.7.7 User tab

The User tab allows you to perform user administration tasks, such as adding new users, changing properties of existing users, and deleting user accounts that are no longer needed.

BM_SAN8	30B_217 - Swi	tch Administrati	ion						Show Basic Mode
itchName: I	IBM_SAN80B_2	17		DomainID: 2(0x2) W	WVN: 10:00:00:0	05:1e:09:97:01		Mon Ju	II 20 2009 20:10:28 GMT+I
unking	SNMP Confi	gure Routing	Extended Fabric	AAA Service Trac	ce FICON C	JP Security F	Policies		
Sv	vitch	Net	work	F	irmware Down	load		License	User
witch Lloo	r Account								
witch ose	a Account								
Add	Modify	Remove Ch	ange Password	Expire Password	Unlock Passw	ord Set P	assword Rule		
lser Name	Role	Description	Status	Expiration Date Expiration S	St Lockout	Home AD	AD List		
ot	root	root	Enabled	No	No	AD0	ALL		
ictory	factory	Diagnostics	Enabled	No	No	AD0	ALL		
dmin	admin	Administrator	Enabled	No	No	AD0	ALL		
ser	user	User	Enabled	No	No	AD0	AD0		
lex	admin	Redbook user	Enabled	No	No	AD0	AD0		
								Appl	y Close Refresh
an and Share	ch Liser Accour	t information		Mode: Advance	d Free Prof	essional Manada	ment Tool 10 B	1 210 217 AD0 LL	er: admin Role: admin

Figure 8-85 displays the layout of the User tab.

Figure 8-85 User tab

To add a new user:

1. Click **Add** to open the Switch Admin: Add User Account window, as shown in Figure 8-86.

🖪 Switch Admin:	Add User Account
User Name	IBMuser
Role	switchadmin 💌
Description	Redbook User
Status	Enabled Disabled
New Password	••••••
Confirm Password	••••••
Admin Domain	
O AII	
Select Admin Do	omain
AD0	
🗌 Physical Fa	abric
	_
Home AD ADU	▼
	QK Cancel Help

Figure 8-86 Add User Account

2. In this example, we add a user named *IBMuser* with the *switchadmin* role. The user is associated with AD0. After entering all the necessary information, click **OK**, and the new user is created (see Figure 8-87).

shiname, ibn	M_SAN80B_217			DomainID:	2(0x2) VWM	V: 10:00:00:05:1	e:09:97:01		Mon Jul 20	2009 20:20:28 GMT+
		Deutien	Enders de la Francis				(D-1-1		
nking Swith	IMP Contigur	e Kouting	Extended Fabri	C AAA Serv	/ice Trace	FICON COP	Security	Policies	License	Hear
39910	ch	INCL	WORK			ware Download	4		LICENSE	0361
/vitch User /	Account									
							_			
Add	Modify Re	move Cha	ange Password.	Expire Pa	ssword Ur	nlock Password	Set F	assword Rule		
ser Name	Role	Description	Status	Expiration Date	Expiration St.	Lockout	Home AD	AD List		
ot	root	root	Enabled		No	No	ADO	ALL		
ctory	factory	Diagnostics	Enabled		No	No	AD0	ALL		
imin .	admin	Administrator	Enabled		No	No	AD0	ALL		
ser	user	User	Enabled		No	No	AD0	AD0		
lex	admin	Redbook user	Enabled		No	No	AD0	AD0		
Muser	switchadmin	Redbook User	Enabled	Default Expir	No	No	AD0	AD0		

Figure 8-87 New user is created

3. A set of buttons above the list of users allows you to perform the user administration tasks. We have seen the use of the **Add button**, Table 8-9 explains the remaining buttons in the User tab and their actions.

Table 8-9 User administration button actions

Button	Action
Modify	Use this button to change the user account properties.
Remove	Deletes the currently selected user.
Change Password	Set the user's password to a new value.
Expire Password	Set the user's password to expired state.
Unlock Password	Reset locked-out users.
Set Password Rule	Define the rules for user's password.

4. For the changes to be committed successfully to the switch, you must click **Apply** to open a window and confirm your actions, as shown in Figure 8-88.

User: Con	firm Action	X
?	You are about to make the following change(s):	
	 Changes to User Account	
	Add user account: IBMuser Name : IBMuser Role : switchadmin Description: Redbook User Status : Enabled LockoutStatus: No ExpiredStatus: No Home Admin Domain: AD0 AD List: [AD0]	
	Do you want to save the changes?	
	⊻es No Cancel	

Figure 8-88 Confirm changes to user account

5. Click **Yes** to confirm and commit the changes and to complete the process of adding a new user.

In this example, we set the new user to be the *switchadmin*. Other available access levels include:

► Admin:

This access level allows change and view access to all functions. From Telnet access, the Admin level allows use of all available commands. Typically, most switch administration is performed at this level.

► User:

This access level provides view access only. Users cannot make zoning changes or any switch configuration changes. This level is best for monitoring switch activity.

SwitchAdmin:

This new role has most of the existing permissions of the traditional Admin role but cannot create or change fabric security policies, cannot create or change fabric zoning policies, and cannot create or manage users.

► FabricAdmin:

The FabricAdmin role can perform administrative tasks, but cannot manage users. It also cannot perform AD management.

ZoneAdmin:

This role allows zone management only.

► BasicSwitchAdmin:

BasicSwitchAdmin access level is a subset of Admin role. Most available tasks are for monitoring purpose and can perform limited local switch management.

Operator:

This role can perform a set of tasks required to do routine maintenance.

SecurityAdmin:

SecurityAdmin can exercise security related tasks. This includes user management tasks.

Attention: The User tab does not display or modify the RADIUS host server database.

8.7.8 Configure tab

Figure 8-89 shows the Configure tab. You cannot make changes to the settings on this tab if the switch is enabled; however, the configuration upload/download facility is available regardless of the switch status. In our example, we disable the switch so that we can make configuration changes.

IBM_SAN	180B_21	7 - Switch	Administrati	on								_ 🗆 🗙
											Show I	Basic Mode
SwitchName	: IBM_SA	N80B_217			DomainID: 2(0×2) WWN	: 10:00:00:05:1	e:09:97:01		Mon Jul 20	2009 20:2	6:28 GMT+00:00
Trunking	SNMP	Configure	Routing	Extended Fabric	AAA Service	Trace	FICON CUP	Security Policies				
s	Switch		Net	work		Firmv	vare Download	ł	Licer	nse		User
BB Credit R_A_TOV E_D_TOV Datafield S	16 / 100 / 200 Size 21/	000			Sequer	nce Level Device P Ime Routir ss Class It Domain	Switching robing ng Priority F Traffic ID Mode					
Fabric	Virtual	Channel	Arbitrated Loc	ıp System İr	teroperability Fir	mware	Upload/Down	nload		Apply	Close	Refresh
Configure Sw	/itch Para	meters			Mode: Adv	vanced	Free Professi	ional Management Tool	10.64.210.217	AD0 User: a	admin R	ole: admin 🛛 🗙

Figure 8-89 Switch Administration: Configure tab

The Configure tab includes the following tabs:

- ► Fabric
- Virtual Channel
- Arbitrated Loop
- ► System
- Interoperability
- ► Firmware
- ► Upload/Download

In the sections that follow, we describe the parameters that are configurable through each of these tabs.

Fabric parameters

The following Fabric parameters are available:

- BB Credit: The buffer-to-buffer (BB) credit represents the number of buffers available to attached devices for frame receipt. This value ranges from 1 to 27. Default value is 16.
- R_A_TOV: The Resource Allocation Time Out Value (R_A_TOV) is displayed in milliseconds. Allocated circuit resources with detected errors are not released until this timeout value has expired. If the condition is resolved prior to the timeout, the internal time out clock resets and waits for the next error condition.
- E_D_TOV: Error Detect Time Out Value (E_D_TOV) is displayed in milliseconds. This timer is used to flag a potential error condition when an expected response is not received (an acknowledgment or reply in response to packet receipt, for example) within the set time limit. If the time for an expected response exceeds the set value, then an error condition occurs.
- ► Datafield Size: The largest datafield size in bytes.
- Sequence Level Switching: When Sequence Level Switching is enabled, frames of the same sequence from a particular source are transmitted together as a group. When this is feature disabled, frames are transmitted interleaved among multiple sequences. Under normal conditions, Sequence Level Switching needs to be disabled for better performance.
- Disable Device Probing: When Disable Device Probing is enabled, devices that do not register with the Name Server are not present in the Name Server data base. Set this mode only if the switch N_Port discovery process (PLOGI, PRLI, INQUIRY) causes an attached device to fail.
- Per-Frame Routing Priority: In addition to the eight virtual channels used in frame routing priority, support is also available for per-frame-based prioritization when this value is set. When Per-Frame Routing Priority is enabled, the virtual channel ID is used in conjunction with a frame header to form the final virtual channel ID.
- Suppress Class F Traffic: When enabled, all class F interswitch frames are transmitted as class 2 frames to support remote fabrics which involve ATM gateways, which do not support class F traffic.
- Insistent Domain ID Mode: Setting this mode makes the current domain ID insistent across reboots, power cycles and failover, which required fabric wide to transmit FICON data.

Virtual Channel parameters

This feature enables fine tuning of ISLs by configuring parameters for the eight virtual channels. These parameters are used for congestion control. Use the default values for these parameters unless expert advice is available. Figure 8-90 displays the Virtual Channel tab.

IBM_SAN80B_217 - Switch Administration	
	Show Basic Mode
SwitchName: IBM_SAN80B_217 DomainID: 2(0x2) VWNI: 10:00:00:05:1e:09:97:01 Mon Jul	20 2009 20:38:28 GMT+00:00
Trunking SNMP Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies	
Switch Network Firmware Download License	User
VC Priority 2 2 VC Priority 3 2 VC Priority 4 2 VC Priority 5 2 VC Priority 6 3 VC Priority 7 3	
Fabric Virtual Channel Arbitrated Loop System Interoperability Firmware Upload/Download	
	Close Refresh

Figure 8-90 Virtual Channel tab

Arbitrated Loop parameters

The Arbitrated Loop parameters include these:

- Send Fan Frames: Specifies that fabric address notification (FAN) frames be sent to public loop devices with notification of their node ID and address. When enabled, frames are sent, and when disabled, frames are not sent.
- Always send RSCN: Following the completion of loop initialization, a Registered State Change Notification (RSCN) is issued when FL_Ports detect the presence of new devices or the absence of pre-existing devices. When this mode is enabled, a RSCN is issued upon completion of loop initialization, regardless of the presence or absence of new or preexisting devices.
- Do Not Allow AL_PA 0x00: This option disallows AL_PA values from being 0.

System parameters

The System tab lets you change the *Disable RLS probing* parameter. Use this setting to disable Read Link Error Status of the AL_PAs.

Interoperability parameters

The Interoperability tab allows you to set the switch to operate in one of the following modes:

- Brocade Native Fabric Mode
- McDATA Fabric Mode
- ► McDATA Open Fabric Mode

If you need to set either of the two McDATA modes, be aware of the following considerations:

- The McDATA Fabric Mode requires that the domain ID is in the range 1 through 31.
- ► The McDATA Open Fabric Mode domain ID range is 97 through 131.

If the domain ID is outside these values when you try to enable McDATA interoperability mode, Web Tools prompts you to change the domain ID first.

When enabling any McDATA interoperability mode, the zoning database is reset.

Firmware parameters

The Firmware tab contains only one parameter, which is *Enable Signed Firmware Download*. When this option is enabled, the system validates the firmware that is downloaded to the switch. Firmware validation cannot be done during the very first download; however, after the first firmware download is complete, the public key is downloaded, so that the validation works on subsequent firmware downloads.

Upload/download parameters

The Upload/Download tab enables you to manipulate the switch configuration. You can store (upload) the configuration to an FTP server or to a Brocade-branded USB memory key and download a previously stored configuration from the FTP server or USB key to the switch.

Figure 6-91 shows an example of the Opload/Download tab.	Figure 8-91	shows an e	example of	the Upload	d/Download tab.
--	-------------	------------	------------	------------	-----------------

R IBM_SAN80B_217 -	Switch Administration					
						Show Basic Mode
SwitchName: IBM_SAN80)B_217	DomainID: 2(0	x2) VWVN: 10:00:00:05:	1e:09:97:01	Mon Jul 2	0 2009 20:47:29 GMT+00:00
SNMP Configure	Routing Extended Fabric	AAA Service	Trace FICON CUP	Security Policies		
Switch	Network	Firmwa	re Download	License	User	Trunking
Function Config Upload	Config Download to Switc nfiguration file: Networ	n k OUSB ansfer Protocol a	nd Path for Configurat	ion file		
Host Name or IP	*Password is optional, if u	ser name is "anonyr	mous"			
User Name	ibm					
Password	•••••					
Protocol Type	File Transfer Protocol (FT	P)			-	
Configuration File Nam	e SAN80B_config_200709				-	
Fabric Virtual Cha	annel Arbitrated Loop	Upload/Download System Interope	d Progress:	Upload/Download	Apply	Close Refresh
Enter the Password		Mode: Advanced	Free Professional Man	agement Tool 10.64.2	10.217 AD0 User:	admin Role: admin 🗙

Figure 8-91 Upload/Download tab

To save the configuration file to an FTP server, proceed as follows:

- 1. Click Config Upload.
- 2. Provide the FTP server IP address, user name, password, and file name of the configuration file.

Naming: Remember to use a sensible naming convention for your configuration files to ensure that you are able to recover to the appropriate point as required.

- 3. Then, click Apply.
- 4. When prompted to verify that you want to perform this function (as shown in Figure 8-92), click **Yes** to continue.



Figure 8-92 Confirm configuration upload

When completed, the confirmation message for the upload displays on the report window.

8.7.9 Routing tab

We discuss the Routing tab in 13.1.5, "Routing policies" on page 601.

8.7.10 Extended Fabric tab

We discuss the Extended Fabric tab in "Extended Fabrics" on page 595.

8.7.11 AAA Service tab

Fabric OS v6.1.0 supports RADIUS and Active Directory server authentication. You can use the Switch Administration AAA Service tab to configure the RADIUS or Active Directory servers. Figure 8-93 shows the AAA tab.

R IBM_SAN80B_217	- Switch A	Administrati	ion									
											Shov	v Basic Mode
SwitchName: IBM_SAN8	0B_217			DomainID: 2	(0×2) VWV	N: 10:00:00:05:1e	:09:97:01			Mon	Jul 20 2009 20):52:29 GMT+00
SNMP Configure	Routing	Extended F	abric AAA S	ervice Trac	e FICON	CUP Security	Policies					
Switch	r -	Network		Firmwa	ire Downloa	d		License	ľ	User	Т	runking
AAA Service												
Primary AAA Service	Switch [Database		•	Secon	dary AAA Servic	e None			•		
RADIUS Configuration	1											
Server Port	1	limeout(s)	Authentication								1	
												<u>A</u> dd
ADLDAP Configuration	n											Modify
Server Port	1	limeout(s)	Domain									Remove
											1	
										0.00	class.	Patroph
										AP	pry Close	Reifesh
A ▼ Configure AAA Service e	od RADIUS	Sservers		Mode: A	dvanced	Free Professiona	l Managem	ent Tool	10.64.210.217	AD0 L	Jser: admin	Role: admin

Figure 8-93 AAA Service tab

Click **Add** to configure RADIUS or Active Directory server. A dialog box displays, as shown in Figure 8-94. Enter the appropriate values and click **OK**.

🛃 SwitchAdmii	n: RADIUS/ADLDAP Configuration
Server Type	RADIUS
Server	
Port	1812
Timeout(s)	3
Secret String	sharedsecret
Authentication	CHAP
	<u>O</u> K <u>C</u> ancel

Figure 8-94 Adding RADIUS server

You can configure up to five RADIUS servers and reorder them at a later time on the AAA Service tab panel. RADIUS servers are contacted in the order that they display in the RADIUS Configuration list.

Figure 8-95 shows an example of configuring an Active Directory server.

🖪 SwitchAdmi	n: RADIUS/ADLDAP Configuration
1	
Server Type	ACTIVE DIRECTORY
Server	
Port	389
Timeout(s)	3
Domain	
	<u>O</u> K <u>C</u> ancel

Figure 8-95 Active Directory server configuration

Now that the servers are defined, you can modify or remove them by highlighting them and clicking either **Modify** or **Remove**. When you have finished listing all the servers in the configuration, you can change the order in which they are contacted for authentication by using the up and down arrow on the right of the window displaying the list of servers. Table 8-10 describes the details of the AAA tab functions.

Function	Description
Primary AAA Service	Primary Service Engine
Secondary AAA Service	A Backup Service Engine
RADIUS configuration	A window displaying RADIUS servers in the configuration
ADLDAP configuration	Active Directory LDAP server
Port	Port for which RADIUS or ADLDAP server is defined
Timeout or timeouts	Timeout value in minutes
Authentication	Authentication protocol used
Up/Down Arrows	Navigate order for which servers are contacted
Add	Add a new RADIUS or ADLDAP server
Modify	Modify an existing RADIUS or ADLDAP server
Remove	Remove an existing RADIUS or ADLDAP server
Apply	Apply and commit changes to the switch
Close	Close the Administration window
Refresh	Refresh the view from the current switch data

Table 8-10 AAA tab functionsPorts tab

8.7.12 Trace tab

If a switch experiences a serious problem, a trace dump can be generated to capture valuable information about the running state. IBM and Brocade technical support teams can use the trace dump to help understand and solve the problem. Tracing is enabled at all times. The tracing information is stored continuously into a circular buffer in switch system memory. Thus, old trace information eventually is overwritten with new information. Capturing a trace dump means storing the current content of the trace buffer. This way, you can preserve important troubleshooting information before it is overwritten.

Trace dump generation takes place in the following cases:

- ► You can trigger the trace dump manually using the CLI traceDump command.
- ► A trace dump can occur when a critical-level LOG message occurs.
- You can use the CLI traceTrig command to set up trace dump generation in case of another particular LOG message.
- A trace dump can occur if a kernel panic occurs.
- ► A trace dump can occur when the hardware watchdog timer expires.

After the trace dump is generated, it needs to be uploaded to an FTP server. Otherwise, the next trace dump will overwrite the existing one.

The Trace tab allows you to set the FTP server upload parameters for a trace dump as follows:

- FTP host server IP address, directory, and login credentials
- Automatic or manual trace dump upload

Use this option to enable automatic trace dump upload as soon as the trace dump is generated.

Figure 8-96 shows the trace dump upload settings. The Trace Dump Availability section of this panel displays information about the last trace dump taken and whether the dump was uploaded automatically to the FTP server.

🖪 IBM_	5AN80	B_217	- Switch /	Administration									
												Sho	w Basic Mode
SwitchName: IBM_SAN80B_217 DomainID: 2(0x2) VW/N: 10:00:00:05:1e:09:97:01 Mon Jul 20 2009 21:08:30 GMT+0								1:08:30 GMT+00:00					
SNMP	Con	figure	Routing	Extended Fabric	AAA Service	Trace FICC	N CUP	Security P	olicies				
	Switch			Network		Firmware Downlo	bad		License	•	User		Trunking
Trace	FTP Ho	ost											
Host	IP	10.64.2	10.103			Remote Di	rectory	SAN80B					
User	Name	ibm				Password	·	•••••					
	D	o 11 - 1- 11											
Irace	Dump	4vallabil	ty										
Trace	e dump g	generatio	on time: Mo	n Jul 20 21:07:08 20	09								
			_										
Trace	e Auto F	TP Uplo	aded:										
Auto F	FTP Upl	oad											
•	Enable	\bigcirc Dis	able										
											Annly	Close	Refresh
											. (66)		
A 7													
Enable At	uto F I P	upload			M	ode: Advanced	Free F	roressional N	nanagement lool	10.64.210.217	ADU USE	r: admin	Role: admin 🗸

Figure 8-96 Switch Administration: Trace tab

8.7.13 Security Policies tab

You use the Security Policies tab to configure the Access Control List (ACL) policies. Fabric OS v6.1.0 supports the following ACL policy types:

- ► Fabric Configuration Server (FCS) policy
- Device Connection Control (DCC) policy
- Switch Connection Control (SCC) policy
- ► IP Filter policy

IBM_S	AN80B_217	- Switch	Administration						
									Show Basic Mode
SwitchNa	me: IBM_SAN8	0B_217		Doma	inID: 2(0×2) VWVN: 1	0:00:00:05:1e:09	:97:01	Mon Jul	20 2009 21:31:39 GMT+00:00
SNMP	Configure	Routing	Extended Fabric	AAA Service	Trace FICON CU	Security Po	licies		
s	witch		Network	F	irmware Download		License	User	Trunking
Security	Policies 🕱	ACL	- Switch Connection	Control Policy					
ACL		R	eject Distribution						
FWCP		— G	eneral Information -						
Authe	ntication	Acc	epts Distribution Ye cy Scope Al	es osent					
IPSec	Policies								
IPFilte	r	M	lembers of SCC Policy						
Ethern	net IPSec	De	fined Policy Set			A	ctive Policy Set		
		l sc							
								Edit Activat	e Close Refresh
A 7				Mode: Advar	nced Free Professio	nal Management	Tool 10.64.210.21	7 Physical Fabric Use	r:admin Role:admin 🖌

Figure 8-97 shows an example of the Security Policies tab.

Figure 8-97 Switch Administration: Security Policies tab

From this tab, you can add new FCS, SCC, DCC, and IP Filter policies by clicking **Edit**. You must also activate the policies after you create them. We explain the different policies in the following sections.

Attention: All the actions in this section require the user to be logged in to Administrative Domain (AD) 255 with the suggested role. If Administrative Domains have not been implemented, log in to AD0.

FCS policy

The FCS policy is used to restrict which switches can perform the fabric-wide configuration changes. If you do not set up and activate this policy, then any switch can change fabric configuration.

If the FCS policy is active, then the following rules apply:

- If the FCS list contains only one switch, there will be no backup FCS switches. In case the FCS switch is unavailable, the fabric is left without an FCS switch.
- If multiple FCS switches are defined, the first switch in the list is designated as primary FCS switch. Others are backup FCS switches. In case of primary FCS switch failure, the next switch on the FCS list becomes the new primary.

Figure 8-98 shows an example of adding two switches to the FCS list.

FCS Policy Configuration Dialog			×
The first one in selected switches list will b	e set as prima	ry FCS switch.	
Switches for selection		Selected Switches	
件 <u>Search</u>		B ^a	8 <u>Search</u>
IBM_2498_B80(3, 10:00:00:05:1e:09:97:01)		IBM_2498_B80(3, 10:00:00:05:1e:09:97:01)	
IBM_2498_B40(4, 10:00:00:05:1e:09:73:fd)	Add>> < <remove< th=""><th>IBM_2498_B40(4, 10:00:00:05:1e:09:73:fd)</th><th></th></remove<>	IBM_2498_B40(4, 10:00:00:05:1e:09:73:fd)	
Enter Offline Switch WWN			
Add offline switch >			
		<u>o</u> k g	<u>C</u> ancel

Figure 8-98 Adding switches to FCS policy list

DCC policy

You use DCC policies to specify which Fibre Channel devices can connect to which Fibre Channel switch ports. If no DCC policy is defined, then any device can attach to any switch port in the fabric. DCC policy is configured by specifying the device port WWN and the switch port to which it can connect. You can define multiple DCC policies, and you can use particular device WWNs and switch ports in several DCC policies. This way, you can create a set of ports that a certain device is allowed to use, and a set of devices that can connect to a certain port.

Devices that are not listed in any DCC policy can connect to any switch port that is not specified in a DCC policy. Proxy devices can always connect to any switch port in the fabric. Setting up a DCC policy has no effect on these devices.

DCC policies names must always have a prefix DCC_POLICY_. The total allowed length of names is 30 characters, including the mandatory prefix. This leaves up to 19 alphanumeric or underscore characters to select a unique DCC policy name.

DCC Policy Name	_POLICY_storage1			
Available Switches & Devices			Switches & Device Members	
	A Search			A Searc
Devices	-		Switches	
Switches (2 Switches)	35		E- 😂 10:00:00:05:1e:09:97:01(IBM_2498_B	30)
- 🥪 3(IBM_2498_B80)			Port0 - index # 0	
Port0 - index # 0				
- Port1 - index # 1				
Port2 - index # 2				
Port3 - index # 3				
— 📟 Port4 - index # 4				
— 🔳 Port5 - index # 5		Add >>		
— 🎟 Port6 - index # 6		CC Remove		
— 🔳 Port7 - index # 7				
— 🔳 Port8 - index # 8				
— 🔳 Port9 - index # 9				
— 🔳 Port10 - index # 10				
Port11 - index # 11				
— 📟 Port12 - index # 12				
Port13 - index # 13				
Port14 - index # 14				
Port15 - index # 15				
Port16 - index # 16				
Port17 - index # 17				
Port18 - index # 18				
Port19 - index # 19	-			
Add Device/Port VW/N			Add >>	

Figure 8-99 shows an example of defining a DCC policy.

Figure 8-99 Defining a DCC policy

SCC policy

You use the SCC policy to control which switches can join the fabric. As opposed to DCC policy (where you can define multiple policies), there can be only one SCC policy, and its name must be SCC_POLICY.

If the SCC policy does not exist, then any switch can join the fabric; however, if you have defined the policy, then only the switches that are included in the policy can be fabric members. Use WWN, Domain ID, or switch names to indicate the member switches.

IP Filter policy

You can use the IP Filter policy to secure the IP management interfaces. By configuring these policies, you can set up a firewall which permits or denies the IP management traffic based on the policy rules. You can have up to 256 rules within an IP Filter policy, and each rule includes:

- The source IP address or an address group prefix
- The destination port number or name (for example, Telnet, SSH, HTTP, and so forth.)
- Protocol type (TCP or UDP)
- Filtering action for the rule (permit or deny)

For example, you can configure a policy to permit Telnet access only from a certain IP address.

To provide separate packet filtering for IPv4 and IPv6 addressing, two IP Filter policy types exist. Each policy type can have up to six policies defined, but only one policy per type can be activated.

Figure 8-100 shows an example of creating an IP Filter policy.

🖪 Create IP Filter P	olicy			X
Policy Details				
Policy Name Telnet_pol	icy1			
Policy Type IPV4			T	
IP Filter Rules				
Add Rule Delete	e Rule Copy	To New Rule		
Item: 1			Export	Copy A Search
Rule Order 🔺	Source IP	Service/Destination Port	Protocol	Permission
1	10.64.223.10	TELNET	tcp	Permit
			Create Policy	/ <u>C</u> ancel

Figure 8-100 Creating an IP Filter policy

8.7.14 FICON CUP tab

The FICON CUP tab within Web Tools allows for FICON configuration. This topic is beyond the intended scope of this book.

8.7.15 Trunking tab

We discuss the Trunking tab in 13.1.3, "ISL Trunking" on page 590.

8.8 Telnet/SSH Client task

This task allows you to connect to the switch using Telnet or the SSH client. To initiate connection:

1. Click Telnet/SSH Client in the Tasks panel (see Figure 8-101).

Other	*
🚽 Telnet/SSH Client	

Figure 8-101 Telnet/SSH Client task

2. In the Preference Dialog box, shown in Figure 8-102, select either the Telnet or SSH client, and provide the path to the client utility (for example, PuTTY). Then, click **OK**.

Wr Pref	ference Dialog	×
Select tł	he Client 🔘 Telnet 🔿 SSH	
Telnet	C:\Users\Administrator\Desktop\putty.exe	
SSH	C:\Users\Administrator\Desktop\putty.exe	
		ancel

Figure 8-102 Telnet/SSH Preference Dialog box

3. In our example, we use PuTTY as the Telnet Client. The utility then launches, as shown in Figure 8-103. After entering IP address of the switch, PuTTY establishes connection and we are prompted to login.
| RuTTY Configuration | | | X |
|---|--|---|-------------------------------------|
| Category: | | | |
| Category:
Session
Logging
Terminal
Keyboard
Bell
Features
Window
Appearance
Behaviour
Translation
Selection
Colours
Connection | Basic options
Specify the destination
Host Name (or IP addr
10.64.210.213
Connection type:
C Raw Telnet
Load, save or delete a
Saved Sessions
DCX4s 10.64.210.213
Default Settings
256b_1 | s for your PuTTY s
you want to conn
ess)
C Riogin C SS
stored session | ession
Port
23
CH O Serial |
| Data
Proxy
Telnet
Rlogin
SSH
Serial | AIX
B5300 10.64.210.217
DCX 10.64.210.210
DCX4s 10.64.210.213
b32_1
Close window on exit:
C Always C New | er © Only on | Cancel |
| About | | Upen | Lancel |

Figure 8-103 PuTTY as SSH client

8.9 Fabric Watch task

To access the Fabric Watch function, click **Fabric Watch** from the Tasks panel, as shown in Figure 8-104.

Manage	*
🛃 Zone Admin	
🛃 Switch Admin	
👰 Port Admin	
🕂 Admin Domain	
^{完党} FCR	
🙀 Fabric Watch	

Figure 8-104 Fabric Watch button

Fabric Area Selection Fabric SVritch Environment SFP State Changes Security Environment Security Reason Last Value Time PabricSS000 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Resource Fill fabricSS008 Informative Above 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) Fri Jul 17 Port fabricSS075 Informative Above 1 Change(s) Fri Jul 17 Port fabricSS075 Informative Above 1 Change(s) S Change(s) Mon Jul 2 F/FL Optical Port Performance End-to-End Filter-Based Informative Above S Change(s) 3 Change(s) Mon Jul 2	
Fabric SFP State Changes Switch Environment SFP Security Resource Informative FRU fabricSS008 Informative Above 1 Change(s) 1 Change(s) FRU fabricSS008 Ports Informative Ports fabricSS027 Informative Above 1 Change(s) 1 Change(s) Ports Informative Port E-Port F/FL Optical Port Performance End-to-End Filter-Based	
Switch Environment SFP Name State Reason Last Value Current Value Time Resource fabricSS000 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Pru fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS018 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) Fri Jul 17 Port fabricSS018 Informative Above 1 Change(s) Fri Jul 17 E-Port fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 Fif-L Optical Port Fif-L Optical Port Fif-L Optical Port Fif-L Optical Port State State State State Fifter-Based Informative Above 3 Change(s) 3 Change(s) Mon Jul 2	
SFP Name State Reason Last Value Current Value Time Security Resource fabricSS000 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 fabricSS017 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 fabricSS027 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 fabricSS027 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 fabricSS048 Informative Above 1 Change(s) 3 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 FrFL Optical Port Fride Contemport Above Above 3 Change(s) Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 3 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4 Change(s) Above 4 Change(s) Fri Jul 17 fabricSS075 Informative Above 4 Change(s) Above 4	_
SPP Name State Reason Last Value Current Value Time Security fabricSS000 informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Resource fabricSS008 informative Above 1 Change(s) 1 Change(s) Fri Jul 17 FRU fabricSS027 informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS048 informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Port fabricSS048 informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Port fabricSS075 informative Above 3 Change(s) 3 Change(s) Mon Jul 2 E-Port fabricSS075 informative Above 3 Change(s) 3 Change(s) Mon Jul 2 FFL Optical Port performance End-to-End Filter-Based Filter-Based	
Security fabricSS000 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Resource fabricSS008 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 FRU fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS027 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS048 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS075 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 E-Port fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 F/FL Optical Port performance End-to-End Filter-Based Filter-Based	
Resource fabricSS008 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 FRU fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Port fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Front fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 F.FL Optical Port FifL Optical Port Fifter-Based Fifter-Based Fifter-Based Fifter-Based	2009 2
FRU fabricSS016 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports Above 1 Change(s) 1 Change(s) Fri Jul 17 Port Above 1 Change(s) 1 Change(s) Fri Jul 17 FPrt E-Port Above 1 Change(s) 1 Change(s) Fri Jul 17 FrEU fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 F.FL.Optical Port Performance End-to-End Filter-Based Filter-Based Filter-Based Filter-Based	2009 2
Into fabricSS027 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 Ports fabricSS048 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 FabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 F.FL Optical Port -	2009 2
Port fabricSS048 Informative Above 1 Change(s) 1 Change(s) Fri Jul 17 E-Port F/FL Optical Port Performance End-to-End Filter-Based	2009 2
Port fabricSS075 Informative Above 3 Change(s) 3 Change(s) Mon Jul 2 F.FL Optical Port Performance End-to-End Filter-Based	2009 2
E-Port F/FL Optical Port]Performance End-to-End Filter-Based	0 2009
F.FL Optical Port Performance End-to-End Filter-Based	
Performance Enu-to-End Filter-Based	
_ End-to-End	
End-to-End Filter-Based	
- Filter-Based	

The Fabric Watch window opens, as shown in Figure 8-105.

Figure 8-105 Fabric Watch initial view

The window is divided into two sections. The left-hand side has a tree structure that lists the *Classes* that can be monitored using Fabric Watch. If you expand the *Classes*, all the *Areas* that are associated with a particular *Class* are displayed.

The main part of the window on the right-hand side has a display with the following tabs:

- Alarm Notification
- Threshold Configuration
- Email Configuration

Also on the right-hand side is the Area Selection, which contains a context driven drop down menu which is used to select elements that are linked to the Area selected in the left-hand window.

8.9.1 Alarm Notification tab

Use the Alarm Notification tab to view the information for all elements of the Fabric Watch, Fabric, or Performance Monitor classes. The information displayed includes:

- ► The name of the fabric
- The last event state
- ► The last event reason
- The last event value
- The current value
- ► The last event time

The Alarm Notification tab refreshes the displayed information according to the threshold configuration.

Figure 8-106 shows the Alarm Notification tab.

የቶ IBM_SAN80B_217 - Fabric	Watch						_ 🗆 ×
Fabric Watch Explorer	Alarm Notification	Threshold Confi	iguration Email C	onfiguration			
Fabric	Area Selection						
Fabric	Eabric Reconfigur	• •					
Switch							
- Environment	Details						
SFP	Name	State	Reason	Last Value	Current Value	Time	
- Security	fabricFR000	Informative	Above	1 Reconfig(s)	3 Reconfig(s)	Mon Jul 20	0 2009
Resource							
FRU							
Ports							
- Port							
- E-Port							
F/FL Optical Port							
Performance							
- End-to-End							
Filter-Based							
View Updated: Tue Jul 21 2009 (00:23:02 GMT+00:0(Free Professional N	Management Tool	10.64.210.217	Physical Fabric	User: admin	Role: ac

Figure 8-106 Fabric Watch Alarm Notification

8.9.2 Threshold Configuration tab

Use the Threshold Configuration tab to view and configure Fabric Watch thresholds for the Fabric Watch class currently selected in the organizational tree on the left side of the window. Figure 8-107 shows the Threshold Configuration tab.

타 IBM_SAN80B_217 - Fabric	Watch				_	
Fabric Watch Explorer	Alarm Notification	Threshold Configuratio	n Email Configuration			
Fabric	Area Selection					
Fabric	Segmentation	-				
Switch						
Environment	Trait Configuration	n Alarm Configuration	Element Configuration	Configuration Report		
SFP	Traits					
Security		System Default	Custom Defined			
Resource	Unit	Segmentation(s)	Segmentation(s)			
FRU	Time Base	None	None	-		
Ports	Law Davadawa	0		_		
Port	Low Boundary					
E-Port	High Boundary	0	0			
F/FL Optical Port	Buffer Size	0	0			
End to End	Activate Level					
Ella-IO-Ella						
Tillet-Daseu	System Defa	ult 🔾 Custom Defined				
					Apply Refre	sh
View Updated: Tue Jul 21 2009 0	00:26:52 GMT+00:00	Free Professional Manage	ment Tool 10.64.210.21	7 Physical Fabric U	Jser:admin Rol	e: admi

Figure 8-107 Configure Thresholds

The Threshold Configuration display changes according to the Class and Area selected in the organizational tree. However, the Threshold Configuration tab always includes the same options, as follows.

- System Default: Click to return settings to default values.
- Custom Defined: Specify new settings.
- Apply: Click to apply the values specified in the current display.
- ► **Refresh:** Refresh view with current information from switch.

Important: When making changes in a given window, they are not saved until you click **Apply**.

Thresholds for the Environmental classes

The Environmental classes are displayed by highlighting **Environment** in the panel on the left and then clicking the Threshold Configuration tab as shown in Figure 8-108.

pric Watch Explorer	Alarm Notification	Threshold	Configuration Em	ail Configuration		
Fabric	Area Selection					
Fabric	Temperature	-				
Switch	Temperature	-				
Environment	Temperature					
CED	Power Supply				-	
31 F	Name	State	Reason	Last Value	Current Value	Time
Security	envTemp001	In_Range	High Below	35 C	35 C	Mon Nov 08 201
Resource	envTemp002	In_Range	High Below	38 C	39 C	Mon Nov 08 201
FRU	envTemp003	In_Range	High Below	30 C	29 C	Mon Nov 08 201
	envTemp005	In_Range	High Below	30 C	29 C	Mon Nov 08 201
] Ports	envTemp006	In_Range	High Below	39 C	37 C	Mon Nov 08 201
Port	envTemp007	In_Range	High Below	38 C	37 C	Mon Nov 08 201
E-Port	envTemp008	In_Range	High Below	41 C	40 C	Mon Nov 08 201
- FIFL Optical Port	envTemp009	In_Range	High Below	29 C	29 C	Mon Nov 08 201
Devésiones	envTemp010	In_Range	High Below	38 C	37 C	Mon Nov 08 201
Performance	envTemp011	In_Range	High Below	36 C	36 C	Mon Nov 08 201
End-to-End	envTemp012	In_Range	High Below	39 C	39 C	Mon Nov 08 201
Filter-Based	envTemp013	In_Range	High Below	33 C	32 C	Mon Nov 08 201
Memory and CPU Usage	envTemp014	In Range	High Below	29 C	27 C	Mon Nov 08 201
- Momory Lloogo	envTemp015	In Range	High Below	33 C	32 C	Mon Nov 08 201
wentory usage	envTemp016	In_Range	High Below	30 C	29 C	Mon Nov 08 201
- CPU Usage	envTemp017	In Range	High Below	34 C	34 C	Mon Nov 08 201
	envTemp018	In Range	High Below	29 C	29 C	Mon Nov 08 201
	envTemp019	In Range	High Below	34 C	33 C	Mon Nov 08 201
	envTemp020	In Range	High Below	31 C	31 C	Mon Nov 08 201
	envTemp021	In Range	High Below	38 C	40 C	Mon Nov 08 201
	envTemp022	In Range	High Below	34 C	35 C	Mon Nov 08 201
	epyTemp023	In Range	High Below	48 C	51 C	Mon Nov 08 201
	envTemp024	In Range	High Below	49 C	52 C	Mon Nov 08 201
	epyTemp025	In Range	High Below	49 C	52 C	Mon Nov 08 201
	epyTemp026	In Range	High Below	38.0	38.0	Mon Nov 08 201

Figure 8-108 Environmental Thresholds

The panel contains tabs that you can use to define how you intend to monitor the environmental factors of the switch:

- Traits
- Alarm Configuration
- ► Element Configuration
- Configuration Report

Each tab contains an Area Selection pull-down menu to select the Fabric Watch area. In the example in Figure 8-108, we selected **Temperature**.

Table 8-11 describes the values and information about the Traits tab.

Value	Description
Unit	The string used to define the unit of measurement for the area
Time base	The time base for the area
Low Boundary	The low threshold for the event setting comparison
High Boundary	The high threshold for the event setting comparison
Buffer size	Size of the buffer zone in the event setting comparison
Activate level	Radio button to use System Default settings or Custom Defined settings
Apply	Apply the new values to the switch
Refresh	Refresh view with current information from the switch

Table 8-11 Traits values and information

Thresholds for the SFP classes

You display the SFP classes by highlighting **SFP** in the panel on the left and then clicking the **Threshold Configuration** tab. The **Area Selection** pull-down menu displays the classes to be configured, as shown in Figure 8-109.

abric Watch Exp <mark>lore</mark> r	Alarm Notification	Threshold	Configuration Ema	il Configuration		
🖥 Fabric	Area Selection					
Fabric	-					
Switch	Temperature	•				
Environment	Temperature					
	RX Power	_				
SFP	TX Power		Reason	Last Value	Current Value	Time
— Security	Current		High Below	32 C	35 C	Mon Nov 08 201
Resource	∜Voltage		High Below	32 C	35 C	Mon Nov 08 201
FRU	sfpTemp138	In_Range	High Below	34 C	37 C	Mon Nov 08 201
1 Post-	sfpTemp139	In_Range	High Below	34 C	38 C	Mon Nov 08 201
Ports	sfpTemp194	In_Range	High Below	31 C	33 C	Mon Nov 08 201
Port	sfpTemp195	In_Range	High Below	31 C	33 C	Mon Nov 08 201
E-Port	sfpTemp197	In_Range	High Below	32 C	34 C	Mon Nov 08 201
- F/FL Optical Port	sfpTemp198	In_Range	High Below	32 C	35 C	Mon Nov 08 201
Performence	sfpTemp200	In_Range	High Below	30 C	32 C	Mon Nov 08 201
	sfpTemp201	In_Range	High Below	36 C	37 C	Mon Nov 08 201
End-to-End	sfpTemp202	In_Range	High Below	36 C	39 C	Mon Nov 08 201
Filter-Based	sfpTemp203	In_Range	High Below	39 C	40 C	Mon Nov 08 201
🗂 Memory and CPU Usage	sfpTemp210	In_Range	High Below	29 C	29 C	Mon Nov 08 201
Memory Lisage	sfpTemp211	In_Range	High Below	31 C	32 C	Mon Nov 08 201
CRUUI	sfpTemp215	In_Range	High Below	32 C	32 C	Mon Nov 08 201
- CPU Usage	sfpTemp219	In_Range	High Below	35 C	38 C	Mon Nov 08 201
	sfpTemp220	In_Range	High Below	34 C	36 C	Mon Nov 08 201
	sfpTemp221	In_Range	High Below	35 C	37 C	Mon Nov 08 201
	sfpTemp222	In_Range	High Below	33 C	36 C	Mon Nov 08 201
	sfpTemp223	In_Range	High Below	31 C	32 C	Mon Nov 08 201

Figure 8-109 SFP thresholds

The available areas are Temperature, RX Power, TX Power, Current, and Voltage.

The Alarm Configuration tab has two areas to show the Default settings and the Customer defined settings as described in Table 8-12.

Value	Description
Changed	Event of counter changed
Below / Low Below	Event of counter fell below low boundary
Low Above	Event of counter fell above low boundary
Above / High Above	Event of counter fell above high boundary
In between / High Below	Event of counter is between the high/low boundaries
ERROR_LOG	Event notification to error log
SNMP_TRAP	Event notification through SNMP trap
RAPI_TRAP	Event notification through RAPI trap
EMAIL_ALERT	Event notification through email
System Default	Radio button indicating system defaults taken
Custom Defined	Radio button indicating custom defined
Apply	Apply the new values to the switch
Refresh	Refresh view with current information from the switch

Table 8-12 Alarm Configuration settings

Thresholds for Port classes

The Port, E_Port, F/FL Copper Port, F/FL Optical Port classes display the following fields for each area:

- Link Loss
- Sync Loss
- ► Signal Loss
- Protocol Error
- Invalid Words
- ► Invalid CRCs
- ► RX Performance
- ► TX Performance
- ► State Changes

abric Watch Explorer	Alarm Notification	n Thresho	ld Configuratio	n Ema	il Configuration		
🖥 Fabric	Area Selection						
Fabric	Link Loss	•					
Switch	Link Loss		l				
Environment	Sync Loss		onfiguration	Elemen	t Configuration Conf	iguration Report	
SFP	Signal Loss						
Security	Protocol Error			TRAD			
Resource	Invalid Words			_IRAF	FORT_LOG_LOCK	NAPI_INAP	
FRU	Invalid CRCs						
- Into	RX Performance						
Ports	TX Performance						
Port	State Changes						
E-Port	Link Resets						
- F/FL Optical Port	C3 Discard						
Performance			_				
End-to-End	Alarms Custom D	efined					
- Filter-Based		ERROR_LC	G SNMP	_TRAP	PORT_LOG_LOCK	RAPI_TRAP	EMAIL_ALER1
Memory and CPU Lleage	Changed						
I wemory and CPO Usage	Low Below						
- Memory Usage	Low Above						
- CPU Usage	High Below						
	High Above						
	Activate Level						
	System Defe	ault 🔿 Cust	om Defined				
							Apply <u>R</u> efres

Figure 8-110 shows the thresholds for the Port class.

Figure 8-110 Port thresholds

Thresholds for Performance classes

Use the Threshold Configuration tab to view and configure End-to-End thresholds for the Performance class that is currently selected in the organizational tree on the left side of the window.

Be aware that you must define the SID/DID pair through the Performance Monitor before you can monitor the threshold in the End-to-End class. Figure 8-111 shows the Threshold Configuration tab for the End-to-End Thresholds.

ric Watch Explorer Alarm 1	Notification	Threshold Co	nfiguration Ema	il Configuration		
Fabric Area Se	election					
Fabric						
Switch RX Per	rformance	•				
Environment RX Per	formance					
SED.	formance	ontig	guration Elemen	Configuration Confi	guration Report	
Alarms	System Defau	itt				
Security	Ef	RROR_LOG	SNMP_TRAP	PORT_LOG_LOCK	RAPI_TRAP	EMAIL_ALER1
Resource Cha	anged					
FRU Low	Below					
Ports Low	Above					
Port High	Below					
E Port High	Above					
F/FL Optical Port Performance						
F/FL Optical Port Performance End-to-End Alarms	Custom Define	ed	SNMP TRAP	PORT LOG LOCK	RAPI TRAP	EMAIL ALERT
F/FL Optical Port Performance End-to-End Filter-Based Cha	Custom Define	ed RROR_LOG	SNMP_TRAP		RAPI_TRAP	EMAIL_ALER
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Low	Custom Define Ef anged Below	ed	SNMP_TRAP	PORT_LOG_LOCK		
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Low	Custom Define Ef anged Below Above	ed RROR_LOG	SNMP_TRAP		RAPI_TRAP	EMAIL_ALERT
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Memory Usage CPU Usage High	Custom Define anged Below Above Below	RROR_LOG	SNMP_TRAP			EMAIL_ALERT
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Memory Usage CPU Usage High High	Custom Define anged Below Above Below Above	ed RROR_LOG	SNMP_TRAP		RAPI_TRAP	EMAIL_ALERI
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Memory Usage CPU Usage CPU Usage	Custom Define anged Below Above Below Above	ed	SNMP_TRAP	PORT_LOG_LOCK	RAPI TRAP	EMAIL_ALERT
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Memory Usage CPU Usage Activate	Custom Define anged Below Above Below Above below	ad	SNMP_TRAP	PORT_LOG_LOCK	RAPI TRAP	EMAIL_ALERT
F/FL Optical Port Performance End-to-End Filter-Based Memory and CPU Usage Memory Usage CPU Usage CPU Usage Activate	Custom Define anged Below Above Below Above a below Above a custom Default	ed RROR_LOG	SNMP_TRAP	PORT_LOG_LOCK	RAPI TRAP	EMAIL_ALERT

Figure 8-111 Threshold Configuration tab for End-to-End class

Use the Threshold Configuration tab to view and configure Filter-Based thresholds for the Performance class currently selected in the organizational tree on the left side of the window, as shown in Figure 8-112.

Thresholds: You must predefine the filter type in the Performance Monitor before you can use the Filter-Based thresholds.

ic Watch Explorer	Alarm Notification	n Threshold Co	nfiguration Ema	il Configuration		
abric 🛛	Area Selection					
abric		1				
Switch	Custom Filter Co	unter 🔻				
invironment	Trait Configuration	on Alarm Confi	auration Elemen	t Configuration Confi	auration Report	
SFP 1	Alarms System D	efault				
Security	-lainio oyotoin b	ERROR LOO				
Resource	Chapman	ERROR_LOG	SNMP_IRAP	PORT_LOG_LOCK	RAPI_IRAP	EMAIL_ALERI
- 	Low Below					
)orte	Low Above					
ons -	High Below					
-on	High Above					
FL Optical Port						
FL Optical Port Performance	Alarms Custom D	efined				
F/FL Optical Port Performance Ind-to-End /	Alarms Custom D	efined ERROR_LOG	SNMP_TRAP	PORT_LOG_LOCK	RAPI_TRAP	EMAIL_ALERT
7FL Optical Port Performance ind-to-End / inter-Based / emory and CPLUIsage	Alarms Custom D Changed	efined ERROR_LOG	SNMP_TRAP	PORT_LOG_LOCK		
IFL Optical Port Performance ind-to-End /iitter-Based Aemory and CPU Usage	Alarms Custom D Changed Low Below	efined				
FL Optical Port Performance ind-to-End iitter-Based //emory and CPU Usage //emory Usage	Alarms Custom D Changed Low Below Low Above	efined	SNMP_TRAP			
Image: Weight of the second	Alarms Custom D Changed Low Below Low Above High Below	efined ERROR_LOG	SNMP_TRAP			EMAIL_ALERT
IFL Optical Port Verformance ind-to-End iliter-Based Aemory and CPU Usage Aemory Usage IPU Usage	Alarms Custom D Changed Low Below Low Above High Below High Above	efined ERROR_LOG	SNMP_TRAP	PORT_LOG_LOCK		EMAIL_ALERT
FL Optical Port Performance Addressed Inter-Based Aemory and CPU Usage Aemory Usage CPU Usage	Alarms Custom D Changed Low Below Low Above High Below High Above	efined ERROR_LOG	SNMP_TRAP	PORT_LOG_LOCK	RAPI TRAP	EMAIL_ALERT
IFL Optical Port Verformance ind-to-End A ilter-Based Aemory and CPU Usage IPU Usage IPU Usage	Alarms Custom D Changed Low Below Low Above High Below High Above Activate Level System Defe	efined ERROR_LOG 	SNMP TRAP	PORT_LOG_LOCK	RAPI TRAP	EMAIL_ALERT

Figure 8-112 Threshold Configuration tab with Filter-Based class

8.9.3 Configuration Report tab

Use the Configuration Report tab to view the current Fabric Watch threshold parameters for the area selected in the Fabric Watch tree.

Figure 8-113 shows the Configuration Report tab for the Port class.



Figure 8-113 Port class -Configuration report

8.9.4 Memory and CPU Usage monitor with Fabric Watch

Fabric Watch can be defined to monitor and alert for memory and CPU usage. From the Fabric Watch window, click **Memory usage** or **CPU usage**, which has two tabs:

- Trait configuration: Defines the polling interval, threshold level, and number of retries to be done before alerting.
- Alarm Configuration: Defines the way or type of alert to be triggered.

Figure 8-114 and Figure 8-115 indicate these Fabric Watch configurations for Memory or CPU usage.

👫 switch - Fabric Watch								_ 🗆 X
Fabric Watch Explorer	Memory Usage	Configura	ition					
Fabric	Trait Configuration Alar		Alarm Configuration					
Fabric	Traits							
Switch	Dolling Interval	100	sec					
- Environment	Folling Interval	120	300					
SFP	Usage Limit	60	%					
- Security	No of Retries	3						
Resource		10						
FRU								
Ports								
- Port								
E-Port								
F/FL Optical Port								
Performance								
End-to-End								
Filter-Based								
Memory and CPU Usage								
Memory Usage								
CPU Usage								
							Apply	Refresh
Sele View Updated: Tue Nov (09 2010 08:21:06 (GMT+00:0	00 Free Profession	al Management Tool	10.18.228.18	ADO	User: admin	Role: admin

Figure 8-114 Fabric Memory usage trait configuration



Figure 8-115 Fabric Watch alarm configuration - memory usage

8.9.5 Modifying settings for switches with one power supply

The IBM default settings for Fabric Watch cause a switch with a single power supply to appear yellow in the Web Tools, indicating a *MARGINAL* status. The status can also be obtained by clicking **Status** in the switch view to open a window that describes the cause of the marginal state, as shown in Figure 8-116.

Switch Report for IBM_E	32_149 AD:AD0 - Windows In	ternet Explor	rer 🛛	_ 🗆 🗵	
🚱 🕤 👻 http://10.64.210.146/switchReport.html?Authori: 🔽 🐓 🗙 Live Search 🖉 🗸					
🚖 🎄 🏾 🏉 Switch Report	for IBM_B32_149 AD:AD0		🐴 🔹 🔊 👻 🌐 🔹 🔂 Page	🕶 🎯 Tools 👻 🂙	
Action Report Switch Health Fort Detail I Healthy I Healthy I Marginal I Faulty I I All	Switch Health Report Switch Name: IBM IP Address: 10.6 Switch State: MAI Duration (H:M): 2:12	Report Time _B32_149 4.210.146 RGINAL ?	e: Tue Jul 21 2009 01:15:07	GMT	
• <u>SAM</u>	Switch State Contributors	State			
	Power supplies monitor	MARGINAL			
	Temperatures monitor	HEALTHY			
	Fans monitor	HEALTHY			
	Flash monitor	HEALTHY			
	Marginal ports monitor	HEALTHY			
	Faulty ports monitor	HEALTHY			
	Missing SFPs monitor	HEALTHY			
All ports are healthy.					
		👌 Internet Pr	otected Mode: Off	💐 100% 🔻 🎢	

Figure 8-116 Checking the switch status

The switch status can be changed to *HEALTHY* using a Telnet connection. Use the switchStatusShow command to display the current health of the switch. After using switchStatusPolicySet to clear the current condition, again use switchStatusShow to demonstrate that a switch with only one power supply is then shown with a *HEALTHY* status. See Example 8-9 for details.

Example 8-9 Using switchStatusPolicySet to clear unnecessary marginal status

IBM B32 1/10.admin> swith	chStatusShow		
Switch Hoolth Dopont		Donont time.	07/21/2000
		Report time:	0//21/2009
01:18:09 AM			
Switch Name: IBM_B32	_149		
IP address: 10.64.2	10.146		
SwitchState: MARGINA	L		
Duration: 02:15			
Power supplies monitor	MARGINAL		
Temperatures monitor	HEALTHY		
Fans monitor	HEALTHY		
Flash monitor	HEALTHY		
Marginal ports monitor	HEALTHY		
Faulty ports monitor	HEALTHY		

Missing SFPs monitor HEALTHY

All ports are healthy IBM B32 149:admin> switchStatusPolicySet

To change the overall switch status policy parameters

The current overall switch status policy parameters: Down Marginal

		-
PowerSupplies	2	1
Temperatures	2	1
Fans	2	1
Flash	0	1
MarginalPorts	2	1
FaultyPorts	2	1
MissingSFPs	0	0

Note that the value, O, for a parameter, means that it is NOT used in the calculation.

** In addition, if the range of settable values in the prompt is (0..0),

** the policy parameter is NOT applicable to the switch.

** Simply hit the Return key.

The minimum number of

Bad PowerSupplies contributing to DOWN status: (0..2) [2] 0 Bad PowerSupplies contributing to MARGINAL status: (0..2) [1] 0 Bad Temperatures contributing to DOWN status: (0..5) [2] Bad Temperatures contributing to MARGINAL status: (0..5) [1] Bad Fans contributing to DOWN status: (0..3) [2] Bad Fans contributing to MARGINAL status: (0..3) [1] Out of range Flash contributing to DOWN status: (0..1) [0] Out of range Flash contributing to MARGINAL status: (0..1) [0] Out of range Flash contributing to MARGINAL status: (0..32) [2] MarginalPorts contributing to DOWN status: (0..32) [2] FaultyPorts contributing to DOWN status: (0..32) [1] FaultyPorts contributing to MARGINAL status: (0..32) [1] MissingSFPs contributing to DOWN status: (0..32) [0]

Policy parameter set has been changed IBM B32 149:admin> switchStatusShow Switch Health Report Report time: 07/21/2009 01:20:28 AM Switch Name: IBM B32 149 IP address: 10.64.210.146 SwitchState: HEALTHY Duration: 00:00 Power supplies monitor HEALTHY Temperatures monitor HEALTHY Fans monitor HEALTHY Flash monitor HEALTHY Marginal ports monitor HEALTHY HEALTHY Faulty ports monitor HEALTHY Missing SFPs monitor

All ports are healthy

To change the default settings, issue the switchStatusPolicySet command.

The first section of response to the command is the same as though you issue the **switchStatusPolicyShow** command and displays a list of the current settings. Here, you can see that the *Power Supplies* line is defined to be *MARGINAL* if the switch is powered by one power supply. These default settings assume that the switch has two power supplies and that one has failed. Obviously, for a switch purchased with a single power supply, this is not valid.

You are then prompted to enter the new values for each setting, starting with the *DOWN* value for the Faulty Ports, then the *MARGINAL* value for Faulty Ports. You can simply press Enter or type the same number to use default values. Then, you are prompted for the next setting, and eventually, for the Power supply *DOWN* and *MARGINAL* values.

Enter zero for the number of *bad power supplies contributing to the DOWN status* as well as zero for the number of *bad power supplies contributing to the MARGINAL status*. Indeed, because we are working with only one power supply, if it goes down, then the whole switch goes down. There is no marginal status.

At the bottom of the Telnet display, after running the switchStatusShow command, you can see that the chassis status has changed from *MARGINAL* to *HEALTHY*.

8.9.6 Email Configuration

Use the Email Configuration tab to configure the destination email ID to receive any alerts selected in the threshold configuration. The Email Configuration tab is shown in Figure 8-117. Also on this tab, you can enable or disable the email function for Fabric Watch alerts and send a test email to ensure that the function is working.



Figure 8-117 Email Configuration tab

8.10 IBM SAN ICL connectivity

In this section, we explain the procedure to interconnect two IBM SAN768B or IBM SAN384B chassis using the ICL cables. Web Tools is the tool that you can use to verify the state of fabric and both chassis after the ICL connectivity is established.

8.10.1 Before you begin

Prior to merging, look at each chassis with Web Tools.

In our example, the first chassis is named SAN384B_213. Figure 8-118 shows the Web Tools status of this chassis.



Figure 8-118 First chassis: SAN384B_213

The chassis is managed through IP address 10.64.210.213. This SAN384B has principle role in the fabric and is the only switch in the fabric.



Next, look at the second chassis, named SAN384B_215, as shown in Figure 8-119.

Figure 8-119 Second chassis: SAN768B_2

We use IP address 10.64.210.215 to manage this chassis. The SAN384B_215 has principal role in its fabric and is actually the only member of the fabric.

8.10.2 ICL cabling

The ICL cable connectors must be connected to corresponding ICL ports on the core (CR8) blades. The two core blades are installed in slots 3 and 6. Because each core blade has two ICL ports, we need four ICL cables.

The basic rules for proper ICL cabling are as follows:

- ICL0 ports must be cabled to ICL1 ports.
- ICL1 ports must be cabled to ICL0 ports. It is not allowed to attach ICL0 to ICL0 or ICL1 to ICL1.

Figure 8-120 shows an example of correct cabling. See Chapter 2, "Data Center Fabric" on page 21 for other ICL interconnection possibilities.



Figure 8-120 SAN384B: ICL cabling

_ 🗆 🗡 IBM_SAN384B_213 - Web Tools Manage Reports Monitor Tools Tasks 🛆 Status 🛛 O Temp 🔘 Power 🔍 Fan 🔹 🖸 HA 🔹 🟦 Beacon 🔹 🚟 Legend 🔹 Admin Domain ADO • Log Out Manage 🛃 Zone Admin Switch Events Switch Information All Events Last Updated: Mon Aug 10 2009 18:03:21 GMT+ ... Switch Admin 耳 Actions 🔹 Port Admin 🔠 Admin Domain Time Level Tue Apr 14 2009 19:27:24 GMT+00:00 🛈 Information 🔺 ^{指载} FCR Tue May 05 2009 21:49:33 GMT+00:00 Information 🙀 Fabric Watch Tue May 05 2009 21:49:44 GMT+00:00 Information Tue May 05 2009 21:49:45 GMT+00:00 1) Information Monitor Tue May 05 2009 21:50:37 GMT+00:00 Dinformation -:**8** M Performance Monitor Tue May 05 2009 21:50:38 GMT+00:00 Information Tue May 05 2009 21:50:38 GMT+00:00 Information III Name Server - S Tue May 05 2009 21:50:38 GMT+00:00 Information Tue May 05 2009 21:50:39 GMT+00:00 1) Information Other ə**s** Tue May 05 2009 21:50:39 GMT+00:00 Information 🚽 Telnet/SSH Client Tue May 05 2009 21:50:39 GMT+00:00 Information Tue May 05 2009 21:50:39 GMT+00:00 Information ATTH -:**8** Tue May 05 2009 21:50:39 GMT+00:00 Dinformation Tue May 05 2009 21:50:39 GMT+00:00 Information 8<u>-</u> Tue May 05 2009 21:50:40 GMT+00:00 Information Fabric Tree Tue May 05 2009 21:50:40 GMT+00:00 i)Information Tue May 05 2009 21:50:40 GMT+00:00 1) Information View by: Name Tue May 05 2009 21:50:41 GMT+00:00 Information 🗉 🕹 Fabric Tue May 05 2009 21:50:41 GMT+00:00 Information BM SAN384B 213 Tue May 05 2009 21:50:42 GMT+00:00 Information IBM_SAN384B_215 Tue May 05 2009 21:51:08 GMT+00:00 Information ac Segmented Switches Tue May 05 2009 21:51:09 GMT+00:00 Information Tue May 05 2009 21:51:09 GMT+00:00 Information 1) Information Tue May 05 2009 21:51:10 GMT+00:00 Tue May 05 2009 21:51:26 GMT+00:00 1) Information Tue May 05 2009 21:51:27 GMT+00:00 Information Tue May 05 2009 21:51:28 GMT+00:00 Information Tue May 05 2009 21:51:29 GMT+00:00 1) Information Tue May 05 2009 21:51:29 GMT+00:00 1) Information Tue May 05 2009 22:28:12 GMT+00:00 ①Information Number of switches: 1 Getting events from switch...done Free Professional Management Tool 10.64.210.213 AD0 User: admin Role: admir

Following these rules, you can interconnect the two chassis. After a few minutes, Web Tools indicates that the fabrics have merged, as shown in Figure 8-121.

Figure 8-121 SAN384B_213 after connecting the ICL cables

SAN384B_213 is still in the principal role, but the fabric now has two members, as shown in Figure 8-122.



Figure 8-122 Fabric members

You can now check the status of the second chassis, SAN384B_215. As shown in Figure 8-123, the chassis is now a member of the same fabric as SAN384B_213, and its role has been changed to subordinate.



Figure 8-123 SAN384B_215 after connecting ICL cables

Finally, look at the ICL ports. In the Web Tools window for SAN384B_213, click **Port Admin** to launch the Port Administration applet.

The two core blades are installed in slots 3 and 6. Select ports on the core blade in slot 3, as shown in Figure 8-124.

1BM_SAN384B_213 - P	ort Adminis	tration							_ 🗆
								Show Basic	Mode
FC Ports GigE Ports									
C Ports Explorer	View D	etails E	Rename Edit Co	nfiguration	Enable D	isable P	ersistent Enable	Persistent Dis	able
🗕 🔍 Port 19				1			10		
 Port 20 	Enable	Irunking	Disable Trunking	Enaple	USabie	PC PC	ort S <u>w</u> ap	Re-Authenticate	
Port 21	GoS En	able Q	oS Disable F-Po	ort Trunking					
- 🕑 Port 22						1			
- 🕑 Port 23	Slot# 📥	Port#	Port Port Id Po	ort Port Type	e Speed (Gb/s)	Port Status	Health	Ingress Rate .	QOS
- 🔍 Port 24	3	0(0×0)	256(0×028	E-Port	8	Online	Healthy	Not Available	Enal
- 🕑 Port 25	3	1(0x1)	257(0x028	E-Port	8	Online	Healthy	Not Available	Ena
Port 26	3	2(0×2)	258(0x028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 27	3	3(0x3)	259(0x028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 28	3	4(0×4)	260(0×028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 29	3	5(0x5)	261(0x028	E-Port	8	Online	Healthy	Not Available	Ena
Port 30	3	6(0×6)	262(0×028	E-Port	8	Online	Healthy	Not Available	Ena
Port 31	3	7(0×7)	263(0×028	E-Port	8	Online	Healthy	Not Available	Ena
[Slot 3(46)	3	8(0×8)	264(0×028	E-Port	8	Online	Healthy	Not Available	Ena
- 🔍 Port 0 (ICL0)	3	9(0×9)	265(0×028	E-Port	8	Online	Healthy	Not Available	Ena
- 🔍 Port 1 (ICL0)	3	10(0xA)	266(0×028	E-Port	8	Online	Healthy	Not Available	Ens
- 🔍 Port 2 (ICL0)	3	11(0xB)	267(0x028	E-Port	8	Online	Healthy	Not Available	Ens
- 🔍 Port 3 (ICLO)	3	12(0xC)	268(0x028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 4 (ICL0)	3	13(0xD)	269(0×028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 5 (ICL0)	3	14(0×E)	270(0×028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 6 (ICLO)	3	15(0×F)	271(0x028	E-Port	8	Online	Healthy	Not Available	Ena
- 🕑 Port 7 (ICL0)									
- 🕑 Port 8 (ICL1)									
- 🔍 Port 9 (ICL1)									
- 🔍 Port 10 (ICL1)									
- 🕑 Port 11 (ICL1)									
- 🕑 Port 12 (ICL1)									
- 🔟 Port 13 (ICL1)									
Port 14 (ICL1)									
📃 🕑 Port 15 (ICL1) 💌									
	1000000			1000000000000					

Figure 8-124 ICL ports

Now, the ICL ports all have E_Port type, are fixed to 8 Gbps, and are grouped in eight-port trunks.

9

IBM System Storage Data Center Fabric Manager

A key component of the IBM/Brocade DCF (Data Center Fabric) architecture is a new product, IBM System Storage Data Center Fabric Manager (DCFM). This is an end-to-end fabric management software platform that combines the capabilities of IBM/Brocade existing fabric management software:

- Enterprise Fabric Connectivity Manager (EFCM)
- Fabric Manager

The DCFM architecture integrates the best management features of EFCM and Fabric Manager. It is based on EFCM's Graphical User Interface (GUI) and Fabric Manager's messaging and data management design for improved performance and scalability.

In this chapter we explore several key capabilities, to help data center managers and administrators better understand the advantages of deploying IBM System Storage Data Center Manager (DCFM).

There are two types of DCFM: *DCFM Professional* and *DCFM Enterprise*. We briefly describe the differences between them and concentrate on the features and capabilities of DCFM Enterprise.

9.1 DCFM products

As stated before, DCFM is available as the following types:

- DCFM Professional: Free
- DCFM Enterprise: Licensed by server

9.1.1 DCFM Professional

DCFM Professional is a free product and is targeted at customers seeking a less extensive management solution for smaller SANs. This software, which is included with IBM/Brocade switches, provides these capabilities:

- Allows management of a *single* Fabric OS (FOS) fabric (up to 1,000 switch ports) at a time.
- ► Performs group switch management beyond the scope of Web Tools.

You can download a free version of DCFM Professional from the Brocade webpage.

Support: Be aware that IBM provides no support for the DCFM Professional version. IBM will provide support for the licensed DCFM Enterprise version only.

Features *not supported* that are available in Enterprise Edition are as follows:

- Full IBM/Brocade Backbone management with features such as QoS and end-to-end performance monitoring
- Support for up to 24 physical fabrics, 9,000 switch ports, and 20,000 end devices
- FICON management for mainframe environments
- ► Fabric-based encryption
- ► Comprehensive FCR (Fiber Channel Routing) and FCIP management
- Advanced Call Home Support
- Support for security schemes (RADIUS, LDAP, Active Directory, NIS/NIS+, and more)
- Historical performance data collection
- Data persistence for up to two years of data, out-of-box Open Database Connectivity (ODBC), and Java Database Connectivity (JDBC) access
- M-EOS support
- ► Remote clients

There is limited support for other features of Enterprise Edition.

Notes for DCFM Professional:

- DCFM Professional does not support the IBM System Storage SAN768B, Brocade DCX, and m-EOS.
- DCFM Professional supports IBM System Storage SAN384B and Brocade DCX-4s.
- DCFM Professional does not allow use as a Fusion Agent proxy for management applications such as IBM TPC.

9.1.2 DCFM Enterprise Edition

DCFM Enterprise is an enterprise-class product targeted at customers that demand a management software solution with comprehensive support for the following capabilities:

- ► IBM/Brocade Backbone switch (SAN768B) Data Center Fabric (DCF)
- ► Fabric-based encryption support for data-at-rest solutions
- End-to-end manageability of the data center fabric from HBA ports through switch ports to storage ports

Fusion Agent: DCFM Enterprise Edition allows use as a Fusion Agent proxy for management applications such as IBM TPC.

DCFM Enterprise provides multi-protocol networking support for the following products:

- ► Fibre Channel
- Fiber Connectivity (FICON)
- Fibre Channel over IP (FCIP)
- ► Fibre Channel Routing (FCR)
- Internet SCSI (iSCSI)
- (Future) Fibre Channel over Ethernet (FCoE) and Converged Enhanced Ethernet (CEE)

9.1.3 Enhanced Group Management

Both products require the Enhanced Group Management (EGM) license, which is an FOS license that enables multi-switch operations for those switches that have EGM enabled. This license is already the default in most switches except the 2498-24E, for example.

It helps automate operations across multiple switches to save time and streamline repetitive operations, which are typically prone to error. Brocade EGM drives consistency across fabrics, while minimizing the risk associated with potential downtime due to configuration mismatches. Enhanced Group Management has the following features:

- ► It offers a FOS enabled client for SAN switch group management.
- It drives consistency across SAN by automating repetitive tasks:
 - Downloads firmware to multiple switches and meets upgrade windows
 - Provisions new switches by uploading an existing switches configuration
 - Sets up a switch configuration once, then replicates it to multiple others
- ► It minimizes risk through troubleshooting, diagnostics, and monitoring:
 - Data collection across multiple switches for holistic problem resolution
 - Snapshots of issues as they occur for fast, effective root cause analysis
 - Regular back-up of last known configurations for quick restores
 - Monitors performance to proactively address over-utilized devices/links
- It ensures compliant security settings:
 - Can be set up once, then replicates across multiple switches the settings for SCC/DCC policies, IPFilter, LDAP, and RADIUS Server configurations

9.1.4 DCFM Enterprise scalability

The scalability of DCFM Enterprise is limited by the used switch types.

- ► Pure FOS Fabrics:
 - Monitor up to 24 physical fabrics with support for:
 - 120 switches
 - 9,000 switch ports
 - 20,000 hosts or storage devices
 - 40 Access Gateways
 - 5 minutes performance monitoring polling

- Mixed Fabrics (FOS and M-EOS):
 - Monitor up to 24 physical fabrics with support for:
 - 60 switches
 - 5,000 switch ports
 - 10,000 hosts or storage devices
 - 40 Access Gateways
 - 5 minutes performance monitoring polling
- Pure M-EOS Fabrics:
 - Monitor up to 24 physical fabrics with support for:
 - 60 switches
 - 5,000 switch ports
 - 10,000 hosts or storage devices
 - 40 Access Gateways
 - 5 minutes performance monitoring polling

9.1.5 DCFM operating system support

In general, DCFM supports different configurations. The configuration support depends on the DCFM version and on the FOS and M-EOS level.

The following firmware platforms are supported by the release of DCFM 10.4.X:

- ► Fabric OS v5.0 or later in a pure Fabric OS fabric
- Fabric OS v6.0 or later in a mixed Fabric OS and M-EOS fabric
- M-EOS and M-EOSn 9.7 or later in a mixed Fabric OS and M-EOS fabric
- M-EOS and M-EOSn 9.9.2 or later in a pure M-EOS fabric

For details about requirements, see *Data Center Fabric Manager User Manual*, GC52-1304-03.

http://www-01.ibm.com/support/docview.wss?rs=1314&context=STBVU4&dc=DA4
00&uid=ssg1S7003231&loc=en_US&cs=utf=8&lang=en

9.2 DCFM installation

The installation of the DCFM Enterprise Edition is fairly straightforward. DCFM should be installed on a separate server. The requirements for the server depend on the platform and the size of the fabric and are described in the *Data Center Fabric Manager Installation Guide*, GA32-0786-00, which is available at this website:

http://www-01.ibm.com/support/docview.wss?uid=ssg1S7003232

9.2.1 Installation of DCFM Enterprise Edition on Windows platform

Follow these steps for the installation:

- 1. Insert the installation DVD into the DVD-ROM drive.
 - a. If autorun is enabled, the installer begins automatically.
 - b. If autorun is not enabled, open the following file: <DVD_drive>\DCFM_win\install.exe

The Introduction panel displays (see Figure 9-1).

10.4.1 DCFM 10.4.1	
	Introduction
 Introduction License Agreement Select Install Folder Pre-Installation Summary Installing Installation Complete 	InstallAnywhere will guide you through the installation of the following - DCFM Enterprise Edition - SMI Agent Only It is strongly recommended that you quit all programs running on this machine, before continuing with this installation. Click the 'Next' button to proceed to the next screen. If you want to change something on a previous screen, click the 'Previous' button. You may cancel this installation at any time by clicking the 'Cancel' button.
InstallAnywhere Cancel	Previous

Figure 9-1 DCFM Introduction panel

- 2. Click **Next** on the Introduction panel.
- 3. Read the agreement on the License Agreement panel, select I accept the terms of the License Agreement and click Next.

The Select Install Folder displays (see Figure 9-2).

10.4.1 DCFM 10.4.1	
	Select Install Folder
 Introduction License Agreement Select Install Folder Pre-Installation Summary Installing Installation Complete 	Where would you like to install? C:\Program Files\DCFM 10.4.1 Restore Default Folder Choose
Cancel	Previous

Figure 9-2 Select Install Folder dialog box

 Select the usual location for your system's application files (for example, C:\Program Files\DCFM 10.4.1) on the Select Install Folder panel, and click Next.

Important: Do *not* install to the root directory (for example, C:\).

5. Review the displayed installation summary on the Pre-Installation Summary panel and click **Install** (see Figure 9-3).



Figure 9-3 Pre-Installation Summary panel

- 6. The Installation Complete panel will be shown. Make sure that the Launch DCFM Configuration check box is selected (default) and click **Done**. This will start the DCFM itself.
- 7. The DCFM will start with a Welcome panel; click Next.
- 8. Select **No** on the Copy Data and Settings panel and then click **Next** (Figure 9-4).

Data migration: There is an option to migrate data from EFCM, FM, or an older DCFM version. We do not cover this topic here. Therefore, you can find more information at the following websites:

Data Center Fabric Manager Installation, Migration and Transition Guide:

http://www-01.ibm.com/support/docview.wss?rs=1314&context=STBVU4&dc= DA400&uid=ssg1S7003035&loc=en_US&cs=utf-8&lang=en

Data Center Fabric Manager Migration Guide:

http://www-01.ibm.com/support/docview.wss?rs=1314&context=STBVU4&dc= DA400&uid=ssg1S7003233&loc=en_US&cs=utf-8&lang=en

DCFM Configuration				_ 🗆 ×
Copy Data and Se	ttings			
You can copy data and setting installed in this machine or from EFCM 9.6 or later FM 5.4 or later DCFM 10.0.1 or later / DCF Do you want to copy data and Yes, from DCFM in th	s to DCFM 10.1.4 from a n a network path. M Pro 10.1.4 settings? e following location	any of the follo	wing applicat	ions
◯ Yes, from EFCM/FM/	CFM installed in this ma	chine or on ne	twork	
Installation Directory				Browse
No				
A You will not be able to min	grate any data to DCFM	10.1.4 after ins	stallation.	
<u>C</u> ancel		< <u>B</u> ack	<u>N</u> ext >	<u>F</u> inish

Figure 9-4 Copy Data and Settings dialog box

9. **Enter** the serial number (found on the DVD jewel case) and license key (on the Key Certificate) on the Server License panel, and click **Next**.

Server license: If your installation does not require a serial number and license key, the Server License panel does not display.

10.Select Internal FTP Server or External FTP Server on the FTP Server panel and click **Next** (see Figure 9-5).

DCFM Configuration	
FTP Server	
Internal FTP Server	
The internal FTP Server will use a default account a configure your own account by selecting SAN > Op	and port 21. You can btions > FTP from the application.
O External FTP Server	
Configure your external FTP Server setting by select application.	cting SAN > Options > FTP from the
Warning - If you choose to use an FTP Server whi same machine as DCFM Server, then the "Firmware available.	ich is not configured on the e Repository" feature will not be
<u>C</u> ancel	< Back Next > Einish

Figure 9-5 FTP Server Dialog box

Attention: If you use an FTP Server that is not configured on the same machine as the management application, the Firmware Repository feature will not be available.

- 11.Complete the following steps on the Server IP Configuration panel (see Figure 9-6) and click **Next**:
 - a. Select an address from the Client Server IP Configuration Return Address list.
 - b. Select an address from the Switch Server IP Configuration Preferred Address list.
| ST DCFM Configuration | | | | |
|---|--------------------|-----------------|----------------|----------------|
| Server IP Configuration | on | | | |
| Configure the server communic | ation IP addresses | | | |
| Client - Server IP Configuration | | | | |
| Return Address | Diomede | | | • |
| Switch - Server IP Configuration | n | | | |
| Preferred
Address | 10.64.210.106 | | | • |
| If DNS is not configured in the hostname. | your network, do n | ot choose the I | Return Addres | is as |
| Cancel | | < <u>B</u> ack | <u>N</u> ext > | <u>F</u> inish |

Figure 9-6 Server IP Configuration

- 12.Complete the following steps on the Server Port Configuration panel (see Figure 9-7):
 - a. Enter a port number in the Syslog Port Number field (default is 514).
 - b. *Enable SSL* by selecting the SSL Enabled check box.
 - c. Enter a port number in the Web Server Port Number field (default is 443 if SSL Enabled is selected; otherwise, the default is 80).
 - d. Enter a port number in the SNMP Port Number field (default is 162).
 - e. Enter a port number in the Starting Port Number field (default is 24600). The server requires 16 consecutive free ports beginning with the starting port number.

Important: Do not use port 2638 for any of these port numbers. Port 2638 is used internally by the server.

💱 DCFM Configurati	on			_ 🗆 🗙
Server Port (Configuration			
DCFM requires Syslog numbers from a "Star	, Web Server, and SNMP port r ing port #".	numbers, as we	II as 16 conse	cutive port
Do not use port 2638	as it is required internally by the	e DCFM Server.		
Syslog Port #	514			
SSL Enabled				
Web Server Port #	80			
SNMP Port #	162			
Starting Port #	24600			
i Change this co	nfiguration by selecting SAN > (Options > Serve	r Port from the	application.
<u>C</u> ancel		< <u>B</u> ack	<u>N</u> ext ≻	Einish

Figure 9-7 Server Port Configuration

13. Then click Next.

- 14. The SMI Agent Configuration panel come up. Enter the following data:
 - a. Enable the SMI Agent by selecting the Enable SMI Agent check box.
 - b. Enable the SLP by selecting the Enable SLP check box, if necessary.
 - c. Enable the SSL by selecting the Enable SSL check box, if necessary.
 - d. Enter the SMI Agent port number in the SMI Agent Port # field (default is 5989 if SSL Enabled is selected; otherwise, the default is 5988).
 - e. Click Next.
- 15. Select the option on the SAN Size panel. You have the following choices:
 - a. Small (managing up to 2000 ports, 1-20 domains)
 - b. Medium (managing up to 5000 ports, 21-60 domains)
 - c. Large (managing up to 9000 ports, 61-120 domains)

Ports: Port count is equal to the total number of switch ports across all fabrics.

16.Click Next.

- 17. Verify your configuration and license information on the Server License Summary panel and click **Next**.
- 16. Select the Start Client check box on the Start Server panel (see Figure 9-8).

DCFM Configuration			
Start Server			
Click "Finish" to start the DCFM Server. Make sure the Services window (under Administr window is open, the DCFM server may fail to star	ative Tools) is t.	closed. If the S	Gervices
Start DCFM Client			
Cancel	< <u>B</u> ack	<u>N</u> ext ≻	Einish

Figure 9-8 Start Server/Client dialog box

18.Click Finish.

After all of the DCFM services are started, the Log In dialog box displays. The default UserId is *Administrator* and the default password is *password*.

9.2.2 DCFM server and client

On a Windows platform, when experiencing problems with starting the DCFM client, you might need to use only one version of Java Runtime. As shown in Figure 9-9, you can select the needed version. If you have more than one version you can select it. The support version is 1.6.0_16 for DCFM.

Important: Use only one DCFM *server* for managing and monitoring your fabric. The use of more than one DCFM server for your fabric is *not supported*.

Start the DCFM *client* instead by typing in your browser: http://<dcfm server ip address> on any host that you want to run the client.

4	🔓 Java Run	time Enviro	onment Setting	<u>js</u>			×
Г	Java Runtime	e Versions —					
	User Syste	em					
	Platform	Product	Location	Path	Rur	ntime Parameter	rs Enabled
	1.6	1.6.0_16	http://java.s	C:\Program Files\Java			
H							
H							
H							
l							
l							
				Eind		<u>A</u> dd	<u>R</u> emove
						ОК	Cancel

Figure 9-9 Java Runtime Environment Settings

9.3 DCFM GUI orientation

In the following sections we show the main features of the DCFM GUI.

Reference: For more details, see the *Data Center Fabric Manager User Manual*, GC52-1304-03, available at this website:

http://www-01.ibm.com/support/docview.wss?rs=1314&context=STBVU4&dc= DA400&uid=ssg1S7003231&loc=en_US&cs=utf-8&lang=en

9.3.1 Front panel

The management application's main window contains a number of areas. Figure 9-10 illustrates the various areas.

You can view all panels by selecting $\textit{View} \rightarrow \textit{Show Panels} \rightarrow \textit{All Panels}.$

💦 View All -	DCFM 10.4.2		
Server Edit	<u>V</u> iew <u>D</u> iscover <u>C</u> o	nfigure <u>M</u> onitor <u>F</u>	eports <u>I</u> ools <u>H</u> elp (Main Menu Bar)
	🔶 🚯 🔶		Decimal V Name V Name V Main Toolbar V 🛧 Search ?
	3 4 4	- 120 -	
SAN			
View All	•		Export ® Q 🕅 🗊 🗗
All Levels		N V Firmv	(wT)
	DGE_IBM_B32	EDG	
	Back Bone_SAN384B	bac	sumare supares
u ∎ ∎ ill s	torage Group		
	Switch Group		
	SAN32B-E4-2	SA v6.4.1	BM_940_F00 0
-<	SAN32B-E4-1	SA v6.4.1	
	switch	swit v6.4.1	KAN SAMENE 27 TELE 1
-6	BM_SAN384B_27	IBM v6.4.1	
	9 🥞 IBM_2498_R06	IBM v6.4.1	
-<	B5000_76	B50 v6.4.1	The second se
<	B5000_75	B50 v6.4.1	
	Desident Lint	<u>`</u>	Had Gao Nong Gao
	Product List)	Dath Com_51/029-0
			Connectivity Map
		۱ 🔤 ک	
A T			
Master Log	Giter Only eve	ents for current view	< Page of 1 > Minimap
Level	Source Name	Source Address	Type
	SAN32B-E4-1	10.18.235.54	Product Event Mini Map
	IBM_SAN384B_27	10.18.228.27	Product Event
	IBM_2498_R06	10.18.228.31	Product Event
	SAN32B-E4-1	10.18.235.54	
	SAN32B-E4-2	10.18.235.56	
	SWICH	10.10.228.18	
	SAN32D-E4-1	10.10.235.54	Product Event Master
	IDIWI_2490_RU0	10.10.220.31	
	DIW_SAN3646_27	10.10.220.27	
	IPM 2409 P06	10.10.233.30	
	DW1_2430_RU0	10.10.220.31	Product Event
	5AN320-E4-2	10.10.235.50	
LCVD NO		MN-303X4IC	BOR8 Clients 3 Administrator (Status Bar)

Figure 9-10 Front Panel

Table 9-1 shows the main components of the front panel and the functions they provide.

Table 9-1	DCFM Front Panel	components

Component	Description
Menu Bar	Lists commands you can perform on the SAN.
Toolbar	Provides buttons that enable quick access to dialog boxes and functions.
Product List	Lists the devices discovered in the SAN.
Master Log	Displays all events that have occurred on the SAN.
Connectivity Map	Displays the SAN topology, including discovered and monitored devices and connections.
Minimap	Displays a "bird's-eye" view of the entire SAN.
Status Bar	Displays data regarding the Server, connection, device, and fabric.

9.3.2 Main toolbar

The toolbar is located at the top of the main window and provides icons to perform the various functions as shown in Figure 9-11.



Figure 9-11 DCFM Main Toolbar

These functions are described in Table 9-2.

lcon	Description
Users	Displays the Server Users dialog box. Use to configure users, user groups, and permissions.
Properties	Displays the Properties dialog box of the selected device. Use to view or edit device properties.
Launch Element Manager	Launches the Element Manager of the selected device. Use to configure a device through its Element Manager.
Discovery Setup	Displays the Discover Setup dialog box. Use to configure discovery.
Zoning	Displays the Zoning dialog box. Use to configure zoning.
Fabric Tracking	Select to turn track fabric changes on and off for the selected device or group.
View Utilization	Displays or hides the utilization legend.
View Reports	Displays the View Reports dialog box. Use to view available reports.
Domain ID/Port #	Use to set the domain ID or port number to display as decimal or hex in the Connectivity Map.
Product Label	Use to set the product label for the devices in the Connectivity Map and product List.
Port Label	Use to set the port label for the devices in the Connectivity Map and Product List.
Product List Search	Use to search for a device in the product list.
Help	Displays the Online Help

Table 9-2 Functions of the Main Toolbar

9.3.3 Product list

The Product List displays an inventory of all discovered devices and ports. It is a quick way to look up product and port information, including serial numbers, firmware, WWN and IP addresses.

Figure 9-12 shows the Product List Panel, which can be displayed by selecting View \rightarrow Show Panels \rightarrow Product List or pressing F9.

💱 Fabirc San384	B - DCFM 10.4.2										_ [
<u>S</u> erver <u>E</u> dit ⊻ie	w <u>D</u> iscover <u>C</u> onfi	igure <u>M</u> onitor <u>R</u> eports	<u>T</u> ools <u>H</u> elp									
	• 🕲 🔶 I		cimal 👻 N	ame 🔻	Name	•			Search]		?
SAN												
Fabirc San384E	-									[• •	J 🕻
All Levels	Na	ame	Device Type	Domain ID 🔺	Firmware	State	Status	WWN	IP Address	Port Count	Tag	
🗉 😑 🔵 🍣 Bad	k Bone_SAN384BBa	ack Bone_SAN384B					Operational					
😐 😑 🧶 Но	st Group											1
🗈 😃 Storag	e Group											1
🖃 🖸 🥯 Sw	ritch Group											
- 0 🗳	IBM_2498_R06 IBM	M_2498_R06	Switch	1	v6.4.1	Online	Healthy	10:00:00:05:1E:C3:BE:29	10.18.228.31	30	0111	
🗉 👛 sv	ritch sw	vitch	Switch	5	v6.4.1	Online	Healthy	10:00:00:05:1E:B0:81:80	10.18.228.18	32	05ff	1
🗉 🗊 (Br	1_SAN384B_27 IBM	M_SAN384B_27	Switch	16	v6.4.1	Online	Healthy	10:00:00:05:1E:94:3A:00	10.18.228.27	124	10ff	1
😥 🗢 B5	000_75 B5	5000_75	Switch	23	v6.4.1	Online	Healthy	10:00:00:05:1E:90:16:E9	10.18.229.77	32	17ff	
- 🧼 SA	N32B-E4-1 SA	AN32B-E4-1	Switch	54	v6.4.1	Online	Healthy	10:00:00:05:1E:54:17:10	10.18.235.54	32	36ff	
- 🧼 SA	N32B-E4-2 SA	AN32B-E4-2	Switch	56	v6.4.1	Online	Healthy	10:00:00:05:1E:54:16:53	10.18.235.56	32	38ff	
😟 🥯 B5	000_76 B5	5000_76	Switch	98	v6.4.1	Online	Healthy	10:00:00:05:1E:90:16:57	10.18.229.78	32	62ff	
	•				00000							•

Figure 9-12 Product List Panel \

Status display in the product list

Figure 9-13 shows three types of icons: status, routing, and tracking.

lcon	Meaning
No icon	Operational Status
۵	Degraded Status
•	Failed Status
	Unknown Status
Я	Routed In
*	Routed Out
•	Device Removed
0	Device Added

Figure 9-13 Status, Routing, and Tracking Icons

Status Icons (Degraded Status, Failed Status, Unknown Status):

Shown as tags these indicate the status of the displayed object. They are overlaid over the product icons. In a worse-case status they are rolled up to closed objects on the Product List.

Routing icons (Routed In, Routed Out):

Show participation in Routing)

► Tracking Icons (Device Removed and Device Added):

Show if an object or a connection has been added or removed

Displaying ports and products in the product list

The structure can be flattened to only display Products or Ports.

You can choose which properties you want to see. Next we show the number of possibilities to change the view in the Product List and Connectivity Panel using the Toolbar.

Figure 9-14 shows the Node WWN of the switch, which can be chosen from the *Product Label* menu located on the toolbar.

K Edge_IBM B32 - DCFM 10.4.2		
Server Edit View Discover Configure	e <u>M</u> onitor <u>R</u> eports	Product Label
🖌 🖷 🔶 🔊 ∻ 🖬	Decimal 🔻	Node VWWN Port #
SAN Edge_IBM B32 ▼	• •	Name Node WWN] IP Address Export @ @ (# , #)
All Levels	Name 💙	Domain ID
E- 🔘 💩 EDGE_IBM_B32	EDGE_IBM_B32	\bigcirc
🕒 🥯 10:00:00:05:1E:34:02:4D	IBM_B32_23	4 F
010400 010401 010500 010501		100000051E34024D

Figure 9-14 Showing options in Product Label menu

The *Port Label* menu on the toolbar allows you to choose how to display the ports (see Figure 9-15).

S Edge_IBM B32 - DCFM 10.4.2			X
Server Edit View Discover Configur	e <u>M</u> onitor <u>R</u> eports <u>T</u> ools <u>H</u> elp	(Port Label)	
🔄 🎨 🖏 🔶 🔳 👗	Decimal Node WWN	Slot / Port # 🔻	•
SAN		Name Rot #	
Edge_IBM B32		Port Address	ď
All Levels	Name 💙	Fort www.	
E- 🔘 🕹 EDGE_IBM_B32	EDGE_IBM_B32	Slot (Port #	
🖃 🤝 10:00:00:05:1E:34:02:4D	IBM_B32_23		
- 0/4			
010400		0/4 F	
010401		0/5 F	-81
0/5	1000	00051E34024D	
010500			
010501			

Figure 9-15 Showing options in Port Label menu

When you right-click the switch, a menu with various choices is presented, as shown in Figure 9-16. You can turn the following displays on or off:

- Occupied Ports
- Unoccupied Ports
- Attached Ports
- Switch to Switch Connections

💱 View All - DC	FM 10.4.2					
<u>S</u> erver <u>E</u> dit ⊻	iew <u>D</u> iscover <u>C</u> onfigure <u>M</u> onitor	<u>R</u> eports	<u>T</u> ools <u>H</u> elp			
	🖏 💠 🗃 👗 🗓	Decimal	▼ Node W	WN 🔻 Slo	ot / Port # 💌	•
SAN						
View All 🔻						• • •
All Levels	Name 💙		Firmware	Device Typ	eTag	Serial # Protoc
 □ ○ ○ EDGE □ ○ ○ EDGE □ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ □ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○	Zoning LSAN Zoning (Device Sharing) Performance Events Configure FCIP Junnels High Integrity Fabric Fabric Binding Router Configuration Routing Domain IDs Jechnical Support View View Track Fabric Changes Accept Change(s) Trace Route Connected End Devices Create View Automatically Map Display	348	v6.2.0g	Switch Initiator Initiator	00ff 00ff	LX030000146
	Por <u>t</u> Display	□ <u>O</u> ccupi	ied Product Por	ts		
	Properties	⊻ <u>U</u> nOcc	upied Product F	Ports		
🗱 🗾 <	Table	I [™] <u>A</u> ttach	ed Ports 1 to Switch Con	nections		

Figure 9-16 Port display choices

9.3.4 Connectivity Map

The Connectivity Map has the following functions:

- Displays physical and some logical connectivity of SAN products. The map grouping includes Fabrics, Switch, Host, and Storage Groups.
- ► Right-clicking in each group will bring up different options.
- Displays connection and product flyovers containing additional information determined by users

The legacy switch strategy to display a different icon for every model is replaced by two icons ('pizza box' and director).

Sample Connectivity Maps

Figure 9-17 shows the Connectivity Map in which you can see that different switches are configured. When you move the mouse pointer over the switch symbol, you get more information.



Figure 9-17 Connectivity map

Figure 9-18 shows the Toolbox, which is located at the top right hand side of the View window and provides tools to zoom in and out of the Connectivity Map, collapse, and expand groups, and fit the topology to the window.



Figure 9-18 Toolbox

You can right-click in Fabrics, Switch, Host, and Storage Groups, and each group will bring up different options.

Fabric right-click menu

The initial DCFM view only displays the switches in a fabric. DCFM will allow you to hide or show all, as well as other zone-based collections of end devices.

When right-clicking the Fabric, you can see the possible choices of showing the devices as in Figure 9-19.



Figure 9-19 Connected End Devices - Show All view

Figure 9-19 shows all the connected devices. But you can choose to display only devices you want to see by clicking **Connected End Devices** \rightarrow **Custom**.

The Dialog Box, in which you can see the list of currently active zones in the fabric, is displayed (see Figure 9-20).

💱 Connected End Devices - Custom display I	or SiteA_fabric1				×
Use this dialog to create a display of the connecte also save and name the zone or group of zones a	d end devices part s an Application.	icipating in a single zone or a gro	up of zones for Sit	eA_fabric1.	You may
Zones in SiteA_fabric1	Application	Test Scenario Zones	•	Save	Delete
GOSH_serverX_1_DS4000_A SYMBIOS LOGIC INC (VWWN 20:06: Procade Communications Systems GOSL_AIX_1_DS4000_A SYMBIOS LOGIC INC (VWWN 20:06: EMULEX CORPORATION(VWWN 10:(Selected Zc QOSL_AIX QOSH_serv	nes 1_DS4000_A rerX_1_DS4000_A			
			ок	Cancel	Help

Figure 9-20 Custom Dialog

This allows you to select one or more zones and to name this zone collection (we called ours "Test Scenario").

In this case, only end devices in the zones will be displayed when the name is selected from the custom menu (see Figure 9-21).



Figure 9-21 Displaying Test Scenario zoned devices Only

You can also choose the way the map is displayed by right-clicking any empty point in the Connectivity Map (see Figure 9-22).

Zoom		Map Display Properties: Layout	t 🛛 🗙
Zoom In	Ctrl-NumPad +	Man Dianlau Laura A	rd Cat as Dafault Laurut
Zoom Out	Ctrl-NumPad -	wap Display Layour	Set as Default Layout
Map Display		Default For Group	
Expand		O Custom Grid	
Collapse	Ctrl-L	O Square	
		⊖ Vertical	
		O Horizontal	
		O Most Connected At Center	
		O Directional	
		Background Color	🖌 Set as Default Color
		Default	
		O Custom	Change
		Line Type	✓ Set as Default Line Type
		⊖ Straight	
		Orthogonal	
		O None	
			OK Cancel Help

Figure 9-22 Map Display

You can set the Layout, Color, and Line Type displayed for the groups presented on the Map.

9.3.5 Master Log

The Master Log lists the events and alerts that have occurred on the SAN. The log can be filtered to display events by category, severity, or user-entered event content.

You can do any of the following tasks:

- Determine log size and enable or disable log paging
- ► Hide / Show selected events
- Display event details

In the first column, the severity of an event (Level) is displayed.

The tags describing severity are shown in Figure 9-23.

Event Icon	Description	
Q	Informational	
Δ	Warning	
8	Error	

Figure 9-23 Severity of an event

9.3.6 Performance Legend

Performance Legend displays ranges and colors used in the Connectivity Map display (see Figure 9-24). This legend is only available when you enable the View utilization option under **Monitor** \rightarrow **Performance** \rightarrow **View Utilization**.

Legend			
		> 80 to 100	
		> 40 to 80	
		> 1 to 40	
		0 to 1	
		Collection Disabled (or) Pending	
	Legend	% Utilization	
	change		

Figure 9-24 Performance Legend

When you select the **Change** button, the next display allows users to set ranges and colors that are going to be used in the Connectivity map (see Figure 9-25).



Figure 9-25 Changing range and colors in connectivity maps

9.3.7 Minimap

The Minimap, which displays in the lower right corner of the main window, is useful for getting a bird's-eye view of the SAN, or to quickly jump to a specific place on the Connectivity Map. To jump to a specific location on the Connectivity Map, click that area on the Minimap. A close-up view of the selected location displays on the Connectivity Map.

Use the Minimap (see Figure 9-26) to view the entire SAN and to navigate to more detailed map views. This feature is especially useful if you have a large SAN because it:

- Displays entire Connectivity Map
- Displays current Connectivity Map view (outlined in green)
- Allows users to drag or click to reposition the current Connectivity Map view



Figure 9-26 Minimap

9.3.8 Status bar

The status bar displays at the bottom of the main window. The status bar provides a variety of information about the SAN and the application. The icons on the status bar change to reflect different information, such as the current status of products, fabrics, and backup.

Figure 9-27 shows the status bar with descriptions of the icons.



Implementing an IBM b-type SAN with 8 Gbps Directors and Switches

352

The Product status icons (number 2 in Figure 9-27 on page 352) are shown here in Figure 9-28.

No icon	Healthy/Operational
Δ	Attention
	Degraded/Marginal
0	Device Added
•	Device Removed/Missing
•	Down/Failed
M	Routed In
	Routed Out
	Unknown/Link Down

Figure 9-28 Product Status Icons

9.3.9 Fabric tracking

Fabric Tracking indicates if any product or connection in the fabric has been added or removed.

A green plus-sign icon is displayed with products or connections that are added, and a red minus-sign icon is displayed with ones that are removed.

Fabric Tracking can be accessed by right-clicking a fabric in the Connectivity Map. Figure 9-29 shows Fabric Tracking.



Figure 9-29 Fabric Tracking

If you click the option **Track Fabric Changes** to disable Fabric Tracking (as shown in Figure 9-29) you will switch off tracking for all devices, switches, and connections in this fabric.

Fabric Tracking: The default for Fabric Tracking for new fabrics is *Enabled*.

If there were changes, a DCFM Message box as shown in Figure 9-30 comes up. Here you have to confirm to reset the status for all devices, switches and connections. If you do **Accept Change(s)** instead of disabling the tracking, the same DCFM Message box comes up. Here you reset the tracking to a new baseline.

· · · · -		Back Bo	CANODAD							
Y "	abric Name		INE_SAN3646							
" D	o you wan	t to contin	iue?							
Switches								-		
status 🔺	Name		IP Ad	dress		WWN		Doma	in ID	
•	IBM_249	8_R06	10.18	.228.31		10:00:00:05:	1E:C3:BE:29	1		
. Democratic				-						
100000000										and the second s
evice Port	s									
tatus 🔺	Device 1	уре	Port		Port WWN		Node VWVN		Attached Port #	
0	Initiator		10:00:00:05:1E:00	:1C:CD	10:00:00:05:1E:0C:1	C:CD	20:00:00:05:1E:0C:1C:C	Ð	221	
0	Initiator		10:00:00:05:1E:53	:10:8A	10:00:00:05:1E:53:1	0:8A	20:00:00:05:1E:53:10:8/	а,	19	(
0	Initiator		27:49:00:05:1E:00	:10:00	27:49:00:05:1E:0C:1	C:CC	20:00:00:05:1E:0C:1C:C	c	201	
100000000										
10000000										
100000000										
	s									
Connection	s Type	1-0000	4	1-Domain ID	1-IP Address	1-Port	2.144AN	2-Domain II) 2-IP Address	2-Po
Connection	s Type	1-VW/M	I 0:05:1E:94:3A:00	1-Domain ID	1-IP Address	1-Port	2-WWN 10:00:00:05:15:90:16:57	2-Domain IE	2-IP Address	2-Po
Connection	s Type ISL	1-VW/M	I 0:05:1E:94:3A:00 0:05:1E:94:3A:00	1-Domain ID 16	1-IP Address 10.18.228.27 10.18.228.27	1-Port 20:D2:0 20:87:0	2-WWN 10:00:00:05:1E:90:16:57 10:00:00:05:1E:29	2-Domain IE 98	2-IP Address 10.18.229.78	2-Po 20:1: 20:1:
Connection	s Type ISL ISL	1-VWM 10:00:0 10:00:0	I 0:05:1E:94:3A:00 0:05:1E:94:3A:00 0:05:1E:94:3A:00	1-Domain ID 16 16	1-IP Address 10.18.228.27 10.18.228.27 10.18.228.27	1-Port 20:D2:0 20:87:0	2-WWN 10:00:00:05:1E:90:16:57 10:00:00:05:1E:C3:BE:29 10:00:00:05:1E:C3:BE:29	2-Domain ID 98 1	 2-IP Address 10.18.229.78 10.18.228.31 10.18.228.31 	2-Po 20:1 20:1
ionnection	s Type ISL ISL ISL	1-VWVM 10:00:0 10:00:0 10:00:0	V 0:05:1E:94:3A:00 0:05:1E:94:3A:00 0:05:1E:94:3A:00	1-Domain ID 16 16 16	1-IP Address 10.18.228.27 10.18.228.27 10.18.228.27	1-Port 20:D2:0 20:87:0 20:86:0	2-WWN 10:00:00:05:1E:90:16:57 10:00:00:05:1E:C3:BE:29 10:00:00:05:1E:C3:BE:29	2-Domain IE 98 1 1	2-IP Address 10.18.229.78 10.18.228.31 10.18.228.31	2-Po 20:1: 20:11 20:11

Figure 9-30 Track Fabric changes dialog box

9.3.10 WWN display

DCFM will display WWNs with colons and accept WWN input from users with or without the colons.

Exception: The spacing of the connectivity map cannot support the display of WWNs with colons without reducing the density of objects on the map.

WWNs will always be displayed with upper-case A, B, C, D, E, and F characters.

9.3.11 Object naming

Object Naming can be accessed by right-clicking a particular device and selecting **Properties** (see Figure 9-31).

Object Names: User defined Object Names are stored on managed devices as well as in the DCFM database.



Figure 9-31 Setting Object Name

9.4 DCFM Fabric Discovery

Discovery is the process by which the management application contacts the devices in your SAN. When you configure discovery, the application discovers products connected to the SAN and illustrates each product and its connections on the Connectivity Map.

9.4.1 Seed switch

To run the discovery, DCFM needs the *seed switch*, which is the switch that will discover and populate DCFM using in-band communication with remaining fabric such as these:

- ► Name Server information
- Zoning information
- ► Fabric membership information

Firmware requirements for the seed switch are as follows:

- Pure FOS fabrics: FOS switch running 5.0 or later firmware.
- Mixed fabrics: FOS switch running 6.0 or later and M-EOS and M-EOSn 9.7 or later.
- Pure M-EOS fabrics: M-EOS and M-EOSn 9.9.2 or later
- DCFM expects the FOS Discovery switch to run the highest level of firmware in the fabric.

When you discover a fabric, the management application checks to confirm that the seed switch is running the latest Fabric OS version in the fabric, and if it is not, the management application prompts you to select a new seed switch.

For Fabric Operating System, seed switches depend on the size of the SAN:

For Small Fabrics:

Use at least an entry-level switch (SAN24B-4).

► For Medium Fabrics:

Use at least a SAN40B-4 (Backbone switches or SAN256B are best).

► For Large Fabrics:

Use at least a SAN40B-4 (Backbone switches or SAN256B are best).

You have to have Fabric Operating System *admin* privilege (or equivalent accounts: *root*, *admin*, or *factory*).

Seed switch: Access Gateway-mode switches, switches connected to the fabric through EX/ VEX port types, and IBM Converged Switch B32 *cannot* be used as a seed switch for discovery.

You can change the seed switch as long as the new one follows the rules and is:

- HTTP-reachable from the management application
- Running the latest Fabric OS version in the fabric
- A primary Fabric Configuration Server (FCS)

Privilege: Discovery needs FOS *admin* privilege (or equivalent accounts: *root, admin,* or *factory*).

9.4.2 Setting up the discovery

The Discovery window can be reached by using **Discover** \rightarrow **Setup**.

Figure 9-32 shows how to open the Discovery window from the Main Menu Bar.

💱 View All - DCFM 1	0.4.2
<u>S</u> erver <u>E</u> dit <u>V</u> iew	Discover Configure Monitor Reports Tools Help
🔬 🖸 🍕	Setup Decimal Vame Vame
SAN	Host Port Mapping Storage Port Mapping
View All 🔻	

Figure 9-32 Accessing Discovery Window

The Discovery window displays, as shown in Figure 9-33.

omo	u Muuresses								
ame			IP Addre	ss www.		1	Discovery Status		
	Add Fabric D	iscovery			×	-▶			Add Fabric
		21 1 1							Add Host
	IP Address	SNMP			1	4D	Discovered: Seed S	Switch	Edit
	Fabric Name	IBM Fabric							Delete
	IP Address	10.64.210.213							Delete
	User ID	admin							
	Password								Change Seed Switch
	1 400 11014							-	Unmonitor
								-	Monitor
	~								
	😲 User ID :	and Password is no	ot required fo	or m-EOS swit	ches.			•	
evio				_		User ID) Commu	nity S	
evio Adc			OK	Cancel	Help	admin	public	^	Discover
evio Adc 0.18.						ledmin	public	12/24	
revio Adc 0.18. 0.18.	111 Swit	ch ese	itch 3	10:00:00:05:	1E-09-9C-02	admin	public		Delete

Figure 9-33 Discovery Setup Window

Select the **Add Fabric** button from the Discovery Setup window to input the seed switch information. You can also change the setting for SNMP (see Figure 9-34).

Add Fabric Discovery
IP Address SNMP
Target Port 181 Time-out (sec) 5 Retries 3
SNMP Version v1 - v1
Set the SNMP communit , carring s used to communicate with devices.
Read 💿 Default 'public'
○ Custom
Write 💿 Default 'private'
○ Custom
OK Cancel Help

Figure 9-34 Discovery Setup Dialog for SNMP

Discovery status

You can determine the discovery status of products by looking at the Status column in the Product List, and also the operational status (Figure 9-35). Be aware of the following considerations:

- ► Unknown is equivalent to the discovery state Offline.
- Healthy/Operational, Degraded/Marginal, and Down/Failed, are equivalent to a discovery state of Online.

All Levels	ontact	Description	State (Status	User Colu 🔺
🗈 🔘 🧆 SiteA_fabric1				Operational	
🖪 🖶 🐣 Host Group					
🗈 🥯 Switch Group					
🗉 👸 IBM_B32_50	ield Support.	Fibre Chann	Online	Healthy)
🕀 🚇 E Port Trunk 3					
- 🕑 20:00:00:05:1E:76:86:80					
- 💩 20:07:00:A0:B8:48:58:A2					
- 🥑 20:08:00:05:1E:76:86:80					
- 💧 10:00:00:05:1E:8C:D5:16					
- 😓 10:00:00:05:1E:8C:CF:ED					
- 20:09:00:05:1E:76:86:80					
🗕 💧 10:00:00:05:1E:8C:D5:16					
🖻 🎱 IBM_SAN384B_213	ield Support.	Fibre Chann	Online	Healthy	
🕀 🚇 E Port Trunk 224					
E Port Trunk 221					
- 🕑 20:54:00:05:1E:94:3A:00			Online	Online	
20:39:00:05:1E:09:97:01			Online	Online	

Figure 9-35 Discovery Status in Product List window

Changing the discovery switch

It is possible to change the seed switch in the DCFM Discovery setup window. In case there is a new switch that has the desired Fabric Configuration Server (FCS) policy, you can do it from here also. The management application requires that the seed switch is the primary FCS switch at the time of discovery.

Monitoring fabrics

You can activate or suspend discovery on a fabric without losing any fabric information. By activating discovery on the fabric, the fabric will go to the state *Discovered Monitored*. By suspending discovery on the fabric, we mean that the fabric will go to the *Unmonitored Discovered* state as shown in Figure 9-36.

When two DCFM monitored fabrics merge, the following events will happen:

- ► Two representations of the single new fabric will exist.
- The fabric that was first discovered will remain active and the other fabric will automatically be placed in the Unmonitored state.
- You can then delete the Unmonitored fabric or swap the monitoring of the two representations.

In Figure 9-36, rounded rectangles point out the same switch IBM_SAN384_213 after fabric merge in two places. A second representation of the switch IBM_SAN384_213 is in the Unmonitored state.

Discover Setup				
Add an IP Address to Discover				
Discovered Addresses				
Name	IP Address	Discovery Status	Community String	
티- 🍣 SiteA_fabric1				Add
— 🦺 ІВМ_В32_50	10.64.210.50	Discovered: Not Manageable	public	F -12
- V IBM_SAN80B_217	10.64.210.217	Discovered: Seed Switch	*****	Eat
✓ IBM_SAN384B_213	10.64.210.213	Discovered	*****	Delete
E 💩 SiteB_fabric1				
(💥 IBM_SAN384B_213	10.64.210.213	Unmonitored: Discovered : Seed Switch	*****	
				Change Seed Switch

Figure 9-36 Unmonitored Fabric after Fabric merge

The management application enables you to view the fabric monitoring status through the Discover Setup dialog box. Figure 9-37 illustrates and describes the icons that indicate the current status of the discovered fabrics.

1	Displays when the fabric is managed and the switch management status is okay.
Â	Displays when the fabric is managed and the switch management status is not okay.
	Displays when the fabric is not managed.
×	

Figure 9-37 Icons indicating the current status of the discovered fabrics

Discovering missed switches

If a fabric has been discovered and if some of its switches segment into single or multiple new fabrics, or if the fabric was deleted, you can now easily re-discover those new fabrics without entering their credentials (see the rounded rectangle in Figure 9-38 in *Previously Discovered Addresses*).



Figure 9-38 Missed Switches Rediscovery

Deleting a fabric from the management application

If you decide that you no longer want the management application to discover and monitor a specific fabric, you can delete it. Deleting a fabric also deletes the fabric data on the server except for user-assigned names for the device port, device node, and device enclosure information (see Figure 9-39).

	esses					
Name 🔺		IP Add	ress VW/N	Disco	very Status	
🗉 🐟 Back Bor	ne_SAN384B					Add Fabric
🗄 🐟 256В_М4	8					
🗉 🗻 IBM Fabri	c					Add Host
EDGE IBI	M B32					Edit
-	-					
						Delete
						Change Seed Switch
						Change Seed Switch
						Lipmonitor
						Of information
						Monitor
						Monitor
						Monitor
						Monitor
						Monitor
						Monitor
		4		<i>⁷⁷⁸</i>		Monitor
reviously Discov	vered Addresses	•				Monitor
reviously Discov	vered Addresses Type ▲	۹ 🜌 Name	VAANI	User ID	Community S	Monitor
reviously Discov 2 Address 0.18.228.17	vered Addresses Type ▲ Switch	Name B8000_17	WWN 10:00:00:1E:76:86:80	User ID admin	Community S public	Monitor
reviously Discov 2 Address 0.18.228.17 0.18.229.111	vered Addresses Type ▲ Switch Switch	Name B8000_17 switch_3	VW/N 10:00:00:05:1E:76:86:80 10:00:00:05:1E:09:9C:02	User ID admin admin	Community S public	Monitor
reviously Discov ? Address 0.18.228.17 0.18.229.111 0.18.229.100	vered Addresses Type ▲ Switch Switch Switch	Name B8000_17 switch_3 switch_2	WWN 10:00:00:51E:76:86:80 10:00:00:51E:09:90:02 10:00:00:51E:49:AB:01	User ID admin admin admin	Community S public	Discover Delete
reviously Discor P Address 0.18.229.17 0.18.229.100 0.18.229.100	vered Addresses Type ▲ Switch Switch Switch	Name B8000_17 switch_3 switch_2 DCY100	VWNN 10:00:00:05:1E:76:86:80 10:00:00:05:1E:99:9C:02 10:00:00:05:1E:49:4AB:01	User ID admin admin admin admin	Community S public	Discover Delete

Figure 9-39 Deleting the fabric from Management Application

9.4.3 DCFM Discovery Verification

There is a limitation of monitored fabrics in DCFM Enterprise Edition.

For pure FOS fabrics:

You can monitor up to 24 physical fabrics with support for:
 120 switches, 9,000 switch ports, 20,000 hosts or storage devices

For mixed fabrics:

You can monitor up to 24 physical fabrics with support for:
 60 switches, 5,000 switch ports, 10,000 hosts or storage devices

For pure M-EOS fabrics:

You can monitor up to 24 physical fabrics with support for:
 60 switches, 5,000 switch ports, 10,000 hosts or storage devices

You can use the **Unmonitor** button to unmonitor fabrics from the Management Application and select a new Fabric to monitor as shown in Figure 9-40.

Discovered Addre	SSES					
Name 🔺		IP Addr	ess WWN	Disco	very Status	
🗉 🐟 Back Bon	e_SAN384B					Add Fabric
🗉 🐟 256B_M48	3					Add Host
🗉 🐟 IBM Fabric	;					
🗄 🌏 EDGE_IBN	1_B32					Edit
						Delete
	C	Monitored Fat	prics			Change Seed Switch Unmonitor Monitor
		Monitored Fab	prics	Ø.		Change Seed Switch Unmonitor Monitor
reviously Discov	ered Addresses	Monitored Fab	prics		•	Change Seed Switch Unmonitor Monitor
reviously Discov	ered Addresses Type A	Monitored Fab	VWWN	User ID	Community S	Change Seed Switch Unmonitor Monitor
reviously Discov 2 Address 0.18.228.17	ered Addresses Type ▲ Switch	Nonitored Fab	WWN 10.00.00.05.1E.76.86.80	User ID admin	Community S public	Change Seed Switch Unmonitor Monitor
reviously Discov P Address 0.18.228.17 0.18.228.111	ered Addresses Type A Switch Switch	Name B8000_17 switch_3	VWWN 10:00:00:05:1E:76:86:80 10:00:00:05:1E:09:9C:02	User ID admin admin	Community S public	Change Seed Switch Unmonitor Monitor
reviously Discov P Address 0.18.229.11 0.18.229.111 0.18.229.100	ered Addresses Type A Switch Switch Switch	Name B8000_17 switch_3 switch_2	VWWN 10:00:00:05:1E:76:86:80 10:00:00:05:1E:49:9C:02 10:00:00:05:1E:49:AB:01	User ID admin admin admin	Community S public	Change Seed Switch Unmonitor Monitor Discover Delete

Figure 9-40 Unmonitor fabrics

9.5 DCFM reports

Presenting and archiving data about a SAN is equally as important as gathering the data.

The following standard report types are available to generate from the collected data out of the DCFM:

- Fabric Summary: Lists information about discovered fabrics including fabric and switch details, device information, and ISL and trunk summary.
- Fabric Ports: Lists discovered ports including used and unused ports. Port data for each fabric is divided into three parts: Fabric-wide port details, Switch-wide port details, and individual port details.

The following device specific reports are available through the Report menu:

- Performance: Lists historical performance-related data.
- Zone: Lists zoning objects.

Viewing reports: Reports can be viewed in the reports dialog, which supports the export of reports to various formats (html, pdf, xml).

9.5.1 Fabric Summary Report and Port Report

The reports can be generated from Main Fabric View. Go to **Report** \rightarrow **Generate** (see Figure 9-41).

🏷 View	All -	DCFM 1	0.4.2			
<u>S</u> erver	Edit	<u>V</u> iew	Discover	<u>C</u> onfigure	Monitor	Reports Tools Help
	•	\$	S			Generate hal ▼ Name ▼
SAN						<u></u>
View	/ All	¥				

Figure 9-41 Reports menu

You can choose the Fabric Summary Report as shown in Figure 9-42.

Generate Reports			>
Select Output Template			
Fabric Summary Rep	ort		1
Fabric Ports Report			
L			
Select Fabrics			
Fabric Name	IP Address	Select	
SiteA_fabric1	10.64.210.217		

Figure 9-42 Dialog box for generating reports

Finally, the fabric report displays (see Figure 9-43).

Server WIN-	@ 160 2	54 18 153								,
303 X4IGI	BOR8									
abric Details										
Fabric Nan	ne Se	ed Switch WWN	# of Sw	itches #ofAg	s #o	Fabric P	orts	Fa	bric Discove	ered Time
Back Bone_SA	N384B 10:0	0:00:05:1E:94:3A:00	8	0		296		SatO	ct 23 15:46:2	2 PDT 2010
otal number of sw	itches: 8									
otal number of AG	6's: 0									
Switch(es) Deta	ails									
Switch Name	Domain ID	IP Address		Switch WWN	F	irmware \	/ersion	Swi	itch Type	# Of Ports
SAN32B-E4-2	56	10.18.235.56	10:00:	00:05:1E:54:16:5	3	v6.4.	1	-	BES	32
switch	5	10.18.228.18	10:00:	00:05:1E:B0:81:8	0	v6.4.	1	Broo	ade 8000	32
IBM_SAN384B_2	27 16	10.18.228.27	10:00:	00:05:1E:94:3A:0	0	V6.4.	1	Broca	de DCX-4S	112
B5000_75	23	10.18.229.77	10:00:	00:05:1E:90:16:E	9	V6.4.	1	Broo	ade 5000	32
BE000 76	0.9	10.18.235.54	10:00:	00:05:1E:04:17:1	7	V0.4.	1	Brok	BES	32
IDM 2400 D06	98	10.18.229.78	10:00:	00:05:1E:90:16:5	20	V0.4.	1	Broc	ade 5000	32
for vd 2 1	2	0.000	50,00	51-E9-43-AE-0E-2	8	vo.4.	<u>.</u>	610	aua 7000	24
		0.0.0.0	00.00.			1110	, 	-		
	-			-						
otal number of Ini	tiator Devices:			7						
otal number of Ta	rget Devices:	Davison		8						
Total number of Lin	kocwo Dovices:	Devices:		2						
fotal number of De	vices:			17						
Device(s) Inform	nation									
Switch Name	Device Name	Device Port WWN	Status	Device Type	Role	Slot #	Speed	Port #	Port Type	Vendor
	[46] "Emulex									
B5000_75	LP9002 FV3.	10:00:00:00:C9:2B: 7E:90	Online	Physical	Initiato	r 0	2	23	F-Port	EMULEX
	A7 IBM-APP-108									CORFORMIN
B5000 76		50:05:07:68:01:10:	Online	Physical	Targe	t 0	2	8	F-Port	IBM
		2/1E2								
_					1			1	1	1

Figure 9-43 Fabric Summary Report

The reports contain the following information:

- ► Details regarding the Fabrics, Switches, and Devices discovered in the SAN:
 - Fabric Detail:

Fabric Name, WWN, Is Secure, Fabric Creation Time, Total Number of Switches, Total Number of AGs, Total number of FC Ports, AD Information

- Switch Details:

Switch Name, Domain ID, IP Address, Switch WWN, Firmware Version, Switch Type, Total Number of Ports

- Device Information:
 - Summary: Total Number of Devices, Total Number of Initiators, Total Number of Targets, Total Number of Initiators + Targets
 - Device Name, Device Port WWN, Status, Physical/Virtual, Role (Initiator/Target), Switch Name, Slot Number, Switch Port Number, Port Type, Device Type, Vendor

The Fabric Ports Report, which can be seen in Figure 9-44, displays information about all the discovered ports in all discovered fabrics.

abric Port	s Rep	oort													Nov	04, 2010	02:27:29	9 PM, PD
Server: WIN 3033	- (4IGB(R8	@ 169.254.1	18.153														
abric : Back	k Bone	SAN3	84B															
				Direc	tor U	tilization							Sv	vitch Uti	lization			
Total Fabric I	Ports	Total N P	umber of orts	Number of Po connected	rts	Number of Free	Ports	Num	ber of Ports allocated	Total Nur Por	nber of ts	Nun	nber of F connecte	Ports I ed	Number of Free	Ports	Number allo	of Port cated
313			0	0		0			0	31	3		66		248			0
Details			·															
IP Address	Switch	n Name	Domain/ Po	t Zone				Con	nected Device)			Port	Port	Port	Port	Port	Physic
			#		Dev	iceName	Vend	or	Device Type	Model	PortW	wn	Name	Speed (GBPS)	Status	State	Туре	Logic
10.18.235.56	SAN32	2B-E4-2	D56 /P0	(Online)										8	No_Mod ule	Offline	U-Port	Physic
10.18.235.56	SAN32	2B-E4-2	D56 /P1	(Online)										8	No_Mod ule	Offline	U-Port	Physio
10.18.235.56	SAN32	2B-E4-2	D56 /P2	(Online)										8	No_Light	Offline	U-Port	Physi
10.18.235.56	SAN32	2B-E4-2	D56 /P3	(Online)										8	No_Mod ule	Offline	U-Port	Physi
10.18.235.56	SAN32	2B-E4-2	D56 /P4	(Online)										8	No_Mod ule	Offline	U-Port	Physic
10.18.235.56	SAN32	2B-E4-2	D56 /P5	(Online)										8	No_Mod ule	Offline	U-Port	Physi
10.18.235.56	SAN32	2B-E4-2	D56 /P6	(Online)										8	No_Mod ule	Offline	U-Port	Physi

Figure 9-44 Fabric Ports Report

9.5.2 Generating performance reports

In order to generate a historical performance report, you have to enable that you want to collect data constantly to receive the necessary historical data required for a meaningful report. To enable, select **Monitor** \rightarrow **Performance** \rightarrow **Historical Data Collection** \rightarrow **Enable SAN Wide**.

To generate a report, select: Monitor \rightarrow Performance \rightarrow Historical Graph

erve	r: {Diomede}	@ IP Ad	dress: {10	.64.210.1	06}			
epor	t Configuration							
avor	ite Name	MyData_20090803						
ain I	Measure	Tx % Utilization						
ispla	iy	Top 5 of Tx % Utilization						
rom		All FC Ports						
or		Last 1 Hour						
ranu	ılarity	5 Minutes						
dditi	onal Measures	Rx % Utilization						
dditi op 5 #	onal Measures 5 of All FC Port Fabric	Rx % Utilization s by Tx % Utilization Source	Source	Port	Destination	Destination Port	Tx %	Rx %
dditi op 5 # 1	onal Measures of All FC Port Fabric SiteA_fabric1	Rx % Utilization s by Tx % Utilization Source IBM_SAN80B_217	Source Port 9	Port Type E-Port	Destination IBM_SAN384B_213	Destination Port	Tx % Utilization 0	Rx% Utilization 0
dditi op 5 # 1 2	onal Measures 5 of All FC Port Fabric SiteA_fabric1 SiteA_fabric1	Rx % Utilization s by Tx % Utilization BM_SAN80B_217 IBM_SAN80B_217	Source Port 9 57	Port Type E-Port E-Port	Destination BM_SAN384B_213 BM_SAN384B_213	Destination Port 8/29 2/20	Tx % Utilization 0	Rx % Utilization 0
dditi pp 5 # 1 2 3	onal Measures 5 of All FC Port Fabric SiteA_fabric1 SiteA_fabric1 SiteA_fabric1	S by Tx % Utilization S by Tx % Utilization IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217	Source Port 9 57 19	Port Type E-Port E-Port F-Port	Destination IBM_SAN384B_213 IBM_SAN384B_213 20:00:00:00:C9:4C:8C:1C	Destination Port 8/29 2/20 10:00:00:00:05:94:C:8C:1C. 10:00:00:00:05:94:C:8C:1C.	Tx % Utilization 0 0	Rx % Utilization 0 0
dditi pp 5 # 1 2 3 4	onal Measures 5 of All FC Port Fabric SiteA_fabric1 SiteA_fabric1 SiteA_fabric1 SiteA_fabric1	Source Source IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217 IBM_SAN80B_217	Source Port 9 57 19 56	Port Type E-Port E-Port F-Port E-Port	Destination IBM_SAN384B_213 IBM_SAN384B_213 20:00:00:00:C9:4C:8C:1C IBM_SAN384B_213	Destination Port 8/29 2/20 10:00:00:05:94:C:8C:1C, 10:00:00:05:94:C:8C:1C, 10:00:00:05:94:C:8C:1C, 20:00:00:05:94:C:8C:1C, 20:00:00:00:05:94:C:8C:1C, 20:00:00:00:00:00:00:00:00:00:00:00:00:0	Tx % Utilization 0 0 0	Rx % Utilization 0 0 0
dditi) pp 5 # 1 2 3 4 5	onal Measures 5 of All FC Port Fabric SiteA_fabric1 SiteA_fabric1 SiteA_fabric1 SiteA_fabric1 SiteA_fabric1	Source Source<	Source Port 9 57 19 56 1	Port Type E-Port E-Port F-Port E-Port U-Port	Destination IBM_SAN384B_213 IBM_SAN384B_213 20:00:00:00:C9:4C:8C:1C IBM_SAN384B_213	Destination Port 8/29 2/20 10:00:00:00:09:4C:8C:1C, 10:00:00:09:4C:8C:1C, 20:00:00:09:4C:8C:1C, 20:00:00:09:4C:8C:1C, 20:00:00:09:4C:8C:1C, 20:00:00:09:4C:8C:1C, 20:00:00:09:4C:8C:1C, 20:00:00:00:09:4C:8C:1C, 20:00:00:00:09:4C:8C:1C, 20:00:00:00:09:4C:8C:1C, 20:00:00:00:09:4C:8C:1C, 20:00:00:00:00:00:00:00:00:00:00:00:00:0	Tx % Utilization 0 0 0	Rx % Utilization 0 0 0 0

The generated report can be seen in Figure 9-45.

Figure 9-45 Historical Performance Report

9.5.3 Generating zoning reports

You can also generate a report for the current zone DB in the fabric.

- ► To generate a report for the edited zone DB, you must save it to the fabric first.
- To generate a zoning report, select **Configure** \rightarrow **Zoning** \rightarrow **Fabric**.
- ► You can also right-click the device and select **Zoning**.

The Zoning dialog box displays, as shown in Figure 9-46.

Zoning						
oning Scope SiteA_fabric	c1 💌	Zo	ne DB Fabric Zone DB 🔻		Zone DB Operation	Zone DB Edit
Zone DB Active Zone	e Config					
Potential Members	Type Domain,Port Ind	ex 🔻	Zones		Zone Configs	
All Levels	Port Type	Alias Sind	AIX_1_DS4000_A_Test AIX_000_A_Test	Find	⊞ 🧕 SiteA_fab1	🚇 Activate
🗄 🥯 Switch Group		>	GoSH_serverX_1_DS4000_A GoSL_AIX_1_DS4000_A	>		Zoning Policies
						Report
			New Zone New Member		New Config	
rocade Native Mode						
					OK Cancel	Apply Help

Figure 9-46 Zoning window
Click **Report** and a DCFM message is issued. Confirm with **OK** and the selected report automatically displays in the View Reports dialog box (see Figure 9-47).

Zanina										
Zoning Summary Report Jun 25, 2009 01:37:10 PM, PDT										
Fabric: SiteA_fabric1										
Server: Diomede@10.64.210.106										
Zone DB:	(Online)					Size	: 626 bytes			
Zone DB\Z	one Configs									
SiteA_fab1										
Zone Nam	e			Number of Members	Members L	ogged In	Active			
AIX_1_DS4	4000_A_Test			2	2		Yes			
QoSH_serv	verX_1_DS4000_A			2	Yes					
QoSL_AIX	_1_DS4000_A			2	2		Yes			
Zone DB\Z	ones									
AIX 1 DS4	4000 A Test (memb	er of 1 Zone Config)				_				
		, c. c. r Lone o oning,								
Alias Mem	bers - DS4000 A									
WWN Men	nbers									
Members Attached to Switch Properties										
interno er i i	openies				Attached to Sw	vitch Proper	rties			
Logged In	Port Name	PortWWN	Node Name	Node WW/N	Attached to Sw Switch Name	vitch Proper Domain ID	rties Port Index			
Logged In Yes	PortName	Port WWN 20:06:00:A0:B8:48:58:A1	Node Name	Node WWWN 20:06:00:A0:88:48:58:A0	Attached to Sw Switch Name IBM_SAN384B_2	vitch Proper Domain ID 2	Port Index 92			
Logged In Yes	PortName	Port WWN 20:06:00:A0:88:48:58:A1	Node Name	Node WWWN 20:06:00:A0:88:48:58:A0	Attached to Sw Switch Name IBM_SAN384B_2 13	vitch Proper Domain ID 2	nties PortIndex 92			
Logged In Yes Alias Meml	Port Name	PortWWN 20:06:00:A0:88:48:58:A1	Node Name	Node WWN 20:06:00:A0:88:48:58:A0	Attached to Sw Switch Name IBM_SAN384B_2 13	vitch Proper Domain ID 2	ties PortIndex 92			
Alias Memi	Port Name bers - AIX_1	Port WWN 20:06:00:A0:58:48:58:A1	Node Name	Node WWN 20:06:00:A0:88:48:58:A0	Attached to Sw Switch Name IBM_SAN384B_2 13	vitch Proper Domain ID 2	PortIndex 92			
Alias Meml WWN Mem Member Pr	Port Name bers - AIX_1 bers operties	Port WWN 20:06:00:A0:88:48:58:A1	Node Name	Node WW/N 20:06:00:A0:88:48:58:A0	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw	vitch Proper Domain ID 2 vitch Proper	ties PortIndex 92 ties			
Alias Meml WWN Mem Member Pr Logged In	Port Name bers - AlX_1 bers operties Port Name	Port WWN 20.06.00.A0.B848.58:A1 Port WWN	Node Name Node Name	Node WW/N 20:06:00:A0:B8:48:58:A0 Node WW/N	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw Switch Name	vitch Proper Domain ID 2 vitch Proper Domain ID	ties PortIndex 92 ties PortIndex			
Alias Mem WWN Mem Member Pr Logged In Yes	PortName bers - AIX_1 bers operties PortName	Port WWN 20.0600.A0.58.48.58.A1 Port WWN 10.00000.029.4C.8C.1C	Node Name Node Name	Node WW/N 20.06:00:A0:88:48:58:A0 Node WW/N 20.00:00:00:C9:4C:8C:1C	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw Switch Name IBM_SAN80B_21 2	vitch Proper Domain ID 2 vitch Proper Domain ID 1	ties PortIndex 92 ties PortIndex 19			
Alias Meml WWN Mem Member Pr Logged In Yes	PortName bers - AIX_1 bers operties PortName	Port WWN 20.0600.A05848-58-A1 Port WWN 10.0000.0029-4C-8C-1C	Node Name	Node WW/N 20.06:00:A0:88448:58:A0 Node WW/N 20:00:00:00:C9:4C:8C:1C	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw Switch Name IBM_SAN80B_21 7	vitch Proper Domain ID 2 vitch Proper Domain ID 1	ties Port Index 92 ties Port Index 19			
Alias Meml WWN Mem Member Pr Logged In Yes	Port Name bers - AIX_1 bers operties Port Name verX_1_DS4000_A(Port WWN 20.0600:A0:58:48:58:A1 Port WWN 10.00:00:00:C9:4C:8C:1C member of 1 Zone Cor	Node Name Node Name	Node WWW N 20.06.00.A0.88448.58:A0 Node WWW N 20.00.00.00.09 #C.8C:1C	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw Switch Name IBM_SAN80B_21 7	vitch Proper Domain ID 2 vitch Proper Domain ID 1	rties 92 1ties 19 19			
Alias Meml Yes Alias Meml WWN Men Member Pr Logged In Yes QoSH_sen WWN Mem	PortName PortName bers - AIX_1 bers operties PortName verX_1_DS4000_A(bers	Port WWN 20:0600:A0:8848:58:A1 Port WWN 10:00:00:00:9:4C:8C:1C member of 1 Zone Cor	Node Name Node Name	Node WWW N 20:06:00:A0:B8:48:58:A0 Node WWW N 20:00:00:00:C9:4C:8C:1C	Attached to Sw Switch Name IBM_SAN384B_2 13 Attached to Sw Switch Name IBM_SAN80B_21 7	vitch Proper Domain ID 2 vitch Proper Domain ID 1	ties Port Index 92 ties Port Index 19			
Alias Meml Yas Alias Meml WWN Mem Member Pr Logged In Yas QoSH_sen WWN Men Member Pr	Port Name bers - AIX_1 bers operties Port Name verX_1_DS4000_A(bers operties	Port WWN 20.0600.A0.8848.58.A1 Port WWN 10.00.00.00.59.4C.8C.1C member of 1 Zone Cor	Node Name Node Name rfig)	Node WW/N 20.0600:A0:88:48:58:A0 Node WW/N 20.00:00:00:9:4C:8C:1C	Attached to Sw Switch Name BM_SAN345_2 13 Attached to Sw Switch Name BM_SAN806_21 7 Attached to Sw	vitch Proper Domain ID 2 vitch Proper Domain ID 1	rties Port Index 92 rties Port Index 19 rties			
Alias Meml Yes Alias Meml WWN Mem Member Pr Logged In Yes QoSH_ser WWN Men Member Pr Logged In	PortName PortName PortName PortName PortName verX_1_DS4D00_A(thers operties PortName PortName	Port WWN 20.0600.A0:84:8:58:A1 Port WWN 10.000000:C9:4C:8C:1C member of 1 Zone Cor Port WWN	Node Name Node Name nfig) Node Name	Node WWVN 20:06:00:A0:58:48:58:A0 Node WWVN 20:00:00:00:C9:4C:8C:1C	Attached to Sw Switch Name BM_SAN3882_1 13 Attached to Sw Switch Name BM_SAN806_21 7 Attached to Sw Switch Name	vitch Proper Domain ID 2 vitch Proper Domain ID 1 vitch Proper Domain ID	ties Port Index 92 Port Index 19 ties Port Index			
Alias Meml Yes Alias Meml WWN Men Member Pr Uogged In Yes Yes	PortName PortName PortName PortName PortName verX_1_DS4000_A(tabers PortName PortName	Port WWN 20.0600.A0:58:48:58:A1 Port WWN 10.00.00.00:C9:4C:8C:1C member of 1 Zone Cor Port WWN 20.0600.A0:58:48:58:A1	Node Name Node Name nfig)	Node WW/N 20.06.00.A0.584/48.58:A0 Node WW/N 20.00.00.00.C9.4C.8C:1C Node WW/N 20.00.00.00.C9.4C.8C:1C	Attached to Sw Switch Name BM_SAN3862 13 Attached to Sw Switch Name BM_SAN86521 7 Attached to Sw Switch Name BM_SAN8652 13	vitch Proper Domain ID 2 vitch Proper Domain ID 1 vitch Proper Domain ID 2	ties Port Index 92 Port Index 19 ties Port Index 92			

Figure 9-47 Zoning reports

9.6 Event logs

You can view all events that take place in the SAN through the Master Log at the bottom of the main window. You can also view a specific log by selecting an option from the **Monitor** \rightarrow Logs menu option (see Figure 9-48).

er <u>C</u> onf	figure	Monitor	Tools	Help				
+ ()+	6	Performanc			►	ame 👻	Port VW	٧N
•	<u> </u>	<u>T</u> echi	nical Suj	pport	►			
		Event	Policies	8				
	Name	Event	t <u>N</u> otifica	ation	►	Tag	Т	
37:71:0A	10:00:	<u>S</u> NMF	P Traps					
1	SiteA_	S <u>y</u> sia	ig Config	guration			_	
		Logs			►	<u>A</u> udit		IR.
:C9:4C:80	:	<u>R</u> epo	nts		►	Event		
0:00:C9:4		🗹 Track	Fabric	<u>C</u> hange:	з	<u>F</u> abric		
0:05:1E:0		<u>A</u> cce	pt Chan	ge(s)		FICO <u>N</u>		
0:05:1E:53	1	Port (Connecti	ivity		Product Status		
		Port (Optics (S	SFP)		Se <u>c</u> urity		
9 4B 213	IBM S	E <u>v</u> ent	ts			Syslog		

Figure 9-48 Viewing Event Logs

As shown in Figure 9-48, you have the option to filter the logs and only display the area of interest. The following options for displaying logs are available:

- Audit
- Event
- Fabric
- ► FICON
- Product Status
- ► Security
- Syslog

Table 9-3 shows the logs and their descriptions.

Table 9-3	Logs
-----------	------

Name	Description
Event Log	Displays all "Product Events" type events from all discovered switches
Fabric Log	Displays "Product Events," "Device Status," and "Product Audit" type events for all discovered fabrics
FICON Log	Displays all the "LIR" and "RLIR" type events, for example, "link incident" type events
Product Status Log	Displays events which indicate a change in Switch Status for all discovered switches

Name	Description
Security Log	Displays all security events for the discovered switches
Syslog Log	Displays syslog messages from switches

The master log contains the columns as shown in Table 9-4.

Table 9-4 Master Log Columns

Column name	Description
Level	The severity of the event
Source Name.	The product on which the event occurred
Source Address.	The IP address (IPv4 or IPv6 format) of the product on which the event occurred
Туре	The type of event that occurred (for example, client/server communication events)
Description	A description of the event
First Occurrence Host Time	The time and date the event first occurred on the host
Last Occurrence Host Time	The time and date the event last occurred on the host
First Occurrence Switch Time	The time and date the event first occurred on the switch
Last Occurrence Switch Time	The time and date the event last occurred on the switch
Operational Status	The operational status of the product on which the event occurred
Count	The number of times the event occurred
Module Name	The name of the module on which the event occurred
Message ID	The message ID of the event
Contributor	The name of the contributor on which the event occurred
Node WWN	The world wide name of the node on which the event occurred
Fabric Name	The name of the fabric on which the event occurred

Figure 9-49 shows how it is possible to hide events by selecting the desired events and choosing the **Hide Selection** option when you right-click in the Master Log window.

vel	Source Name	Source Addres	s Type		Description		
٩	IBM_SAN384B_27	10.18.228.27	Security Event		Login information: Login successful via TELNET/SSH/RSH. I		
<u> </u>	IBM_2498_R06	10.18.228.31	Performance E	vent	SNMP V3 not configured. GE and FCIP statistics can not be		
<u> </u>	IBM_SAN384B_27	10.18.228.27	Performance E	vent	SNMP V3 not configured. GE and FCIP statistics can not be		
1	Administrator	10.18.228.151	Performance E	vent	Historical Data Collection is enabled on 256B_M48,Back Bo		
1	Administrator	10.18.228.151	Performance E	vent	Historical Data Collection enabled on 256B_M48		
(IBM_SAN384B_27	10.18.228.27	E well N	1	SNMP configuration attribute, snmp.inform, has changed fro		
1	IBM_SAN384B_27	10.18.228.27	E-mail		SNMP configuration attribute, snmp.inform, has changed fro		
1	IBM_SAN384B_27	10.18.228.27	Display Details		Login information: Login successful via TELNET/SSH/RSH.		
1	IBM_2498_R06	10.18.228.31	Hide Selection	nt Event	Syslog registration succeeded for the switch: 10.18.228.3		
1	IBM_2498_R06	10.18.228.31	Chaux N		SNMP configuration attribute, Trap recipient port 2 , has cha		
1	administrator	10.18.228.38	Show •	vent	Server authentication (Client IP:10.18.228.38, Authenticatio		
1	IBM_SAN384B_27	10.18.228.27	Table 🕨		Login information: Login successful via TELNET/SSH/RSH.		
٩	IBM_SAN384B_27	10.18.228.27	Security Event		Security violation: Login failure attempt via TELNET/SSH/RS		
1	IBM_SAN384B_27	10.18.228.27	Security Event		Changed account dennis.		
1	IBM_SAN384B_27	10.18.228.27	Security Event		Login information: Login successful via TELNET/SSH/RSH.		
1	IBM_SAN384B_27	10.18.228.27	Security Event		Changed account dennis.		
(ì)	IBM SAN384B 27	10 18 228 27	Security Event		Login information: Login successful via TELNET/SSH/RSH /		

Figure 9-49 Hiding highlighted events

You can display the details for a particular event as shown in Figure 9-50 by selecting the event, right clicking it, then selecting **Display Details**.

	💱 Event Details						×	1	
	Event Field			Value					
	Probable Cause								
	Count			1					
	Resolved			No					
	Message			ISL [Domain 1 (1)]	Port 85 (55) - Domain5 (5) Port56 (38)]	Modified			
	Time(Switch)			Thu Aug 13 14:37:	59 PDT 2009				
	ModuleName						_		
	Event Source								
	Audit								
	Status								
A v	Severity			Info					
MesterLog	Source Name			BACKBONE_SAN3	848			l of	1
master Log	Virtual Fabric ID								
Level	MessageiD Recommonded 1	tion						ccurrence	e Host.
8	I Contributore	2001						ig 13 17:5	2:56 P 🔺
1	Time(Host)			Thu Aug 13 14:37:	59 PDT 2009			ig 13 17:4	9:47 P 📶
(Ì)				The Aug 15 14:51.	331012000			ua 13 14:4	3:18 P
(Ì)		unsuccessory consideration						ia 13 14 4	318 P
Č.		010000000000000000000000000000000000000		**********************				1214.2	0.69 0
Å	1					Close	Help	ug 10 14.0	0.50 F
-								ig 13 14.3	0.50 P
<u> </u>	DM_0AR0040_210	10.04.210.213	TTOUGET EVEN	L	Trace damp available (Slot 3): (Feaso	n. 1100)	111977	#ag 13 14:3	8:58 P
<u></u>	IBM_SAN384B_213	10.64.210.213	Product Even	t	First failure data capture (FFDC) ever	nt occurred.	Thu A	Aug 13 14:3	8:41 P
<u>(</u>)	IBM_SAN384B_213	10.64.210.213	Product Even	t	Port 2/25 is changed from FCR port to	o non FCR port.	Thu A	Aug 13 14:3	8:04 P
	BACKBONE_SAN3848	3	Fabric		ISL [Domain 1 (1) Port 85 (55) - Doma	ain5 (5) Port56 (38)]	M Thu A	Aug 13 14:3	7:59 P
(I)	BACKBONE_SAN3848	3	Fabric		ISL [Domain 1 (1) Port 221 (dd) - Don	nain5 (5) Port9 (9)] N	10 Thu A	Aug 13 14:3	7:59 P
1	BACKBONE_SAN384E	3	Fabric		ISL [Domain 5 (5) Port 9 (9) - Domain	1 (1) Port221 (dd)] N	Ao Thu A	Aug 13 14:3	7:59 P
()	BACKBONE_SAN3848	3	Fabric		ISL [Domain 5 (5) Port 8 (8) - Domain	1 (1) Port220 (dc)] N	Ao Thu A	Aug 13 14:3	7:59 P

Figure 9-50 Event Details

Figure 9-51 displays how to define a filter for the events. To do this, select the option **Filter** on the top of the window Master Log.

- To include an event type in the filter, select the event from the Available Events table and click the right arrow.
- To exclude an event type from the filter, select the event from the Selected Events table and click the left arrow.

Type A Su Authentication Ev Info	ubtype	Level			Tuno A	Coulada un a	I second	
Authentication Ev Info					Type -	Subtype	Level	
	ormational	(l)			Zoning Event	Warning	1	
Authentication Ev Wa	arning	1						
Authentication Ev Fat	ıtal	8						
Call Home Event Info	ormational	1						
Call Home Event VVa	arning	1		The later				
Call Home Event Fat	ıtal	8						
Config Manageme Info	ormational	1						
Config Manageme Wa	arning	1						
Config Manageme Fat	ıtal	8						
ata Encryption E Info	ormational	1						
ata Encryption E Wa	arning	1						
ata Encryption E Fat	ıtal	8						
evice Status Event Infr	ormational	(i)	-					

Figure 9-51 Defining a filter for the event

Figure 9-52 shows the results of defining a filter for only Zoning Events in the Master Log.

Master Log 🗹 Filter 🗌 Only events for current view								
Level	Source Name	Source Address	Туре	Description	First Occurrence Host 💙			
<u> </u>	IBM_SAN80B_217	10.64.210 217	Zoning	Failed to delete zone DB content from Fabric SiteA_fab1.	Mon Jun 15 04:50:32 PDT			
<u> </u>	IBM_SAN80B_217	10.64.210.217	Zoning	Failed to activate zone config SiteA_fab1 and save the zon	Mon Jun 15 00:53:08 PDT			
<u> </u>	IBM_SAN80B_217	10.64.210.217	Zoning	Failed to activate zone config SiteA_fab1 and save the zon	Mon Jun 15 00:44:27 PDT			
<u>^</u>	IBM_SAN80B_217	10.64.210.247	Zoning	Failed to activate zone config SiteA_fab1 and save the zon	Mon Jun 15 00:42:41 PDT			

Figure 9-52 Master Log with the filter (zoning events only)

9.7 Performance management

In this DCFM performance management section, we concentrate only on the performance management features in DCFM, explaining how you can become familiar with their use. However, we do not describe the theory behind it and also do not provide real life examples.

For more information about Performance monitoring, see Chapter 16, "Performance monitoring" on page 739.

Performance monitoring provides details about how much traffic and errors a specific port or switch generates on the fabric over a specific time frame. You can also use performance to indicate the switches that create the most traffic and to identify the ports that are most congested.

You can monitor the performance of your SAN using the following methods:

- Gather and display real time performance data, monitoring, and graphical display (FC ports, GigE, and FCIP).
- Persist and display historical performance data (FC and GigE (GE) ports as well as FCIP tunnels) for selected fabrics or the entire SAN.
- ► Support End-to-End monitors for real time and historical performance data.
- Enforce user-defined performance thresholds and notification when thresholds are exceeded.
- ► Display percentage utilization on the client for FC and FCIP links.
- Provide user-defined aging scheme (5 minutes, 30 minutes, 2 hours and 1 day granularity).
- Provide enhanced performance reports.

In Figure 9-53 you can see the menu with possible options that you can use when managing performance data with DCFM.



Figure 9-53 Pull-down menu

9.7.1 Performance measures

There are several performance measures available to you, depending on the object type from which you want to gather performance data (see Table 9-5).

De nom oton	De se sindien
Parameter	Description
Tx% Utilization	Available for FC and GE ports, FCIP tunnels, and End-to-End monitors.
Rx% Utilization	Available for FC and GE ports, FCIP tunnels, and End-to-End monitors.
Tx MB/Sec	Available for FC and GE ports, FCIP tunnels, and End-to-End monitors.
Rx MB/Sec	Available for FC and GE ports, FCIP tunnels, and End-to-End monitors.
CRC Errors	Available for FC ports and End-to-End monitors
Signal Losses	Available for FC ports only.
Sync Losses	Available for FC ports only.
Link Failures	Available for FC ports only
Sequence Errors	Available for FC ports only
Invalid Transmissions	Available for FC ports only
Rx Link Resets	Available for FC ports only
Tx Link Resets	Available for FC ports only
Dropped Packets	Available for FCIP tunnels only.
Compression Ratio	Available for FCIP tunnels only.
Latency	Available for FCIP tunnels only
Link Retransmits	Available for FCIP tunnels only

Table 9-5 Performance measures

9.7.2 Collecting performance data

Data collected through Advanced Performance Monitoring is deleted when the switch is rebooted. Using the Data Center Fabric Manager (DCFM) Enterprise Edition, you can store performance data persistently.

9.7.3 Real time performance data

Real time performance enables you to collect data from managed switches in your SAN, and is only supported on the following managed objects:

- ► FC (E_ and F_ports) and
- ► GE_ports as well as FCIP tunnels.

You can use real time performance to configure the following options:

- ► Select the polling rate from 10 seconds up to 1 minute.
- Select up to 32 ports from up to a maximum of 10 switches for graphing performance.
- Choose to display the same Y-axis range for each displayed object per measure type for easier comparison of graphs.

To generate a real time performance graph for a switch, complete the following steps:

- 1. Select the fabric, switch, or port for which you want to generate a performance graph.
- 2. Select Monitor \rightarrow Performance \rightarrow Real-Time Graph.

💱 Real Time Port Selector х Show FC Ports Ŧ FC Ports ٠ AvailabISL Ports Selected (0 of 32 Ports / EE Monitors / FCIP Tunnels from 0 of 10 switches / HBAs). All Levi Device Ports Find Name Port Name Port Port Type Port WWN Switch Name Fabric Name E OEE Monitors 384B Back Bone 🔺 GE Ports FCIP Tunnels Ð Managed HBA Ports Ð Managed CNA Ports 💌 B5000_75 Þ 00000_70 🗄 🧼 B5000_76 B5000_76 IBM_2498 🗄 🤭 IBM_2498_R06 E IBM_SAN384B_27 IBM_SAN3 SAN32B-E 🕀 🧼 SAN32B-E4-1 🗄 🧼 SAN32B-E4-2 SAN32B-E switch 🗄 🤖 switch Ŧ • • Cancel Help

The Real time Port Selector dialog box displays (see Figure 9-54.

Figure 9-54 Real Time Port Selector

- 3. Select the object type (FC Ports, ISL Ports, Device Ports, EE Monitors, GE Ports, FCIP Tunnels, Managed HBA ports, Managed CNA ports and 10 GE ports).) for which you want to graph performance from the Show list (see the rounded rectangle in Figure 9-54).
- 4. Click the right arrow to move the selected ports from the Available to the Selected table.

The Real Time Performance Graphs dialog box displays (see Figure 9-55).



Figure 9-55 Real Time Performance Graph

You can select the measure by which you want to gather performance data from the Measures list. To select more than one measure, click the *Additional Measures* expand arrows and select the check box for each additional measure (see Figure 9-56).

_						
	💱 Real Tim	e Performa	ance Graphs			
	Select	Measures	T× % Utilization	•	Reference Line	
	Additional Measures		Tx % Utilization	-	1	
	- radicertain		Rx % Utilization			
	Source	Source	Rx MB/sec		Graph	
			Tx MB/sec			100.00
			CRC Errors			
			Signal Losses			75.00
			Sync Losses			
			Link Failures	-	N/ I Million Aligne	

Figure 9-56 Additional Measures menu

The performance measures are described in detail in Table 9-5 on page 375.

9.7.4 Historical performance data

Performance should be enabled constantly to receive the necessary historical data required for a meaningful report. The following options and features are available for obtaining historical performance data, which:

- Enables you to collect historical performance data from the entire SAN or from selected switch.
- Persists data on every polling cycle (5 minutes).
- Stores up to 3456 records (maximum) for each port. Most ports require 600 KB disk space; however, the 256-Port Director requires 7GB disk space.
- ► Uses the Round Robin Database (RRD) style aging scheme.
- ► Enables 5 minute, 30 minute, 2 hour, and 1 day granularity.
- Supports interpolation for up to 6 data points.
- ► Generates reports.

To enable historical performance collection for all fabrics in the SAN, select Monitor \rightarrow Performance \rightarrow Historical Data Collection \rightarrow Enable SAN Wide.

To enable historical performance collection for selected fabrics, select **Monitor** \rightarrow **Performance** \rightarrow **Historical Data Collection** \rightarrow **Enable Selected**. (see Figure 9-57).

Historical Dat	ta Collection									
elect the Fabric	s on which you	i would like to e	nable Data C	ollection						
ê yejekle					Salastad					
Available				•	Selected	1		1	1	
Fabric Name	WWN	Fabric Status	Descriptio		Fabric Name	WWW	Fabric Status	Description		
10:00:00:05:	10:00:00:05:	Operational								
SiteA_fabric1	10:00:00:05:	Operational								
Iccocccccccccccccccccccccccccccccccccc	000000000000000000000000000000000000000	000000000000000000000000000000000000000	000		Include I	newly discover	red fabrics			
	100000000000000000000000000000000000000	100100000000000000000000000000000000000								
								OF	Cancel	Help

Figure 9-57 Historical performance collection for selected fabrics

Generating a historical performance graph

To generate a historical performance graph for a switch, complete these steps:

- 1. Select the switch for which you want to generate a performance graph.
- 2. Select Monitor \rightarrow Performance \rightarrow Historical Graph.
 - You can also right-click the switch and select $\mbox{Performance} \rightarrow \mbox{Historical Graph}.$

The Historical Performance Graph dialog box displays (see Figure 9-58).



Figure 9-58 Historical Performance Graph

Historical Performance Graph:

- ► Display: The Top N performers (5, 10, 15, 20) for a selected object type.
- ► From Object: FC, Device, ISL Ports, FCIP Tunnels, EE Monitors, Custom
- ► For: Last hour/day/week/custom
- Granularity: 5/30/120/1920 minutes
- Measures: Many different measurements

You can filter the historical data by:

- Filtering data by ports
- Filtering data by time

You can save the historical performance graph by selecting the button **Save** (see the rounded rectangle in Figure 9-58).

Historical reports/tables

To generate a historical performance report for a device, proceed as follows:

- ► Select the device for which you want to generate a performance report.
- ► Select Monitor → Performance → Historical Report.

or Right-click the device and select Performance \rightarrow Historical Report.

The Historical Performance Table dialog box displays (see Figure 9-59).



Figure 9-59 Historical Performance table

Click Apply to display Historical Performance Report (see Figure 9-60.

View Reports									
Show In Browser Delete Report Help	•	Export To	▲ ▶ Ħ 1		n Q	Q 75% ▼ Clos	3 0		
All Reports									
🗄 🗂 By Time									
E By Report Type									
E E Fabric Ports Report									
Fabric Summary Report	Histo	rical Performance	Report						
E E Historical Performance Report	Server	(Diomede)	@ IP Add	dress : (10	.64.210.1	1063			
 Historical Performance Report_IBM_SAN80B_217_Administrator_Thu Jun 25 10:0 			6						
Historical Performance Report_IBM_SAN80B_217_Administrator_Thu Jun 25 08:3	Report	: Configuration							
Historical Performance Report_IBM_SAN80B_217_Administrator_Thu Jun 25 08:31:32 PDT	2009	- Manua - 10-0	-1- 20000002						
🗉 🗂 By User	ravon	e Name MyD	ata_20090803						
	Main N	leasure Tx%	Utilization						
	Displa	Тор	5 of Tx % Utilization						
	From	All F	C Ports						
	For	Last	1 Hour						
	Granu	arity 5 Mi	nutes						
	Additic	nal Measures Rx 9	Utilization						
	Top 5	of All FC Ports by	Tx % Utilization						
	#	Fabric	Source	Source Port	Port Type	Destination	Destination Port	Tx % Utilization	Rx % Utilization
	1	SiteA_fabric1	IBM_SAN80B_217	9	E-Port	IBM_SAN384B_213	8/29	0	0
	2	SiteA_fabric1	IBM_SAN80B_217	57	E-P ort	IBM_SAN384B_213	2/20	0	0
	3	SiteA_fabric1	IBM_SAN80B_217	19	F-Port	20:00:00:00:C9:4C:8C:1C	10:00:00:00:C9:4C:8C:1C, 10:00:00:00:C9:4C:8C:1C	0	0
	4	SiteA_fabric1	IBM_SAN80B_217	56	E-P ort	IBM_SAN384B_213	2/21	0	0
	5	SiteA_fabric1	IBM_SAN80B_217	1	U-Port			0	0

Figure 9-60 Historical Performance Report

9.7.5 Performance thresholds

Performance allows you to apply thresholds and event notification to real-time performance data, as well as historical performance data depending on the setting. A performance monitor process (thread) monitors the performance data against the threshold setting for each port and issues an appropriate alert to notify you when the threshold is exceeded.

License: A Threshold Policy requires a Fabric Watch License.

To create a threshold policy, select **Monitor** \rightarrow **Performance** \rightarrow **Configure Thresholds.** The Set Threshold Policies dialog box displays (see Figure 9-61).

Available Thre	shold Policies			Assigned Threshold Policies	
Name	High	Type Low	Buffer	Febrics and Products □ 10:00:00:67:E:37:71:0A □ □ </th <th>Name WWM 10:00:00:05: 10:00 IBM_SAN18 10:00 IBM_SAN4 10:00 SteA_fabrict 10:00 IBM_SAN64 10:00 IBM_SAN64 10:00 IBM_SAN60 10:00 IBM_SAN80 10:00 IBM_B32_50 10:00</th>	Name WWM 10:00:00:05: 10:00 IBM_SAN18 10:00 IBM_SAN4 10:00 SteA_fabrict 10:00 IBM_SAN64 10:00 IBM_SAN64 10:00 IBM_SAN60 10:00 IBM_SAN80 10:00 IBM_B32_50 10:00
Add) Edit Di	uplicate Dele	te	Assign fabric level policies to new switc	hes

Figure 9-61 Set Threshold Policies dialog box

To add a policy, click the **Add** button and the New Threshold Policy dialog box displays (see Figure 9-62).

🎇 New Threshold	Policy					×
Name	FC_ISL					
Description						
Policy Type	E Port 💌					
Manager	Ter Of 1 William -		Selected Thres	holds		
weasure		D	Measure	High	Low	Buffer
High Boundary	90 %		Tx % Utilizati	90	10	3
Low Boundary	10 % (FOS only)	\blacksquare				
Buffer Size	3 % (FOS only)					
					OK Can	cel Help

Figure 9-62 New Threshold Policy

You can choose the following parameters:

► Policy Type:

Set for either E Port or F/FL Port

Measure:

Choose Tx% Utilization, Rx% Utilization

Attention: You cannot add the same measure more than once. If you try to add another threshold with the same measure, the new values overwrite the older threshold values in the Selected Thresholds table.

You can create an SNMP trap and an event in the Master Event Log when thresholds are exceeded:

- High Boundary threshold <Measure, value set for high boundary> exceeded for <switch name>
- Low Boundary threshold <Measure, value set for low boundary> exceeded for <switch name>
- <Measure, value set for high or low boundary> has returned to normal for <switch name>

You can Edit, Duplicate, and Delete the policy as shown in Figure 9-63.

Available Thresh	old Policies			•	Assigned Threshold Policies	
Name • test_Thresho	IdPolicy	Type F/FL Port		Find	Fabrics and Products 10:00:00:05:16:37:71:0A BM_SAN18BR_137 BM_SAN86B_140 BM_SAN80B_217 BM_SAN80B_213 BM_B32_50 BM_B32_50	Name WWM 10:00:00:05: 10:00 IBM_SAN18 10:00 IBM_SAN64 10:00 SteA_fabric1 10:00 IBM_SAN80 10:00 IBM_SAN80 10:00 IBM_SAN80 10:00 IBM_SAN824 10:00 IBM_B32_50 10:00
▲ ▼ Measure Tx % Utilization	High 80	Low 20	Buffer 3			
Add	Edit	Duplicate Dele	ste		Assign fabric level policies to new switc	• mes

Figure 9-63 Set Threshold Policy

To assign a Threshold Policy, do the following steps (see Figure 9-64).

1. Select one or more threshold policies you want to assign to a fabric or switch in the Available Threshold Policies table.

Press Ctrl or Shift and then click to select multiple policies.

2. Click the right arrow button to apply the selected policies to the selected fabrics and switches.



Figure 9-64 Assigning Threshold Policy

9.7.6 Connection utilization

Attention: Connection utilization is only supported on the following managed objects: E_ports, F_ports, N_ports, and FCIP tunnels.

Performance connection utilization for switch ports provides the following features:

- Enables you to turn the utilization display on and off from the menu and tool bar.
- Displays moving dotted colored lines that originate from a port.
- Displays two lines in the topology (when turned on); one represents percentage utilization for transmit and the other percentage utilization for receive. The movement of the line determines if it is a transmit or a receive:
 - Receive (Rx): The line moves into a port.
 - Transmit (Tx): The line moves out of a port.
- Displays different colors to represent the percentage utilization range

Connections: Fabrics where performance data collections are not enabled display connections as thin black lines (normal display).

Legend	1	Legend		
Legend > 1	80 to 100 40 to 80 1 to 40 to 1 ollection Disabled (or) ending	Legend	 > 80 to 100 > 40 to 80[±]/₂ > 1 to 40[±]/₂ 0 to 1 Collection Disabled (or) Pending 	
Legend % change	Utilization	Color apply	Utilization cancel	

The Utilization Legend display and configuration is shown in Figure 9-65.

Figure 9-65 Utilization Legend display and configuration

The range is configurable:

- ▶ 0 to 1% Utilization = gray line.
- ▶ 1 to T1, where T1 is the first threshold, = dashed blue line.
- ► T1 to T2, where T2 is the second threshold, = dashed yellow line.
- ► T2 to 100% = dashed red line.

If Data Collection is Disabled for a Fabric, standard black connection lines are displayed.

To enable connection utilization select you can do one of the following actions:

- $\blacktriangleright \quad \text{Select Monitor} \rightarrow \text{Performance} \rightarrow \text{View Utilization}.$
- ► Press CTRL + U.
- ► Click the Utilization icon in the ToolBar (see Figure 9-66).

Figure 9-66 shows the "Marching Ants," the colored animated dashed line in the View Utilization view, which display utilization for FC and FCIP.



Figure 9-66 Displaying colored animated dashed line

9.8 Encryption configuration

You can configure encryption switches from DCFM. Go to the Encryption Center and select **Configure** \rightarrow **Encryption** as shown in Figure 9-67 to go to the Encryption Center.

View All - DCFM 10.4.2		
Server Edit View Discover	Configure Monitor Report	ts <u>T</u> ools <u>H</u> elp
	Element M <u>a</u> nager	Decimal 🔻
SAN View All	Firmware <u>M</u> anagement R <u>o</u> uting	
All Levels Name 🔻	Logical Switc <u>h</u> es	
E- 🔍 🔘 🍣 EDGE_IBNEDGE_IB		
IBM_B32_23 IBM_B32	Zoning	
🕀 🔮 📥 Host Gro	<u>N</u> ames	
🖸 🔮 🏷 Routed P	FCIP Tunnels	

Figure 9-67 Display the Encryption Center

The Encryption Center will start. From here you have the possibility to configure an encryption switch or an encryption blade (SAN32B-E4 or Encryption Blade). See Figure 9-68.

Secryption Center						_ 🗆 X
Encryption <u>V</u> iew <u>G</u> roup S <u>wi</u> tch	Engine Smart Card	<u>H</u> elp				
		Search Encrys	otion Devices		Encryption Alerts 🛆 1	<u>ا</u> ا
Encryption Devices (Group View) 🔺	Fabric	Switch / Engine Status	Switch Group Membership .	Target Status	HA Cluster	
ANO GROUP DEFINED> BM_SAN384B_27 ASlot 7 Engine	Back Bone_SAN3	Healthy Awaiting initialization	(1) Not a member	None configured		
E SAN32B-E4-1	Back Bone SAN3	Healthy	Group Leader			
		Online		1 OK	HAC1(SAN32B-E4-2 / Engine)	
E- 🧼 SAN32B-E4-2	Back Bone_SAN3	Healthy	Group Member			
- O- Engine		Online		None configured	HAC1(SAN32B-E4-1 / Engine)	

Figure 9-68 Encryption Center

You can perform the following configurations:

- Storage Encryption Configuration:
 - Launch the Configure Encryption dialog.
 - View switch, group, or engine properties.
 - View the Encryption Group Properties Security tab.
 - View encryption targets, hosts, and LUNs.
 - View LUN centric view.
 - View all re-key sessions.
 - Add/remove paths and edit LUN configuration on LUN centric view.
 - Rebalance encryption engines.
 - Decommission LUNs.
 - Edit smart card.

- Create a new encryption group or add a switch to an existing encryption group.
- Edit group engine properties (except for the Security tab).
- Add targets.
- Select encryption targets and LUNs to be encrypted or edit LUN encryption settings.
- Edit encryption target hosts configuration.
- Storage Encryption Key Operations:
 - Launch the Configure Encryption dialog.
 - View switch, group, or engine properties,
 - View the Encryption Group Properties Security tab.
 - View encryption targets, hosts, and LUNs.
 - Initiate manual LUN re-keying.
 - Enable and disable an encryption engine.
 - Zeroize an encryption engine.
 - Restore a master key.
 - Edit key vault credentials.
- Storage Encryption Security:
 - Launch the Configure Encryption dialog.
 - View switch, group, or engine properties.
 - View encryption targets, hosts, and LUNs.
 - Create a master key.
 - Backup a master key.
 - View and modify settings on the Encryption Group Properties Security tab (quorum size, authentication cards list and system card requirement).
 - Establish link keys for LKM key managers.

For more details, see *Implementing the IBM System Storage SAN32B-E4 Encryption Switch*, SG24-7922, available at this website:

http://www.redbooks.ibm.com/abstracts/sg247922.html?Open

9.9 User management

DCFM allows you to manage users and to start select **Server** \rightarrow **User** as shown in Figure 9-69.

Privilege: You must have the User Management privilege to perform this task. This user are System Administrator and Security Officer.

💱 View All - DCFM 🛙	10.4.2
Server Edit View	Discover Configure Monitor Reports Tools Help
Lisers Active Sessions	🔄 💠 🔳 🕌 🗋 Decimal 🕶 Name 💌
Server Properties	
Options	
Exit	Name V
🕞 😌 🔵 💩 EDGE	_IBM_B32 EDGE_IBM_B32
🕒 🧼 IBM_B32_	_23 IBM_B32_23

Figure 9-69 Display user management

You can now manage the different users. Figure 9-70 shows the possible actions:

ID Description E-mail Address Administrator Administrator Addinistrator Administrator dcfmuser dcfmuser dcfmclient DCFMCL Jack FICON Add Edit Roles System Administrator System Administrator Operator System Administrator Security Administrator Operator Security Officer Host Administrator Host Administrator System Administrator Ecryption manger System Administrator System Administrator Security Administrator System Administrator System Administrator System Administrator System Administrator System Administrator Soperation System Administrator Soperation System Administrator Soperation System Administrator Soperation System Administrator	Users				Find >	Resource Groups	_
Security Officer Security Officer Operator Operator Security Officer Secur	ID Administrator dcfmclient Jack Roles System Admin Sone Administ Coperator Security Admi Zone Administ Coperator	Description Administrator dcfmuser DCFMCL FICON t t Remove	E-mail Notific	E-mail Address		All Fabrics All Fabrics System Administrator Control Administrator Con	

Figure 9-70 Server User management

- User definitions:
 - Add new user
 - Delete existing user
 - Edit a user definition
- ► Resource Groups definitions:
 - Add new resource group
 - Delete existing resource group
 - Edit the resource group
- Roles definition:
 - Add new role
 - Delete an existing role
 - Edit a role
- Email event notification setup

9.10 DCFM Server Management Console

The DCFM Server Management Console (SMC) is an automatically installed, stand-alone application for managing the management application server.

From Windows you can launch the management console from the Start \rightarrow All Programs menu and then select the DCFM folder. Select the Server Management Console.

The SMC panel has six tabs, as shown in Figure 9-71.

You can perform the following tasks using the SMC:

- From the Services tab, you can start, stop, and restart services on the server.
- From the Ports tab, you can change the management application server or Web Server port number.
- From the Authentication tab, you can configure an authentication server (LDAP or Radius server), and establish authentication policies.
- From the Database tab, you can restore server application data.
- From the Technical Support Information tab, you can collect information for technical support.
- The HCM Upgrade tab enables you to upgrade the management application to include a new version of HCM.

	Redulori restore rec	annoar Sapport information	Them opgrade	
DCFM Services				
Name	Process Name	Status	Start Time	
)atabase Server	dbsrv10.exe	Started	Oct 27, 2010 2:31:41 PM PDT	Start
IMOM Server	cimomsvc.exe	Started	Oct 27, 2010 2:32:13 PM PDT	
Service Location Protocol	slpd.exe	Started	Not Available	Stop
Neb Server	dcfmsrv.exe	Started	Oct 27, 2010 2:32:07 PM PDT	Ohren Oliviold
Built in FTP Server	dcfmsrv.exe	Started	Oct 27, 2010 2:32:07 PM PDT	Stop CIMOM
/lain Server	dcfmsrv.exe	Started	Oct 27, 2010 2:32:07 PM PDT	Refresh
Configure SMI Agent				
Configure SMI Agent				

Figure 9-71 DCFM Server Management Console

9.10.1 Changing server port numbers

Use the Ports tab of the Server Management Console to change the management application server and Web Server port numbers (see Figure 9-72). The default Web Server port number is 80. The management application server default port number is 24600.

Server restart: The server automatically restarts if you change the server port number. You must manually restart the server if you change only the Web Server port number.

DCFM Se	rver Cor	nsole				
ervices	Ports	Authentication	Restore	Technical Support Information	HCM Upgrade	
hange the lease mail rofession DCFM Serv	e DCFM picke sure the all Edition	orts by entering the e new port number starting from DCFM 24600 Apply 80 Apply	e new port n rs do not fail t server port	umbers and clicking on the Apply In the range of 16 consecutive p	button. Changes w	vill be effective only after DCFM Server re Edition and 13 consecutive ports for

Figure 9-72 DCFM Server Management Console Ports

9.10.2 Restoring the database

First, configure the backup options for the DCFM server database as well as the path to the backup files. Go to the DCFM main menu under **SAN** \rightarrow **Options**. The Options dialog box will display as shown in Figure 9-73.

Options					
Category Backup Display End Node Display Ethernet Event Event Storage Flyovers Look and Feel Names Security Misc Client Export Port Discovery Etherce	This option allows you to confi periodically copies and stores directory is relative to the serv backup to the network. If you on network credentials as well. Enable Backup Include FTP Root Director Include Technical Supp Include Upload Failure D Previous backup attempt h Next Backup Start Time	gure backup settings. Backup is a application files to an output direct er and must use a network share use a network path as the output ory ort Directory eata capture Directory as failed. It will be retried at the r 2 — Hours 34 — Minu	kup settings. Backup is a service process that In files to an output directory. The output ust use a network share format to support work path as the output directory, you must add ory ure Directory . It will be retried at the next scheduled time. Hours 34 \bigcirc Minutes		
IP Configuration Memory Allocation	Backup Interval	24 Hours 💌	Backup Now		
Support Mode	Network Drive Credentials Domain Workgroup User Name Password		Browse		
		OK Cancel	Apply Help		

Figure 9-73 Backup Options dialog box

From the dialog box, you can choose **Backup** on the left pane. Set the Backup Interval, Output Directory, and Backup Now options. When a backup is available you can restore this backup from DCFM Server Management Console.

Go to the Restore Database option in DCFM Server Management Console. To perform this operation, you must know the path to the backup files (see rounded rectangle in Figure 9-74).

STORE Server Console					
Services Ports Authentication	Restore	Technical Suppor	t Information	HCM Upgrade	
Restore function will replace the applic	ation data fil	es used by the DCF	M server		
Restore Path			Browse	Restore	
					Close Help

Figure 9-74 DCFM Server Management Console - Restore

Insert the path where the backup files are stored and then click **Restore** to start the process of restoring the DCFM Server Database.

9.10.3 Configuring authentication

You can configure the method that the DCFM server will use for authentication as shown in Figure 9-75.

STDCFM Server Console			
Services Ports Authentication R	Restore Technical Support Information	HCM Upgrade	
This DCFM server currently uses LOCAL a	as the primary authentication, and NONE as	the secondary Authentication	
Primary Authentication Local Databas Local Databas Switch Windows Don	se Secondary Authentica se nain	ation None	
Authentication Audit Trail Display			Test Apply
			Close Help

Figure 9-75 DCFM Server Console Authentication

All responses to authentication requests coming from clients are logged to an audit trail log file.

This file is automatically backed up on the first day of every month.

Select the **Authentication** tab and click **Display** next to the Authentication Audit Trail. The Login dialog box displays. Enter your username and password in the appropriate fields and click **OK**.

The Authentication Audit Trail log displays as in Figure 9-76.

The audit trail shows user names that have attempted to log in to the management application, and changes to user authentication.

DCFM Server Console	5	Authentication Au	udit Trial					
Services Ports Aut	hentication	Client To Server Au	thentication	Authenticatio	n Settings Changes			
This DCFM server currently	y uses LOC	glient IP	Authentica	ation Method	User Id	Login Time	Authentication Statu	n Status
Primary Authentication	Local Dat	10.64.210.103	local/none		administrator	Thu Jul 02 05:44:47 P	Success	· · · · ·
1 million () r ioc		10.64.210.106	local/none		Administrator	Thu Jul 02 04:37:35 P	Failure	
		10.64.210.106	local/none		Administrator	Thu Jul 02 04:51:13 P	Success	
		10.64.210.106	local/none		Administrator	Thu Jul 02 13:31:56 P	Success	
		10.64.210.106	local/none		Administrator	Thu Jul 02 13:32:02 P	Success	
								Close
Authentication Audit Trail	Display					Test	Apply	
						Close	Help	

Figure 9-76 Authentication Audit Trail

9.10.4 Capturing technical support information

The Technical Support Information tab of the SMC allows you to capture technical support information, such as server data for all services. This information is saved in a zip file in a location that you specify (see Figure 9-77).

If you do not specify an output path, the management application automatically saves the data to the <Install DIR>/support directory.

DCFM Server Console	
Services Ports Authentication Restore Technical Support Information HCM Upgrade	
Technical Support Information collects the logs and configuration files for all the switches in the discovered fabrics.	
Output Path C:/Supportshow Browse Capture	
	Close Help

Figure 9-77 Technical Support Information

It allows users to capture data collection of the DFCM server (Figure 9-78).



Figure 9-78 Technical Support - Capturing Support Show

9.10.5 Gathering switch information for support

To gather switch information for support (it will activate the supportsave command), right-click the switch, then choose from DCFM main menu, Technical Support \rightarrow Switch / Host SupportSave (see Figure 9-79).



Figure 9-79 Collecting data for switch

The Technical SupportSave dialog box displays as shown in Figure 9-80. Select the switches you want to collect data for in the Available Core Switches table and click the right arrow to move them to the Selected Switches table.

C	telese linets								4	elected Switc	hes and Hosts		
Svvi	Iches Hosts									Address	Name	1040.01	Type
Avai	able Switches			- 1					1	0 18 235 54	Brocade BES	10:00:00:05	Switch
All Le	Available Switches	Name	Device Type	Tag	Serial #	VWW	IP Address	Dor					
24	<u>∽</u> ⊴ 2568_M48	256B											
E 1	Back Bone_SAN3848	B Dack B	Cusiliala		0.OE0	10.	40.49.22		÷.				
		D5000	Switch	1	AGEU	10:	10.18.22		1				
	BS000_76	BS000	Switch	о о	AGFU	10:	10.10.22						
	BM_2498_R06	IBM_24	Switch	U	ASSU	10:	10.18.22						
	BM_SAN384B_27	IBM_S	Switch	1	ANNU	. 10:	10.18.22						
	SAN32B-E4-1	SAN32	Switch	3	ALVU	. 10:	10.18.23						
	SAN32B-E4-2	SAN32	Switch	3	ALV0	. 10:	10.18.23						
	switch	switch	Switch	U)	AVS	10:	10.18.22						
	🛡 🔾 🥪 EDGE_IBM_B32	EDGE_I											
	- 🗢 IBM_B32_23	IBM_B	Switch	0	LX03	10:	10.18.22		1				
									1				
		•	denedenedenet									10100101	

Figure 9-80 Technical Support Data

Note the location where the **supportsave** data is being written to, at the bottom of the window. Click **OK** to start the collection. A message box will display as shown in Figure 9-81.



Figure 9-81 DCFM supportsave message box

9.10.6 Viewing technical support information

To view the technical support information, select **Monitor** \rightarrow **Technical Support** \rightarrow **View Repository**.

The **supportSave** repository will be displayed as shown in Figure 9-82. From here you can ftp, email, delete, or view the available **supportsave**. For email or ftp, you have to configure this first.

Repository Switches	Hosts			
Available Supp	ort and Failur	re Data Capture Files		
File Name A Supportinfo Supportinfo	Size(MB) 9.32 6.76	Last Modified Thu Nov 04 Tue Oct 191		E-mail FTP View
				Delete

Figure 9-82 Supportsave repository

9.10.7 HMC upgrade

As you see in Figure 9-83 you can also update the HMC from the DCFM server Console. Select the location where the update is stored and click **Upgrade**.

DCFM Sei	rver Con	sole					
Services	Ports	Authentication	Restore	Technical Support Info	ormation H	CM Upgrade	
Use this tab	to upgra	de to a newly inst	alled version	of HCM.			
HCM Install:	ation Fold	er			Browse	Upgrade	
				,			
							Close Help

Figure 9-83 HMC upgrade

10

Host Connectivity Manager

The Host Connectivity Manager (HCM) is a management software application for configuring, monitoring, and troubleshooting Brocade HBAs and Converged Network Adapters (CNAs) in a storage area network (SAN) environment.

The management software has two components:

- ► The agent, which runs on the host
- The management console, which is the graphical user interface client used to manage the HBA or CNA

You can manage the software on the host or remotely from another host. The communication between the management console and the agent is managed using Java Script Object Notation - Remote Procedure Call (JSON-RPC) over https.

Reference: All HCM, utility, SMI-S Provider, boot software, and driver installation packages, as well as the Driver Update Disk (DUD), are described in the *Brocade Adapters Installation and Reference Manual*, 53-1001254-05, available at this website:

http://www.brocade.com/services-support/drivers-downloads/HBA/index.
page

10.1 HCM features

In this section we discuss software features and the tree node menus.

10.1.1 Software features

Common HBA and CNA management software features include these:

- Discovery using the agent software running on the servers attached to the SAN, which enables you to contact the devices in your SAN
- Configuration management, which enables you to configure local and remote systems. With HCM you can configure the following items:
 - Local host
 - Brocade 4 Gbps and 8 Gbps HBAs
 - HBA ports (including logical ports, base ports, remote ports, and virtual ports)
 - Brocade 10 Gbps single-port and 10 Gbps dual-port converged network adapters (CNAs)
 - CEE ports
 - FCoE ports (CNA only)
 - Ethernet ports (CNA only)
- Diagnostics, which enable you to test the adapters and the devices to which they are connected:
 - Link status of each adapter and its attached devices
 - Loopback test, which is external to the adapter, to evaluate the ports (transmit and receive transceivers) and the error rate on the adapter
 - Read/write buffer test, which tests the link between the adapter and its devices
 - FC protocol tests, including echo, ping, and traceroute
 - Monitoring, which provides statistics for the SAN components listed in Table 10-1.
 - Security, which enables you to specify a CHAP secret and configure authentication parameters
 - Event notifications, which provide asynchronous notification of various conditions and problems through a user-defined event filter
10.1.2 Tree node pop-up menus

You can use the HCM GUI main menu or the Command Line Utility to configure, monitor, and troubleshoot your SAN components. The instructions for using each feature are detailed in subsequent sections of this chapter. For each SAN component, you can optionally right-click its icon and a pop-up menu displays, showing the features available for that component (see Table 10-1).

The HCM GUI consists of three layers, and the features display differently depending on the configuration. There are three possible configuration scenarios, as follows:

- Both the storage driver and the link layer driver are installed.
- Only the storage driver is installed.
- Only the link layer driver is installed.

Whether the FCoE Port node or the Ethernet node are presented in the tree depends on the drivers that are installed.

SAN component	Pop-up menu feature
Host	Refresh All Start Polling Upload Boot Code Image Change Agent Password Configure Names Basic Port Configuration Persistent Binding Statistics \rightarrow Teaming Statistics Authentication Teaming Support Save Restore VLAN and Team Tree \rightarrow Copy Search Collapse All Expand All
Brocade HBA 4 Gbps or 8 Gbps	Refresh Define Name Upload Boot Code Image Basic Port Configuration Persistent Binding Port Statistics Diagnostics Authentication Enable Adapter Tree \rightarrow Copy Search Collapse All Expand All

Table 10-1 HCM tree pop-up menus

SAN component	Pop-up menu feature
HBA Port	$\begin{array}{l} \mbox{Refresh} \\ \mbox{Define Name} \\ \mbox{Port Configuration} \rightarrow \mbox{Basic} \mid \mbox{Advanced} \\ \mbox{Persistent Binding} \\ \mbox{Virtual Port} \rightarrow \mbox{Create} \mid \mbox{Delete} \\ \mbox{Statistics} \rightarrow \mbox{Port statistics} \mid \mbox{FCP IM Module statistics} \mid \mbox{Fabric Statistics} \mid \mbox{Doc Statistics} \mid \mbox{Doc Statistics} \\ \mbox{Diagnostics} \\ \mbox{FC-SP} \rightarrow \mbox{Authentication} \mid \mbox{Authentication Statistics} \\ \mbox{Enable Port} \\ \mbox{Beacon} \rightarrow \mbox{Port} \mid \mbox{Link} \\ \mbox{Tree} \rightarrow \mbox{Copy} \mid \mbox{Search} \mid \mbox{Collapse All} \mid \mbox{Expand All} \\ \end{array}$
Converged Network Adapter (CNA), 10 Gbps	Refresh Define Name Upload Boot Code Image Basic Port Configuration Persistent Binding Port Statistics Diagnostics Authentication Enable Adapter Tree \rightarrow Copy Search Collapse All Expand All
FCoE Port	Refresh Persistent Binding Virtual Port \rightarrow Create Delete Statistics \rightarrow Fabric IOC FCOE FC-SP \rightarrow Authentication Authentication Statistics Enable Port Tree \rightarrow Copy Search Collapse All Expand All
Ethernet Port	Refresh Statistics \rightarrow Eth Eth IOC VLAN VLAN Configuration Tree \rightarrow Copy Search Collapse All Expand All

10.2 Getting started with HCM software

In the topics that follow, we show some of the key features of HCM.

10.2.1 HCM software launch

The following procedures describe how to launch the HCM application in Windows and Linux.

Launching the application on Windows platforms

After installing the HCM software, locate Brocade HCM on the Windows platform by selecting Start \rightarrow Programs \rightarrow Brocade Adapter Software \rightarrow Host Connectivity Manager or click the desktop Host connectivity manager icon to launch the application.

The Login Dialog box (Figure 10-1) displays when the HCM software is first launched.

🗣 Host Conn	ectivity Manager	×
Userld	Administrator	
Password		
	Remember password	
	Skip Login Dialog	
	Login Cancel Help	

Figure 10-1 HCM Login Dialog box

The factory default user ID and password are *Administrator* and *password*. After you log in for the first time, change the default password to a new one using the HCM GUI.

Launching the application on Linux platforms

After installing the HCM software, locate Brocade HCM on the Linux platform:

- If using a GNOME shell, double-click the Host connectivity manager icon to launch the application.
- If using a KDE shell, single-click the Host connectivity manager icon to launch the application.

Or start the application from the GUI console terminal command prompt using the following commands:

- [root@dpe2950228036 ~]# cd /opt/brocade/adapter/client/
- [root@dpe2950228036 client]# ./hcm.sh

Attention: This command will not work from the SSH terminal, it is required to be executed from the GUI console connected locally or, for example, by VNC viewer.

Launching the application from web browser

After installing the HCM software in the server with the Brocade HBA/CNA, Host Connectivity Manager can also be connected using the web browser by entering the URL:

https://server-host:34568/index.html

Where:

- server-host is the hostname or IP address of the server with the Brocade HBA/CNA adapter with the driver installed and the HCM agent running.
- ► 34568 is the TCP/IP port through which the HCM agent communicates with the HCM server.

10.2.2 Command line utility

The HCM has a command line utility known as the Brocade CLI Utility (BCU). This utility can be started from the shortcut in the Desktop or from the command line prompt (Example 10-1).

Example 10-1 BCU - Brocade CLI utility

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu --version
Brocade CLI utility
Version:FCHBA2.2.0.2
```

10.2.3 HCM configuration data

The HCM configuration data files hold values defined by user for HCM. The default data folder depends on the platform:

Windows:

C:\Users\Administrator\HCM\data (<user home dir>\hcm\data)

Linux:

/root/hcm/data (<user home dir>/hcm/data)

10.2.4 Remembering the password

The Login dialog has a check box to remember the password. If you check the **Remember password** check box, you do not need to enter the password the next time you launch the application.

10.2.5 Skipping login

Take one of the following actions to manage the Skip Login feature:

► Enable *Skip Login* by checking the **Skip Login Dialog** check box:

If the Skip Login check box is checked, it automatically disables the **Remember password** option.

► Disable Skip Login by setting *hba-application.skip-login=false* in the file: <*user home Dir* >*HCM/data/HBAApplication.properties*

Select the **Skip Login** check box if you do not want the Login dialog box to display the next time the application is started.

10.2.6 Changing an HCM application password

You can change the default password of the application to a different password using the Change HCM Password dialog.

Note the following considerations when you change a password:

- You must validate your user identity by supplying your old password before you can change to a new password. The new password must be different than the old password.
- ► The password can begin with an alphabetic, numeric, or special character.
- The default minimum and maximum length of the password is 8 and 64 characters. You can configure the password length in the file:

<user home Dir >/HCM/data/HBAApplication.properties

```
# min chars for the application password
password_min=8
#max chars for the application password
password max=64
```

► The password is encrypted and stored in the *noitacitnehtua.properties* file.

Follow these steps:

 From the Host Connectivity Manager, select Configure → Change Password → Change Password for HCM User; the Change HCM Password dialog box displays (Figure 10-2).

🗣 Host Conn	ectivity Manager	X
Userid	Administrator]
Password]
	Remember password	
	🗌 Skip Login Dialog	
	Login <u>C</u> ancel <u>H</u> elp	

Figure 10-2 Change HCM Password dialog box

- 2. Type the current password for the account. The default user name and password are *Administrator* and *password*.
- 3. Type the old password for the account.
- 4. Type the new password of the account.

The new password must have at least one character different from the old password.

- 5. Retype the new password in the Confirm New password field.
- 6. Click OK.

Case: Both the user name and passwords are case-sensitive.

10.2.7 Changing an HCM agent password

You can change the default password of the agent to a different password using the **Change HCM Agent Password** dialog.

Note the following considerations when you change a password:

You must validate your user identity by supplying your old password before you can change to a new password. The new password must be different than the old password. Follow these steps:

 From the Host Connectivity Manager, click Configure → Change Password → Change Agent Password; the Change HCM Agent Password dialog box displays (Figure 10-3).

Change Agent Password			
Host Name	localhost		
User Name	admin		
Old password			
New password			
Confirm New password			
	OK Cancel Help		

Figure 10-3 Change HCM Agent password dialog box

- 2. Type the current password for the account. The default user name and password are *admin* and *password*.
- 3. Type the new password of the account.

The new password must have at least one character different from the old password.

- 4. Retype the new password in the Confirm New password field.
- 5. Click **OK**.

Case: Both the user name and passwords are case-sensitive.

10.2.8 Resetting a password or restoring a factory default password

After a successful installation, copy this file to your personal folder:

<user home Dir> /HCM/data/noitacitnehtua.properties

You do this so that in case the password is lost, you can overwrite the noitacitnehtua.properties file in the data folder with the local copy. This restores the factory default user name (*Administrator*) and password (*password*).

10.2.9 Backing up data after an uninstall

If you uninstall the Brocade HCM software, you are prompted to back up the application configuration data that was created during installation.

The following application configuration files are backed up in the data directory:

- HBAApplication.properties
- SetupDiscovery.properties
- HbaAliasdb.properties
- ► log4j.xml
- noitacitnehtua.properties

To restore the backed-up configuration data when you re-install the HCM, you must manually overwrite the new data directory contents with the backed-up data. This restores your previous settings. The restore can be also done by using HCM as described in 10.2.10, "Backing up HCM data using HCM".

10.2.10 Backing up HCM data using HCM

To back up HCM data whenever required using HCM, select the **Host** and then click **Tools** \rightarrow **Backup HCM Data**, the Backup HCM Data window displays (Figure 10-4).

🍨 Backup HCM Data		×
This dialog allows you to o	create backup of data and configuratio	n files.
Output Directory:	Administrator/brocade/HCM Local	Browse Start Backup
		<u>C</u> lose <u>H</u> elp

Figure 10-4 HCM Data backup

We need to enter a Backup directory and then click **Start Backup**, which will complete and indicate its success with a Backup completion message (Figure 10-5).

HCM Message 🛛 🗙		
٩	Backup data successfully completed.	
	ок	
Figure	10-5 Backup comple	tion

Figure 10-5 Backup completion

Click **OK** and close the Backup HCM Data window, and the required config data can be now seen in the backup directory mentioned, which will be used later when a restore is required.

10.2.11 Restoring HCM data using HCM

Restoring HCM data is performed from the Host Connectivity Manager by selecting the host and then click **Tool** \rightarrow **Restore** \rightarrow **HCM Data**. The **HCM Data** window displays (Figure 10-6).

🍨 HCM Data	×
HCM 2.2.0.2 configuration backup data take available	n on Wed Oct 20 11:46:09 PDT 2010 is
Restore from previous backup data at	Users\Administrator\brocade\HCM Local
◯ Restore default data	
Start Restore	
	<u>C</u> lose <u>H</u> elp

Figure 10-6 HCM Data restore

We need to enter the backup directory and click Start Restore, which will complete the restore, and success will be indicated with the completion message (Figure 10-7).



Figure 10-7 HCM Data restore completion

HCM has to be restarted to use the restored data config.

10.2.12 HCM main window

From the Host Connectivity Manager main window (Figure 10-8), you can manage all the adapters installed in this computer. Alternatively, you can manage adapters installed in remote computers, if the computers are networked. Only one host can be managed at a time; multiple host management is not supported.

For instructions on how to install both the driver and GUI, the driver only, or the GUI only, see the *Brocade Adapters Installation and Reference Manual*, 53-1001254-05, available at this website:

http://www.brocade.com/services-support/drivers-downloads/HBA/index.pag
e

File View Discovery Configure Monitor To							i i i i
Lie Aless Discovery Configure Monitor To	ol <u>H</u> elp	Menu Bar					
🗈 🌷 localhost	Properties Adapters						
ALX0417D084	Host Information						71
E- I0:00:00:05:1E:0C:1C:CC	Host Name	V/IN-303	3X4IGB0R8				
- 👰 10:00:05:1E:0C:1C:CC	Operating System Typ	e Microsof	ft Windows Server 20	08,32-bit.			
ID:00:00:05:1E:0C:1C:CD	Operating System Ve	rsion Service	Pack 2 (build 6002)				- 11
- 10:00:00:05:1E:0C:1C:CD	Agent Release Versio	n FCHBA2	2.2.0.2				
AXU0428E003 Ø 00:05:1E:AF:08:A0 Ø 00:05:1E:AF:08:A2 Ø 00:05:1E:AF:08:A1 Ø 10:00:00:05:1E:AF:08:A1 Ø 10:00:00:05:1E:AF:08:A1		Conte	ext View				
00:05:1E:AF:08:A3							
Device tree Window							
Master Log Application Log							
Master Ion Filter None				1	Clear filter	Refrech	-1
master log Tillet Indrie		Log View			Ciedi Tillei	Nellean	2
Sr No Severity		WWWN/MAC		Category			_
1 V INFO		10:00:00:05:1E:0C:1	C:CC	IOC			
2 INFO		10:00:00:05:1E:0C:1	C:CC	LPORT			
		10:00:00:05:1E:0C:10	0.00	PORT			
5 D INFO		10:00:00:05:1E:0C:10	0.00	LEORT			
6 A MINOR	2	10:00:00:05:1E:0C:1	0.00	PORT			-
•		11111					
System Information	User: admin	Agent: localhost	Port: 34568 Last 0	Jpdated: Mo	n Oct 18 13:29	02 PDT 20	010

Figure 10-8 Host Connectivity Manager main window

10.2.13 HCM product icons

On the left side of the Host Connectivity Manager, there is a navigation tree for representing the managed host with adapters and ports. Each tree node has an icon to represent the type of node. If the operational status is offline, link-down, or error, a small red diamond displays on the upper right corner of the icon.

Table 10-2 shows the product icons that represent the components that HCM manages.

ltem	lcon	ltem	lcon
Host (Agent UP)		Remote Port (Initiator) online	هٰ
Host (Agent Down)		Remote Port (Initiator) offline	3
HBA Online	¢.	Remote Port (Target) online	<mark>.</mark> 1
HBA Offline	*	Remote Port (Target) offline	ţţ
CNA Online	CNA	LUN	Ŧ
CNA Offline	CNA	Ethernet Port	
Port (with SFP) link up	Ø	Base Port (link up)	ø

Table 10-2 HCM product icons

Item	lcon	Item	lcon
Port (with SFP) link down		Base Port (link down)	
Port (without SFP) link up	Ø	Virtual Port (online)	(20
Port (without SFP) link down		Virtual Port (offline)	2
FCoE Port			

10.2.14 Discovery

Discovery enables you to contact the adapters present in a specified host in your SAN. The setup discovery profile is saved in the SetupDiscovery.properties file to remember the history of each host and related attributes of discovered hosts.

When you log in to HCM, the specified host is automatically contacted (discovered) and displayed on the navigation tree. By default, the local host is automatically contacted (discovered) and displayed on the navigation tree. When you configure and turn on discovery, the application discovers Brocade adapters in that host, connected to the SAN.

Discovery: The HCM application enables you to discover Brocade adapters, ports, virtual ports, remote ports, and LUNs using out-of-band discovery only.

10.2.15 Setting up out-of-band discovery for an adapter

When performing out-of-band discovery, you are managing the adapter remotely. The application connects to the agent running on the host server over the IP network and product information is copied back from the Brocade adapter to the server. If you do not configure the application to directly discover the devices, the connections and attached devices might not display correctly.

 From the Host Connectivity Manager, click **Discovery** → **Setup**. The Setup for Discovery dialog box displays (Figure 10-9).

Setup for Host Discovery	×
Host Name	localhost 🔹
Port #	34568
User ID	admin
Password	•••••
Remember Host	r
Polling Frequency (seconds)	60
Keep Polling	r
<u>_</u>	Cancel Help

Figure 10-9 Setup for Discovery dialog box

2. From the *Host Name* list, select the host name from where you will discover the adapter.

For the first time, the Host Name list will contain only the Local host. You must specify the Hostname or the IP address for discovering the remote servers. Only previously-discovered servers are available in the Host Name list.

- 3. Type the port number in the *Port Number* text box. The default is 34568.
- 4. Type in the user ID and password that will authenticate the SAN product with the agent. The default user ID and password are *admin/password*.

Change the agent password on the host for security reasons.

Tip: Click the **Remember Host** check box if you do not want to type it in each time you set up discovery.

5. In the *Polling Frequency (Seconds)* text box, specify the value for how frequently the application has to poll for newly discovered devices.

All parameters related to the adapters that are installed in that server are refreshed each time the poll occurs.

Polling: If the Keep Polling check box is checked, polling occurs after the specified polling interval. If the check box is not checked, polling stops.

6. Click OK.

10.2.16 Logging off HCM

End the HCM session using one of the following methods:

- ► From the Host Connectivity Manager, click File → Exit.
- ► Click the X in the upper-right corner of the HCM window to close it.

10.3 Host configuration

In the topics that follow we discuss host configuration aspects.

10.3.1 Host security authentication

Use the HCM GUI or the command line utility to display the authentication settings and status. There are five well-known DH groups; however, only DH-CHAP group 0, called NULL DH, is supported in this release.

Solaris: Security authentication is not supported on Solaris platforms.

10.3.2 Configuring security authentication using the GUI

You can access the Fibre Channel Security Protocol Configuration dialog box by selecting the Host, an HBA, or an HBA port from the device tree.

Solaris: FC-SP is not available for Solaris platforms.

- 1. Select the appropriate device based on how you want to configure security authentication:
 - From the host level, select the host from the device tree.
 - From the HBA level, select the adapter from the device tree.
 - From an HBA port, select a port from the device tree.
- Select Configure → FC-SP from the main menu, or perform the appropriate following step to open the security authentication dialog box:
 - From the host level, right-click the host and select FC-SP from the list.

The Fibre Channel Security Protocol Configuration (host level) dialog box displays

 From the adapter level, right-click the adapter and select FC-SP from the list. The Fibre Channel Security Protocol Configuration (adapter level) dialog box displays. This dialog box is identical to the Fibre Channel Security Protocol Configuration (host level) dialog box.

 From the adapter port level, right click a port and select FC-SP → Authentication from the list. The port level Fibre Channel Security Protocol Configuration dialog box displays, as shown in Figure 10-10.

🍨 Fiber Channel	Security Protocol Configuration	×
Enable Authenti	cation	
CHAP Secret	•••••	
Retype Secret	•••••	
Algorithm	MD5 💌	
Group	DHNULL	
	QK <u>Cancel Apply H</u> elp	

Figure 10-10 Port level Fibre Channel Security Protocol Configuration dialog box

- 3. Configure the following parameters on the Port Security Authentication tab:
 - Select the Enable Authentication check box to enable or disable the authentication policy.

If authentication is enabled, the port attempts to negotiate with the switch. If the switch does not participate in the authentication process, the port skips the authentication process.

b. Type and retype the secret.

The maximum length of the secret is 63 bytes. The default secret for each interface is its port world wide name (PWWN) without the colons; for example, 0102030405060708.

- c. Select the algorithm type from the list:
 - MD5: A hashing algorithm that verifies a message's integrity using Message Digest version 5.
 - SHA1: A secure hashing algorithm that computes a 160-bit message digest for a data file that is provided as input.
 - MD5SH1: Similar to the MD5 hashing algorithm, but used for DH-CHAP authentication
 - SHA1MD5: Similar to the SHA1 hashing algorithm, but used for DH-CHAP authentication

- d. Select DHNULL as the group value (this is the only group that is supported).
- 4. Click **Apply** to apply the changes.
- 5. Click **OK** to save the changes and close the dialog box.

10.3.3 Configuring security authentication using the CLI

The following commands are used to configure and display the security authentication of ports.

1. Check the port state of the Brocade adapter as shown in Example 10-2.

Example 10-2 Port state check

C:\Pro	C:\Program Files\BROCADE\Adapter\driver\util>bcu portlist										
Port#	Туре	PWWN/MAC	FC Addr/ Eth dev	Media	State	Spd					
1/0 1/1 2/0 2/1	fc fc cee fcoe eth cee fcoe eth	10:00:00:05:1e:0c:1c:cc 10:00:00:05:1e:0c:1c:cd 00:05:1e:af:08:a0 10:00:00:05:1e:af:08:a0 00:05:1e:af:08:a2 00:05:1e:af:08:a1 10:00:00:05:1e:af:08:a1 00:05:1e:af:08:a3	10c900 10dd00 051701 LAC# 5 051401 LAC# 6	SW SW SW	Linkup Linkup CEE Linkup Linkup CEE Linkup Linkup Linkup	8G 8G 10G 10G					

2. Set the authentication algorithm for the port as shown in Example 10-3 where we set the algorithm for port 1/0.

Example 10-3 Authentication algorithm for Brocade adapter port

C:\Program Files\BROCADE\Adapter\driver\util>bcu auth --algo 1/0 md5 Authentication algorithm set

3. Enable the authentication secret as shown in Example 10-4 for port 1/0.

Example 10-4 Set the auth secret

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu auth --secret 1/0
"sec2ibmsw"
Successfully set the auth secret
```

4. Display the authentication settings. Example 10-5 displays the Auth policy state for port 1/0.

Example 10-5 Authentication state for HBA port 1/0

C:\Program Files\BROCADE\Adapter\driver\util>bcu authshow 1/0									
Port	Port Status	Hash Type	Group Type	Auth Status					
1/0	Linkup	MD5	DH-NULL	uninit					

10.3.4 Buffer credits

Buffer-to-buffer credit flow control is implemented to limit the amount of data a port sends, based on the number and size of the frames sent from that port. This scheme allows Fibre Channel to be self-throttling, thereby allowing it to establish a reliable connection without the need to accommodate dropped frames due to congestion. Buffer credit limits between each device and the fabric are communicated at the time of fabric login. One buffer credit allows a device to send one frame of data (typically 1 or 2 KB). Buffer credits cannot be configured on an adapter.

The default BB Credit is 1. The baseline for the calculation is one credit per kilometer at 2 Gbps. This yields the following values for 10 km:

- 5 credits per port at 1 Gbps
- 10 credits per port at 2 Gbps
- 20 credits per port at 4 Gbps
- 40 credits per port at 8 Gbps

See *Implementing an IBM/Brocade SAN with 8 Gbps Directors and Switches*, SG24-6116 for more information about buffer credits.

10.3.5 Basic port configuration

For each port, you can configure the following parameters using the Basic Port Configuration dialog box, the Command line Utility or both. Table 10-3 lists the features and configuration options.

Port configuration parameter	Configurable using the GUI	Configurable using the CLI	For more Information			
Port logging level ¹	Yes	Yes	10.3.7, "Port logging level" on page 423			
Configure speed (HBA only)	Yes	Yes	10.3.8, "Port speed" on page 426			
Frame data field size	Yes	Yes	10.3.9, "Frame data field size" on page 428			
Persistent Binding Note: The persistent binding option is available on Windows platforms only.	Yes	Yes	10.3.10, "Persistent binding" on page 428			
QoS (HBA only)	Yes	Yes	10.3.11, "QoS (HBA only)" on page 430			
Path Time Out	Yes	Yes	10.3.12, "Path Time Out" on page 433			
Target Rate Limiting	Yes	Yes	10.3.13, "Target rate limiting" on page 435			
¹ If an Ethernet por additional feature	t is selected, the Ba e called "Eth Loggi	asic Port Configura ng Level."	tion dialog displays an			

Table 10-3 Basic port configuration options

10.3.6 Opening the Basic Port Configuration dialog box

There are slight changes in HCM's basic port configuration dialog, depending on the operating system. You can access the Basic Port Configuration dialog box by selecting the Host, an HBA, an HBA port, a CNA, or an FCoE port from the device tree.

Follow these steps:

- 1. Select a device from the device tree.
- Select Configure → Basic Port Configuration from the main menu. The Basic Port Configuration dialog box displays (Figure 10-11).

Basic Port Config	uration							X
ALXU417DU64	Serial # ALX0417D	084					Hardware P	ath 08:00
	Ports							
	Port # WWN / MAC		Name Port Type	Configured State	Operating State	Configured Speed	Operating Speed	Frame Data Fie
	0 10:00:00:05:1E	:0C:1C:CC	NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
	1 10:00:00:05:1E	:0C:1C:CD	NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
						888888		•
	Port Parameters	Boot-over-	SAN					
							-	Apply
	Port VW/N / MAC	10:00:00:0	05:1E:0C:1C:CC	Port #	0			Apply to All
	Port Enable	Ľ		Port loggi	ng level Log	Warning 🔹 🔻	-	
	Configured Speed	Auto Nego	otiate	 Frame dat 	a field size 211	2 💌		
	Persistent Binding	r		QoS enak	le 🗌			
	MPIO mode enable			Target rat	e limiting 🗌			
	Path time out	30		Default ra	te limit 1 G	b/s 🔻		
							OK <u>C</u> ancel	Help

Figure 10-11 Basic Port Configuration dialog box - Windows, Linux, and VmWare

10.3.7 Port logging level

The number of messages logged by the host depends on the predetermined logging level. Although the adapter might generate many messages, only certain types of messages are logged based on the specified logging level.

Configuring the port logging level using the GUI

Follow these steps:

- Select Configure → Basic Port Configuration from the Host Connectivity Manager. The Basic Port Configuration dialog box displays.
- 2. Select a value from the *Port Logging* Level list as shown in Figure 10-12. Supported values are Log Invalid, Log Critical, Log Error, Log Warning, and Log Info.

AXU04720647 Serial # ALX0417D084 Hardware Path 08:00 Ports Port # VWWN /MAC Name Port Type Configured State Operating State Configured Speed Operating Speed Frame Data I 0 100:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes 1 10:00:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes Port Parameters Boot-over-SAN Port WWWN / MAC 10:00:00:5:1E:0C:1C:CC Port # 0 Port Benable I 10:00:00:5:1E:0C:1C:CC Port # 0 Port WWWN / MAC 10:00:00:5:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I I Out Operating Speed Auto Negotiate Frame Data I I Port Dord a conduct I I:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I I:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I I:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Benable I Configured Speed Auto Negotiate Frame Data I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:CC Port # 0 Port Dord a conduct I II:00:00:00:1E:0C:1C:0C Port # 0 Port Dord a conduct I	Basic Port Config	juration							
Ports Port # VWVN / MAC Name Port Type Configured State Operating State Configured Speed Operating Speed Frame Data I 0 10:00:00:05:1E:0C:1C:CC NPORT 1 10:00:00:05:1E:0C:1C:CD NPORT Port Parameters Boot-over-SAN Port WVVN / MAC 10:00:00:05:1E:0C:1C:CC Port # 0 Port VWVN / MAC 10:00:00:05:1E:0C:1C:CC Port # 0 Port Seed Auto Negotiate Apply Apply Apply Apply to All Port Enable Image: Target rate limiting Apply Path time out 30 Default rate limit 1 Gb/s	ALX0417D084 CNA AXU0428E003	Serial # ALX0417D	084					Hardware F	ath 08:00
Port # VWWN / MAC Name Port Type Configured State Operating State Configured Speed Frame Data f 0 10:00:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes 1 10:00:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes 1 10:00:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes Image: State Configured		Ports							
0 10:00:00:05:1E:0C:1C:CC NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes 1 10:00:00:05:1E:0C:1C:CD NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes Image: Port Parameters Boot-over-SAN Image: Port WWN / MAC 10:00:00:05:1E:0C:1C:CC Port # 0 Image: Port # 0 Apply Port Dert Bable Image: Port # 0 Image: Port # 0 Image: Port # 0 Apply Port Enable Image: Port # 0 Image: Port # 0 Image: Port # Apply Port Enable Image: Port # 0 Image: Port # 0 Image: Port # Apply Port Enable Image: Port # 0 Image: Port # 0 Image: Port # Apply Port Enable Image: Port # 0 Image: Port # 0 Image: Port # Apply Port Enable Image: Port # Image: Port # Image: Port # Image: Port # Apply Apply Port Enable Image: Port # Image: Port # Image: Port # Image: Port #		Port # VW/N / MAC	Na	me Port Type	Configured State	Operating State	e Configured Speed	Operating Speed	Frame Data F
1 10:00:00:05:1E:0C:1C:CD NPORT Enabled Linkup Auto Negotiate 8 Gb/s 2112 Bytes Image: State of the state of		0 10:00:00:05:1E:	:0C:1C:CC	NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
Port Parameters Boot-over-SAN Port VWWN / MAC 10:00:00:51E:0C:1C:CC Port # 0 Apply to All Port Enable Port Enable Port Enable Port Seed Auto Negotiate Frame data field size 2112 Persistent Binding Path time out 30 Default rate limit 1 Gb/s OK Cancel Help		1 10:00:00:05:1E	:0C:1C:CD	NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
Configured Speed Auto Negotiate Frame data field size 2112 Persistent Binding Path time out 30 Default rate limit 1 Gb/s QK Cancel Help		Port WWN / MAC Port Enable	10:00:00:05:1	1E:0C:1C:CC	Port #	0 ng level La	g Warning	>	Apply Apply to All
Persistent Binding QoS enable MPIO mode enable Path time out 30 Default rate limit 1 Gb/s QK Cancel Help		Configured Speed	Auto Negotia	te	 Frame dat 	ta field size 21	12 🔻		
MPIO mode enable Target rate limiting Path time out 30 Default rate limit 1 Gb/s		Persistent Binding			QoS enak	ole 🗌			
Path time out 30 Default rate limit 1 Gb/s QK Cancel Help		MPIO mode enable			Target rat	te limiting			
OK Cancel Help		Path time out	30		Default ra	ate limit 1	Gb/s 💌		
QK Cancel Help									
<u>OK</u> <u>Cancel</u> <u>H</u> elp									
								OK <u>C</u> ancel	Help

Figure 10-12 Adapter Port Logging level

- 3. Click Apply to apply the changes.
- 4. Click **OK** to save the changes and close the window.

Configuring the port logging level using the CLI

Follow these steps:

1. Check the state of the port logging level (Example 10-6)

Example 10-6 Display log level for Brocade adapter port

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu log --level 1/0
FW log level is Warning
HAL log level is Warning
FCS log level is Warning
DRV log level is Warning
AEN log level is Warning
```

2. Change the log level (Example 10-7)

Example 10-7 Change log level of Brocade adapter port

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu log --level 1/0
info
Log level set to Info
```

3. Display the changed the log level state (Example 10-8).

Example 10-8 Displaying the changed log level state

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu log --level 1/0
FW log level is Info
HAL log level is Info
FCS log level is Info
DRV log level is Info
AEN log level is Info
```

Ethernet logging level

The number of messages logged by the host depends on the predetermined logging level. Although the Ethernet port might generate many messages, only certain types of messages are logged based on the specified logging level.

Configuring the Ethernet logging level using the GUI

Follow these steps:

- 1. Select an Ethernet port from the Host Connectivity Manager device tree.
- 2. Select **Configure** \rightarrow **Port Configuration** \rightarrow **Basic** from the Host Connectivity Manager, the Basic Port Configuration dialog box displays.
- 3. Select the Eth Parameter tab and select a value from the Eth Logging Level list on the Eth Parameters Tab (Figure 10-13).

Supported values are Log Invalid, Log Critical, Log Error, Log Warning, and Log Info.

Basic Port Configuration
Port Parameters Boot-over-SAN Eth Parameters
Eth MAC Address: 00:05:1E:AF:08:A2 Eth Logging Levet Log Info
OK Cancel Apply Help

Figure 10-13 Basic Port Configuration Eth Parameters Tab

- 4. Click **Apply** to apply the changes.
- 5. Click **OK** to save the changes and close the window.

Configuring the Ethernet logging level using the CLI

1. Check the present state of the ethloglevel (Example 10-9).

Example 10-9 State of ethlog level

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu ethlog --level 2/0
Log level is Info
```

2. Change the state of the ethloglevel (Example 10-10).

Example 10-10 Changing ethloglevel

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu ethlog --level 2/0
warning
Log level set to Warning
```

10.3.8 Port speed

Port speed is the maximum amount of data that can pass through the port at a given second. The unit of measurement is in gigabits per second (Gbps).

Attention: For the 10 Gbps CNA, the only option is auto-negotiate.

Configuring the port speed using the GUI

Follow these steps:

 Select Configure → Basic Port Configuration from the Host Connectivity Manager.

The Basic Port Configuration dialog box displays.

2. Select a value from the Configured Speed list.

Speed options for the HBA are 1 Gbps, 2 Gbps, 4 Gbps, and 8 Gbps. The available speed options depend on the HBA's speed and the port's SFP. Auto-negotiate is the preferable setting and it is the default as shown in Figure 10-14.

🍓 Basic Port Configu	ration		×
Port Parameters	Boot-over-SAN		
Port WWN / MAC	10:00:00:05:1E:0C:1C:CC	Port #	0
Port Enable	2	Port logging level	Log Info 🔹
Configured Speed	Auto Negotiate	Frame data field size	2112
Persistent Binding	×	QoS enable	
MPIO mode enable		Target rate limiting	
Path time out	30	Default rate limit	1 Gb/s 💌
			QK Cancel Apply Help

Figure 10-14 HBA Port config indicating speed

3. Click Apply to apply the changes.

A port disable/enable configuration dialog displays, confirming the configured speed, which will take effect when the port is disabled or enabled (Figure 10-15).

HCM Mes	ssage 🗙
?	The port 10:00:00:05:1E:0C:1C:CC parameters update succeeded. The configured speed takes effect on port disable and port enable. Do you want to perform a port disable and port enable now?
	Caution: Remote port connectivity is lost when you disable a port.

Figure 10-15 Speed Change Confirmation Dialog box

- 4. Click Yes to continue, or No to cancel the operation.
- 5. If the port can be disabled and enabled, click **Yes** and it will complete the Speed change and indicate the completion state (Figure 10-16).

HCM Me	ssage 🗙
•	Port 10:00:00:05:1E:0C:1C:CC disable and enable completed.
	OK

Figure 10-16 Disable and enable of HBA port after speed change

6. Click **OK** to close the window.

Configuring the port speed using the CLI

The bcu port command is used to set the speed from the CLI (Example 10-11).

Example 10-11 Speed setting of HBA port from CLI

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu port --speed 1/0 auto
Setting will be enforced after port --disable and --enable
```

10.3.9 Frame data field size

Buffer credits determine the maximum amount of frame data. If the number of buffer credits is not large enough to handle the link distance and speed, performance can be severely limited.

See "Buffer credits" on page 421 for information about buffer credits.

Specifying the maximum frame size using the GUI

Follow these steps:

- Select Configure → Basic Port Configuration from the Host Connectivity Manager, and the Basic Port Configuration dialog box displays (Figure 10-17 on page 429).
- 2. Select the frame size from the **Frame Data Field Size** list. Options include 512, 1024, 2048, and 2112 Mbps. The default value is 2112.
- 3. Click **Apply** to apply the change.
- 4. Click **OK** to close the window.

Specifying the maximum frame size using the CLI

The command **bcu port --dfsize** is used to Set the maximum data frame size using CLI (Example 10-12).

Example 10-12 Specifying the maximum frame size

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu port --dfsize 1/0 2112
Setting will be enforced after port --disable and --enable
```

10.3.10 Persistent binding

Persistent binding enables you to permanently assign a system SCSI target ID to a specific FC device. Persistent binding can be achieved by binding to world wide port name (WWPN), world wide node name (WWNN), or device ID (DID).

You can access the Persistent Binding dialog box by selecting the Host, an HBA, a CNA, a CEE port, or an FCoE port from the device tree.

Enabling and disabling persistent binding using the GUI

Persistent binding can be enabled or disabled from the HCM GUI using the following steps:

- 1. Launch the Basic Port Configuration dialog at the port level.
- 2. Check or uncheck the persistent binding check box in the Basic Port Configuration dialog (Figure 10-17).

ALX0417D084	Seria	I # ALX0417D0	084						Hardware F	Path 08:00
	Ports									
	Port #	WWN/MAC		Name	Port Type	Configured State	Operating State	Configured Speed	Operating Speed	Frame Data Fie
	0	10:00:00:05:1E:	0C:1C:CC		NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
	1	10:00:00:05:1E:	0C:1C:CD		NPORT	Enabled	Linkup	Auto Negotiate	8 Gb/s	2112 Bytes
	Port	Enable		otiate		Port loggi	ng level Log	a Info 🔻	_	Appry to All
	Cor	figured Speed	Auto Nea					2 · · ·		
	Cor Per:	figured Speed sistent Binding	Auto Neg			QoS enal		2		
	Cor Per: MPI	ifigured Speed sistent Binding O mode enable	Auto Neg			QoS enal Target ra	te limiting			
	Con Per: MPI Path	figured Speed sistent Binding D mode enable n time out	Auto Neg			QoS enal Target ra Default ra	ole	ib/s 🔻		

Figure 10-17 Basic Port Configuration dialog box, Frame Size and Persistent Binding

Windows: The Persistent Binding option is available only for Windows hosts.

- 3. Click **Apply** to apply the change.
- 4. Click **OK** to close the window.

Persistent binding using the CLI

The **bcu pbind** and **bcu drvconf** commands are used to list and configure persistent binding. The **bcu drvconf** --**pbind_enable** option is used to enable persistent binding from the CLI. This option enables persistent binding in all Brocade adapters in host driver level and have no option to enable or disable for individual adapters as the HCM GUI have.

Example 10-13 shows the CLI options for enabling persistent binding.

Example 10-13 Persistent binding with CLI

```
C:\Users\Administrator>bcu pbind --list 2/1
Persistent mapping status: Disabled
pbind map:
                        10:00:00:05:1e:af:08:a1
local port pwwn:
remote port pwwn:
                        20:36:00:a0:b8:47:39:b0
Bus:
                0
Target:
                4
local port pwwn:
                        10:00:00:05:1e:af:08:a1
remote port pwwn:
                        20:37:00:a0:b8:47:39:b0
Bus:
                0
Target:
                5
C:\Users\Administrator>bcu drvconf --key pbind enable --val 1
Successfully set value = 1 for key = pbind enable
C:\Users\Administrator>bcu pbind --list 2/1
Persistent mapping status: Enabled
pbind map:
local port pwwn:
                    10:00:00:05:1e:af:08:a1
remote port pwwn:
                        20:36:00:a0:b8:47:39:b0
Bus:
                0
                4
Target:
local port pwwn:
                        10:00:00:05:1e:af:08:a1
remote port pwwn:
                        20:37:00:a0:b8:47:39:b0
                0
Bus:
                5
Target:
```

10.3.11 QoS (HBA only)

QoS: The QoS feature is not supported on the converged network adapter (CNA).

The QoS feature is not supported on the converged network adapter (CNA). Quality of Service (QoS) works in conjunction with the QoS feature on switch F_Ports. The Fabric operating system (FOS) provides a mechanism to assign traffic priority (high, medium, or low) for a given source and destination traffic flow. By default, all flows are marked as medium. This feature is supported only on 8 Gbps HBA ports installed on specific switch models that use Fabric OS v6.2 and later. The following licenses must be installed on the switch connected to each HBA port (edge switch):

- Adaptive Networking (AN) license
- Server Application Optimization (SAO) license

To determine if these licenses are installed on the connected switch, execute the Fabric OS **licenseshow** command. For more information about QoS, see *Implementing an IBM/Brocade SAN with 8 Gbps Directors and Switches*, SG24-6116.

Configuring QoS on the switch side

On the switch side, you can create QoS zones using the PWWNs that correspond to devices in a source/destination traffic flow. You need a Server Application Optimization (SAO) license installed on the switch to enable QoS. In addition, an Adaptive Network (AN) license is required on the switch to enable QoS on the switch ports.

You enable or disable QoS settings on ports with the **portCfgQos** command. For more information about configuring QoS, see *Implementing an IBM/Brocade SAN with 8 Gbps Directors and Switches*, SG24-6116.

Configuring QoS on the HBA side

There are three possible QoS states:

- Enabled, online: QoS is established with the switch.
- Enabled, offline: QoS negotiation failed and QoS was not established with the switch. Possible reasons for failure might be that the license is not installed on the switch or QoS is not enabled on the port.
- Disabled.

Tip: You must first disable the port and enable the port before QoS changes.

Follow these steps:

- 1. In the Tree View, select the adapter for configuration.
- Select Configure → Basic Port Configuration from the Host Connectivity Manager.

The Basic Port Configuration dialog box displays (Figure 10-18).

Basic Port Config	uratio	n										
CMA AXU0428E003	Seria	al # ALX0417D084	4							Hardware I	Path 08:00	
	Ports											
	Port #	WWWN / MAC		Name	Port Type	Configured St	ate Operating	State	Configured Speed	Operating Speed	Frame Data Fi	e
	0	10:00:00:05:1E:0C	:1C:CC		NPORT	Enabled	Linkup		Auto Negotiate	8 Gb/s	2112 Bytes	
	1	10:00:00:05:1E:0C	:1C:CD		NPORT	Enabled	Linkup		Auto Negotiate	8 Gb/s	2112 Bytes	
	4 166	566666666666666666666666666666666666666	666666666	666666	5666666666666		66666666666666666666	666666	66666666			
	A 7											1
	Port	Parameters Bo	ot-over-	SAN								
											Apply	1
	Por	t WWN / MAC 10	0:00:00:0	5:1E:0	0C:1C:CC	Port #		0		1		í
			_								Apply to All	1
	Por	t Enable				Port lo	gging level	Log	Info 🔻			
	Cor	nfigured Speed A	uto Nega	tiate		 Frame 	data field size	211	2 🔻			
	Per	sistent Binding 🛛	•			QoS e	nable	V	>			
	MP	IO mode enable				Targe	rate limiting					
	Pat	h time out 30)			Defau	t rate limit	1 G	b/s 🔻			
										01/	L Links	i
											- Telb	I

Figure 10-18 Basic Port Configuration

3. Disable the port by unchecking the **Port enable** check box.

A confirmation dialog box displays (Figure 10-19).



Figure 10-19 Port Disable confirmation dialog box

- 4. Click OK.
- 5. Click the QoS enable check box.
- 6. Click the **Port enable** check box to re-enable the port.
- 7. Click **OK** to apply the changes.

A confirmation box displays (Figure 10-20).



Figure 10-20 Update confirmation dialog box

- 8. Click **Yes**, which will perform a port disable and then an enable, and will indicate success with a confirmation, Click **OK**.
- 9. Click **OK** in the *Basic Port Configuration* window to return to the HCM main window.

Enabling and disabling QOS using the CLI

The **bcu port** is the command used to enable or disable QOS. First enter the bcu **port** --disable <port_id> command, followed by the **bcu port** --enable <port_id> command, before the **bcu qos** --enable or **bcu qos** --disable commands take effect. The sequence is listed in Example 10-14.

Example 10-14 Enabling QOS with the CLI

```
C:\Program Files\BROCADE\Adapter\driver\util>bcu port --disable 1/0
port disabled
C:\Program Files\BROCADE\Adapter\driver\util>bcu port --enable 1/0
port enabled
C:\Program Files\BROCADE\Adapter\driver\util>bcu qos --enable 1/0
qos for port id 1/0 enabled
Setting will be applied after port --disable and port --enable
```

C:\Program Files\BROCADE\Adapter\driver\util>bcu port --disable 1/0 port disabled

C:\Program Files\BROCADE\Adapter\driver\util>bcu port --enable 1/0 port enabled

10.3.12 Path Time Out

The Path Time Out value is used to handle path failover when the timeout value is reached. The value range is 0 to 60. If The Path time Out value is set to 0, it forces an immediate failover.

Specifying Path Time Out using the GUI

Follow these steps:

 Select Configure → Basic Port Configuration from the Host Connectivity Manager.

The Basic Port Configuration dialog box displays (Figure 10-21).

凳 Basic Port Config	uratio	n										×
ALX0417D084	Seria	al # ALX0417D	084								Hardware P	ath 08:00
	Ports											
	Port #	WWWN / MAC		Name	Port Type	Config	ured State	Operating S	tate	Configured Speed	Operating Speed	Frame Data Fie
	0	10:00:00:05:1E	0C:1C:CC		NPORT	Enable	d	Linkup		Auto Negotiate	8 Gb/s	2112 Bytes
	1	10:00:00:05:1E	0C:1C:CD		NPORT	Enable	d	Linkup		Auto Negotiate	8 Gb/s	2112 Bytes
	4 33										101111111111111	•
	Port	Parameters	Boot-over	-SAN								
												Apply
	Por	t WWN / MAC	10:00:00:	05:1E:0	00:10:00		Port #		0			Apply to All
	Por	t Enable					Port loggi	na level	Log	Info 💌	-	Obbit to Oil
						_	ronnoggi	giorei				
	Co	nfigured Speed	Auto Neg	otiate		•	Frame da	ta field size	2112	2 🔻		
	Per	rsistent Binding	\checkmark				QoS enat	le	\mathbf{r}			
	MP	IO mode enable					Target ra	e limiting				
	Pat	h time out	30			\geq	Default ra	te limit	1 Gk	o/s 🔻		
											OK Cancel	Help

Figure 10-21 Path Time Out

- 2. Type a value in the *Path Time Out* text field. A timeout value of 30 is the default.
- 3. Click **OK** to close the window.

Specifying the Path Time Out using the CLI

The Path Time Out value is set by using the command **bcu fcpim** as shown in Example 10-15.

Example 10-15 Path Time Out value with CLI

```
C:\Users\Administrator>bcu fcpim --pathtov 1/0 20 path timeout is set to 20
```

10.3.13 Target rate limiting

The target rate limiting feature is used to minimize congestion at the adapter port caused by a slow drain device operating in the fabric at a slower speed. A remote port's operating speed is determined from the fabric. Traffic destined to the remote port is limited to its current operating speed.

Enabling and disabling rate limiting using the GUI

Target rate limiting is supported only when the adapter port is connected to the fabric. Therefore, target rate limiting is not supported when the port is directly connected with another device. Follow these steps:

 Select Configure → Basic Port Configuration from the Host Connectivity Manager; the Basic Port Configuration dialog box displays (Figure 10-22).

Basic Port Config	juration								
ALX0417D084 AXU0428E003	Serial # AXU0	428E003						Hardware	Path 12:00
	Ports								
	Port # VW/N / M	AC .	Name	Port Type	Configured Sta	te Operating S	tate Configured Speed	Operating Speed	Frame Data Fie
	0 10:00:00:	5:1E:AF:08:A0		NPORT	Enabled	Linkup	Auto Negotiate	10 Gb/s	2112 Bytes
	1 10:00:00:	5:1E:AF:08:A1		NPORT	Enabled	Linkup	Auto Negotiate	10 Gb/s	2112 Bytes
		6666666666666666666		66666666666666	66666666666666666	666666666666666666666666666666666666666	666666666666666666666666666666666666666	66666666666666	
	A T								
	Port Parameter	s Boot-over	r-SAN	Eth Para	meters				
									Apply
	Port WWN / M	AC 10:00:00	05:1E2	AF-08-A0	Port #		0		
									Apply to All
	Port Enable	V			Port lo	ging level	Log Warning 🔻		
	Configured S	eed 10 Gb/s			Frame	data field size	2112 💌		
	Persistent Bin	aing 🗹			QoS e	nable			
	MPIO mode er	able 🗌			Target	rate limiting	r		
	Path time out	30			Defaul	rate limit	4 Gb/s 💌		
							-		_
								<u>OK</u> <u>C</u> ance	el <u>H</u> elp

Figure 10-22 Target Rate Limiting

2. Enable the Target Rate Limiting feature by clicking the corresponding check box.

Attention: Target Rate Limiting and QoS cannot be enabled at same time for an adapter.

3. Select the default rate limit from the list. Options include 1 Gbps, 2 Gbps, and 4 Gbps; the default is 2 Gbps.

4. Click **OK** to close the window.

A disable port/enable port warning message displays (Figure 10-23).



Figure 10-23 Disable Port Warning Message

4. Click Yes to continue.

A disable port/enable port completion message displays (Figure 10-24).

HCM Mes	ssage 🗙
٩	Port 00:05:1E:AF:08:A0 disable and enable completed.
	OK

Figure 10-24 Disable/Enable port completion message

5. Click OK.

Enabling and disabling rate limiting using the CLI

The **bcu** ratelim command is used to enable the Target rate limit. Example 10-16 shows the configuration sequence where we change the target rate limit for the CNA port 2/1 from 1G to 4G.

Example 10-16 Target Rate Limit with CLI

```
C:\Users\Administrator>bcu port --disable 2/1
port disabled
C:\Users\Administrator>bcu port --enable 2/1
port enabled
C:\Users\Administrator>bcu ratelim --enable 2/1
ratelim for port id 2/1 enabled
Setting will be enforced after port --disable and --enable
C:\Users\Administrator>bcu ratelim --query 2/1
Target Rate Limiting: enabled
Default TRL Speed is: 1G
```

```
C:\Users\Administrator>bcu ratelim --defspeed 2/1 4
Setting will be enforced after port --disable and --enable
C:\Users\Administrator>bcu ratelim --query 2/1
Target Rate Limiting: enabled
Default TRL Speed is: 4G
C:\Users\Administrator>bcu port --disable 2/1
port disabled
C:\Users\Administrator>bcu port --enable 2/1
port enabled
```

10.3.14 Boot over SAN

The boot over SAN feature allows you to target remote boot devices (LUNs on SAN storage arrays) from which to boot the host system. When the host's operating system and adapter driver are installed on the remote device, the adapter BIOS and user-configurable boot instructions stored in adapter flash memory allow the host to boot from the device.

SAN boot: Various operating systems require you to follow specific guidelines to enable servers to boot from a SAN. Understanding these requirements is key to a successful deployment of a boot over SAN environment.

Boot LUNs are identified to adapter ports using the BIOS Configuration Utility and CLI commands. These utilities also allow you to enable or disable BIOS for booting the host system over SAN, set boot options, and set the port speed. For instructions, see the *Brocade Adapters Installation and Reference Manual*, 53-1001254-05, available at this website:

http://www.brocade.com/services-support/drivers-downloads/HBA/index.pag
e

After you have configured boot devices using the BIOS Configuration Utility, you can enable or disable BIOS for boot over SAN, set boot options, and set port speed using the HCM GUI. All configuration is stored in flash memory.

10.3.15 Configuring Boot over SAN

The boot-LUN table lists the vendor information, LUN capacity, and whether the LUNs are accessible. These fields are not editable.

You can access the *Boot over* SAN dialog box by selecting the Host, an HBA, or CNA from the device tree.

Attention: Boot over SAN configuration using the *Basic Port Configuration* dialog box is enabled on all platforms if the agent version is 1.1 or higher.

 Select Configure → Basic Port Configuration from the Host Connectivity Manager.

The Basic Port Configuration dialog box displays.

2. Click the **Boot-over-SAN** tab. The Boot-over-SAN dialog box displays (Figure 10-25).

ALX0417D084	Seria	al # AXU0428E003						Hardware I	Path 12:00
	Ports								
	Port #	VW/N/MAC	Name	Port Type	Configured State	Operating State	Configured Speed	Operating Speed	Frame Data Fi
	0	10:00:00:05:1E:AF:08:A0		NPORT	Enabled	Linkup	Auto Negotiate	10 Gb/s	2112 Bytes
	1	10:00:00:05:1E:AF:08:A1		NPORT	Enabled	Linkup	Auto Negotiate	10 Gb/s	2112 Bytes
	1999							9999999999999999999	
	1 10000								
	A T	Parameters Pact aver	CAN	File Dare	matara				
	Port	Parameters Boot-over	-SAN	Eth Para	ameters				
	Port	Parameters Boot-over	-SAN	Eth Para	ameters Root Out	ion Auto Discos	vered From Fabric	.	Apply
	Port	Parameters Boot-over	-SAN Auto N	Eth Para	meters Boot Opt	ion Auto Discov	vered From Fabric	•	Apply Apply to All
	Port BIOS	Parameters Boot-over Enable 🗹 Speed	-SAN Auto N	Eth Para	meters Boot Opt	ion Auto Discov	vered From Fabric	•	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable Speed	-SAN Auto Ne	Eth Para	Boot Opt	ion Auto Discov	vered From Fabric	▼ Move Up	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over	-SAN Auto N	Eth Para	ameters Boot Opt	ion Auto Discov	vered From Fabric	Move Up	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable Speed	-SAN Auto Ne	Eth Para	ameters Boot Opt	ion Auto Discov	vered From Fabric	Move Up	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable P Speed	-SAN Auto N	Eth Para	ameters Boot Opt	ion Auto Discov	vered From Fabric	Move Up Nove Down Delete	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable P Speed	-SAN Auto N	Eth Para	emeters Boot Opt	ion Auto Discov	LUNC	Move Up Move Down Delete	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable Speed	-SAN Auto N	Eth Para	Boot Opt	ion Auto Discov	Vered From Fabric	Move Up Move Down Delete	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over Enable Speed	-SAN Auto N/	Eth Para	Boot Opt	ion Auto Discov	vered From Fabric	Move Up Move Down Delete	Apply Apply to All
	Port BIOS Boo	Parameters Boot-over	-SAN Auto N/	Eth Para	Boot Opt	ion Auto Discov	Vered From Fabric	Move Up Aove Down Delete	Apply Apply to All

Figure 10-25 Boot over SAN View

- 3. Click the **BIOS Enable** check box to enable Boot Over SAN.
- 4. From the *Boot Option* list, select one of the following choices:
 - Auto Discovered from Fabric: Enables Boot over SAN using boot LUN information stored in the fabric. This is the default setting.

- First Visible LUN: Enables Boot over SAN from the first discovered LUN in the SAN.
- **User Configured LUNs**: Allows the user to select and prioritize the remote target and LUN for booting over SAN.
- 5. Select the Boot Device Port WWN row in the table, then click the up and down arrows to move the row up or down in the table or use "move up" and "move down" buttons in the side of the rows. The host will attempt to boot from the first LUN in the table, and then move on to succeeding LUNs.
 - You can delete a row using the Delete button.
 - For User Configured LUNs click the Boot Device Port WWN and LUN fields to manually enter boot LUNs to the table. These LUNs must be visible to the adapter to be accessible as boot LUNs.
- 6. Click OK.

The Vendor Info, LUN Capacity, and Accessible status that corresponds to the selected boot device and LUN displays automatically.

10.3.16 Boot code image upload

You can upload a boot code image on the local host or on an HBA. The boot-over-SAN feature is not supported on the converged network adapter (CNA). Follow these steps to upload the latest boot code using the HCM GUI.

Solaris: On Solaris systems, the Boot Code Image Upload menu is disabled if the host does not have a Fibre Channel HBA card or if the driver version is lower than 1.1.0.7 (the version must be 1.1.0.7 or higher for Solaris).

10.3.17 Updating the boot code using the GUI

1. Download the boot code (brocade_adapter_boot_fw_v1-1-0-6) from the following website, to a folder on your local drive:

http://www.brocade.com/services-support/drivers-downloads/HBA/index.
page

- 2. Launch HCM.
- 3. Right-click a host or adapter from the device tree and select **Upload Boot Code Image** from the list.
 - Right-clicking a host uploads the boot code image to all adapters that are installed on the host.

 Right-clicking an adapter uploads the boot code image to the selected adapter only.

The Boot Code Image Upload dialog displays (Figure 10-26).

🗣 Update Boot Image	×
File Name	Browse
	QK Cancel Help

Figure 10-26 Boot Code Image Upload dialog box

- 4. Click the Browse button and navigate to the location of the boot code image.
- 5. Select the boot code image and click **Open**.

The selected file uploads. If an error occurs during the uploading process, an error message displays.

10.3.18 Virtual port configuration

Virtual ports (V_Ports) appear to the hosts as physical ports in the data network. One or more virtual ports are assigned to each host, and a host can access storage at a virtual port only if the virtual port has been assigned to the host.

V_Port: You cannot create a V_Port that already exists in the Names dialog. If you need to re-create a V_Port that has been deleted through an interface other than the currently managing HCM or the V_Ports deleted on Linux servers reboot, you must first manually remove the V_Port's WWN from the Names dialog box in HCM. If you do not manually remove the V_Port from HCM, an error message displays that the V_Port already exists. See ""Removing a name entry" on page 449 for instructions.

10.3.19 Creating a virtual port

You create virtual ports on HBA ports and FCoE ports only; virtual ports are not supported on an adapter. Virtual ports are not supported for VMware and Solaris agents. Follow these steps:

- 1. Select a physical HBA port or an FCoE port from the device tree.
- 2. Select **Configure** \rightarrow **Virtual Port** \rightarrow **Create** from the main menu.
or

Right-click the physical port and select Virtual Port \rightarrow Create from the list.

The Virtual Port Creation dialog box displays as shown in Figure 10-27. The following fields are system-generated:

- Physical port world wide name.
- Virtual port world wide name: This WWN must be unique.
- Virtual node world wide name: The system returns the default node WWN, which is the physical port node WWN.

Virtual Port Creat	ion	
Physical Port WWN	10:00:00:05	:1E:AF:08:A1
Virtual Port WWN	29:DE:00:0	5:1E:AF:08:A1
🗹 Use auto-gener	rated	Generate Again
Virtual Node WWN	20:00:00:05	:1E:AF:08:A1
Symbolic Name		
Name		
Description		
<u>o</u> k	<u>C</u> ancel	Apply <u>H</u> elp

Figure 10-27 Virtual Port Creation dialog box

Attention: By default, the Use auto-generated check box is selected and the Generate Again button is enabled. You can still edit the Virtual Port WWN field if Use auto-generated is selected.

- 3. (Optional). Provide a symbolic name for the virtual port.
- 4. (Optional). Provide an alias name for the virtual port. By creating an alias, you can assign a familiar name to a device or group multiple devices into a single name. This can simplify cumbersome data entry and allows an intuitive naming structure.
- (Optional). Enter descriptive information about the virtual port into the Description text box.
- 6. Click **OK** to apply the changes and close the window.

🏂 Host Connectivity Manager					
File View Discovery Configure	e <u>M</u> onitor <u>T</u> ool <u>H</u> elp				
🗉 🧶 localhost	Properties				
🕀 🗢 ALX0417D084	E Virtual P	ort Paramet	ers		
E- 🎇 AXU0428E003	Port VAAA	J	29 DE:00:05:1E:AE:08	·A1	
E 🖲 00:05:1E:AF:08:A0	Node VW	N	20:00:00:05:1E:AF:08	:A1	
😐 🚇 10:00:00:05:1E:	AF:08:A0 Fabric Na	me	10:00:00:05:1E:90:16:	57	
00:05:1E:AF:08	A2 Switch IP	Addr	10.18.228.18		
O:05:1E:AF:08:A1 O:05:1E:AF:08 O:05:1E:AF:08	FC Addre	SS	051402		
E @ 10:00:00:05:1E	AF:08:A1 FPMA MA	C Address	0E:FC:00:05:14:02		
	S1E:AE:08:A1 State		online		
29 DE:00:00	S1E:AE:08:A1 Symbolic	Name			
0:05:45:45:09	Roles		FCP Initiator		
- DOLUS.1E:AF:08	Base Port		False		
Master Log Application Log Master log Filter None					Clear filter Refresh
Sr No	Severity	W	WN / MAC	Category	Sub Category
96		10:0	0:00:05:1E:0C:1C:CC	PORT	Online
97	INFO	10:0	0:00:05:1E:0C:1C:CC	LPORT	Online
95	INFO	10:0	0:00:05:1E:0C:1C:CC	PORT	Enabled
92	INFO	10:0	0:00:05:1E:0C:1C:CC	LPORT	Offline
93	A MINOR	10:0	0:00:05:1E:0C:1C:CC	PORT	Offline
94	INFO	10:0	0:00:05:1E:0C:1C:CC	PORT	Disabled
89		10:0	0:00:05:1E:0C:1C:CC	PORT	Enabled
90		10:0	0:00:05:1E:0C:1C:CC	PORT	Online
91		10:0	0:00:05:1E:0C:1C:CC	LPORT	Online
86		10:0	0:00:05:1E:0C:1C:CC	LPORT	Offline
87	MINOR	10:0	0:00:05:1E:0C:1C:CC	PORT	Offline
			Llear: edmin	Agent: Joselhost Dort: 24522	Least Undetext: Thu Oct 21 16:01:05 PDT 2010
			User: aamin	Agent: iocainost Port: 34558	Last opdated: Thu Oct 21 16:01:05 PDT 2010

The new virtual port will now display in the Tree View as shown in Figure 10-28.

Figure 10-28 Newly Created virtual port on the CNA

10.3.20 Deleting a virtual port

Follow these steps:

- 1. Select a virtual port from the device tree.
- 2. Select **Configure** \rightarrow **Virtual Port** \rightarrow **Delete** from the main menu.

or

Right-click the virtual port and select **Delete** from the list.

A warning message displays, asking for confirmation (Figure 10-29).



Figure 10-29 Virtual Port Deletion

3. Click **OK** to continue.

10.3.21 HCM logging levels

In this section we discuss considerations regarding logging levels.

Setting the logging level for modules

You can set the logging level for the following modules:

- Agent communication log, where all messages are exchanged between the HCM GUI application and the HCM agent.
- ► HCM debug log, where messages are logged locally.

If you do not set an HCM logging level, then TRACE, which is the most verbose and the default setting, is used.

Configuring the HCM logging level using the GUI

Follow these steps:

 Select Configure → HCM Logging Levels from the Host Connectivity Manager.

The Configure HCM Logging Levels dialog box displays (Figure 10-30).

靠 Configure HCM Logging	Levels 🛛 🔀	1
Agent Communication Log	TRACE -	
HCM Debug Log	TRACE	
<u>o</u> k	Cancel Apply Help	

Figure 10-30 Configure HCM Logging Levels dialog box

- 2. From both the Agent Communication Log and the HCM Debug Log lists, select one of the following choices:
 - Trace, which is the most verbose.
 - Debug

- Info
- Warning
- Error
- Fatal, which is the least verbose.
- 3. Click **Apply** to apply the change.

10.3.22 Advanced port configuration

You can access the Advanced Port Configuration dialog box by selecting an HBA port or an FCoE port from the device tree.

For each port, you can configure the following parameters using the Advanced Port Configuration dialog box, the Command Line utility, or both. Table 10-4 lists the features and configuration options.

Table 10-4 Features and configuration options

Port Configuration parameter	Configurable using the GUI	Configurable using the CLI
Interrupt Control Coalesce	Yes	Yes
Interrupt Control Latency	Yes	Yes
Interrupt Control Delay	Yes	Yes

10.3.23 Opening the Advanced Port Configuration dialog box

Follow these steps:

- 1. Select an HBA port or FCoE port from the device tree.
- 2. From the Host Connectivity Manager, select Configure \rightarrow Port Configuration \rightarrow Advanced.

The Advanced Port Configuration dialog box displays (Figure 10-31).

锋 Advanced Port Configur	ation 🗙
Queue Depth	
Interrupt Control Coalesce	On 💌
Interrupt Control Latency	225
Interrupt Control Delay	1125
	<u>OK Cancel Apply Help</u>

Figure 10-31 Advanced Port Configuration dialog box

Interrupt Control Coalesce

Interrupt control coalescing allows the system to change CPU utilization by varying the number of interrupts generated. Increasing the latency monitor timeout value should result in a lower interrupt count and less CPU utilization, which might result in higher throughput.

Configuring the Interrupt Control Coalesce using the GUI

Follow these steps:

- 1. Select a port from the device tree.
 - From the Host Connectivity Manager, select Configure \rightarrow Advanced Port Configuration.

or

- Right-click a port and select **Port Configuration** \rightarrow **Advanced**.

The Advanced Port Configuration dialog box displays (Figure 10-32).

靠 Advanced Port Configur	ation 🔀
Queue Depth	
Interrupt Control Coalesce	On 🔻
Interrupt Control Latency	5
Interrupt Control Delay	25
	<u>QK Cancel Apply H</u> elp

Figure 10-32 Advanced Port Configuration dialog box CNA

- 2. Set the latency and delay values:
 - Select **On** from the Interrupt Control Coalesce list.
 - Specify the latency monitor timeout value in microseconds, if coalesce is set to on. Latency timeout values supported are 0-225 microseconds. Setting the latency time out value to 0 disables the latency monitor time out interrupt.
 - Specify the delay timeout value in microseconds, if coalesce is set to on.
 Delay timeout values supported are 0-1125 microseconds. Setting the delay timeout value to 0 disables the latency monitor time out interrupt.
- 3. Click OK.

10.3.24 NPIV

N-Port ID Virtualization (NPIV) enables a single Fibre Channel protocol port to appear as multiple, distinct ports. NPIV provides separate port identification within the fabric for each operating system image (partition) behind the port, as if each operating system image had its own unique physical port.

Each NPIV device has a unique virtual port ID (PID), port WWN, and node WWN. The virtual port has the same properties as an N_Port and is therefore capable of registering with all services of the fabric. In other words, multiple virtual devices emulated by NPIV appear no different than regular devices connected to a non-NPIV port. The maximum number of virtual PIDs for an N_Port on a FC switch is 255. For a CEE switch, the maximum number of V_Ports is 64.

NPIV is available at the physical port level or at the virtual fabric level. If virtual fabric ports are detected, then you cannot configure NPIV parameters at the physical port level. If virtual fabric ports are deleted on the switch port side, the NPIV parameters can then be configured at the physical port level. No settings are available for V_Ports from basic port configuration.

Solaris: NPIV is not supported on Solaris platforms.

10.3.25 Name configuration

The Host Connectivity Manager allows you to configure names as a method of providing familiar, simple names to world wide names for adapters, ports, virtual ports, and remote ports in the SAN. (A logical port can be a base port or a virtual port.) Only unique names are allowed.

You can access the *Configure Names* dialog box by selecting an HBA, an HBA port, a Virtual Port, a CNA, or a CEE port from the device tree.

You can perform the following name tasks using either the *Configure Names* dialog or the *Define Names* dialog:

- Associate a name that represents an adapter, port, virtual port, or remote port. Note the following considerations about names:
 - Among all adapters, two cannot have duplicate names.
 - Among all the ports, two cannot have duplicate names.
 - A port and adapter can have the same name.
 - You cannot associate a name for a storage device.
 - Name changes on remote ports and virtual ports are sent to the *.properties file local to the HCM application but are not sent to the agent.

- Add a detached WWN and an associated name with Type and operational status as Unknown.
- Remove or disassociate a name from a WWN.

Define Names: You can launch the Define Names dialog by right-clicking an adapter, port, remote port, or V_Port.

Name validation

Observe the following considerations when you define a name:

- The name cannot begin with a number.
- The name cannot begin with an underscore (_) or hyphen (), however an underscore or hyphen character is allowed within the name; for example, name1_name-2.
- ► No special characters are allowed, except for an underscore or hyphen.
- ► The maximum length of the name is 15 characters.
- ► The maximum length of the description is 80 characters.

Editing the name fields

Only the name, the world wide name (WWN), and the description fields are editable. Depending on the component, the following occurs when you edit the name fields:

- ► Name changes on the adapter and ports are sent to the agent and stored in the *HbaAliasdb.properties* file.
- Name changes on remote ports and virtual ports are sent to the *HbaAliasdb.properties* file local to the HCM application but are not sent to the agent.
- 1. Select an HBA, an HBA port, a Virtual Port, a CNA or a CEE port from the device tree.
- 2. Select **Configure** \rightarrow **Names** from the Host Connectivity Manager.

or

Right-click a device from the device tree and select Define Name.

The *Configure Names* dialog box displays all the discovered and detached (undiscovered) names (Figure 10-33).

lame 🔻	MAC	Operational status	Туре	Description	
C1_0	10:00:00:05:1E:0C:1C:CC	Discovered	Port	HBA1 Port0	
	20:00:00:05:1E:0C:1C:CC	Discovered	Node		Remove
	27:49:00:05:1E:0C:1C:CC	Discovered	Virtual Port		
	10:00:00:05:1E:0C:1C:CD	Discovered	Port		
	2D:ED:00:05:1E:0C:1C:CD	Discovered	Virtual Port	1	DCFM / FM Format
	00:05:1E:AF:08:A0	Discovered	CNA		
	00:05:1E:AF:08:A0	Discovered	CNA Port		Import
	20:37:00:A0:B8:47:39:B0	Discovered	Remote Port		
	20:36:00:A0:B8:47:39:B0	Discovered	Remote Port		Export
	22:99:00:05:1E:AF:08:A0	Discovered	Virtual Port		
	00:05:1E:AF:08:A1	Discovered	CNA Port		

Figure 10-33 Configure Names dialog box

- 3. Select a row and edit the name, the WWN, and the description, as needed.
- 4. Click OK.

A Name Change Confirmation dialog box displays (Figure 10-34).

HCM Me	ssage 🗙
٩	You are about to send the information to the agent. Do you want to proceed?
	<u>Y</u> es <u>N</u> o

Figure 10-34 Name Change Confirmation dialog box

5. Click Yes.

Adding name entries

You can add up to 2000 names, which are then stored in the *HbaAliasdb.properties* file. The entries persist during reboot.

The WWN types are as follows:

- Node
- ► Port
- Remote Port
- V_Port

- Dual Role (port type that acts as initiator and target)
- Unknown

Follow these steps:

- 1. Select an HBA, an HBA port, a Virtual Port, a CNA or a CEE port from the device tree.
- 2. Select **Configure** \rightarrow **Names** from the Host Connectivity Manager.

The Configure Names Dialog box opens as in Figure 10-35.

lomo 🛒	MARCH CMAC	Operational status	Turno	Description	
(01-0	10:00:05:15:00:10:00	Discovered	Port	HBA1 Port0	
01-0	20:00:00:05:15:00:10:00	Discovered	Node	HBAT FOILD	Remove
	27:49:00:05:1E:00:10:00	Discovered	Virtual Port	1	
	10:00:05:1E:00:10:00	Discovered	Port	1	
	20:ED:00:05:1E:00:10:0D	Discovered	Virtual Port	1	
	00:05:1E:AF:08:A0	Discovered	CNA	1	DCFIW / FM Format
	00:05:1E:AF:08:A0	Discovered	CNA Port	1	Import
	20:37:00:A0:B8:47:39:B0	Discovered	Remote Port	1	
	20:36:00:A0:B8:47:39:B0	Discovered	Remote Port	1	Export
	22:99:00:05:1E:AF:08:A0	Discovered	Virtual Port	1	
	00:05:1E:AF:08:A1	Discovered	CNA Port	1	
					rix Dupiicates

Figure 10-35 Configure names dialog

- 3. Type a name that represents an adapter, port, or storage device into the **Name** text box.
- 4. Type a valid WWN that corresponds to the name in the **Detached WWN/MAC** text box.
- 5. Click Add.
- 6. Click **OK** to close the window.

The new component is added to the Name list.

Removing a name entry

The Remove functionality clears the name and description values of a selected detached WWN:

Follow these steps:

- 1. Select an HBA, an HBA port, a Virtual Port, a CNA, or a CEE port from the device tree.
- 2. Select **Configure** \rightarrow **Names** from the Host Connectivity Manager.

or

Right-click a device from the device tree and select Define Name.

The Configure Names dialog box displays all the names available at the host.

- 3. Select one of the following choices from the Display list:
 - Current Host
 - All WWNs/MACs
 - Only Nodes
 - Only Ports
 - Only Logical Ports
 - Only Virtual Ports
 - Only Remote Ports

A list of names for the devices you selected displays (Figure 10-36).

Name 🔻	WWWN / MAC	Operational status	Туре	Description	
inux_hba1	10:00:00:05:1E:AF:0B:28	Unknown	Unknown	· · · · · · · · · · · · · · · · · · ·	
C1-0	10:00:00:05:1E:0C:1C:CC	Discovered	Port	HBA1 Port0	Remove
	20:00:00:05:1E:0C:1C:CC	Discovered	Node		
	27:49:00:05:1E:0C:1C:CC	Discovered	Virtual Port		
	10:00:00:05:1E:0C:1C:CD	Discovered	Port		DCEM / EM Format
	2D:ED:00:05:1E:0C:1C:CD	Discovered	Virtual Port		
	00:05:1E:AF:08:A0	Discovered	CNA		Import
	00:05:1E:AF:08:A0	Discovered	CNA Port		
	20:37:00:A0:B8:47:39:B0	Discovered	Remote Port		Export
	20:36:00:A0:B8:47:39:B0	Discovered	Remote Port		
	22:99:00:05:1E:AF:08:A0	Discovered	Virtual Port		
	_00:05:1E:AF:08:A1	Discovered	CNA Port		Fix Duplicates.
	00:05:1E:AF:0B:29	Unknown	CNA Port		
	10:00:00:05:1E:0C:1C:CC	Unknown	Remote Port		
	10:00:00:05:1E:AF:08:A1	Unknown	Remote Port		
	00:05:1E:AF:0B:28	Unknown	CNA Port	-	

Figure 10-36 Remove a Name Entry

- 4. Select a device to highlight it and click the **Remove** button to remove the discovered device from the list. The Remove button clears the names of the discovered WWN and the entire row of the detached (undiscovered) WWN.
- 5. Click **OK** to close the window.

10.3.26 Exporting the properties for a WWN

You can export the properties for a world wide name in .csv, .properties, or .txt file format.

Follow these steps:

- 1. Select an HBA, an HBA port, a Virtual Port, a CNA or a CEE port from the device tree.
- 2. Select **Configure** \rightarrow **Names** from the Host Connectivity Manager.

The Configure Names dialog box displays as in Figure 10-37.

lame 🔻	WWW / MAC	Operational status	Type	Description	
C1-0	10:00:00:05:1E:0C:1C:CC	Discovered	Port	HBA1 Port0	
	20:00:00:05:1E:0C:1C:CC	Discovered	Node	38	Remove
	27:49:00:05:1E:0C:1C:CC	Discovered	Virtual Port		
	10:00:00:05:1E:0C:1C:CD	Discovered	Port		
	2D:ED:00:05:1E:0C:1C:CD	Discovered	Virtual Port		DCEM (EM Format
	00:05:1E:AF:08:A0	Discovered	CNA		Der mit in mit er mat
	00:05:1E:AF:08:A0	Discovered	CNA Port		Import
	20:37:00:A0:B8:47:39:B0	Discovered	Remote Port		
	20:36:00:A0:B8:47:39:B0	Discovered	Remote Port		Export
	22:99:00:05:1E:AF:08:A0	Discovered	Virtual Port		
	00:05:1E:AF:08:A1	Discovered	CNA Port		
	00:05:1E:AF:0B:29	Unknown	CNA Port		Fix Duplicates
	10:00:00:05:1E:0C:1C:CC	Unknown	Remote Port		
	10:00:00:05:1E:AF:08:A1	Unknown	Remote Port		
	00:05:1E:AF:0B:28	Unknown	CNA Port		
	10:00:00:05:1E:AF:08:A0	Unknown	Remote Port	-	

Figure 10-37 Export Properties of a WWN

- 3. Select one of the following choices from the Display list:
 - Current Host
 - All WWNs/MACs
 - Only Nodes
 - Only Ports
 - Only Logical Ports
 - Only Virtual Ports
 - Only Remote Ports

4. Click the **Export** button.

The Save dialog box displays. You can save the properties file in .txt, .csv, or .properties format (Figure 10-38).

Export files	5		×
Save in:	Client		▼ ☞ @ □ 않는
Name		SizeType	Date modified Attributes
File <u>N</u> ame:	FC_HBA1_prt0		
Files of <u>Type</u> :	Text Documents (.txt)		-
			Save Cancel

Figure 10-38 Export Save As dialog box

- 5. Name the file, and click **Save**.
- 6. Click **OK** to close the window.

10.3.27 Importing the properties for a WWN

1. Select **Configure** \rightarrow **Names** from the Host Connectivity Manager.

The Configure Names dialog box displays.

- 2. Select one of the following choices from the Display list:
 - Current Host
 - All WWNs/MACs
 - Only Nodes
 - Only Ports
 - Only Logical Ports
 - Only Virtual Ports
 - Only Remote Ports

3. Click the Import button.

The Import dialog box displays (Figure 10-39).

🏪 Import file	:S		×
Look in:	client	-	
FC_HBA1	_prt0.txt		
File <u>N</u> ame:	FC_HBA1_prt0.txt		
Files of <u>T</u> ype:	Text Documents (.txt)		-
			Import Cancel

Figure 10-39 Import Properties dialog box

- 4. Navigate to the location of the .properties, .csv, or .txt file from which you will import properties for the selected device.
- 5. Click the file, and click Import.
- 6. Click **OK** to close the window.

10.3.28 Importing properties in EFCM format

You can use this procedure to import properties in Enterprise Fabric Connectivity Manager (EFCM) format.

Follow these steps:

1. In the Configure Names dialog box, select **EFCM Format** and then select **Import** (Figure 10-40).

Name 🔻	VWW	I/MAC	Operational status	Туре	Description	
C1-0	1 0:00:	:00:05:1E:0C:1C:CC	Discovered	Port	HBA1 Port0	Remove
	20:00:	:00:05:1E:0C:1C:CC	Discovered	Node		- Itemove
	27:49:	00:05:1E:0C:1C:CC	Discovered	Virtual Port		
	10:00:	:00:05:1E:0C:1C:CD	Discovered	Port		
	2D:ED	:00:05:1E:0C:1C:CD	Discovered	Virtual Port		DCFM / FM Format
	00:05:	1E:AF:08:A0	Discovered	CNA		EFCM Format
	00:05:	1E:AF:08:A0	Discovered	CNA Port		CEM / EM Format
	20:37:	00:A0:B8:47:39:B0	Discovered	Remote Port		Evnort
	20:36:	00: A0: B8: 47: 39: B0	Discovered	Remote Port		Export
	22:99:	00:05:1E:AF:08:A0	Discovered	Virtual Port		
	_00:05:	1E:AF:08:A1	Discovered	CNA Port		• · · · · · · · · · · · · · · · · · · ·
etached W			Name			Add

Figure 10-40 Import from ECFM format

The Import dialog box displays (Figure 10-41).

韇 Import file	25		×
Look in:	lient	-	
	1_EF.txt		
	- Suprat		
File <u>N</u> ame:	FC_HBA1_EF.txt		
Files of Type:	Text Documents (.txt)		•
			Import Cancel

Figure 10-41 Import ECFM format dialog box

- 2. Navigate to the file and click Import.
- 3. Click OK.

Attention: The same procedure can be followed for importing adapter properties in DCFM or Fabric Manager (FM) format. We need to select DCFM/FM format in step 1 instead of ECFM format.

10.3.29 VLAN configuration

A Virtual LAN (VLAN) is a collection of network nodes that share the same broadcast domain regardless of their physical location or connection point to the network. A VLAN serves as a logical workgroup with no other physical barriers and allows users to share information and resources as though located on the same LAN.

Attention: VLAN configuration is a Windows-only feature.

There are three types of VLANS:

► Regular VLAN:

A regular VLAN is identified using a VLAN ID (with a range of 1-4094, where 0 is used for an untagged VLAN) and a VLAN name.

Passthru VLAN:

A Passthru VLAN has VLAN ID 0 and PASSTHRU as its VLAN Name. It can be created or deleted at any time and is treated as a regular VLAN; however, a Passthru VLAN is not editable.

► Port VLAN (PVID):

You create a Port VLAN using Windows Device Manager. The VLAN ID is assigned when it is created and the VLAN name is PORT VLAN. You cannot create, edit, or delete a Port VLAN using the Host Connectivity Manager (HCM).

VLANs: If a PORT VLAN exists in the VLAN configuration, you cannot perform any add, delete, or edit operations on any VLAN. In addition, you cannot view statistical information about any VLAN.

10.3.30 Adding a VLAN

You can access the VLAN Configuration dialog box by selecting an Ethernet port from the device tree. This procedure provides instructions about how to add a VLAN to an Ethernet port.

Attention: You can create a regular VLAN or a passthru VLAN only if a Port VLAN ID (PVID) does not exist. You cannot name a regular VLAN "PORT LAN" or "Passthru."

Follow these steps:

- 1. From the Ethernet port level, select an Ethernet port from the device tree.
- 2. Select **Configure** \rightarrow **VLAN Configuration** from the main menu.

or

Right-click an Ethernet port and select **VLAN Configuration** from the list (Figure 10-42).

El 🧕 localhost	4 Durant	<i>ti</i>			
ALX0417D0	B4	nies			
E- S AXLI0428E0	C3	Port Information			
E 00:05:16	Eth Revealed Back	Dev	Local Area Connection 5		
	Pon	t Type	eth and an		
	10.00.05.1E.AF.06.A0 Cur	toru MAC	00:05:1E:AF:08:AZ		
	10.00.00.05.1E.AF.06.A0 1ac	ID	4		
	22:99:00:05:1E:AF:08:A0	dware Path	12:00:02		
	Pofrach Stat	tus	Linkup		
≝ 🕑 00:05:	Eth	Log Level	Log Warning		
Master Log Applica	tion Log				Clear filter Refres
Master Log Applica Master log Filter	tion Log None		N / MAC	Category	Clear filter Refres
Master Log Applica Master log Filter Sr No 36	tion Log None Seventy Q INFO	VWV 10:0	N / MAC 0:00:05:1E:00:1C:CC	Category PORT	Clear filter Refres Sub Category Online
Master Log Applica Master log Filter Sr No 16 7	tion Log None Severity Q INFO Q INFO		N/MAC 0:00:051E:0C:1C:CC 0:00:051E:0C:1C:CC	Category PORT LPORT	Clear filter Refres Sub Category Online Online
Master Log Applica Master log Filter ir No 6 7 5	tion Log None Severity Q INFO Q INFO	www 10:0 10:0 10:0	N/MAC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC	Category PORT LPORT PORT	Clear filter Refres Sub Category Online Online Enabled
Master Log Applica Master log Filter Sr No 16 17 15 12	tion Log None Severity Q INFO Q INFO Q INFO Q INFO	VWV 10.0 10.0 10.0 10.0 10.0	N/MAC 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00	Category PORT LPORT PORT LPORT	Clear filter Refres Sub Category Online Enabled Offline
Master Log Applica Master log Filter Sr No 16 17 15 13 13	tion Log Severity Q INFO Q INFO Q INFO Q INFO A MINOR	VWV 10:0 10:0 10:0 10:0 10:0	N / MAC 0.00.05.1E.0C.1C:CC 0.00.05.1E.0C.1C:CC 0.00.05.1E.0C.1C:CC 0.00.05.1E.0C.1C:CC 0.00.05.1E.0C.1C:CC	Category PORT LOORT PORT LOORT PORT	Clear filter Refres Sub Category Online Online Enabled Offline Offline
Master Log Applica Master log Filter 36 37 35 32 33 34	tion Log None Severity ↓ NFO ↓ NFO ↓ NFO ↓ NFO ↓ NFO ↓ NFO ↓ NFO	VWV 10:0 10:0 10:0 10:0 10:0 10:0	N/MAC 000.051E0C1C:CC 000.051E0C1C:CC 000.051E0C1C:CC 000.051E0C1C:CC 000.051E0C1C:CC 000.051E0C1C:CC	Category PORT LPORT LPORT LPORT PORT	Clear filter Refres Sub Category Online Online Enabled Offline Offline Disabled
Master Log Applica Master Log Filter Sr No 66 17 15 15 12 13 13 14 19	tion Log None Severity Q INFO Q INFO Q INFO Q INFO Q INFO Q INFO Q INFO	Vwv 100 100 100 100 100 100 100 100	N/MAC 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00 0:00:05:1E:00:10:00	Category PORT LPORT LPORT PORT PORT PORT	Clear filter Refres Sub Category Online Online Enabled Offline Disabled Enabled
Master Log Applice Master log Filter Sr No 96 37 35 32 33 34 39 30	tion Log None Severity NFO NFO NFO NFO NFO NFO NFO NFO NFO NFO	VWV 100 100 100 100 100 100 100 100	N / MAC 0.00.551E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC 0.00.051E0C1CCC	Category PORT LOORT PORT LPORT PORT PORT PORT	Clear filter Refres Sub Category Online Enabled Offline Offline Disabled Enabled Online
Master Log Applica Master log Filter 36 37 35 33 34 44 39 30 31	tion Log None Severity NFO NFO NFO NFO NFO NFO NFO NF	VWV 100 100 100 100 100 100 100 100 100 10	N/MAC 00051E001000 00051E001000 00051E001000 00051E001000 00051E001000 00051E001000 00051E001000 00051E001000	Category PORT PORT PORT PORT PORT PORT PORT PORT	Clear filter Refres Sub Category Online Online Enabled Offline Disabled Enabled Online Online
Master Log Applica Master Log Filter Sr No 56 37 35 32 33 34 39 30 30 31 36	tion Log None Severity ↓ NFO ↓ NFO	VWV 100 100 100 100 100 100 100 100 100 10	N/MAC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC 000.051E0C1CCC	Category PORT LPORT PORT PORT PORT PORT PORT PORT LPORT LPORT	Clear filter Refres Sub Category Online Online Enabled Offline Disabled Enabled Online Online Offline
Master Log Applice Master Log Filter Sr No 96 97 95 93 93 94 93 93 94 93 93 94 88 90 91 86 87	tion Log None Severity NFO NFO NFO NFO NFO NFO NFO NF	WWV 100 100 100 100 100 100 100 100 100 10	N / MAC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC 000.05 1E00:10:CC	Category PORT LOORT PORT PORT PORT PORT PORT LPORT LPORT LPORT	Clear filter Refres Sub Category Online Online Enabled Offline Offline Disabled Enabled Online Online Offline Offline

Figure 10-42 Vlan Configuration Selection

The VLAN Configuration dialog displays (Figure 10-43).

VLAN ID	VLAN Name	
		Add
		Edit
		Remove
		1

Figure 10-43 VLAN Configuration dialog box

Click Add on the VLAN Configuration dialog (Figure 10-44). The Add VLAN dialog displays.

Nadd VLAN	×
Port MAC	00:05:1E:AF:08:A2
VLAN ID	101
VLAN Name	VL101
🗌 Create Pa:	ssthru
[OK Cancel Help

Figure 10-44 Add VLAN dialog box

- 4. Enter a VLAN identifier in the VLAN ID text box. The range is 1 to 4094.
- 5. Enter a VLAN name in the VLAN Name text box. The VLAN name must not exceed 31characters.
- 6. (Optional) Click the **Create Passthru** checkbox to designate the VLAN as a Passthru VLAN.
- 7. Click **OK**.

10.3.31 Editing a VLAN

You can access the VLAN Configuration dialog box by selecting an Ethernet port from the device tree. This procedure provides instructions about how to edit an existing VLAN. (You cannot edit a PORT VLAN or a Passthru VLAN.) Follow these steps:

- 1. From the Ethernet port level in the Tree View, select an Ethernet port from the device tree.
- 2. Select Configure \rightarrow VLAN Configuration from the main menu.

or

Right-click an Ethernet port and select VLAN Configuration from the list.

The VLAN Configuration dialog displays (Figure 10-45).

VLAN Con	figuration	×
VLAN ID	VLAN Name	7
101	VL101	Add
		Edit
9	<u>Cancel</u>	Apply <u>H</u> elp

Figure 10-45 Edit VLAN Configuration

- 3. Select a VLAN from the list.
- 4. Click Edit on the VLAN Configuration dialog.

The Edit VLAN dialog displays (Figure 10-46).

触 Edit VLAN	×
Port MAC	00:05:1E:AF:08:A2
VLAN ID	101
VLAN Name	VLan101
[QK <u>C</u> ancel <u>H</u> elp

Figure 10-46 Edit VLAN dialog box

- 5. Type a new name in the VLAN Name text box.
- 6. Click OK.

10.3.32 Removing a VLAN

You can access the VLAN Configuration dialog box by selecting an Ethernet port from the device tree. This procedure provides instructions about how to remove an existing VLAN.

- 1. From the Ethernet port level, select an Ethernet port from the device tree.
- 2. Select **Configure** \rightarrow **VLAN** Configuration from the main menu.

or

Right-click an Ethernet port and select **VLAN Configuration** from the list. The VLAN Configuration dialog displays (Figure 10-47).

VLAN ID	VLAN Name	
101	VLan101	Add
		Edit
		Remove

Figure 10-47 Remove VLAN Configuration

- 3. Select the VLAN for removal
- 4. Click Remove on the VLAN Configuration dialog.

A warning dialog displays (Figure 10-48).

HCM Mes	ssage X
⚠	The vlan(s) will be removed. The operation will take effect after you click OK or Apply on the Configuration dialog. Are you sure you want to continue?
	OK

Figure 10-48 Remove VLAN warning dialog box

5. Click **OK** to remove the VLAN from the configuration.

10.4 Monitoring

In the following topics we discuss the various monitoring capabilities.

10.4.1 Performance monitoring

The Host Connectivity Manager (HCM) Port Statistics window enables you to monitor the performance of the CNA and the traffic between the CNA and the LUNs. You can use the information to isolate and troubleshoot areas that impact application performance.

The components listed in Table 10-5 display statistics when the FCoE port node is selected.

Component	Statistics monitored
Local Host	 Port, Teaming
НВА	► Port
HBA Port	 Port FCP IM Module Fabric IOC QoS
CNA	► Port
CEE Port	 Port CEE FCP IM Module
Ethernet Port	 Eth IOC VLAN Eth
FCoE Port	FabricIOC
Logical Port and base port	 Logical Port
Virtual Port	Logical PortVirtual Port
Device (HCM does not have a statistics monitor for LUNs)	▶ Remote Port → Target IFCP IM

Table 10-5 Statistics monitored by component

10.4.2 Polling frequency rate

The faster the polling rate, the more quickly the HCM GUI receives indications from the host. However, faster polling rates consume more of your system's CPU and network resources and can therefore slow the system.

Controlling the polling frequency rate: To control port statistics polling, do one of the following actions from any of the Statistics dialog boxes:

1. To enter a Statistics dialog box, right-click the required component in the Tree View and select the statistics option from the menu as shown in Figure 10-49.

Elle View Discovery Conf □	figure <u>Monitor Tool H</u>	elp			
∃-					
 	i le	Properties LPOR	Ts		
AXU0428E003 AXU0428E003 AXU0428E003 AXU0428E003		FCoE Port infor	mation		
E 💽 00:05:1E:AF:08		State	Linkup		
	:A0	FCoE MAC	00:05:1E:AF:08:A0		
E 🚇 10:00:00:05	5:1E:AF:08: Refresh		10:00:00:05:1E:AF:08:A	40	
🕀 👰 10:00:0	30:05:1E:AF	N	20:00:00:05:1E:AF:08:A	40	
22:99:0	00:05:1E:AF Persistent	Binding I Classe	s Class-3	19481 202X 4000000 1945-1 C	- (D) 0000 Estemics I Comise D
🔄 ២ 00:05:1E:A	F:08:A2 Virtual Port	t ▶ vame	Brocade-1020 2.2.0.2	VVIN-303X4IGBURG / Windows Serve	er (K) 2006 Enterprise Service P
⊡	t:A1 Statistics	► F <u>a</u> bric	Statistics		
	EC-SP	IOC St	atistics bled		
	Enable Por	t F <u>C</u> oE S	Statistics		
	Tree		3		
	1100		1		
		Bandwidth	40 %		
Master Log Application Log	9				·····
Master Log Application Log Master log Filter None	9				Clear filter Refre
Master Log Application Log Master log Filter None Sr No	g Severity		WWN / MAC	Category	Clear filter Refre
Master Log Application Log Master log Filter None Sr No	9 Severity Q INFO		WWW / MAC 10:00:00:05:1E:0C:1C:CC	Category PORT	Clear filter Refre Sub Category Online
Master Log Application Log Master log Filter None Sr No 16	g Saverity (1) INFO (1) INFO		WWWI/MAC 10:00:00:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC	Category PORT LPORT	Clear filter Refre Sub Category Online Online
Master Log Application Log Master log Filter None Sr No 16 17	g Severity Q INFO Q INFO Q INFO		WWN/MAC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC	Category PORT LPORT PORT	Clear filter Refre Sub Category Online Online Enabled
Master Log Application Log Master log Filter None Sr No 16 15 15	9 9 10 10 10 10 10 10 10 10 10 10		WWW//MAC 10.00.00.05/E0C1C.CC 10.00.00.05/E0C1C.CC 10.00.00.51E0C1C.CC 10.00.00.51E0C1C.CC	Category PORT LPORT PORT LPORT	Clear filter Refre Sub Category Online Online Enabled Offline
Mester Log Application Log Master log Filter None Sr No 36 37 32 33	g ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO		WWN/MAC 10:00:00:51E0:10:00 10:00:00:51E0:10:00 10:00:00:51E0:10:00 10:00:00:51E0:10:00 10:00:00:51E0:10:00	Category PORT LPORT PORT LPORT PORT	Clear filter Refre Sub Category Online Enabled Offline Offline
Master Log Application Log Master log Filter None Sr No 36 37 35 32 33 34	Severity Q INFO Q INFO Q INFO MINO MINOR Q INFO		VWWN / MAC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC 10:00:00:05:1E:0C:1C:CC	Category PORT LPORT LPORT LPORT PORT PORT	Clear filter Refra Sub Category Online Enabled Offline Disabled
Master Log Application Log Master log Filter None Sr No 36 37 35 32 33 34 39	g Severity Q INFO Q INFO Q INFO A MINOR Q INFO Q INFO Q INFO		WWN/MAC 10.00.00.651E.0C.1C.CC 10.00.00.551E.0C.1C.CC 10.00.00.51E.0C.1C.CC 10.00.00.51E.0C.1C.CC 10.00.00.51E.0C.1C.CC 10.00.00.51E.0C.1C.CC	Category PORT LPORT LPORT LPORT PORT PORT PORT	Clear filter Refra Sub Category Online Online Enabled Offline Offline Disabled Enabled
Mester Log Application Log Mester log Filter None Sr No 56 37 35 32 33 34 39 30	3 Severity ① INFO ① INFO ① INFO ② INFO ③ INFO ③ INFO ③ INFO		WWN / MAC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC 10.00.00.551E0C1C.CC	Category PORT LPORT PORT LPORT PORT PORT PORT PORT	Clear filter Refr Sub Category Online Enabled Offline Offline Disabled Enabled Online
Mester Log Application Log Mester log Filter None Sr No 55 52 33 34 44 39 30 31	Severity Q INFO Q INFO Q INFO MINFO MINFO Q INFO Q INFO Q INFO Q INFO		VWWN/MAC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC 10.00.00.051E0C.1C.CC	Category PORT LPORT PORT PORT PORT PORT PORT LOORT	Clear filter Refra Sub Category Online Enabled Offline Disabled Enabled Online Online Online
Master Log Application Log Master log Filter None Sr No 36 37 35 32 33 34 39 30 31 35 32 33 34 39 30 30 31 35	g Severity ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO ① INFO		WWN/MAC 10.00.00.651E.0C1C.CC 10.00.00.551E.0C1C.CC 10.00.00.51E.0C1C.CC 10.00.00.51E.0C1C.CC 10.00.00.51E.0C1C.CC 10.00.00.51E.0C1C.CC 10.00.00.51E.0C1C.CC 10.00.00.51E.0C1C.CC	Category PORT LPORT PORT PORT PORT PORT PORT PORT LPORT LPORT	Clear titler Refro Sub Category Online Online Enabled Offline Disabled Enabled Online Online Online Offline

Figure 10-49 Statistics from HCM

The statistics dialog box for the selected element opens (Figure 10-50).

Fabric Statis	stics for Port : data 🗹 Pollin	10:00:00:05:11 g frequency in s	seconds 5	Start pollin	g <u>R</u> eset					
Date	Num FLOGIs	FLOGI respo	FLOGI accep	FLOGI accep	FLOGI reject	Unknown re	Allocation w	FLOGIs recei	Incoming FL	Ir
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
								000000000]
									<u>C</u> lose <u>H</u> e	slp

Figure 10-50 Port Statistics dialog box

Statistics: The statistics gathered and displayed will vary depending on which component and element are selected.

- 2. Click the Start Polling box to manually poll the port statistics.
- 3. Type the polling rate in the **Polling Frequency in Seconds** text box. The range is between 5 and 3600 seconds. The default is 5 seconds.
- 4. Click the Stop Polling box to stop port statistics polling.
- 5. Check the Keep Running Data check box to see the trend.

10.4.3 Resetting statistics

Follow these steps:

1. Click the **Reset** button on any of the Statistics dialog boxes (Figure 10-51).

Date	Num FLOGIs	FLOGI respo	FLOGI accep	FLOGI accep	FLOGI reject	Unknown re	Allocation w	FLOGIs recei	Incoming FL	In
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
ri Oct 22 09	2	0	0	2	0	0	0	0	0	2
ri Oct 22 09	2	0	0	2	0	0	0	0	0	2

Figure 10-51 Reset the statistics

A warning dialog displays (Figure 10-52).

Date	Num FLOGIs	FLOGI respo	FLOGI accep	FLOGI accep	FLOGI reject	Unknown re	Allocation w	FLOGIs recei	Incoming FL	Int
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2
Fri Oct 22 09	2	0	0	2	0	0	0	0	0	2

Figure 10-52 Reset Statistics warning message

2. Click Yes.

All of the statistics are reset to 0.

10.4.4 Master Log

The Master Log Properties dialog box, described in Table 10-6, displays a list of all events that have occurred. Event monitoring enables early fault detection and isolation on a selected adapter. You can filter the events based on the user-defined criteria shown in Figure 10-54 on page 465.

Field	Description
Filter button	Click to launch the Master Log Filter dialog box.
Clear Filter button	Click to clear the master log filter option set.
Sr No column	Displays a numbering sequence in ascending order.
Severity column	Displays the event severity (informational, minor, major, or critical).
WWN/MAC column	Displays the world wide name (WWN) or the media access control (MAC) address of the device on which the event occurred.
Category column	Displays the category of event; for example, Rport or ITNIM.
Subcategory column	Displays the subcategory of the main category.
Description column	Displays a brief description of the event.
Date/Time column	Displays the date and time when the event occurred.

Table 10-7 describes the icons that represent the four event types.

Table 10-7 HCM Master Log events

Description

Critical-level messages indicate that the software has detected serious problems that will eventually cause a partial or complete failure of a subsystem if not corrected immediately; for example, a power supply failure or rise in temperature must receive immediate attention.

Major messages represent conditions that do not impact overall system functionality significantly. For example, timeouts on certain operations, failures of certain operations after retries, invalid parameters, or failure to perform a requested operation.

Minor messages highlight a current operating condition that should be checked or it might lead to a failure in the future. For example, a power supply failure in a redundant system relays a warning that the system is no longer operating in redundant mode and that the failed power supply needs to be replaced or fixed.

Information-level messages report the current non-error status of the system components; for example, the online and offline status of a fabric port.

10.4.5 Filtering event log entries

Event filtering enables you to block events based on user-defined criteria (severity or type of log). Events that have been filtered out do not display in the Master Log:

1. Click the **Filter** button in the Master Log section of the bottom pane of the HCM main window (Figure 10-53).

🏪 Host Connectivity Ma	anager						
Eile ⊻iew Discovery g	<u>Configure Monitor Tool</u>	Help					
🗉 🧶 localhost	1	Properties LPORTs					
🖅 < ALX0417D084		E FCoF Port informa	tion				
E 🛒 AXU0428E003		State	Linkup				
E- 💽 00:05:1E:A	F:08:A0	FCoE MAC	00:05:1E:AF:08:A0				
E- 🧕 10:00:0	00:05:1E:AF:08:A0	Port WWWN	10:00:00:05:1E:AF:08:A0				
E 💽 10	:00:00:05:1E:AF:08:A0	Node VWVN	20:00:00:05:1E:AF:08:A0				
22	22:99:00:05:1E:AF:08:A0		Class-3				
	1E:AF:08:A2	Symbolic Name	Brocade-1020 2.2.0.2 V	MN-303X4IGB0R8 Windows Serve	r (R) 2008 Enterprise Service Pac		
• 00:05:1E:AF:08:A1		IOC ID	2				
			12:00:00				
		Port Log	Enabled				
		FCoE Information					
		Priorities	3				
		PGID	1				
		Bandwidth	40 %		•		
Master log Filter No	ne				Clear filter Refresh		
Sr No	Severity		AMIN / MAC	Category	Sub Category		
96	😲 INFO	-	0:00:00:05:1E:0C:1C:CC	PORT	Online 🔺		
97	😲 INFO	•	0:00:00:05:1E:0C:1C:CC	LPORT	Online		
95	🛈 INFO	•	0:00:00:05:1E:0C:1C:CC	PORT	Enabled		
92	INFO		0:00:00:05:1E:0C:1C:CC	LPORT	Offline		
93	A MINOR		0:00:00:05:1E:0C:1C:CC	PORT	Offline		
94	INFO		0:00:00:05:1E:0C:1C:CC	PORT	Disabled		
89	INFO		0:00:00:05:1E:0C:1C:CC	PORT	Enabled		
90	INFO		0:00:00:05:1E:0C:1C:CC	PORT	Online		
91	 INFO 		0:00:00:05:1E:0C:1C:CC	LPORT	Online		
86	 INFO 		0:00:00:05:1E:0C:1C:CC	LPORT	Offline		
87	A MINOR		0:00:00:05:1E:0C:1C:CC	PORT	Offline 👻		
		666666666666666666666666666666666666666	000000000000000000000000000000000000000				
			User: admin Age	nt: localhost Port: 34568 Last	Updated: Fri Oct 22 09:27:04 PDT 2010		
l.							

Figure 10-53 Filter Log Entries

The Master Log Filter dialog box displays (Figure 10-54).

🍨 Master Log Fil	lter			×
Event Time				
🗹 From		Oct 12 2010 03:5	56:05 PM	
🗹 To		Oct 21 2010 03:5	56:05 PM	
Event Severity				
🗹 Level	🗌 Critical	🖌 Major	🗾 Minor	Information
Category				
🗹 Category		ADAPTER	-	
WWN / MAC				
			T	
		[<u>O</u> K <u>C</u> ance	I <u>A</u> pply <u>H</u> elp

Figure 10-54 Master Log Filter dialog box

2. Filter the events using one or a combination of the criteria shown in Figure 10-54.

Events: The Category is the type of event; for example, an adapter, port, or audit.

3. Click Apply to save your changes, or click Cancel to exit the window.

or

Click **OK** to save the changes and exit the window.

10.4.6 Application log

The application log displays all application-related informational and error messages, as well as the following attributes (Figure 10-55):

- Date and time the message occurred
- Severity of the message
- Description of the message
- ► The agent IP address

🇣 Host Connectivity Manager			
<u>File ⊻iew D</u> iscovery <u>C</u> onfigure <u>M</u> onitor <u>T</u> ool	Help		
□ e vew biscovery configure worker □ we biscovery configure worker	Properties LPORTS FCOE Port information State FCoE MAC Port WWN Node VWWN Supported Classes Symbolic Name IOC ID Hardware Path	Linkup 00:05:1E:AF:08:A0 10:00:00:05:1E:AF:08:A0 20:00:00:05:1E:AF:08:A0 Class-3 Brocade-1020 2.2.0.2 WIN-303X4IGB0F 2 12:00:00	18 Windows Server (R) 2008 Enterprise Service Pac
	Port Log FCoE Information Priorities	Enabled	
	PG ID Bandwidth	1 40 %	
Master Log Application Log			
Date/Time 💙	Severity		Description
10/22/2010 09:37:04	INFO		Start discovery
10/22/2010 09:37:04	INFO		Non-phased discovery completed su
10/22/2010 09:37:04	😲 INFO		Discovery did not find new info for h
10/22/2010 09:36:04	😲 INFO		Start discovery
10/22/2010 09:36:04	😲 INFO		Non-phased discovery completed su
10/22/2010 09:36:04	😲 INFO		Discovery did not find new info for h
10/22/2010 09:35:04	😲 INFO		Start discovery
10/22/2010 09:35:04	INFO		Non-phased discovery completed su
10/22/2010 09:35:04	INFO		Discovery find new info for host: loc
10/22/2010 09:34:04	INFO		Start discovery
10/22/2010 09:34:04	😲 INFO		Non-phased discovery completed su 👻
		User: admin Agent: localhost I	Port: 34568 Last Updated: Fri Oct 22 09:37:04 PDT 2010

Figure 10-55 HCM Application Log

10.4.7 Syslog support

Syslog forwarding is the process by which you can configure the Host Connectivity Manager (HCM) agent to send Syslog messages to other computers through port 514. You can configure the HCM agent to forward events to a maximum of three Syslog destinations. These events will display in the operating system logs.

10.4.8 Opening the Syslog Server Configuration dialog box

Follow these steps:

- 1. Select an adapter from the device tree.
- 2. Select **Configure** \rightarrow **Syslog** from the main menu.

The Syslog Server Configuration dialog box displays (Figure 10-56).

🗣 Syslog Server Conf	iguration	×
Host name / IP address	10.18.228.36	Add
Host Na	me/IP Address	
		Remove
Set this IP in all disc	overed agents in future	
	OK Cancel Apply	Help

Figure 10-56 Syslog Server Configuration dialog box

- 3. Enter the host name or IP address of the destination device into the *Host Name/IP Address* field.
- 4. Click Add to register the host as a Syslog destination.
- 5. Click **OK** to close the dialog box.

10.4.9 Removing a host server

Follow these steps:

- 1. Select an adapter from the device tree.
- 2. Select **Configure** \rightarrow **Syslog** from the main menu.

The Syslog Server Configuration dialog box displays (Figure 10-57).

🍡 Syslog Server Configurati	on 🔀
Host name / IP address	Add
Host Name/ IP A	ddress
10.18.238.36	Remove
	Teniove
Set this IP in all discovered	agents in future
<u>o</u> k	Cancel Apply Help

Figure 10-57 Syslog Server remove dialog box

- 3. Select the Server from the list.
- 4. Click **Remove** to remove the host as a Syslog destination.
- 5. Click **OK** to close the dialog box.

11

Virtual Fabrics

Virtual Fabrics is an architecture to virtualize hardware boundaries. Traditionally, SAN design and management is done at the granularity of a physical switch. The Virtual Fabrics feature allows SAN design and management to be done at the granularity of a port.

In this chapter we discuss Virtual Fabrics and provide examples of how to implement this feature.

11.1 IBM/Brocade Virtual Fabric

In this section we explain what the IBM/Brocade Virtual Fabrics feature is, and how it is configured to an operational state in a live environment.

11.1.1 Virtual Fabrics introduction

IBM/Brocade Virtual Fabrics allows IT organizations to manage IT assets by corporate function, utilize different permission levels for SAN administrators, and maintain required levels of data and fault isolation without increasing cost and complexity. In addition, Virtual Fabrics can reduce hardware costs by optimizing resource utilization.

With the release of FOS v6.2, organizations can utilize an ANSI standard-based implementation of Virtual Fabrics. The Virtual Fabrics feature includes two new capabilities: Logical switches and logical fabrics, both available in the base FOS firmware.

Physical switches can be partitioned into independently managed logical switches, each with their own data, control, and management paths. In addition, they can be configured in any mode, including McDATA Fabric or McDATA Open Fabric modes.

Logical switches can allocate fabric resources "by the port" rather than by the switch. They also provide a way to simplify charge-back for storage by customer, department, or application while cost-effectively consolidating SAN resources. Because logical switches do not need to be enabled on every switch in a SAN, deployment is simple and non-disruptive in existing environments.

11.1.2 Logical switches and logical fabrics

Next we describe some of the capabilities of these components.



Figure 11-1 introduces logical switches and logical fabrics.

Figure 11-1 Logical switches and logical fabrics

Layer-2 traffic isolation is available with a special eXtended ISL (XISL) shared by multiple logical fabrics, or with dedicated ISL connections between Logical switches in the same logical fabric. Both ISL and XISL connections can use front ports or Inter-Chassis Link (ICL) connections with frame trunking and Dynamic Path Selection (DPS) for full bandwidth utilization. The logical fabrics capability supports Integrated Routing at Layer 3. Routing connections attach an integrated backbone fabric to multiple edge fabrics. Zoning allows traffic to flow between specific devices in any edge fabric.

Virtual Fabrics is available on 8 Gbps products that are "Virtual Fabrics-capable" such as the IBM SAN768B, IBM SAN384B, IBM SAN80B and the IBM SAN40B switches. For investment protection, products that are not Virtual Fabrics capable (such as earlier 2 and 4 Gbps FOS and M-EOS products) can seamlessly connect to Virtual Fabrics-capable products without requiring a reconfiguration of the existing switches. See Table 11-1.

Platform	Maximum Logical Switches*/Chassis
SAN768B	8
SAN384B	8
SAN80B-4	4
SAN40B-4	3
SAN24B-4	Currently not supported

 Table 11-1
 Supported logical switch creation limits

*Numbers include the Default Switch and Base Switch.

Attention: On the SAN80B-4 and the SAN40B-4, the Default Switch and Base Switch can be the same.

To simplify Virtual Fabrics management, organizations can use DCFM. After they are created, Logical switches and fabrics are managed the same as their physical counterparts. Alternatively, organizations can use the standard FOS CLI to enter commands or script configuration and management operations for Virtual Fabrics.

The Virtual Fabrics (VF) feature is easy to set up and simple to manage for "port-level" partitioning of physical switches into independent logical switches. It does not reduce fabric or chassis scalability, preserving ROI and seamlessly supporting advanced FOS features such as frame trunking, DPS, Fibre Channel Routing, Adaptive Networking, Top Talkers, Access Gateway, Access Gateway trunking, and FCIP for extension.

11.2 What Virtual Fabrics are

In this section we discuss the different features of Virtual Fabrics. For more detailed information see the Fabric OS version 6.4.+ Administrators Guide only available through the Partner Network website at (navigate to Product Documentation and register or login):

http://www.brocade.com/data-center-best-practices/resource-center/index
.page

This section describes the logical switch and logical fabric features.

The Virtual Fabrics suite consists of the following specific features:

- Logical switch
- Logical fabric
- Device sharing

Virtual Fabrics is supported on the following platforms:

- IBM System Storage SAN40B
- IBM System Storage SAN80B
- ► IBM System Storage SAN384B
- IBM System Storage SAN768B

Other non-Virtual Fabric capable switches can connect to Virtual Fabrics without any reconfiguration.

11.2.1 Logical switch

A logical switch is the fundamental component of a Virtual Fabric. When enabled on a VF-capable switch, Virtual Fabrics allows users to divide the switch into multiple logical switches. Ports in the physical switch can be dynamically allocated to any logical switch in the chassis and can be reallocated to Logical switches as needed. Port, switch, and fabric management are performed in the same way as for physical switches or fabrics.

Default logical switch

The default logical switch (default switch) is automatically created when Virtual Fabrics is enabled on a VF-capable switch. Initially, the default switch contains all the physical switch resources and ports. For Director switches, the ports on any blade inserted into the chassis initially belong to the default switch. Ports required by user defined logical switches are dynamically allocated from the default switch by the chassis administrator. As long as the Virtual Fabrics feature is enabled, there is a default switch, even when all ports in the default switch have been allocated to other logical switches. The default switch supports all the same port types as the physical switch.

Base switch

Base Switch is a logical switch used to communicate among different logical switches. The legacy EX_port is connected to the base logical switch. Also, Inter-Switch Links (ISLs) connected to the Base Switch are used to communicate among different fabrics. The default logical switch supports E_ and EX_ports.

Logical Switch

Logical Switch is a collection of zero or more ports, that act as a single Fibre Channel (FC) switch. When Virtual Fabrics is enabled on the chassis, there is always at least one default logical switch instance. You must assign each logical switch (default or general) in the same chassis to a different logical fabric. The logical switch supports all E_ and F_ports.

Attention: EX_ports are only allowed on the Base Switch.

11.2.2 Logical fabric

The Fabric ID (FID) assigned to a logical switch identifies its traffic as belonging to a specific logical fabric. Logical switches in other chassis with the same FID can join into a logical fabric. Logical switches within a logical fabric can be directly connected with ISLs (front ports and/or ICL connections), supporting frame trunking and DPS. As is the case in a physical fabric, the ISL connection carries traffic for a single fabric. An alternative to dedicated ISL connections at Layer 2 uses the base fabric to carry traffic for multiple logical fabrics on the same physical connection, maintaining fabric isolation.

11.2.3 ISL sharing

When a base switch is connected to another base switch, an XISL connection is created. When logical switches with the same FID are configured to use the XISL, the base switches automatically create a Logical ISL (LISL) within the XISL. The LISL isolates traffic from multiple fabrics: each LISL is dedicated to traffic for a single fabric. Think of it this way: the physical XISL connection between two base switches automatically forms an LISL "tunnel" dedicated to the traffic to and from logical switches, as shown by the dashed lines in Figure 11-21 on page 497.

11.2.4 Administrative Domains

An Administrative Domain (Admin Domain or AD) is a logical grouping of fabric elements that defines which switches, ports, and devices can be viewed and modified. An Admin Domain is a filtered administrative view of the fabric.

Basically Admin Domains define which users can manage which devices, hosts, and switches.

Important: Virtual Fabrics and Admin Domains are mutually exclusive and are not supported at the same time on a switch:

- ► To use Admin Domains, you must first disable Virtual Fabrics.
- ► To use Virtual Fabrics, you must first delete all Admin Domains.

11.2.5 User accounts

Table 11-2 lists the predefined user accounts offered by Fabric OS available in the local switch user database.

Account name	Logical fabric	Description
admin	LF1-128 home: 128	Observe-modify permission.
factory	LF1-128 home: 128	Reserved.
root	LF1-128 home: 128	Reserved.
user	LF1-128 home: 128	Observe-only permission.

Table 11-2 Default local user accounts

The password for all default accounts should be changed during the initial installation and configuration for each switch.

11.3 Configuring Virtual Fabrics

In this section we present a limited set of instructions and commands for configuring and managing Virtual Fabrics. For complete explanations, read the Fabric OS version 6.2.0 Administrators Guide and Fabric OS Command Reference Manual available only available through the Partner Network website at (navigate to Product Documentation and register or login):

http://www.brocade.com/data-center-best-practices/resource-center/index
.page

Virtual Fabrics (VF) can be managed with Data Center Fabric Manager (DCFM), in this section we demonstrate how to configure VF using the standard Fabric OS v6.4.+ Command Line Interface (CLI), and DCFM.

11.3.1 Changing the context to a different logical switch

When Virtual Fabric is enabled, you want to move between the defined virtual switches. This is done using either Webtools or the **setcontext** command from CLI.

This is how we did it:

- 1. Connect to the physical chassis and log in using an account assigned to the admin role.
- 2. Set the context to the logical switch you want to manage, if you are not already in that context. In Example 11-1 we show how to switch to FID 20.

Example 11-1 To change the logical switch context to FID 20:

```
IBM SAN384B 27:admin> setcontext 20
```

11.3.2 Enabling Virtual Fabrics

Virtual Fabrics is disabled by default on switches that you *upgrade* to Fabric OS v6.2.0 or later. Virtual Fabrics is enabled by default on a new chassis. Before you can use the Virtual Fabrics features, such as logical switch and logical fabric, you must enable Virtual Fabrics.

Attention: When you enable Virtual Fabrics, the CPs are rebooted and all EX_Ports are disabled after the reboot.

DCFM

To enable virtual fabrics (VF) all you need is to do is to select the switch that VF is going to be configured on, and then right click to get the drop down menus for the switch and select the Enable Virtual Fabric option, as shown in Figure 11-2.

Requirement: SNMP V3 must be enabled and configured for management of Virtual Fabrics,


Figure 11-2 Enable Virtual Fabric

The warning message will display, shown in Figure 11-3. Read the warning message and select the **OK** button.



Figure 11-3 VF warning message

When this operation is completed and the reboot is done, you will see a **V** symbol above the VF enabled switch, and there will be a chassis group in the product list, as shown in Figure 11-4.



Figure 11-4 VF enabled switch

CLI

To perform management of virtual fabrics, you must have admin privileges on the switch chassis.

Example 11-2 checks whether Virtual Fabrics is enabled or disabled and then enables it.

Example 11-2 Enabling Virtual Fabrics

<pre>IBM_SAN384B_27:admin> fosconfig FC Routing service:</pre>	show enabled
iSCSI service:	Service not supported on this Platform
iSNS client service:	Service not supported on this Platform
Virtual Fabric:	disabled
Ethernet Switch Service:	disabled

IBM_SAN384B_27:admin> fosconfig --enable vf
WARNING: This is a disruptive operation that requires a reboot to take
effect.
All EX ports will be disabled upon reboot.
Would you like to continue [Y/N]: y

11.3.3 Disabling Virtual Fabrics

In this section we discuss how to disable Virtual Fabrics.

DCFM

To disable Virtual Fabrics, select the switch in the chassis group displayed in the product list, right-click to open the drop down menu options and select the option to disable Virtual Fabrics, shown in Figure 11-5.



Figure 11-5 Disable Virtual Fabric

The same warning message is shown as in enabling the VF, as shown in Figure 11-3 on page 477. Read the warning and select the **OK** button if applicable.

CLI

Example 11-3 checks whether Virtual Fabrics is enabled or disabled and then disables it.

Example 11-3 Disabling Virtual Fabrics

```
IBM_SAN384B_27:admin> fosconfig --show
FC Routing service: disabled
iSCSI service: Service not supported on this Platform
iSNS client service: Service not supported on this Platform
Virtual Fabric: enabled
IBM_SAN384B_27:FID128:admin> fosconfig --disable vf
WARNING: This is a disruptive operation that requires a reboot to take
effect.
Would you like to continue [Y/N]: y
VF has been disabled. Your system is being rebooted.
```

Attention: Enabling and disabling Virtual Fabrics is disruptive and will reboot the switch.

11.3.4 Logical switch management

DCFM is used to manage logical switches after Virtual Fabrics has been enabled. From the DCFM Configure drop-down menu, select the **Logical Switches** option, shown in Figure 11-6.



Figure 11-6 Logical switches DCFM

This opens the Logical Switches management window, shown in Figure 11-7. When Virtual Fabrics is enabled, a base switch is automatically created with an FID of 128, the same as the backbone switch, and all ports in the switch are placed into this base switch.

		.15							
orts					Existing Logical Switches				
Slot / Port	User Po	Port Address	FID N	Find	Switch / Ports	Chassis	FID	Port Number	New Fabric
/0	0	100000	128 Di 🔺	>	🗉 🤳 Discovered Logical Switches			-	
/1	1	100100	128 🥳	_	— 🌭 256B_M48			35	New Switch
/2	2	100200	128		🗈 🐟 Back Bone_SAN384B		128	38	E-44
/3	3	100300	128		🖻 🤪 IBM_SAN384B_27	ibm_dcx4s_213	128		Euit
/4	4	100400	128 M		20:00:00:05:1E:94:3	,		1/0	Delete
/5	5	100500	128 M		- 🕑 20:01:00:05:1E:94:3	/		1/1	
/6	6	100600	128 M		- 🕑 20:02:00:05:1E:94:3	/		1/2	
17	7	100700	128 M		- 🕑 20:03:00:05:1E:94:3	/		1/3	
/8	8	100800	128 🗸		- 🕑 20:04:00:05:1E:94:3	/		1/4	
/9	9	100900	128 🗸		- 🕑 20:05:00:05:1E:94:3	/		1/5	
/10	10	100a00	128		- 🕑 20:06:00:05:1E:94:3	/		1/6	
/11	11	100b00	128		- 20:07:00:05:1E:94:3	,		1/7	
/12	12	100c00	128 W		20:08:00:05:1E:94:3	,		1/8	
/13	13	100d00	128 W		- 0 20:09:00:05:1E:94:3	,		1/9	
/14	14	100e00	128		- 🕑 20:0A:00:05:1E:94:3	3.		1/10	
/15	15	100f00	128		- 20:0B:00:05:1E:94:3	i <i>,</i>		1/11	
/16	16	101000	128 D 🔻		- 20:0C:00:05:1E:94:3	i,		1/12 💌	
	888888888		•			 E000000000000000000000000000000000000			1

Figure 11-7 Logical Switch management

11.3.5 Modifying the base switch

To modify the base switch, select the base switch from the Logical Switches window and select the **Edit** button. This will allow the modification of all base switch parameters, as shown in Figure 11-8.

Edit Properties					×
Fabric Switch					
Logical Fabric ID	128	Б	Base Switch		
256 Area Limit	Disable 💌	в	Base Fabric for Transport		
R A TOV	10000				Sequence Level Switching
E D TOV	2000				Disable Device Probing
WAN TOV	0				Per-frame Routing Priority
Maximum Hops	7				Suppress Class F Traffic
BB Credit	16				Long Distance Fabric
Data Field Size	2112				
Interoperability Mode	Brocade Native 🔻				
				Oł	Cancel Help

Figure 11-8 Edit Properties

After the configuration edit is complete, select the **OK** button from the Edit screen and then select the **OK** button from the Logical Switches management window.

This action opens a confirmation window. Read the message on the window and select **OK**. This performs a configuration operation and displays the progress of the command under the status field, as shown in Figure 11-9.

accept them. War not perform the c	rning: Almost any changes to hanges.) logical switches can disrupt da	ata traffic in the	fabric. Click Start f	to continue, or Cancel to
Ports are disabled	l before moving them from or	ne Logical switch to another.			
Re-Enable po	rts after movi⊓g them				
Unbind Port A	ddresses while moving them	n			
Jetailed Changes	Description	Name	To FID	From FID	Status
Chassis 📥		IDM CANODAD OT ME			Success
Chassis 🔺 10.18.228.27	Configure Switch	IDIVI_SAN304D_27_VF			
Chassis A 10.18.228.27 Status	Configure Switch	IDM_SAN3040_27_VF		, 	
Chassis A 10.18.228.27 Status Chassis: 10.18.22 Completed	Configure Switch 28.27, Partition FID: 128, Task	C Update fabric properties, was	completed suc	ccessfully	

Figure 11-9 Confirmation window

11.3.6 Creating a logical switch

When the logical switch is created, it is automatically enabled and it has no ports assigned.

To create a logical switch, open the Logical Switches view, and select the **New Fabric** option. This action brings up the New Logical Fabric template. Select the options required for the new fabric, shown in Figure 11-10, and when done, select the **OK** button.

New Logical Fabric Te	mplate						×
Fabric Switch							
Logical Fabric ID	1 6	Base Switch					
	r E	Base Fabric for Transport					
R A TOV	10000			Seq	uence Le	vel Swit	ching
E D TOV	2000			Disa	ble Devic	e Probin	g
WAN TOV	0			Per-	frame Ro	uting Prie	ority
Maximum Hops	7			Sup	press Cla	ss F Tra	ffic
BB Credit	16 🚔			Long	g Distance	e Fabric	
Data Field Size	2112						
Interoperability Mode	Brocade Native 💌						
			ок		Cancel	н	elp

Figure 11-10 New Logical Fabric Template

The new logical fabric displays in the Logical Switches window. Select the new fabric and then select the **New Switch** button, as shown in Figure 11-11

hassis	ibm_dcx4s_21	3 🕶								
Ports					Existing	Logical Switches				
Slot / Port	User Port #	Port Address	FID	Find	Switch	/ Ports	Chassis	FID	Port Numbe	New Fabr
1/0	0	100000	128	12	E .	Discovered Logical Switches				_
1/1	1	100100	128		11 F	less SAN384B-10:00:00:05:1e	:94:			New Swit
1/2	2	100200	128			line 256B_M48				C-0
1/3	3	100300	128			ledge_IBM_B32				Edit
1/4	4	100400	128		Þ	lessentime Sansada - 10:00:00:05:1e	:94:	128		Delete
1/5	5	100500	1281			IBM_SAN384B_27_V	F ibm_dcx4s_213	128		
1/6	6	100600	1281			Log SAN384B-10:00:00:05:1e	:94:			
1/7	7	100700	1281			log NewFabric		1		
1/8	8	100800	128		- J	Undiscovered Logical Switch	es			
1/9	9	100900	128							
1/10	10	100a00	128							
1/11	11	100b00	128							
1/12	12	100c00	128							
1/13	13	100d00	128							
1/14	14	100e00	128							
1/15	15	100f00	128							
1/16	16	101000	1281							
1/17	17	101100	1281							
1/18	18	101200	128							
1/19	19	101300	128							
1/20	20	101400	1281	-						
17.21	21	101500	1281	-						

Figure 11-11 Add new switch

The new logical switch dialog frame opens. Configure the new logical switch as required by modifying the fields as shown in Figure 11-12.

New Logical Switch			×
Fabric Switch			
Logical Fabric ID	1	Base Switch	
256 Area Limit	Disable 💌	Base Fabric for Transport	
R A TOV	10000		Sequence Level Switching
E D TOV	2000		Disable Device Probing
WAN TOV	0		Per-frame Routing Priority
Maximum Hops	7		Suppress Class F Traffic
BB Credit	16		Long Distance Fabric
Data Field Size	2112		
Interoperability Mode	Brocade Native 🔻		
			OK Cancel Help

Figure 11-12 New logical switch Fabric parameters

Under the Switch option, you can change the switch name and domain ID, as shown in Figure 11-13.

New Logical Switch	×
Fabric Switch	
Name ITSO_SW2	
Preferred Domain ID 25	
	OK Cancel Help

Figure 11-13 New logical switch

Select the **OK** button to add the switch.

From the logical switch window, select the new logical switch and add the ports that are required for this switch by selecting them and adding them to the newly created logical switch as shown in Figure 11-14. This process can be used at any time to add or delete ports from the logical switch.

Chassis	ibm_dcx4s_21	3 🕶								
Ports					Existing	Logical Switches				
Slot / Port	🔺 User Port #	Port Address	FID	Find	Switch	/ Ports	Chassis	FID	Port Numbe	New Fabr
1/0	0	100000	1281	. >	i 🗉 🤳	Discovered Logical Switches				
1/1	1	100100	128		all i F	less SAN384B-10:00:00:05:1e:94	4			New Swite
1/2	2	100200	128		all i F	lacktrian 256B_M48				F .13
1/3	3	100300	128			ledge_IBM_B32				Ealt
1/4	4	100400	128			less SAN384B-10:00:00:05:1e:94	4:	128		
1/5	5	100500	128			IBM_SAN384B_27_VF	ibm_dcx4s_213	128		
1/6	6	100600	128		9	AN384B-10:00:00:05:1e:9	4:			
1/7	7	100700	1281			lewFabric		1		
1/8	8	100800	128			🖻 🥞 10.18.228.27	ibm_dcx4s_213	1		
1/9	9	100900	1281			MCC_A_Core1_DC)	<		1/4	
1/10	10	100a00	128			MCC_A_Core1_DC)	<		1/5	
1/11	11	100b00	128			MCC_FabricA_01 (i	1		1/6	
1/12	12	100c00	128			MCC_FabricA_01 (i	1		1/7	
1/13	13	100d00	128			WMMCC SAN02A			1/8	
1/14	14	100e00	128			Undiscovered Logical Switches				
1/15	15	100f00	128							
1/16	16	101000	1281							
1/17	17	101100	1281							
1/18	18	101200	128							
1/19	19	101300	128							
1/20	20	101400	1281							
1/21	21	101500	1281	-						

Figure 11-14 Add ports to logical switch

Now select the **OK** button to process the new configuration. The Logical Switch Change Confirmation and Status window displays. Read the information in the window and then select the **Start** button to complete the addition of the logical switch, as shown in Figure 11-15.

Logical Switch Cha	ange Confirmation and Sta	tus			×
The following Logical accept them. Warning not perform the chan Ports are disabled be Re-Enable ports a	I switch changes are ready to g: Almost any changes to logic ges. fore moving them from one Log after moving them	be sent to the c al switches car jical switch to a	hassis switches n disrupt data trat nother.	below. Review the char fic in the fabric. Click Ste	nges carefully before you nt to continue, or Cancel to
Unbind Port Addr	esses while moving them				
Detailed Changes					
Chassis 🔺	Description	Name	To FID	From FID	Status
10.18.228.27	Create Switch [FID: 1]	ITSO_SW2			Not Started
Status					
				Sta	rt Cancel Help

Figure 11-15 Logical switch change confirmation and status

The status bar displays the status of the activation. It will change to *Successful* when completed, and the newly created fabric and switch will display in DCFM, as shown in Figure 11-16.



Figure 11-16 DCFM logical switch

11.3.7 Deleting a logical switch

To delete a logical switch, open the Logical Switches configuration window, select the switch you want to delete, and select the **Delete** button. A warning message will pop up. Read the warning and click the **Yes** button, as shown in Figure 11-17.

	II_UCX45_21	3 🗸								
Ports					Existing	Logical Switches				
Slot / Port 🔺	User Port #	Port Address	FID	Find	Switch	/ Ports	Chassis	FID	Port Numbe	New Fabri
/0	0	100000	128 🔺	\geq	E 🤳	Discovered Logical Switches				
/1	1	100100	128 🧭	\sim		left 256B_M48				New Swite
/2	2	100200	128			ledge_IBM_B32				E-13
/3	3	100300	128		D	less SAN384B-10:00:00:05:1e:9	4:	128		Eart
/4	4	19fec0	1			- 10 IBM_SAN384B_27_VF	ibm_dcx4s_213	128		Delete
/5	5	19fe80	1			SAN384B-10:00:00:05:1e:9	4:	1		0.0.010
/6	6	19fe40	1			ITSO SW2	ibm_dcx4s_213	1		
/7	7	19fe00	1	DCFM	Messag	je			×	
/8	8	19fdc0	1							
/9	9	100900	128		Deletir	ng the following logical switch w	ill assign all its ports to [Default Logical	switch	
/10	10	100a00	128	-	🌙 and de	elete the configured logical switc	h. Do you want to conti	nue?		
/11	11	100b00	128							
/12	12	100c00	128			<u>Y</u> es	No			
/13	13	100d00	128							
/14	14	100e00	128							
/15	15	100f00	128							
/16	16	101000	1281							
/17	17	101100	1281							
/18	18	101200	128							
/19	19	101300	128							
/ 20	20	101400	128							

Figure 11-17 Delete switch

When the delete is completed, then select the **OK** button to activate the new configuration.

Attention: The default logical switch cannot be deleted.

11.3.8 Displaying the logical switch configuration

Example 11-4 shows the configuration created using the CLI.

IBM_SAM	\384B_2	27_VF:	FID128:a	admin>	lscfg	Isha	0W	
Created	d swite	ches:	128(ds)) 1				
Slot	1	2	3	4	5	6	7	8
Port								
0	128		128		1	128	128	128
1	128	l	128	i	i	128	128	128
2	128	i	128	i	i	128	128	128
3	128	İ	128	i	i	128	128	128
4	1	ĺ	128	i	i	128	128	128
5	1	İ	128	i	i	128	128	128
6	1	İ	128	i	i	128	128	128
7	1	İ	128	İ	İ	128	128	128
8	1	İ	128	İ	İ	128	128	128
9	128	ĺ	128	ĺ	Í	128	128	128
10	128		128			128	128	128
11	128		128			128	128	128
12	128		128			128	128	128
13	128		128			128	128	128
14	128		128			128	128	128
15	128		128			128	128	128
16	128							128
17	128							128
18	128							128
19	128			ļ	ļ			128
20	128			ļ	ļ			128
21	128				ļ			128
22	128							128
23	128			ļ	ļ			128
24	128			ļ	ļ			128
25	128							128
20 27	120							120
20	12ŏ 120	1						120 120
∠ö 20	120							120 120
3U 7A	120 129							120 120
30	120			ļ	l			120
21	120	I	I	I 1	I			120

Example 11-4 To display the logical switch configuration

11.3.9 Changing the fabric ID of a logical switch

To change the fabric ID of an existing logical switch, select the **Logical Switches** window and select the **Edit** button. This opens the Edit Properties, where you can change the logical fabric ID, as shown in Figure 11-18.

Ec	lit Properties					×
	Fabric Switch					
	Logical Fabric ID	35	Base Switch			
	256 Area Limit	Disable 💌	Base Fabric for Transport			
	R A TOV	10000			Sequence Level Switchin	g
	E D TOV	2000			Disable Device Probing	
	WAN TOV	0			Per-frame Routing Priority	
	Maximum Hops	7			Suppress Class F Traffic	
	BB Credit	16			Long Distance Fabric	
	Data Field Size	2112				
	Interoperability Mode	Brocade Native 💌				
				Oł	Cancel Help	

Figure 11-18 Change Logical Fabric ID

The fabric ID indicates in which fabric the logical switch participates. By changing the fabric ID, you are moving the logical switch from one fabric to another.

On the Logical Switches window, the switch will display under the new fabric ID, as shown in Figure 11-19.

nassis	ibm_dcx4s_21	3 🕶							
orts				1	Existing Logical Switches				
Slot / Port	▲ User Port #	Port Address	FID	Find	Switch / Ports	Chassis	FID	Port Numbe	New Fabr
/0	0	100000	128	>	E J Discovered Logical Switches				
(1	-	100100	128	<	256B M48				New Swit
2	2	100200	128		EDGE IBM B32				
3	3	100300	128		E SAN384B-10:00:00:05:1e:	94:	35		Edit
14	4	19fec0	35		E 🗿 ITSO_SW2	ibm_dcx4s_213	35		
15	5	19fe80	35		• 4			1/4	Doloto
6	6	19fe40	35					1/5	
17	7	19fe00	35		- • 6			1/6	
/8	8	19fdc0	35		- 0 7			1/7	
/9	9	100900	128	-				1/8	
/10	10	100a00	128		📃 🗄 💩 SAN384B-10:00:00:05:1e:9	94:	128		
/11	11	100b00	128			ibm_dcx4s_213	128		
/12	12	100c00	128		📃 🖵 🤳 Undiscovered Logical Switche	s			
/13	13	100d00	1281						
/14	14	100e00	128						
/15	15	100f00	128						
/16	16	101000	1281						
/17	17	101100	1281						
/18	18	101200	128						
/19	19	101300	128						
/ 20	20	101400	128						
/ 04	21	101500	128						

Figure 11-19 Logical Switch view with changed ID

To activate the change, select the **OK** button on the logical switches window, then read the confirmation message and select the **Start** button to complete the operation.

Attention: It might be necessary to delete the fabric from DCFM and then rediscover the fabric for the new logical switch to be shown.

11.3.10 Changing a logical switch to a base switch

Only the base switch can be used for Inter Switch Links. If there is no base switch already, you might want to change one of the logical switches to a base switch. To do this, select the logical switch in the Logical Switch View window and then select the **Edit** button. The Edit Properties window will display, where you can check the base switch button and then the **OK** button, as shown in Figure 11-20.

Edit Properties			×
Fabric Switch			
Logical Fabric ID	128	🖉 Base Switch	
256 Area Limit	Disable 🗸 🗸	Base Fabric for Transport	
R A TOV	10000		Sequence Level Switching
E D TOV	2000		Disable Device Probing
WAN TOV	0		Per-frame Routing Priority
Maximum Hops	7		Suppress Class F Traffic
BB Credit	16		Long Distance Fabric
Data Field Size	2112		
Interoperability Mode	Brocade Native 💌		
			OK Cancel Help

Figure 11-20 Edit Properties base unit

To activate the change, select the **OK** button in the Logical Switches window, then read the confirmation message and select the **Start** button to complete the operation.

Important: Trunk areas must be disabled to change a switch into a base switch. You can do this using the **porttrunkarea** --disable all command. The switch must be disabled to do this.

11.3.11 Configuring a logical switch for XISL use

When you create a logical switch, by default it is configured to use XISLs. Use the following procedure to allow or disallow the logical switch to use XISLs in the base fabric.

1. Check with the **switchshow** command whether the switch is enabled for XISL use as shown in Example 11-5.

Example 11-5 Check XISL with switchshow

IBM_SAN384B_213:FID128:admin> switchshow switchName: IBM_SAN384B_213 switchType: 77.3 switchState: Online switchMode: Native switchRole: Principal switchDomain: 1

```
switchId:
              fffc01
switchWwn:
              10:00:00:05:1e:94:3a:00
zonina:
              0FF
switchBeacon:
              0FF
FC Router:
              0FF
Allow XISL Use: OFF
LS Attributes: [FID: 128, Base Switch: No, Default Switch: Yes]
Index Slot Port Address Media Speed State
                                         Proto
_____
 0
      1
              010000
                                No Module
          0
                            N4
                      --
 1
      1
          1
              010100
                                No Module
                      --
                           N4
 2
      1
          2
              010200
                           N4
                                No Module
                      --
```

- 2. Enter the switchdisable command to disable the switch (no output returned)
- 3. Use the **configure** command to configure the switch as shown in Example 11-6:

Example 11-6 use configure to allow or disallow XISL use

```
switch 100:FID100:admin> configure
Configure...
  Fabric parameters (yes, y, no, n): [no] y
    Domain: (1..239) [1] 100
    Allow XISL Use (yes, y, no, n): [yes]
    Enable a 256 Area Limit
      (0 = No,
       1 = Zero Based Area Assignment,
       2 = Port Based Area Assignment): (0..2) [0]
    R A TOV: (4000..120000) [10000]
    E D TOV: (1000..5000) [2000]
    WAN TOV: (0..30000) [0]
    MAX HOPS: (7..19) [7]
    Data field size: (256..2112) [2112]
    Sequence Level Switching: (0..1) [0]
    Disable Device Probing: (0..1) [0]
    Suppress Class F Traffic: (0..1) [0]
    Per-frame Route Priority: (0..1) [0]
    Long Distance Fabric: (0..1) [0]
    BB credit: (1..27) [16]
    Disable FID Check (yes, y, no, n): [no]
```

```
Insistent Domain ID Mode (yes, y, no, n): [no]
Virtual Channel parameters (yes, y, no, n): [no]
F-Port login parameters (yes, y, no, n): [no]
Zoning Operation parameters (yes, y, no, n): [no]
RSCN Transmission Mode (yes, y, no, n): [no]
Arbitrated Loop parameters (yes, y, no, n): [no]
System services (yes, y, no, n): [no]
Portlog events enable (yes, y, no, n): [no]
ssl attributes (yes, y, no, n): [no]
rpcd attributes (yes, y, no, n): [no]
webtools attributes (yes, y, no, n): [no]
```

WARNING: The domain ID will be changed. The port level zoning may be affected

- 4. Respond to the remaining prompts or press Ctrl-d to accept the other settings and exit.
- Enter the switchenable command to re-enable the switch (no output is returned).

11.3.12 Creating a logical fabric using XISLs

The following procedure describes the flow in how to create a logical fabric using multiple chassis and XISLs. We discuss this topic in more detail in 11.4, "A real life example of Virtual Fabrics" on page 495. Follow these steps:

- 1. Set up the base switches in each chassis:
 - a. Connect to the physical chassis and log in using an account assigned to the admin role with the chassis-role permission.
 - b. Enable the Virtual Fabrics feature, if it is not already enabled. This automatically creates the default logical switch, with FID 128. All ports in the chassis are assigned to the default logical switch.
 - c. Create a base switch and assign it a fabric ID that will become the FID of the base fabric.
 - d. Assign ports to the base switch.
 - e. Repeat the prior steps for all chassis that are to participate in the logical fabric.
- 2. Physically connect ports in the base switches to form XISLs.
- 3. Enable all of the base switches. This forms the base fabric.

- 4. Configure the logical switches in each chassis:
 - a. Connect to the physical chassis and log in using an account assigned to the admin role with the chassis-role permission.
 - b. Create a logical switch and assign it a fabric ID for the logical fabric. This FID must be different from the FID in the base fabric.
 - c. Assign ports to the logical switch.
 - d. Physically connect devices and ISLs to the ports on the logical switch.
 - e. (Optional) Configure the logical switch to use XISLs, if it is not already XISL-capable. By default, newly created logical switches are configured to allow XISL use.
 - f. Repeat the prior steps for all chassis that are to participate in the logical fabric, using the same fabric ID whenever two switches need to be part of a single logical fabric.
- 5. Enable all logical switches by using the switchenable command.

Now the logical fabrics are formed.

The **fabricShow** command displays all logical switches configured with the same fabric ID as the local switch and all non-Virtual Fabric switches connected through ISLs to these logical switches.

The **switchShow** command displays logical ports as E_Ports, with -1 for the slot and the user port number for the slot port.

11.4 A real life example of Virtual Fabrics

In this section we demonstrate how to set up Virtual Fabrics in a live environment. The case is built in a lab environment and can be scaled larger or smaller according to customer needs.

In order to demonstrate the ability to share ISLs, we build four logical switches that merge into two logical fabrics. The shared ISLs, called XISLs, will carry all traffic between the two data centers. This includes the two fabrics we build in the example, as well as other future departments or users who might buy parts of a partitioned switch, but do not have their own ISLs.

New users or departments can use the existing XISLs and still have their own individual switched fabrics spanning over sites.

11.4.1 The scenario

In this scenario we assume that a customer has two data centers and wants to build a switched fabric that spans the data centers. The customer has a mix of UNIX servers and Windows servers and wants to have only one chassis at each site. The customer also wants two redundant fabrics in order to apply an IBM/Brocade best practice, and so that a failure in one fabric will not cause total system down situations.

For this purpose we are partitioning switches building two redundant fabrics where server HBAs and storage controllers connect to separate switched fabrics. UNIX systems will access "just a bunch of disks" (JBOD) at site B and Windows systems will access IBM DS4000 at site A.

The customer has provided two ISL connections and wants these to be shared among current and future users. For this purpose we create base switches on each site which can only be used for ISL traffic. These extended ISLs are called XISLs.

Because we are only going to have two fabrics, then two ISLs might be sufficient, but making the ISLs into XISLs gives us the flexibility of having separate fabrics in the future to make use of the existing infrastructure.

To perform SAN management, we create a user with the credentials to administer *only* the hardware ports that belong to their respective SAN's.

The customer is purchasing two Virtual Fabric capable SAN-switches; one is the IBM System Storage SAN768B Director for site A and the other is an IBM System Storage SAN80B for site B.



The Virtual Fabrics that we are building are logically shown in Figure 11-21.

Figure 11-21 Logical setup



The Virtual Fabrics that we are building are shown physically in Figure 11-22.

Figure 11-22 Virtual Fabric Lab. Setup

11.4.2 Enabling Virtual Fabric on the switches

By default, Virtual Fabric is enabled on the VF-capable switches. However, if the system is being upgraded from Fabric OS v5.3, then Virtual Fabric is disabled and will need to be enabled.

Example 11-7 shows that VF is disabled.

Example 11-7 Virtual Fabric is disabled

<pre>IBM_SAN80B_4_217:admin> fosconfi</pre>	igshow				
FC Routing service:	disabled				
iSCSI service:	Service not	supported	on	this	Platform
iSNS client service:	Service not	supported	on	this	Platform
Virtual Fabric:	disabled				

Note that at this stage without Virtual Fabric enabled, Admin Domain will be available. Virtual Fabric and Admin Domain cannot work at the same time and Admin Domain will be disabled when enabling Virtual Fabric.



Figure 11-23 shows that the Admin Domain is enabled while Virtual Fabric is disabled.

Figure 11-23 Admin Domain enabled

Example 11-8 shows VF enabled.

Example 11-8 Enabling Virtual Fabric

IBM_SAN80B_4_217:admin> fosconfig --enable vf
WARNING: This is a disruptive operation that requires a reboot to take
effect.
All EX ports will be disabled upon reboot.
Would you like to continue [Y/N]: y
VF has been enabled. Your system is being rebooted.

This operation will be performed at both switches. Example 11-9 shows Virtual Fabric as enabled.

Example 11-9 After reboot Virtual Fabric is enabled

IBM_SAN80B_4_217:FID128:admin>	fosconfigshow
FC Routing service:	disabled
iSCSI service:	Service not supported on this Platform
iSNS client service:	Service not supported on this Platform
Virtual Fabric:	enabled

We now enable Virtual Fabric on both our switch chassis. At this time only the default logical switch with Fabric ID (FID) 128 exists. All ports in the two switches belong to the default switch, and because these have the same FID, the switches will merge into a single fabric. Example 11-10 shows this situation.

Example 11-10 Fabrics have merged

IBM_SAN80B_217:FID128:admin> fabricshow					
Switch ID Worldwide Name	Enet IP Addr Name				
1: fffc01 10:00:00:05:1e:46:8a:00 2: fffc02 10:00:00:05:1e:09:97:01	10.64.210.210 "IBM_SAN768B_210" 10.64.210.217 "IBM_SAN80B_217"				
The Fabric has 2 switches COMMAND OUTPUT REMOVED FOR CLARITY					

Attention: Depending on the product and FOS version, the switch ports on the newly created Virtual Fabric might be disabled or persistently disabled, and they will need to be re-enabled.

Zoning: If different zoning configurations exist on the switches that are being interconnected, they can merge if there is no zoning conflict. This can be avoided by persistently disabling the ports before enabling the Virtual Fabric.

- Command example: portcfgpersistentdisable 3/8
- Command example: portcfgpersistentetnable 3/8

Later we create additional logical switches.



Figure 11-24 shows that Admin Domain is disabled when Virtual Fabric is enabled.

Figure 11-24 Virtual Fabric enabled

11.4.3 Creating logical switches

In this section we create six logical switches. Two of these will be base switches that are only used for carrying ISL traffic between chassis. The four remaining logical switches will be two at each site. Example 11-11 shows an example of a logical switch being created.

Example 11-11 A logical switch is created on the SAN80B switch

IBM_SAN80B_217:FID128:admin> lscfg --create 100
About to create switch with fid=100. Please wait...
Logical Switch with FID (100) has been successfully created.

Logical Switch has been created with default configurations. Please configure the Logical Switch with appropriate switch and protocol settings before activating the Logical Switch. Example 11-12 shows that all the ports belong to the default switch.

IBM_SAN80B_217:FID128:admin> lscfgshow									
Created	switc	hes:	128(ds)	100					
Port	0	1	2	3	4	5	6	7 8	9
FID	128	128	128	128	128	128	128	128 128	128
Port	10	11	12	13	14	15	16	17 18	19
FID	128	128	128	128	128	128	128	128 128	128
Port	20	21	22	23	24	25	26	27 28	29
FID	128	128	128	128	128	128	128	128 128	128
Port	30	31	32	33	34	35	36	37 38	39
FID	128	128	128	128	128	128	128	128 128	128
Port	40	41	42	43	44	45	46	47 48	49
FID	128	128	128	128	128	128	128	128 128	128
Port	50	51	52	53	54	55	56	57 58	59
FID	128	128	128	128	128	128	128	128 128	128
Port	60	61	62	63	64	65	66	67 68	69
FID	128	128	128	128	128	128	128	128 128	128
Port	70	71	72	73	74	75	76	77 78	79
FID	128	128	128	128	128	128	128	128 128	128

Example 11-12 All ports still belong to the default switch

We see that now one *additional* switch with FID 100 is present, but all resources still belong to FID 128 (the default switch).

11.4.4 Assigning ports to the newly created switch

In Example 11-13 we have logged on to the new default switch.

Example 11-13 Switch to the newly created logical switch

IBM_SAN80B_217:FID128:admin> setcontext 100
Please change passwords for switch default accounts now.
Use Control-C to exit or press 'Enter' key to proceed.

```
Password was not changed. Will prompt again at next login until password is changed.
```

The commands we show are all issued from the switch with FID 100.

Now we want to add resources to the newly added switch. This can be done with or without the **force** option. SAN administrators might want to use the **-force** option in order to save time.

In Example 11-14 we are adding ports 0, 8, and 16 to the logical switch. These are disabled by default and need to be enabled (Figure 11-15).

Example 11-14 Ports are added to the logical switch

```
switch_100:FID100:admin> lscfg --config 100 -port 0 -force
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.
switch_100:FID100:admin> lscfg --config 100 -port 8 -force
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.
switch_100:FID100:admin> lscfg --config 100 -port 16 -force
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.
switch_100:FID100:admin> lscfg --config 100 -port 16 -force
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.
switch_100:FID100:admin> portenable 0
switch_100:FID100:admin> portenable 8
switch_100:FID100:admin> portenable 16
```

Example 11-15 The switch now has 3 ports

switch_100:FID10	00:admin> switchshow						
switchName:	switch_100						
switchType:	64.3						
switchState:	Online						
switchMode:	Native						
switchRole:	Principal						
switchDomain:							
switchId:	fffc01						
switchWwn:	0:00:00:05:1e:09:97:02						
zoning:	FF						
switchBeacon:)FF						
FC Router:)FF						
Allow XISL Use:	ON						
LS Attributes:	[FID: 100, Base Switch: No, Default Switch: No]						
Area Port Media	Speed State Proto						
0 0 id	N2 Online F-Port 10:00:00:c9:28:ec:1a						
8 8 id	N2 Online F-Port 10:00:00:c9:32:a8:65						
16 16 id	N2 Online L-Port 9 public						

At this point the switch must be disabled to set a unique Domain ID and to allow the use of XISL (allow is the default setting). Domain IDs and switchnames will be configured as shown in Figure 11-25.

Switchmane		SAN80B SAN7			SAN768B	
	FID 100	FID 105	FID 120	FID 100	FID 105	FID 120
	Domain ID	Domain ID	Domain ID	Domain ID	Domain ID	Domain ID
SAN80B_switch_100	1					
SAN80B_switch_105		1				
SAN80B_switch_120			1			
SAN768B_switch_100				100		
SAN768B_switch_105					105	
SAN768B_switch_120						120

Figure 11-25 Switch names and Domain IDs

Attention: If switch Domain IDs are not unique, the switches will segment, and a fabric merge will not happen.

Example 11-16 shows how we are setting the Domain ID.

```
Example 11-16 Setting the Domain ID
switch 100:FID100:admin> configure
Configure...
  Fabric parameters (yes, y, no, n): [no] y
    Domain: (1..239) [1] 100
    Allow XISL Use (yes, y, no, n): [yes]
    Enable a 256 Area Limit
      (0 = No.
       1 = Zero Based Area Assignment,
       2 = Port Based Area Assignment): (0..2) [0]
    R A TOV: (4000..120000) [10000]
    E D TOV: (1000..5000) [2000]
    WAN TOV: (0..30000) [0]
    MAX HOPS: (7..19) [7]
    Data field size: (256..2112) [2112]
    Sequence Level Switching: (0..1) [0]
    Disable Device Probing: (0..1) [0]
    Suppress Class F Traffic: (0..1) [0]
    Per-frame Route Priority: (0..1) [0]
    Long Distance Fabric: (0..1) [0]
    BB credit: (1..27) [16]
    Disable FID Check (yes, y, no, n): [no]
  Insistent Domain ID Mode (yes, y, no, n): [no]
  Virtual Channel parameters (yes, y, no, n): [no]
  F-Port login parameters (yes, y, no, n): [no]
  Zoning Operation parameters (yes, y, no, n): [no]
  RSCN Transmission Mode (yes, y, no, n): [no]
  Arbitrated Loop parameters (yes, y, no, n): [no]
  System services (yes, y, no, n): [no]
  Portlog events enable (yes, y, no, n): [no]
  ssl attributes (yes, y, no, n): [no]
  rpcd attributes (yes, y, no, n): [no]
  webtools attributes (yes, y, no, n): [no]
WARNING: The domain ID will be changed. The port level zoning may be
```

Now enable the switch using the command switchenable.

affected

At this time, using the same steps as before, we create one additional logical switch on the SAN80B, and we create two new logical switches on the SAN768B switch. We assign ports to the switches as indicated in Figure 11-26.

Device		SAN80B			SAN768B	
	FID 100	FID 105	FID 120	FID 100	FID 105	FID 120
	Fabric 1	Fabric 2	Base sw	Fabric 1	Fabric 2	Base sw
WIN-A HBA1				3/15		
WIN-A HBA2					10/15	
UNIX-A HBA1				3/14		
UNIX-A HBA2					10/14	
DS4000 ctrl 1				3/0		
DS4000 ctrl 1					10/0	
ISL 1			27			3/8
ISL 2			75			10/8
WIN-B HBA1	0					
WIN-B HBA2		48				
UNIX-B HBA1	8					
UNIX-B HBA2		56				
JBOD ctrl 1	16					
JBOD ctrl 2		64				

Figure 11-26 Switch connections

At this point we have created four switches with individual names and unique Domain IDs. The switches are configured to allow XISL.

11.4.5 Creating the base switch

The base switch is used for Inter Switch Link traffic called XILS only. We assign our two current ISL connections to the base switch, and because our logical switches are configured for XISL use, the switches will merge into a single fabric.

In Example 11-17, before creating the base switch, the other individual logical switches are shown as stand-alone switches.

Example 11-17 The logical switches are stand alone switches

SAN80B_switch_100:FID100:admin> fab Switch ID Worldwide Name	r icshow Enet IP Addr Name
1: fffc01 10:00:00:05:1e:09:97:02	10.64.210.217 "SAN80B_switch_100"
COMMAND OUTPUT REMOVED FOR CLARITY	

Now we create the base switches on both of the chassis in our setup. Example 11-18 shows how it is done on the SAN80B.

Switches: The logical switches can be created from any of the other switches, as long as the user has administrator privileges on the switch chassis.

Example 11-18 The base switch is created and ports assigned

IBM_SAN80B_217:FID128:admin> lscfg --create 120 -base -force
About to create switch with fid=120. Please wait...
Logical Switch with FID (120) has been successfully created.

Logical Switch has been created with default configurations. Please configure the Logical Switch with appropriate switch and protocol settings before activating the Logical Switch.

IBM_SAN80B_217:FID128:admin> lscfg --config 120 -port 27
This operation requires that the affected ports be disabled.
Would you like to continue [y/n]?: y
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.

```
IBM_SAN80B_217:FID128:admin> lscfg --config 120 -port 75 -force
Making this configuration change. Please wait...
Configuration change successful.
Please enable your ports/switch when you are ready to continue.
```

After enabling the switch ports, the base switch as well as the remaining switches will merge into logical fabrics. The switches that merge will be the ones that have similar FIDs. A logical switch cannot merge with another logical switch if the FIDs are different. Example 11-19 shows that the switches have merged.

Example 11-19 Switches now merge successfully

SAN80B_switch_10	0:FID100:admin> switchshow
switchName:	SAN80B_switch_100
switchType:	64.3
switchState:	Online
switchMode:	Native
switchRole:	Principal
switchDomain:	1
switchId:	fffc01
switchWwn:	10:00:00:05:1e:09:97:02
zoning:	OFF
switchBeacon:	OFF
FC Router:	OFF

COMMAND OUTPUT REMOVED FOR CLARITY

11.4.6 Creating a user to manage the Virtual Fabric

In this section we create a user to manage the Virtual Fabrics that we created in the previous sections. The user will have administrator privileges to perform management on Virtual Fabrics FID100 and FID105, but will not have any privileges to perform management on the switch chassis.

We use WebTools to perform this task.



Figure 11-27 shows the admin user privileges for all Virtual Fabrics.

Figure 11-27 Logged in as admin user

We create a user named "Alex" with permission to only manage FID 100 and 105.

🔄 Switch Admin:Add User Account								X
User Name	Alex							
Description	Redbook user							
Status	Enabled Disabled							
New Password								
Confirm Password								
Logical Fabric								
Logical Fabric ID				User Role				
100				admin			•	
101				No Access			•	
102				No Access			•	
103				No Access			•	
104				No Access			•	
105				No Access			•	
106			No Access			-	-	
				admin			1	_
Home Logical Fab	ric Id ·	100		user		3		
Chargie Accare I	Role			switchadmin				
Chasais Access i			30	Tabricadmin				
				zoneaumin				
				operator			-	
				operator				

Figure 11-28 shows how the user Alex is created.

Figure 11-28 Create user Alex

After applying the new user, Alex will be able to log in to the switch. Alex will have admin rights for FID 100 and FID 105 and will be able to only perform management tasks on resources that are applied to the user Alex.



Figure 11-29 shows which ports the user Alex can manage.

Figure 11-29 Logged in as user Alex

The next step for user Alex is to create zones for each server HBA. Zoning is covered in greater detail in Chapter 12, "Basic zoning" on page 513.

We have now finished creating Virtual Fabrics and have a working setup where SAN switches have been partitioned to separate individual fabrics.

Our scenario shows how to add just a few ports to a logical switch. In a real life situation, it is more likely that an entire switch blade will be used as a logical switch, and a separate switch blade will be used for ISL connections.
12

Basic zoning

In this chapter, we discuss the basics of zoning, which allows you to define specific groups of fabric-connected devices to ensure that the access between them is controlled. Zoning enables you to partition a storage area network (SAN) into logical groups of devices that can access each other.

12.1 Zoning in general

Zoning allows you to define specific groups of fabric-connected devices to ensure that the access between them is controlled.

Attention: Be aware that any devices that are not configured in a zone will not be accessible.

Zoning enables you to partition a storage area network (SAN) into logical groups of devices that can access each other. Zoning is critical even in Fabrics with storage based LUN masking. Often storage based LUN masking is viewed as a replacement for zoning, however this is *not* the case. In a heterogeneous server environment, zoning is another layer of security to existing storage LUN masking. It allows administrators to secure not just their storage, but also allows them to isolate servers and even adapter cards from each other.

Zones can be configured dynamically. They can vary in size, depending on the number of fabric-connected devices, and devices can belong to more than one zone. Because zone members can access only other members of the same zone, a device not included in a zone is not available to members of that zone.

12.1.1 Mixed fabrics

When using a mixed fabric—that is, a fabric that contains two or more switches running different fabric operating systems— use the switch with the highest Fabric Operating System (Fabric OS) level to perform zoning tasks. If the switch is running Fabric OS v6.0.x or earlier, it must have an Advanced Zoning license enabled.

If the fabric includes a third-party switch product, only worldwide name (WWN) zoning is supported. Other types of zoning, including QuickLoop, are not supported.

When zone or Fabric Assist (FA) zone members are specified by fabric location only (domain or area), or by device name only (node name or port WWN), zone boundaries are enforced at the hardware level, and the zone is referred to as a *hard zone*.

When zone members are specified by fabric location (domain or area) and other members of the same zone are specified by device name (node name or port WWN), zone enforcement depends on Name Server lookups, and the zone is referred to as a *soft zone*.

12.1.2 Zone configurations

A zone configuration is a group of one or more zones. A zone can be included in more than one zone configuration. When a zone configuration is in effect, all zones that are members of that configuration are in effect.

Several zone configurations can reside on a switch at once, and you can quickly alternate between them. For example, you might want to have one configuration enabled during the business hours and another enabled overnight. However, only one zone configuration can be enabled at a time.

The different types of zone configurations are as follows:

Defined configuration:

The complete set of all zone objects defined in the fabric.

► Effective configuration:

A single zone configuration that is currently in effect. The effective configuration is built when you enable a specified zone configuration.

Saved configuration:

A copy of the defined configuration plus the name of the effective configuration, which is saved in flash memory. (You can also provide a backup of the zoning configuration and restore the zoning configuration.) There might be differences between the saved configuration and the defined configuration if you have modified any of the zone definitions and have not saved the configuration.

Disabled configuration:

The effective configuration is removed from flash memory.

Important: Ensure that only one person is making configuration changes to your environment at any one time. Using the **killtelnet** command provides a view of who is logged in to the switch and a method for removing any sessions that should not be in place:

```
BDPOCO1LO1:admin> killtelnet
Collecting login information....
List of sessions (2 found)
```

Session N	o USER	TTY	IDLE	LOGIN@	FROM
\sim	\sim	งการการการการการการการการการการการการการก	๛๛๛๛๛๛๛๛	~~~~~~~	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
0	admin0	nts/0	1:50	17:52	9.155.66.103
v	aamino	P		-/ ••-	212001001200
1	admin0	pts/1	0.00s	18:53	9.155.66.205
Enter Sess	ion Number	to termin	ate (q to	quit)	

12.2 Zoning using DCFM

In DCFM, one way to launch the Zone Admin is by right-clicking a fabric in the View panel, as shown in Figure 12-1, and selecting **Zoning** \rightarrow **Fabric**.

Attention: Zone Admin displays only if an Advanced Zoning licence is installed on the switch.



Figure 12-1 Opening Zone Admin

The *Zoning dialog box* is used to set up, maintain, and activate the zones across the fabric. From here, you can also define aliases for members in a zone and create the zones that form the active configuration across the fabric, as shown in Figure 12-2.

Zoning oning Scope Back Bone_SAN384B Zone DB Active Zone Configuration	▼ n	Zone DB Fabric Zone DB	Zone DB Edit
Potential Members Type WMM1 All Levels Image: Constraint of the second	Alias Name A	Zones Zone Configurations Image: Solution of the second secon	Activate
	•	New Zone Vew Vew Member New Configuration	Report
ocade Native Mode		OK Cancel	Apply Help

Figure 12-2 Zoning dialog box

Administrative privileges are required to access this function. When administering zoning on an IBM System Storage SAN Switch, follow these steps:

- 1. Define aliases for device WWPN.
- 2. Define zones to establish groupings.
- 3. Add zone members (using the aliases you defined in Step 1).
- 4. Place zones into one or more zone configurations.
- 5. Enable one of the zone configurations (only one can be enabled at a time).

Zoning: When configuring zones for encryption, Alias zoning is not supported in containers. You must use the real WWPN for the zoning configuration.

You can choose how zoning elements are displayed in the Zoning dialog box. The zoning view that you select determines how members are displayed in the Alias Selection List. The views filter the fabric and device information that is displayed in the Selections for the selected view, making it easier for you to create and modify zones, especially when creating hard zones as in Figure 12-3.

💱 Zoning			_ 🗆 X
Zoning Scope Back Bone_SAN384B Zone DB Active Zone Configuration	Zone DB Fabric Zone DB 🔻	Zone DB Operation	Zone DB Edit
Potential Members Type WWN All Levels WWN Image: Source of the second se	Zones Zone Configurations Find Cone 2_DS Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configurations Cone Configura		Activate Zoning Policies
Bronaria Native Moria			
		OK Cancel /	Apply Help

Figure 12-3 Zoning dialog box view

12.2.1 Administrative Domains

An Administrative Domain (Admin Domain or AD) is a logical grouping of fabric elements that defines what switches, ports, and devices you can view and modify. An Admin Domain is a filtered administrative view of the fabric.

Authorization: To manage Admin Domains, you must be a physical fabric administrator. A physical fabric administrator is a user with the admin role and access to all Admin Domains (AD0 through AD255). Only a physical fabric administrator can perform Admin Domain configuration and management.

Admin Domains permit access to a configured set of users. Using Admin Domains, you can partition the fabric into logical groups and allocate administration of these groups to different user accounts so that these accounts manage only the Admin Domains that are assigned to them and do not make changes to the rest of the fabric.

For example, you can put all the devices in a particular department in the same Admin Domain for ease of managing those devices. If you have remote sites, you can put the resources in the remote site in an Admin Domain and assign the remote site administrator to manage those resources.

Admin Domains and zones: Do not confuse Admin Domains with zones:

- Zones define which devices and hosts can communicate with each other.
- Admin Domains define which users can manage which devices, hosts, and switches.

You can have up to 256 Admin Domains in a fabric (254 user-defined and two system-defined), numbered from 0 through 255. Admin Domains are designated by a name and a number. In this book, we refer to specific Admin Domains using the format ADn, where *n* is a number between 0 and 255.

The Admin Domain is used mainly in terms of fabric administration perspective. Each Admin Domain has its own zone database, with both defined and effective zone configurations and all related zone objects (zones, zone aliases, and zone members). Within an Admin Domain, you can configure zoning only with the devices that are present in that Admin Domain (direct members).

If you upgrade a fabric to Fabric OS v5.2.0 or higher, the zone database from the pre-v5.2.0 fabric is referred to as the *root zone database* and is owned by Admin Domain 0 (AD0). Each zone database has its own name space.

Fabric OS v6.1 adds support for distributing the Defined Zone Configuration database in InteropMode 2.

12.2.2 Implementing Administrative Domains

If you implement Admin Domains, you must set the default zoning mode to **No Access** before you create Admin Domains. To do so, click **Zoning Policies** (see the rounded rectangle in Figure 12-4).

Zoning		
Zoning Scope Back Bone_SAN384B	Zone DB Fabric Zone DB 🔻	Zone DB Operation Zone DB Edit
Zone DB Active Zone Configuration Potential Members Type WWN ▼ All Levels WWN © © Switch Group Domain,Port Index All © © Botton 75 © © B5000_76 © © B5000_76 © © BM_2498_R06 © © BM_2498_R06 © © BM_2498_R06 © © BM_2498_R06 © © BM_2498_R06 © © SAN32B-E4-1 © SAN32B-E4-2 © © switch	Find Image: Second	Zoning Policies
		Report
	New Zone V New Member New Configuration	
Brocade Native Mode		OK Cancel Apply Help

Figure 12-4 Disable default zoning mode

The Zoning Policies dialog box displays. Click **Disable** (No Access) as shown in Figure 12-5 and click **OK**.

Zoning Policies	5	×
Fabric Name	Back Bone_SAN384B	
Default Zone	Disable (No Access)	
	 Enable (All Access) 	
	OK Cancel Help	

Figure 12-5 Zoning Policies

12.3 Implementing zoning

In this section, we provide details about how to manage zoning.

12.3.1 Managing zoning

You can monitor and manage zoning with the Web Tools Zone Admin, CLI and with DCFM. The information is collected from the selected switch.

In DCFM you must be logged into with a user name that has the following privileges:

- Zoning Activation
- Zoning Online
- Zoning Offline

The Role, *System Administrator*, for example, has these privileges; see Figure 12-6.

ID Description E-mail Notific E-mail Address Administrator Administrator System Administrator dcfmuser administrator Security Administrator dcfmuler DCFMCL Security Administrator Jack FICON Security Officer Add Edit Remove Roles System Administrator System Administrator Security Administrator System Administrator Security Officer System Administrator Security Administrator System Administrator Security Administrator System Administrator Security Administrator Security Administrator Security Administrator Solution Security Administrator Security Administrator Security Administrator Security Administrator Security Administrator Security Officer Security Officer Network Administrator Security Officer Network Administrator Security Officer Network Administrator Security Officer Network Administrator Security Officer Network Administrator Security Officer<	Users			Find >	Resource Groups
Vetwork Administrator Host Administrator Ecryption manger	ID Administrator dcfmuser dcfmclient Jack Add Edit Roles System Admin Security Admir Zone Administ Operator Security Office Network Administr Ecryption man	Description Administrator dcfmuser DCFMCL FICON Remove	E-mail Notific E-mail Address		All Fabrics System Administrator Security Administrator Cone Administrator Cone Administrator Cone Administrator Network Administrator Host Administrator Copen System Administrator Copen System Administrator Coperator
Add Edit Remove	Add Edit	Remove			Add Edit Remove

Figure 12-6 DCFM User Management

All other roles only allow *view* or *read-only* access. Most of the zoning operations are disabled in *read-only* mode. A user can be set up for zone administration, such as the zone administrator, see Figure 12-7 which shows the rules set up for this user.



Figure 12-7 Zone Administrator

12.3.2 Creating an alias

By defining an alias to a port (or ports) or WWN (or WWNs), you can simplify your understanding of the device that you are working with on the other tabs. Using a sensible naming convention also assists with troubleshooting at a later stage, making it easier to find specific devices, especially when a SAN grows in complexity. Assign aliases and ensure that they are maintained to help to identify SAN components correctly using the Alias tab.

Methods for creating an alias

You can specify members of an alias using the following methods:

- ► A switch domain and port index number pair (for example, 2 and 20)
- Device node and device port WWNs

In this section we describe methods for creating an alias using DCFM.

Important: When configuring zones for encryption, alias zoning is not supported in containers. You must use the real WWPN in order for frame redirection to be applied, regular zones for hosts and targets must be defined in the effective configuration. Hosts and targets must be zoned together by worldwide port name (WWPN) rather than worldwide node name (WWNN) in configurations where frame redirection will be used. If hosts or targets are zoned together using worldwide node name, frame redirection will not occur properly.

Using DCFM to create an alias

To use DCFM to create an alias, follow these steps:

- From the DCFM Main window, click Configure → Zoning → Fabric. to open the Zoning dialog box,
- 2. Select Alias in the **Type** pull-down menu, as shown in Figure 12-8.

S Zoning		
Zoning Scope Back Bone_SAN384B Zone DB Active Zone Configuration	Zone DB Fabric Zone DB	Zone DB Edit
Potential Members Type WWN ▼ All Levels WWN ⊡	Find 	Activate Zoning Policies
▲	New Zone New Member New Configuration	
Brocade Native Mode	OK Cancel A	Apply Help

Figure 12-8 Choose display format



3. Click New Alias (see Figure 12-9).

Figure 12-9 New Alias

new Allas				
Alias Name ITSO_BTYPE				
Potential Members	Type VW/N			Selected Members
All Levels	Alias Name 🔺 Name	D	Find	[FCID:171300] (WWN 10:00:00:05:1E:53:10:8B) Brocade Corr
	B5000 75	s-		
↓ 10:00:00:05:1E:0F:81:CD		000		
10:00:00:05:1E:53:10:8B		100		
a 20:07:00:A0:B8:48:58:A1	DS4700_B_75			
50:05:07:68:01:40:27:E2	ITSOCLS1N1	3		
50:05:07:68:01:30:27:E2	ITSOCLS1N1	3		
50:05:07:68:01:40:50:34	ITSOCLS1N2	1000		
organization 50:05:07:68:01:30:50:34 😸	ITSOCLS1N2			
orgentication 50:05:07:68:01:40:37:E5	ITSOCLS1N3			
organization 50:05:07:68:01:30:37:E5	ITSOCLS1N3			
organization 50:05:07:68:01:40:50:5C	ITSOCLS1N4			
organization 50:05:07:68:01:30:50:5C	ITSOCLS1N4			
organization 50:05:07:68:01:40:1D:21 💧	ITSOCLS1N5			
organization 50:05:07:68:01:30:1D:21 💩	ITSOCLS1N5			
organization 50:05:07:68:01:40:1D:22 💩	ITSOCLS1N6			
50:05:07:68:01:30:1D:22	ITSOCLS1N6		-	
				Detached WWN

4. The New Alias dialog box displays, as shown in Figure 12-10.

Figure 12-10 New Alias dialog box

Enter a name for the new alias, and click the WWN you want to attach to the alias. Click the right arrow to move the WWN into the Selected Members section.

If the device you want to alias is not connected to the fabric jet and is therefore not visible in the Potential Members section, you can also manually type in the WWN of the device in the Detached WWN field on the right bottom and click **Add**. Click **OK**.

The new alias displays in the Alias section of the Zoning dialog box (see the rounded rectangle in Figure 12-11).



Figure 12-11 Zoning dialog box with new alias

- 5. Click **Apply** or **OK** or repeat Steps 3-4 to add additional aliases. Save without enabling.
- 6. When this is completed, click **Apply** and/or **OK.** DCFM will save the changes in the fabric without activating it in the active config (Figure 12-12).



Figure 12-12 DCFM Message box

12.3.3 Creating a zone

A *zone* is a region within the fabric in which specified devices can communicate. A device can communicate only with other devices that are connected to the fabric within its specified zone.

You use the Zoning dialog box to create and manage zones. A zone can have one or multiple members and can include ports, WWNs, aliases, AL_PAs, or Quickloop.

Support: Quickloop is no longer supported from v4.4.x Fabric OS onwards.

Specifying members of a zone

You can specify members of a zone using the following methods:

- Alias names
- Switch domain and port index number pair (for example, 2 and 20)
- WWN (device)

Important:

- Create individual zones of each host to the disk storage subsystems. Also, hosts need a separate HBA for tape communication and, again, must be in another individual host/tape zone.
- Best practice is to have only one initiator (host HBA) in a zone, unless there is a specific requirement, such as encryption zones.
- This small granularity of zoning removes unnecessary PLOGI activity from host to host, as well as removing the risk of issues caused by a faulty HBA affecting others.

Using DCFM to create a zone

Follow these steps to create a zone with DCFM:

- From the DCFM Main window, click Configure → Zoning → Fabric to open the Zoning dialog box.
- 2. Select Alias in the **Type** pull-down menu.
- 3. Go to the Zone tab, and click New Zone, as shown in Figure 12-13.

zoning Scope Back Bone_s Zone DB Active Zone (SAN384B 💌	Zone DB Fabric Zone DB 🔻	Zone DB Operation Zone	DB Edit
Alias I Cna1_win Cna2_win D Ds5100_ch3_bot D Ds5100_ch3_bot D Ds5100_ch3_top D Ds5100_ch3_top D Ds5100_ch3_top D Ds5100_ch3_top D DS4700_A D DS4700_B_75 ITSOCLS1N1p1 ITSOCLS1N1p2 ITSOCLS1N1p3 ITSOCLS1N2p1 ITSOCLS1N2p2 ITSOCLS1N2p3 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N4p1 ITSOCLS1N3p2 ITSOCLS1N4p1 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSOCLS1N4p2 ITSO	Type Alias	Zones Find Image: Construct of the state of the s	Find Sofg A Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg Image: Sofg	Activate Ig Policies Report

Figure 12-13 New Zone

4. Enter a name for the new zone, and click outside of the naming field Figure 12-14. The new zone is displayed in the Zones section.

LSAN: If you are creating an LSAN zone, the zone name must begin with the letters, LSAN_.

ning Scope Back Bone_S	AN384B 🔻		Zone DB Fabric Zone DB 🔻	Zone DB Operation Zone DB Edit
Alias	Type Alias	▼ Find	Zones	Zone Configurations
Cna1_win cna2_win cna2_win Ds5100_ch3_bot Ds5100_ch3_bot Ds5100_ch3_top Ds4700_B_75 InSO_BTYPE ITSOCLS1N1p1 ITSOCLS1N1p3 ITSOCLS1N1p4 ITSOCLS1N2p3 ITSOCLS1N2p3 ITSOCLS1N2p3 ITSOCLS1N2p4 ITSOCLS1N2p4 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1 ITSOCLS1N3p1			ImailUS Imail_US Imail_CS Section of the section of t	
⊡-ITSOCLS1N4p2 New Alias Edit Exp	port	•	New Zone V New Member	New Configuration

Figure 12-14 Create new zone name

5. Now highlight the aliases that you want to have in the zone and move these aliases into the new zone by clicking the right arrow. See Figure 12-15.

In the example we add a host ITSO_BTYPE and a target DS4700_A to our new zone called ITSO_SANB_WIN2K_DS4K.



Figure 12-15 Move aliases to a zone

6. The Zones Section now has the aliases in the zone ITSO_SANB_WIN2K_DS4K. See Figure 12-16.

Repeat step 5 to add more aliases to the zone if required.

🖻 🛃 ITSO_SANB_WIN2K_DS4K
⊟-DS4700_A
- 🗊 [FCID:621b00] (VWVN 20:06:00:A0:B8:48:58:A1
E-ITSO_BTYPE
- IFCID:171300] (VWWN 10:00:00:05:1E:53:10:8B)

Figure 12-16 Aliases in zone

7. To save the configuration changes, click **Apply** or **OK**, a DCFM Message window opens that warns you that the changes made will only be saved to the fabric. See Figure 12-17.

💱 Zoning		
Zoning Scope Back Bone_SAN384B	Zone DB Fabric Zone DB V	Zone DB Operation Zone DB Edit
Zone DB Active Zone Configuration	4	4
Alias Type Alias	✓ Zones	Zone Configurations
 □ cna1_win □ cna2_win □ Ds5100_ch3_bot □ Ds5100_ch3_top □ Ds4700_A □ Ds4700_B_75 □ ITSO_BTYPE □ TSOC_S1Mtp1 	Find Find	Find Find Solution Find Find Solution Find Find Solution Find Fi
		×
ITSOCLS1N1p3 ITSOCLS1N1p4 ITSOCLS1N1p4 ITSOCLS1N2p1 Ensure no	ed zone DB will be saved to the fabric without activating a zone c other user is making changes to the same area prior to submitting	onfiguration.
	this again	Report
New Alias Edit	OK Cancel	
Brocade Native Mode		OK Cancel Apply Help

Figure 12-17 Save the configuration

12.3.4 Creating a zone configuration

To create a zone configuration:

- From the DCFM Main window, click Configure → Zoning → Fabric to open the Zoning dialog box
- 2. Click **New Config** and name the new config in the Zone Configs section (see Figure 12-18).

Zone DB Active Zone Configuration		
Alias Type Alias E cna1_win - E cna2_win - E Ds5100_ch3_bot - E Ds5100_ch3_top - E Ds5100_ch3_top - E Ds5100_ch3_top - E DS4700_A - E ITS0CLS1N1p1 - E ITS0CLS1N1p2 - E ITS0CLS1N1p3 - E ITS0CLS1N2p1 - E ITS0CLS1N2p2 - E ITS0CLS1N2p4 - E ITS0CLS1N3p2 - E ITS0CLS1N4p1 - E ITS0CLS1N3p2 - E ITS0CLS1N4p1 - ITS0CLS1N4p1 - - ITS0CLS1N4p1 - -	▼ Zones Zone Configurations Find □ cfg ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ </th <th>DS4K Tg Report</th>	DS4K Tg Report

Figure 12-18 Name the new config

3. Highlight the Zone or Zones that you want to move to the ITSO_Backup_cfg and move the Zone or Zones by clicking the right arrow. See Figure 12-19.



Figure 12-19 Move zone to the new config

4. Click **OK** or **Apply** to save the config to the fabric without activating it.

12.3.5 Enabling zone configurations

Several zone configurations can reside on a switch at the same time, and you can alternate between them quickly. For example, you might want to have one zone configuration enabled during the business hours and another enabled for backups overnight. However, only one zone configuration can be enabled at a time.

When you enable a zone configuration, the entire zoning database is saved automatically, and then the selected zone configuration is enabled.

If the zoning database size exceeds the maximum allowed, you cannot enable the zone configuration.

To enable a zone configuration, follow these steps:

- From the DCFM Main window, click Configure → Zoning → Fabric to open the Zoning dialog box.
- 2. To activate a configuration, highlight the configuration in the Zone Config section and click **Activate...** See Figure 12-20.

Zoning Scope Back E Zone DB Active	3one_SAN384B ▼ Zone Configuration	Zone DB Fabric Zone DB	T	Zone DB Operation	Zone DB Edit
Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Calculation Alias Alias Calculation Alias	Type Alias	 Zones Find A cna1_DS Cna2_DS A cna2_DS A tzone Mitzone MitSo_SANB_WN2K_DS4K DS4700_A ITSO_BTYPE A Isan_BM_SAN384B Mike_win2k_38_ds4kENktst_dp1 Mike_win2k_38_ds4kENktst_dp2 Mike_win2k_38_ds4kENktst_dp2 Mike_win2k_38_cds4kENktst_dp3 Mike_WV2K_38_Enctest Mike_WV2K_60_Enctest 		Zone Configurations	Activate Zoning Policies
ITSOCLS1N2p3 New Alias Edit	Export	New Zone V New Member	•	New Configuration OK Cancel	Apply Help

Figure 12-20 Enable Config

The Activate Zone Configuration window displays. This window gives detailed information about the changes that will take place by activating the new configuration. Carefully read the information given. To activate the new configuration, click **OK**, as shown in Figure 12-21.

Activate Zone Configuration		×
The changes to zoning that will be Warning: Any zoning activation car	in affect after activation are detailed here. n disrupt fabric traffic. Review your changes carefully be	fore clicking on OK.
Fabric Name	Back Bone_SAN384B	
Current Active Zone Configuration	IBM_RB	
Selected Zone Configuration	ITSO_win2k_DS4K	
Summary		
Active zone configuration changes	\$	
1 Zone Added 2 Zone Markhans Added	31 Zones Removed 430 Zones Mamiltone Domescal	
2 Zone Members Added	138 Zone Members Removed	
Active Zone Configuration Compa	rison Full View	🗹 Change Only
□ □	(WWN 10:00:00:05:1E:AF:08:A1) Brocade Communication (WWN 20:38:00:A0:B8:47:39:B0) SYMBIOS LOGIC INC. (WWN 20:37:00:A0:B8:47:39:B0) SYMBIOS LOGIC INC. (WWN 10:00:00:05:1E:AF:08:A0) Brocade Communication (WWN 20:38:00:A0:B8:47:39:B0) SYMBIOS LOGIC INC. (WWN 20:37:00:A0:B8:47:39:B0) SYMBIOS LOGIC INC. 2X_DS4K (WWN 10:00:00:05:1E:53:10:8B) Brocade Communication (WWN 20:06:00:A0:B8:48:58:A1) SYMBIOS LOGIC INC.	is Systems, Inc. is Systems, Inc.
Zana DB Campariaan Comparad		0000000000000
Zone DB Comparison	merge	
Generate a report with the acti	vation of new zone configuration	
	<u>ok</u> c	ancel <u>H</u> elp

Figure 12-21 Activate Zone Configuration window

 DCFM saves the zone database to the fabric, and enables the zone configuration that replaces the old one. A message box displays to inform you that these changes were successfully made (see Figure 12-22). Click OK.

Precautions:

- Remember to back up your configuration prior to making any configuration changes so that you can always get back to your starting point if there are any problems.
- Take care when enabling zone configurations. Adding new zones does not impact any currently running definitions, although removing a zone might have a large impact to the current environment.



12.3.6 Adding a zone to a existing zone configuration

The process used to add a new zone into an existing zone configuration is the same as adding it to an existing zone configuration (Figure 12-23).

Select the zone that you require to add, and by selecting the active zone configuration, place this zone into the active configuration using the arrow buttons. This zone is added to the active zone configuration and will show in this configuration without the green button to show that it is not yet active.

The active zone configuration, in the example, *IBM_RB*, will no longer have the green button next to the name to indicate that there are zones not active in the configuration. Select the active zone configuration and click the **Activate** button.

	Zoning
Zone DB V Zone DB Operation Zone DB Edit	oning Scope Back Bone_SAN384B Zo
Zone Configurations	Zone DB Active Zone Configuration Alias Type Alias Find Stress Fi
Image: Second second	Characteria constraints of the second
Member New Configuration	In InSOCESTN294 New Alias Edit Export Brocade Native Mode

Figure 12-23 Adding zone to active zone configuration

The next window shows you what is about to change; this must only be the new zone that was added (Figure 12-24).

💱 Activate Zone Configuration		×
The changes to zoning that will be i Warning: Any zoning activation can	n affect after activation are detaile disrupt fabric traffic. Review you	ed here. ir changes carefully before clicking on OK.
Fabric Name	Back Bone_SAN384B	
Current Active Zone Configuration	IBM_RB	
Selected Zone Configuration	IBM_RB	
Summary		
Active zone configuration changes 1 Zone Added 2 Zone Members Added		
Active Zone Configuration Compar	ison Full View	✓ Change Only
 □ ● ● ● ITSO_SANB_WIN: □ ● ● ● [FCID:171300] □ ● ● ● [FCID:621b00] 	2K_DS4K (VWVN 10:00:00:05:1E:53:10:8B) E (VWVN 20:06:00:A0:B8:48:58:A1)	Brocade Communications Systems, Inc. SYMBIOS LOGIC INC.
Zone DB Comparison Compare/	Merge	
Generate a report with the activ	vation of new zone configuration	
		OK Cancel Help

Figure 12-24 Add to existing zone configuration

Click the **OK** button and this will activate the zones displayed in the active zone configuration comparison full view window. This process is concurrent and will not affect any other configured zones.

12.3.7 Analyzing a zone configuration

After any configuration is saved, you can right-click the Fabric Name in the Connectivity $Map \rightarrow$ select **Connected End Devices** \rightarrow **Custom...** See Figure 12-25.

Niew	All - DCFM 10.4.2						
Server	Edit View Discover Co	onfigure <u>M</u> onitor <u>F</u>	eports <u>T</u> ools <u>H</u> elp				
	🖌 🍕 🚭 🔶		Decimal 🔻	Name	▼ Port Address	▼	✓ ★ Search ?
SAN							
View	All 🔻		0 5 0	₹ E		E	Export 🔍 🍳 🎇 🎵 💕
All Leve	ls	Name 🤝	Firmware				▲
🕀 🔾 ,	📚 EDGE_IBM_B32	EDGE_IBM_B32	4				
E 😑	🔾 🍛 Back Bone_SAN384E	Back Bone_SAN384	в				
±	😑 🤳 Host Group 🤳 Storage Group			:ch Grou	9		
D -	😌 🥪 Switch Group						
	🕀 🥯 SAN32B-E4-2	SAN32B-E4-2	v6.4.1		_]	-	
	🕀 🧼 SAN32B-E4-1	SAN32B-E4-1	v6.4.1				
	🗉 🦢 switch	switch	v6.4.1	0000005	EE779EE 200000	2008	
	IBM_SAN384B_27	IBM_SAN384B_27	v6.4.1	5000005	12377012 200000	Zoning	200004030A0 200000A
	⊡ ¹ ¹ ¹ ¹ ¹ ¹ ¹ ¹ ¹ ¹	IBM_2498_R06	v6.4.1			LSAN Zoning (Device Sharing)	
		B5000_76	V6.4.1		Host Group	Performance	Storage Group
	⊞- 🧼 B5000_75	D5000_75	V0.4.1			Events	
					Back	Configure FCIP <u>T</u> unnels	
						High Integrity Fabric	-
			•		1999	Fabric Binding	
						Router Configuration	
Master	Log 🔲 <u>Filter</u> 🗌 Only ev	ents for current view	·	< Page	1 of 1 >	Routing Domain IDs	1 K
Level	Source Name	Source Address	Туре		Description	Technical Support	•
) IBM_SAN384B_27	10.18.228.27	Zoning Event		Successfully at 📤	View	•
	BM_SAN384B_27	10.18.228.27	Zoning Event		Updated Zone 🖾	Track Fabric Changes	
	BM_SAN384B_27	10.18.228.27	Product Event		The effective co	Accept Change(s)	
	switch	10.18.228.18	Product Event		The effective co	Trace Route	
(SAN32B-E4-1	10.18.235.54	Product Event		The effective co	Connected End Devices	Include Virtual Devices
1	SAN32B-E4-1	10.18.235.54	Product Event		port 40 (0×28) e	Create View Automatically	O Hide All
(SAN32B-E4-1	10.18.235.54	Product Event		port 36 (0×24) e 🚽	Map Display	O Show All
4 88888		10 10 005 F1	<u> </u>			Collapse	<u>C</u> ustom
\$ \$ \$	6 🗢 🕹 🕘	🎸 🕅 😵	BOR8 Clients 3 adi	ministrator		Properties	·

Figure 12-25 Analyze Zone Config

The Connected End Devices Window opens (Figure 12-26). Select the zones you want to show in the connectivity map \rightarrow Click the right arrow to move the zones to **Selected Zones**.

💦 Co	nnected End Devices - Custom display	for Ba	ck Bo	ne_SAN38	4B			×
Use	this dialog to create a display of the connect	ed end	devic	es participat	ing in a single zone	or a group of zo	nes for Back	
Bone	SAN384B. You may also save and name t	ne zone	e or gr	oup of zone	s as an Application	- ·		
Zone	es in Back Bone, SAN384B			Application	<custom></custom>	•	Save	Delete
				Selected 7o	nes			
	MIKE WOK SO Enclose	000	6	ITSO SANB	JAIN2K DS4K			
	Mike VACK 38 Enclest			1130_3AND	034N			
		#						
	Server101822838_svc	8						
		##						
. <u> </u>		88 - C						
E-	onal DS		M					
. E	ana2_DS	- Hereiter - Hereiter						
E-	💑 🗌 Isan_IBM_SAN384B							
E -	Nike_win2k_38_ds4kENKtst_dp0 💀							
E -	Nike_win2k_38_ds4kENKtst_dp1 💀	88 A						
⊡ -	mike_win2k_38_ds4kENKtst_dp2							
E-	mike_win2k_38_ds4kENKtst_dp3							
E-	zone_DS4700_B_DS4700_B_75							
E-	Zone_DS4700_B_ITSOCLS1N1p1							
E-	zone_DS4700_B_ITSOCLS1N1p2							
E-	zone_DS4700_B_ITSOCLS1N2p1							
E -	zone_DS4700_B_ITSOCLS1N2p2	-						
	Zone DS4700 B ITSOCLS1N3p1	-						
						ок	Cancel	Help

Figure 12-26 Connected End Devices window



In the connectivity map, now only the selected zone displays. See Figure 12-27.

Figure 12-27 Connectivity map

From the Connectivity map, you can now gather more information. For example, select the link between an adapter card and a switch by right-clicking it, then click **Properties**. The Connection Properties window opens (see Figure 12-28).

Switch 23 Back Bone_SAN 10.18.229.77 B5000_75	.N384B	🗊 Produ	ıct				
 Switch 23 Back Bone_SAN 10.18.229.77 B5000_75 	.N384B	🧊 Produ	ıct				
23 Back Bone_SAN 10.18.229.77 B5000_75	N384B I	-					
Back Bone_SAN 10.18.229.77 B5000_75	N384B						
10.18.229.77 B5000_75		Back Bone	SAN384B				
B5000_75							
10:00:00:05:1E:9	:90:16:E9	20:06:00:A	A0:B8:48:58:A0				
ort Type 1-WWPN	1-IP A	Address	1-Speed (Gb 2-Port a	2-Port Type	2-WWPN	2-IP Address	2-S
ort 20:1B:00:05	05: 10.18	8 220 77	4	N	20:07:00:A0:B8:48:58:A1		
		0.223.11	4	••		388838888	
o Pronerties			4				•
n Properties							•
n Properties • Switch 🗊 Produc	uct		4			20222222	•
n Properties Produce 27	uct		4			222222222	
n Properties Switch I Produce 27	uct		4	1			
n Properties Switch I Produc 27	uct		4	N			
n Properties Switch 🗊 Produc 27	uct		4	N			
n Properties Switch I Produc 27 B5000_75			4	N			
n Properties Switch I Produc 27 . B5000_75	uct		4				
n Properties Switch I Produc 27 . B5000_75	uct		4	1			
	ort Type 1-WWPN	'ort Type 1-VWVPN 1-IP tot 20:45:00.05: 10.1	fort Type 1-WWPN 1-IP Address	Int Type 1-WWPN 1-IP Address 1-Speed (Gb 2-Port # tot 2018:00:05: 10.48:229.77 4	I-P Address I-Speed (Gb 2-Port # 2-Port Type 2011B:00:05: 10.18.229.77 4 N	Image: Northway with the second sec	Image: Nort Type 1-WWPN 1-IP Address 1-Speed (Gb 2-Port # 2-Port Type 2-WWPN 2-IP Address 10rt 2018:00:05 10:18:228:77 4 N 20:07:00:40:B6:48:58:41

Figure 12-28 Connection Properties

12.4 Basic zoning using Web Tools

Web Tools is an easy-to-use interface that enables organizations to monitor and manage *single* Brocade Fabric OS (FOS) switches. (For fabric-wide monitoring, management, and zone administration, see 12.2, "Zoning using DCFM" on page 516.)

Tool: DCFM is the preferred tool for all zone configuration and administration. The basic version, called DCFM Professional, does not require a licence and can be downloaded from Brocade, however it is not supported by IBM.

DCFM Professional is designed for organizations that have a FOS-only environment and want a management solution for smaller SANs based on a single fabric. DCFM professional can be download from the following link:

http://www.brocade.com/forms/jsp/dcfmdownload/dcfm_download.jsp

Features removed: Starting with Fabric OS version 6.1.1, the following features related to fabric configuration and management have been removed from the Web Tools management interface and implemented in Data Center Fabric Manager (DCFM):

- Add Un-Zoned Devices
- Analyze Zone Config
- Define Device Alias
- Device Accessibility Matrix
- ► Fabric Events
- ► Fabric Summary
- ► FCIP Tunnel Configuration
- ► GigE Ports Interface
- ► GigE Ports Route
- Non-Local Switch Ports Display in Zoning Tree
- Remove Offline or Inaccessible Devices
- Zone Database Summary Print

Tasks can be performed by using a Java-capable Web browser from standard laptop, desktop PCs, or workstations from any location within the enterprise.

12.4.1 To start zoning with Web Tools

Follow these steps:

- 1. Open the Web browser and type the IP address of the device in the Address field, for example, http://9.155.77.77 and press Enter. Click **Run** on the signed certificate applet. If you select the check box, **Always trust content** from this publisher, the dialog box is not displayed when you open Web Tools again.
- 2. A browser window opens to open Web Tools and a Login dialog box opens.

Browser window: If you are using Firefox, the browser window is left open. You can close it anytime after the Login dialog box displays. If you are using Internet Explorer, the browser window automatically closes when the login dialog box displays.

3. Log in using your User name and Password (see Figure 12-29).

₩ Please Login							
Please enter user name and password.							
Resource	9.155.87.48						
<u>U</u> ser Name	admin						
Password	•••••						
	QK Cancel Options >>						

Figure 12-29 Login dialog box

Be aware that Web Tools uses Role-Based Access Control (RBAC). See Table 12-1 for the capabilities of the various roles.

Table 12-1 R	oles and their	capabilities
--------------	----------------	--------------

Role	Capabilities
admin	You have full access to all of the Web Tools features.
operator	You can perform any actions on the switch that do not affect the stored configuration.
securityadmin	You can perform actions that do not affect the stored configuration.
switchadmin	 You can perform all actions on the switch, except that: You cannot modify zoning configurations. You cannot create new accounts. You can only view your own account and change your account password.
zoneadmin	You can only create and modify zones.
fabricadmin	You can do everything the Admin role can do except create new users.
user	You have non-administrative access and can perform tasks such as monitoring system activity.
basicswitchadmin	You have a subset of Admin level access.

4. The first thing that you see when you log in to a switch with Web Tools is the Switch Explorer, shown in Figure 12-30.

18M_SAN384B_27 - We	eb Tools		
Manage Reports Monitor	Tools		
Tasks Manage Zone Admin	Admin Domain AD0	Egend Switch Status Policy	/ Log Out
Switch Admin Port Admin Admin Domain		Switch Events Switch Information All Events Last Updated: Wed Nov 03 20	010 10:27:39 PDT (Auto-Refr
방문 FCR 행왕 Fabric Watch		Time Tue Nov 02 2010 15:24:07 PD1 Tue Nov 02 2010 19:24:07 PDT	Level Message Information Zoning tr
Monitor Performance Monit		Tue Nov 02 2010 19:25:08 PDT Tue Nov 02 2010 19:25:08 PDT Tue Nov 02 2010 19:25:08 PDT Tue Nov 02 2010 19:25:19 PDT	Information Zoning tr Information The effect Information Zoning tr Information Zoning tr
Other		Tue Nov 02 2010 19:25:20 PDT Tue Nov 02 2010 19:25:20 PDT Wed Nov 03 2010 09:08:56 PDT Wed Nov 03 2010 09:08:56 PDT	Information The effect Information Zoning tr Information Zoning t
	2 2 	Wed Nov 03 2010 03:08:56 PDT Wed Nov 03 2010 09:08:56 PDT Wed Nov 03 2010 09:11:47 PDT Wed Nov 03 2010 09:11:47 PDT	Information Zoning tr Information Zoning tr Information The effect
Fabric Tree 🔗		Wed Nov 03 2010 09:11:47 PDT Wed Nov 03 2010 09:30:21 PDT Wed Nov 03 2010 09:30:21 PDT	Unformation Zoning tr Unformation Zoning tr Unformation The effe
Fabric	-	Wed Nov 03 2010 09:30:21 PDT Getting events from switchdone	Q/Information Zoning tr ▼
	Free Profession	al Management Tool 10.18.228.27 Al	00 User: admic Role: admin

Figure 12-30 Switch Explorer

5. Be sure that the role assigned to you has the rights to perform zoning (see Table 12-1 on page 545). The role assigned to you is shown in the Switch Explorer in Figure 12-30 (see the rounded rectangle). Click **Zone Admin**.

🗄 BDPOC01L01 - Zone Administration				
Zoning Modes	Basic Zones			
Basic Zones	Print Edit View Zoning Actions Tools			
Traffic Isolation Zones	⊡ New 🔻 Resource View 🔻 🍫 Refresh 🔻 Enable Config 🛛 Save Config 🛛 Clear All			
	Alias Zone Config			
	Name XIV_WS_HS20_lab_20_P0 New Alias Delete Rename			
	Member Selection List Alias Members			
	A Search 1 Member. A	Search		
	Ports & Attached Devices(200 Members)	57		
	Here www.s (sz Devices)			
	< <u>Remove Member</u>			
	Add Other			
	Current View: Fabric View 🕒 Effective Zone Config:	shared		
Switch Commit Messages:				
Zone Admin opened at Do Jul 23 2009 18:02:44 GMT+00:00				
Loading information from Fabric Done 9.155.87.48 AD0 User: admin Role: admin				

6. The Zone Admin window opens, as shown in Figure 12-31.

Figure 12-31 Zone Administration window

Changes: Any changes you make in the Zone Administration window are held in a buffered environment and are not updated in the zoning database until you save the changes. If you close the Zone Administration window without saving your changes, your changes are lost. Consider the following terms:

- Saving: Updates the zoning database on the switch with the local changes from the Web Tools buffer.
- *Refreshing:* Copies the current state of the zoning database on the switch to the Web Tools buffer, overwriting its current contents.

12.4.2 Creating an alias

By defining an alias to ports or WWNs, you can simplify the configuration of a device that is being zoned. Using a sensible naming convention also assists with troubleshooting at a later stage, making it easier to find specific devices, especially when a SAN grows in complexity. Assign aliases and ensure that they are maintained to help to identify SAN components correctly using the Alias tab.

You can specify members of an alias using the following methods:

- ► A switch domain and port index number pair (for example, 2 and 20)
- Device node and device port WWNs

In this section we describe methods for creating an alias:

 Select a format to display zoning members in the Member Selection by clicking View → Choose Fabric Resources View, then. Select Fabric View or Devices Only as shown in Figure 12-32.

IBM SAN384B 27 - Zone A	Administration			
Zoping Modes	Basic Zones			
Basic Zones	Print Edit View Zoning Action:	and the second sec		
Traffic Isolation Zones	Choose Fabric Resou	urce View Ctrl-W Finable Config Save Config Clear All		
	Alias Z Refresh Zoning	Choose your desired fabric resource view type		
	Name DS4700 A	Abric Ctric		
		Tour must Found Tournus		
	Member Selection List	Alias Members		
	🕂 💻 Port 🛃 Choose Fabric I	Resource View		
	Select how you wa	vant to view fabric resources		
	Fabric View Devices Only	Displays the physical hierarchy of the current switch (slots and ports) and devices within the fabric. A flat list of attached and imported physical devices by WWN, and a list of FC Virtual Initiators on switches that support ISCSI. Allows selection of ports for port-based zoning, or of devices for WWN-based zoning (recommended). V Displays a flat list of attached and imported physical devices by WWN. Allows selection of physical devices for WWN-based zoning only. Selection of ports for port-based or mixed zoning schemes, and of virtual initiators for ISCSI FC Zone creation, is not supported in this view. QK Qancel		
	Current View: Fabric View	실 Effective Zone Config: IBM_RB		
Switch Commit Messages:				
Zone Admin opened at Wed Nov 03 2010 10:01:37 PDT The transaction (id = 0) was aborted at Wed Nov 03 2010 10:25:39 PDT Varnina: Forced closure: Unsaved zonina changes will be tost.				
Loading information from Fabric Done		Free Professional Management Tool 10.18.228.27 AD0 User: admin Role: admin		

Figure 12-32 Select a format
2. Click the **Alias** tab, and click **New Alias**. The Create New Alias dialog box displays, as shown in Figure 12-33.

🛃 IBM_5AN384B_27 - Zone A	idministration
Zoning Modes	Basic Zones
Basic Zones	Print Edit View Zoning Actions
Traffic Isolation Zones	🖸 New 🔻 Resource View 🔻 🗞 Refresh 🔻 Enable Config Save Config Clear All
	Alias Zone Zone Config
	Name DS4700_A New Alias Delete Rename
	Member S Create New Alias
	1 Member.
	Alias name ITSO_DS5100_A1 mber >> /e Member Dther
	Current View: Fabric View Effective Zone Config: IBM_RB
Switch Commit Messages:	
Zone Admin opened at Wed Nov 0 The transaction (id = 0) was abort	I3 2010 10:01:37 PDT
Warning: Forced closure. Unsaved	d zoning changes will be lost.
Loading information from Fabric I	Done <u>Free Professional Management Tool</u> 10.18.228.27 AD0 User: admin Role: admin 😥

Figure 12-33 New Alias

Enter a name for the new alias, and click **OK**. The new alias displays in the Name drop-down list, In this example, we create an alias with the name **ITS0 DS5100 A1**

- 3. Expand the Member Selection List to view the nested elements. The choices available in the Member Selection List depend on the selection in the View menu.
- 4. Click the elements in the Member Selection List that you want to include in the alias. The **Add Member** button becomes active (Figure 12-34).
- 5. Click **Add Member** to add an alias member. The selected member is added to the Alias (Figure 12-34).
- 6. Optionally, click **Add Other** to include a WWN or port that is not currently a part of the fabric. At this point, you can either save your changes, or you can save and enable your changes (Figure 12-34).
- 7. Click **Save Config** to save the configuration changes. Click **OK** in the window that opens. Remember that this is not applying to the fabric (Figure 12-34).



Figure 12-34 Save without enabling

12.4.3 Creating a zone

A *zone* is a region within the fabric in which specified devices can communicate. A device can communicate only with other devices that are connected to the fabric within its specified zone.

You use the Zone tab to specify which devices or switch ports are in the selected zone and to create and manage zones. A zone can have one or multiple members and can include ports, WWNs, aliases, AL_PAs, or Quickloop.

Quickloop: Quickloop is no longer supported from v4.4.x Fabric OS onwards.

You can specify members of a zone using the following methods:

- Alias names
- Switch domain and port index number pair (for example, 2 and 20)
- WWN (device)

Important: Create individual zones of each host to the disk storage subsystems. Also, hosts need a separate HBA for tape communication and, again, must be in another individual host/tape zone.

This small granularity of zoning removes unnecessary PLOGI activity from host to host, as well as removing the risk of issues caused by a faulty HBA affecting others.

12.4.4 Using Web Tools to create a zone

1. From the Zone Administration Main window, go to the Zone tab, and click **New Zone**. The Create New Zone dialog box displays. Enter a name for the new zone, and click **OK**, as shown in Figure 12-35.

🛃 IBM_SAN384B_27 - Zone A	dministration
Zoning Modes	Basic Zones
Basic Zones	Print Edit View Zoning Actions
Traffic Isolation Zones	🛃 New 🔻 Resource View 🔻 🤣 Refresh 🔻 Enable Config 🛛 Save Config 🛛 Clear All
	Alias Zone Zone Config
	Name ITSO_SANB_WIN2K_DS4K Vew Zone Delete Rename Clone
	Member Seleci 💀 Create New Zone
	Ports a 2 Members.
	Image: Second second
	QK Cancel Other
	Current View: Fabric View 🔂 Effective Zone Config: IBM_RB
Switch Commit Messages: Zone Admin opened at Wed Nov 0 The transaction (id = 0) was abort Warning: Forced closure. Unsaved	3 2010 10:01:37 PDT ed at Wed Nov 03 2010 10:25:39 PDT I zoning changes will be lost.
Loading information from Fabric [Done <u>Free Professional Management Tool</u> 10.18.228.27 AD0 User: admin Role: admin 🕄

Figure 12-35 Create new zone

The new zone displays in the Name drop-down list.

LSAN: If you are creating an LSAN zone, the zone name must begin with the letters, LSAN_.

- 2. Expand the Member Selection List to view the nested elements. The choices that are available in the list depend on the selection made in the View menu.
- Select an element in the Member Selection List that you want to include in your zone. Note that LSAN zones should contain only port WWN members. The Add Member button becomes active. Click Add Member to add the zone member. The selected member is moved to the Zone Members window (Figure 12-36).
- 4. Optionally, click **Add Other** to include a WWN or port that is not currently a part of the fabric. At this point you can either save your changes or save and enable your changes (Figure 12-36).
- 5. Click **Save Config** to save the configuration changes. without applying them to the fabric. Click **OK** at the next window (Figure 12-36).



Figure 12-36 Zone members

12.4.5 Creating a zone configuration

Use the Zone Config tab to create or to update a zone configuration. You use zone configurations to enable or disable a group of zones at the same time. To create a zone configuration, follow these steps:

 Click the Zone Config tab, and click New Zone Config. The Create a New Config dialog box opens. Enter a name for the new configuration and click OK, as shown in Figure 12-37.

🛃 IBM_SAN384B_27 - Zone Administra	ation				_ 🗆 ×
Zoning Modes	nes				
Basic Zones	dit ⊻iew Zoning <u>A</u> ctions				_
Traffic Isolation Zones	w 🔻 Resource View 🔻	🍫 Refresh 🔻 🛛 Enable C	onfig Save Config Cla	ear All	_
Alias	Zone Zone Config				
Name	IBM_RB	▼ New Zone Co	onfig <u>D</u> elete Re <u>n</u> ame <u>C</u> lo	one	
Membe	er Seleci 🄜 Create New Config	X	Zone Config Membe	rs	
	Zones		32 Zones.		
	Image: Second second	ingelhost More Me mbers)	 cna1_DS cna2_DS iTSO_SANB itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_S itSan_IBM_	E_WIN2K_DS4K AN384B 38_Enctest 60_Enctest _38_ds4kENKtst_dp0 _38_ds4kENKtst_dp1 _38_ds4kENKtst_dp2 _38_ds4kENKtst_dp3	
Curren	t View: Fabric View		6	Effective Zone Config:	IBM_RB
Switch Commit Messages:					-
Zone Admin opened at Wed Nov 03 2010 10: The transaction (id = 0) was aborted at Wed	:01:37 PDT Nov 03 2010 10:25:39 PDT				199
Warning: Forced closure. Unsaved zoning ch	nanges will be lost.				-
Loading information from Fabric Done		Free Professional Managemen	<u>t Tool</u> 10.18.228.27 AD	00 User:admin Role:ad	łmin 🛛 😥

Figure 12-37 Create New Zone Config

2. Expand the Member Selection List to view the nested elements.

The choices that are available in the list depend on the selection made in the View menu.

3. Select an element in the Member Selection List that you want to include in your configuration.

The Add Member button then becomes active.

4. Click **Add Member** to add zone configuration members. The selected members are moved to the Config Members window, as shown in Figure 12-38.

Click **Save Config** to save the zone configuration changes. without applying them to the fabric, as shown in Figure 12-38.



Figure 12-38 Zone Config

12.4.6 Enabling zone configurations

Several zone configurations can reside on a switch at the same time, and you can alternate between them quickly. For example, you might want to have one zone configuration enabled during the business hours and another enabled overnight. However, only one zone configuration can be enabled at a time.

When you enable a zone configuration from Web Tools, the entire zoning database is saved automatically, and then the selected zone configuration is enabled.

If the zoning database size exceeds the maximum allowed, you cannot enable the zone configuration.

To enable a zone configuration, follow these steps:

- 1. In the Zone Administration window, click Enable Config.
- 2. Select the zone configuration to be enabled from the drop-down menu and click **OK**, as shown in Figure 12-39.

N 18M_SAN384B_27 - Zone	Administration				
Zoning Modes	Basic Zones				
Basic Zones	Print Edit View Zoning Actions				
Traffic Isolation Zones	🚇 New 🔻 Resource View 💌 🤣 Refresh 🔻 Enable Config Save Config Clear All	_			
	Alias Zone Zone Config				
	Name ITSO_Singelhost Vew Zone Config Delete Rename Clone				
	Member Select Choose Zone Config to be enabled				
	Image: Select a config to enable: Image:				
	Current View: Fabric View 🕒 Effective Zone Co	nfig: IBM_RB			
Switch Commit Messages: Zone Admin opened at Wed Nov The transaction (id = 0) was abo Warning: Forced closure. Unsave	/ 03 2010 10:01:37 PDT onted at Wed Nov 03 2010 10:25:39 PDT red zoning changes will be lost.				
Loading information from Fabric	Done Free Professional Management Tool 10.18.228.27 AD0 User: admin F	Role: admin 🛛 😵			

Figure 12-39 Choosing the right config to enable

This saves the zone database to the fabric, and enables the zone configuration that replaces the old one. A message box displays to inform you that this save can result in temporary disruption to I/O. Click **Yes**, as shown in Figure 12-40.

Precautions:

- Remember to back up your configuration prior to making any configuration changes so that you can always get back to your starting point if there are any problems.
- Take care when enabling zone configurations. Adding new zones does not impact any currently running definitions, although removing a zone might have a large impact to the current environment.

Enable C	onfig ITSO_Singelhost 🛛 🗙
•	You are about to enable the Zoning Configuration: ITSO_Singelhost. This action will replace the old zoning configuration with the current configuration selected. Data disruption will occur on enabling QoS zones. This could be a lengthy process and may result in temporary interruption of I/O. Do you want to enable configuration ITSO_Singelhost? <u>Yes</u> <u>No</u>
Figure	e 12-40 Enabling the zone configuration

3. The commit process can be monitored and you can wait for the commit to be successful. When the save is complete, the Effective Zone Config is now ITSO_Singlehost (Figure 12-41).

BM_5AN384B_27 - Zone #	Administration	-01
Zoning Modes	Print Edit View Zoning Actions	😤 Refresh ▼ Enskle Confin Save Confin Clear &II
	Alias Zone Zone Config Name IBM_RB	New Zgne Config Delete Rename Gone
	Member Selection List	Add Member >> 32 Zones; Add Member >> 32 Zone_DS4700_B_ITSOCLS1N2p2 Add Member >> 32 Zone_DS4700_B_ITSOCLS1N3p1 < Remove Member < Remove Member < Zone_DS4700_B_ITSOCLS1N4p1 < Zone_DS4700_B_ITSOCLS1N4p1 < Zone_DS4700_B_ITSOCLS1N4p1 < Zone_DS4700_B_ITSOCLS1N4p1 < Zone_DS4700_B_ITSOCLS1N4p1 < Zone_DS4700_B_ITSOCLS1N4p2 Zone_DS4700_B_ITSOCLS1N4p2 Zone_DS4700_B_ITSOCLS1N4p2 Zone_DS4700_B_ITSOCLS1N4p2
	Current View: Fabric View	Cffective Zone Config: ITSO_Singelhost
start of commit (Enable Config) The zone transaction (id = 34669) start of commit at: Wed Nov 03 Commit succeeded.	at: Wed Nov 03 2010 11:43:50 PDT is complete.Wed Nov 03 2010 11:43:50 PDT 2010 11:43:50 PDT	
Successfully committed the chang	jes to the fabric.	Free Professional Management Tool 10.18.228.27 AD0 User: admin Role: admin

Figure 12-41 Effective zone config

12.4.7 Analyzing a zone configuration

After any configuration is saved, select **Analyze Config**, as shown in Figure 12-42, to check the validity of the zone configuration. Analyzing a zone configuration can alert you to ports and WWNs that you have not included.

IBM_2109_M48 - Zone Administration		_ 🗆 🗵
<u>File Edit ⊻iew Zoning Actions T</u> ools		
📇 New 🔹 Resource View 🔹 🕎 Refresh	 Enable Config Save Config Clear All 	
Alias Zone Zone Config		
Name ITSO_Analyze	New Zone Config Delete Rename Clone Analyze Zone Config Device Accessibility	
Member Selection List	Zone Config Members	
	件 <u>Search</u>	件 <u>Search</u>

Figure 12-42 Analyze Zone Config

You are prompted to refresh the current configuration from the switch so that the analyze operation checks the most recent information from the fabric, as shown in Figure 12-43.

IBM_2109_M48 - Zone Administration	
Eile Edit View Zoning Actions Tools	
📇 New 🔹 Resource View 🝷 🍫 Refresh 🝷 Enable Config Save Config Clear All	
Alias Zone Config	
Name ITSO_Analyze New Zone Config Delete Rename Clone Analyze Zone Config Device Accessibility	
Member Selection List Zone Config Members	
At Search At Search	<u>Search</u>
⊡ Zones □ x345_tic29_to_xiv_lab2 □ x345_tic3_xiv_lab2_all □ x345_tic3_xiv_lab2_all	
E ZGPFS_SLE06v2	
Refresh Fabric	
It's recommended to refresh with the latest Eabric status before analyzing coning config	
Do you want to refresh the Fabric now?	
Yes Cancel	

Figure 12-43 Refresh status

Remember to review the output of the analysis and make adjustments (if appropriate) before activating the configuration. Figure 12-44 shows an example of the output, which indicates the WWNs listed are not members of the selected configuration.

IT50_Analyze Analysis
1. The following SAN components are not in the selected configuration:
Symbios Logic Inc. 20:14∖00:a0:b8:11:19:b2
Symbios Logic Inc. 20:06:00:a0:b8:11:19:b2
Symbios Logic Inc. 20:17:00:a0:b8:11:19:b2
Symbios Logic Inc. 20:06:00:a0:b8:11:f9:b2
Symbios Logic Inc. 20:47:00:a0:b8:47:52:ea
Symbios Logic Inc. 20:06:00:a0:b8:47:52:ea
Symbios Logic Inc. 20:56:00:a0:b8:47:52:ea
Symbios Logic Inc. 20:06:00:a0:b8:47:52:ea
21:00:00:1b:32:00:74:34
20:00:00:1b:32:00:74:34
21:00:00:1b:32:1b:84:fc
20:00:00:1b:32:1b:84:fc
Qlogic Corp. 21:00:00:e0:8b:9d:1a:4c
Qlogic Corp. 20:00:00:e0:8b:9d:1a:4c
Qlogic Corp. 21:00:00:e0:8b:9d:8c:4c
Qlogic Corp. 20:00:00:e0:8b:9d:8c:4c
Qlogic Corp. 21:01:00:e0:8b:bd:1a:4c
Qlogic Corp. 20:01:00:e0:8b:bd:1a:4c
Qlogic Corp. 21:01:00:e0:8b:bd:8c:4c
Qlogic Corp. 20:01:00:e0:8b:bd:8c:4c
IBM 50:05:07:63:03:ff.ce:63
Close

Figure 12-44 Sample of Analyze Config output

The Zoning Configuration Analyze window displays a summary of the saved configuration and attempts to point out some of the zoning conflicts before applying the changes to the switch. Some of the potential errors it might catch include these:

- Ports, WWNs, or devices that are part of the selected configuration but that are not part of the fabric
- Zones with only a single member

12.4.8 Zoning and E_Ports

When creating a zone, you only work with device ports or host ports (F_Ports, FL_Ports, and L_Ports). Any ISL ports (E_Ports) should not be included in zone definitions. Consider the example presented in Figure 12-45.



Figure 12-45 Zoning implementation: Zoning and E_Ports

To create Zone A, we include these:

- ▶ Domain ID 4, Port 6 (4,6)
- ▶ Domain ID 5, Port 9 (5,9)

However, we do not include any ISL ports:

- Domain ID 4, Port 7 (4,7)
- Domain ID 5, Port 8 (5,8)

Similarly, to create Zone B, we include these:

- Domain ID 4, Port 5 (4,5)
- Domain ID 5, Port 10 (5,10)

Zones do not affect data traffic across ISLs in cascaded switch configurations. Because hard zoning enforcement is performed at the destination, an ISL can carry data traffic from all zones.

Therefore, when dealing with zoning, the fabric should be seen as a "cloud" to which devices are attached. That is, define the end-to-end destinations, and do not include the path to get there.

12.4.9 Broadcast zone

Fibre Channel allows sending broadcast frames to all Nx_Ports if the frame is sent to a broadcast well-known address (FFFFF); however, many target devices and HBAs cannot handle broadcast frames. To control which devices receive broadcast frames, you can create a special zone, called a *broadcast zone*, that restricts broadcast packets to only those devices that are members of the broadcast zone.

If there are no broadcast zones or if a broadcast zone is defined but not enabled, broadcast frames are not forwarded to any F_Ports. If a broadcast zone is enabled, broadcast frames are delivered only to those logged-in Nx_Ports that are members of the broadcast zone and are also in the same zone (regular zone) as the sender of the broadcast packet.

A broadcast zone can have domain, port, WWN, and alias members.

You can set up and manage broadcast zones using the standard zoning commands, which we describe in 12.3, "Implementing zoning" on page 521.

Broadcast zoning is enforced only for Fabric OS v5.3.x or later switches. If the fabric contains switches running Fabric OS versions earlier than v5.3.x, then all devices that are connected to those switches receive broadcast packets, even if they are not members of a broadcast zone.

12.5 Backing up a zone configuration

In case the configuration is lost or unintentional changes are made, keep a backup copy of the configuration file. Keep individual backup files for all switches in the fabric and avoid copying configurations from one switch to another.

You can copy the configuration backup to an FTP server or the USB drive. IBM/Brocade 8 Gbps switches support taking configuration backup in USB drive. However, the USB drive must be a Brocade-branded USB drive.

12.5.1 Backing up a zone configuration to an FTP server

To back up the zone configuration to an FTP server, follow these steps:

1. Click Switch Admin on the Switch Main Page as shown in Figure 12-46.

HT IBM_SAN384B_27 - Web Too	ols	
Manage Reports Monitor Tool:	8	
Tasks A Manage	Status Temp Power Fan HA Beacon Elegend Switch Status Policy	Log Out
Switch Admin Port Admin Admin Domain Str FCR		A P
Fabric Tree		
BM_2498_R06 EM_SAN3845_27 SAN328-54-1 SAN328-54-2 Segmented Switches		
Number of switches: 7		-
	Free Professional Management Tool 10.18.228.27 AD0 User: admin	Role: admin

Figure 12-46 Switch Admin

2. Then, click **Show Advanced Mode** as shown in Figure 12-47.

🛃 IBM_SAN	384B_27 - Switch /	Administration					
						Show	Advanced Mode
SwitchName:	IBM_SAN384B_27	DomainID: 16(0×10)	/w/wN: 10:0	0:00:05:1e	:94:3a:00	Wed Nov 03	2010 13:54:52 PDT
Switch N	letwork Firmware	Download License	User	Blade	Trunking		
Switch Nar	me and Domain ID						
Name	IBM_SAN384B_27	Manufactur	er Serial #	ANN0616	E003		
Domain ID	16	Supplier Set	rial #	109400//			
Switch Sta	tus		DNS Cor	figuration			-
[Switch Admir	histration openedj: Vve	ed NOV 03 2010 13:53:52	PDI				-
Mo	ode: Basic Free Pro	ofessional Management 1	<u>fool</u> 10.	18.228.27	AD0	User: admin	Role: admin 🛛 🖌

Figure 12-47 Advanced mode

- 3. Select the **Configure** tab on the top tab bar, and click the **Upload/download** tab at the bottom tab bar.
- 4. Select both Config Upload and Network.

Enter the details of the FTP OR SCP server to receive the zone configuration backup to the FTP server, as shown in Figure 12-48.

E IBM_SAN384B_27 -	Switch Adminis	ration						
							Shov	v Basic Mode
SwitchName: IBM_SAN38	4B_27	DomainID: 16(0x10	D) VWVN:10	:00:00:05:	1e:94:3a:0	0	Wed Nov 03 2	2010 13:39:13 PDT
Configure Routing	Extended Febrie	A A A Service	Traca		Securi	u Dolicioo	1	
Switch Netwo	rk Firm	ware Download	Licen	se	User	Blade	Trunking	SNMP
Function Config Upload Select source of con	Config Downloa figuration file:	d to Switch Network C L Interails, Transfer P tional, if user name	JSB Protocol and is "anonymou	Path for (S"	Configura	tion file		
Host Name or IP	10.18.228.36							
User Name	root							
Password	••••							
Protocol Type	Secure Copy Pr	otocol (SCP)					•	
Configuration File Name	8 SAn384b_27						•	
	Upl	oad/Download Prog	ress:					
Fabric Virtual Cha	nnel Arbitrated	Loop System	Interoperat	ility Fir	mware 🄇	Upload/Do	wnload	
Switch Administration ope	ened]: Wed Nov 03	2010 13:30:12 PDT	ſ			A	pply Close	Refresh
Select Protocol	lode: Advanced	Free Professional	Management	<u>Tool</u> 10	0.18.228.23	7 AD0	User: admin	Role: admin 🛛 🖌

Figure 12-48 Completing the FTP server details for the configuration backup

The details to complete in this window include these:

- **Host Name or IP**: The host name or IP address of the FTP server where you want to store the configuration backup (for example, 10.64.228.36).
- User Name: The user name of the FTP Server to upload the config file (for example, root).
- Password: The password for the user name.
- Protocol Type:
 - File Transfer Protocol (FTP): The default setting.
 - Secure Copy Method (SCP)
- Configuration File Name: The name of the configuration file.
- 5. When the information is complete, click **Apply**. Confirm the configuration upload by clicking **Yes**, as shown in Figure 12-49.

Confirm	configuration upload 🛛 🗙
?	Configuration file transfer may take a while
	Do you want to proceed?
	Yes No

Figure 12-49 Confirmation window

When the configuration upload completes successfully, a message displays as shown in Figure 12-50.

SwitchName: IBM_SAN384B_27 DomainID: 16(0x10) WWN: 10:00:00:05:1e:94:3a:00 Wed Nov 03 2 Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies Switch Network Firmware Download License User Blade Trunking Function © Config Upload O Config Download to Switch Select source of configuration file: Network O USB Provide Host details, Transfer Protocol and Path for Configuration file *Password is optional, if user name is "anonymous" Host Name or IP 10.18.228.36 User Name root	
SwitchName: IBM_SAN384B_27 DomainID: 16(0x10) VWW: 10:00:00:05:1e:94:3a:00 Wed Nov 03 2 Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies Switch Network Firmware Download License User Blade Trunking Function Config Upload Config Download to Switch Select source of configuration file Network USB Provide Host details, Transfer Protocol and Path for Configuration file "Password is optional, if user name is "anonymous" Host Name or IP 10.18.228.36 User Name root Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Image: Provide Host Details Imag	Basic Mode
Configure Routing Extended Fabric AAA Service Trace FICON CUP Security Policies Switch Network Firmware Download License User Blade Trunking Function © Config Upload © Config Upload © Config Upload © Config Upload © Config Upload © Network © USB Provide Host details, Transfer Protocol and Path for Configuration file "Password is optional, if user name is "anonymous" Host Name or IP 10.18.228.36 User Name root Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval Interval	010 14:03:52 PDT
Switch Network Firmware Download License User Blade Trunking Function © Config Upload © Config Download to Switch Select source of configuration file: © Network © USB Provide Host details, Transfer Protocol and Path for Configuration file *Password is optional, if user name is "anonymous" Host Name or IP 10.18.228.36 User Name root Image: Content of Content	
Function Config Upload Config Download to Switch Select source of configuration file: Network USB Provide Host details, Transfer Protocol and Path for Configuration file *Password is optional, if user name is "anonymous" Host Name or IP 10.18.228.36 User Name root Provide Provide Host Interview Provide Host Interview Provide Host Interview 	SNMP
Host Name or IP 10.18.228.36 User Name root	
User Name root	
Password	
Protocol Type Secure Copy Protocol (SCP)	
Configuration File Name SAN384B_27	
Upload/Download Progress:	
Fabric Virtual Channel Arbitrated Loop System Interoperability Firmware Upload/Download	
Apply Close	Refresh
[Switch Administration opened]: Wed Nov 03 2010 13:53:52 PDT [upload started]: Wed Nov 03 2010 14:02:52 PDT Initiating configuration file [SAN384B_27] upload to 10.18.228.36 ConfigUpload completed successfully. [upload completed]: Wed Nov 03 2010 14:02:52 PDT	

Figure 12-50 Configuration upload successful message

12.5.2 Backing up a zone configuration to a Brocade USB device

Only IBM/Brocade 8 Gbps switches and DCX Backbone, with Fabric OS v6.1x or later support backup of the configuration using the Brocade supplied USB drive.

Here are some points to consider:

- ► In the case of the DCX Backbone, insert the USB drive on the active CP only.
- Enable the USB device. An LED lights after a successful enable.
- Disable the device before unplugging it to prevent data corruption on the USB drive, and the indicator LED stops glowing.
- You need to purchase the USB drive separately. The USB drive does not ship with the switch.

To back up a zone configuration to a USB device, follow these steps:

1. Plug in the USB device to the USB port. Open Web Tools, and click the USB icon, as shown in the Figure 12-51.

USB: Make sure to plug in the USB device to the switch (the Active CP in the case of the DCX Backbone).

HIBM_SAN80B_217 - Web Tools		
Manage Reports Monitor Tools		
Tasks ×	Status O Temp	O Power O Fan A Beacon A Chassis Beacon E Chassis Beacon Log Out
💑 Zone Admin	Logical Switch 128 🔻	
Switch Admin	Switch View	
Port Admin		
🖗 Fabric Watch	4 -	
Monitor 😞		
I Performance Monitor		
III Name Server	Switch Events, Information	
Other	Switch Events Switch Infor	mation
Telnet/SSH Client	Last updated at	Fri Jul 31 2009 22:38:59 GMT+00:00
	Name	IBM SAN80B 217
	Status	Healthy
	Fabric OS version	v6.2.0e
	Domain ID	1(0x1)
	VWWN	10:00:00:05:1e:09:97:01
	Type	64.3
	Bole	Principal
Fabric Tree 🛛 🔗	Base Switch	No
figure hur higher 🗮	Default Switch	Yes
view by. Name	Allow XISL Use	Off
🖻 🕹 Fabric	E Ethernet	
BM_B32_50	Ethernet IPv4	10.64.210.217
- BM_SAN384B_213	Ethernet IPv4 petmask	255 255 240 0
BM_SAN80B_217	Ethernet IPv4 gateway	10.64.208.1
Segmented Switches	Ethernet IPv6	None
	FC	
Number of switches: 3		
	d	

Figure 12-51 Configuration backup to the USB device

2. Click Mount USB Device as shown in Figure 12-52.

IBM_SAN80B_21 Mount the USB device Unmount the USB dev USB device by select	7 - USB to an online USB port to copy files to/from the switch. ice before disconnecting. Files can be deleted from the ng them and click Delete.
USB Device Details	
Device Status	Unmounted
Moun <u>t</u> USB Device	Refresh Toggle USB Device status

Figure 12-52 Mounting the USB device

3. Confirm the mount by clicking **Yes** in the message dialog box as shown in Figure 12-53.

BM_SAN80B_217 - USB	_ 🗆 ×
Mount the USB device to an online USB port to copy files to/from the switch. Unmount the USB device before disconnecting. Files can be deleted from the USB device by selecting them and click Delete.	
USB Device Details	
Device Status Unmounted	
Mount USB Device Refresh	
Firmware List	Delete
F/W Versi Type Size Date Of Crealocation	
Confirmation	
USB Device is unmounted.	
User cannot manage USB Device and its elements.	
Config List	
Name of file Type Size D Do you want to mount the USB Device?	
Yes No	

Figure 12-53 Confirmation for mounting the USB device

When the USB device is mounted, you might see backup files as highlighted in Figure 12-54.

IBM_SAN80B_217 - USB							_ 🗆 >
Mount the USB device to an onl Unmount the USB device before USB device by selecting them a	ine USB port to o e disconnecting. Ind click Delete.	opy files to/from the switc Files can be deleted from t	ch. the				
USB Device Details							
Device Status Mounted							
Unmount USB Device	fresh						
Firmware List							Delete
FAV Versi 🔺 Type	Size	Date Of Crea location					
Config List							
Name of nie Typ TSO_Bacup_Cfg_200 FILE	e Size	Date Of Crea 5258 Fri Jul 31 22:	location AusbAusbstor				
Firmware Key List							
Name of file A Type	Size	Date Of Crea location					
						<u>C</u> lo	se
			Free Professional Management Tool	10.64.210.217	FID 128	User: admin	Role: adm

Figure 12-54 List the contents of the USB Device

4. Next, follow the steps that are similar to those described in 12.5.1, "Backing up a zone configuration to an FTP server" on page 562 to back up the configuration, except that you need to select the USB check box in order to select the USB drive as the source (as highlighted in Figure 12-55). Then, select the Configuration File Name and click **Apply**.

DomainID: 1(C Extended Fabric AAA Service ork Firmwar winload to Switch e: O Network OUSB Infe	Dx1) WWW 10:00:00: Trace FICON CUI re Download	05:1e:09:97:01 P Security Policies License	Fr	Show Basic Mode
DomainID: 1(C Extended Fabric AAA Service ork Firmwar wmload to Switch e: O Network OUSB Info	0x1) WWW 10:00:00: Trace FICON CU re Download	05;1e:09:97:01 P Security Policies License	Fri	i Jul 31 2009 22:53:53 GMT+00:00
Extended Fabric AAA Service ork Firmwar wwnload to Switch e: Network OUSB Inf	Trace FICON CUI re Download	P Security Policies License	User	Trunking
ork Firmwar wwnload to Switch e: O Network OUSB Inf	re Download	License	User	Trunking
wnload to Switch e: O Network (OUSB) Inf	2			
up_c(g_20090731) Upload/Download	l Progress:	Upload/Download	• •	pply Close Refresh
	Upload/Download	Upload/Download Progress:	Upload/Download Progress:	Upload/Download Progress:

Figure 12-55 Config Upload to a USB device

5. Select **Yes** in the confirmation window, as shown in Figure 12-56.



Figure 12-56 Confirmation for the configuration upload

When the configuration upload completes successfully, a message displays as shown in Figure 12-57.

	000_217-3	switch Adminis	stration								
										Sho	ow Basic Mode
/itchName:	IBM_SAN808	3_217		DomainID: 1(0×1) VWVN	: 10:00:00:05:	1e:09:97:01		Fri Jul	31 2009 2	22:55:53 GMT+0
NMP C	onfigure F	touting Exten	ded Fabric	AAA Service	Trace	FICON CUP	Security Policies				
Switc	:h	Network		Firmvva	re Download	1	License		User		Trunking
-Function	fig Upload 🔾) Config Downlo	ad to Switch								
		-	<u></u>	@.ump							
								-			
Configurat	tion File Name	ITSO_Bacup_C	ctg_2009073	1				-			
Fabric ID		128									
								•			
								•			
				Upload/Download	d Progress:			•			
Fabric	Virtual Char	nnel Arbitrate	ed Loop S	Upload/Download	d Progress: perability F	Firmware	Upload/Download	•			
Fabric	Virtual Char	nnel Arbitrate	ed Loop S	Upload/Download	d Progress: berability f	Firmware	Upload/Download	•	Apply	Close	e Refresh
Fabric	Virtual Char	nnel Arbitrate	ed Loop S	Upload/Download system Interop	d Progress: [berability F	Firmware	Upload/Download	•	Apply	, Close	e Refresh
Fabric	Virtual Char Instranor clos	nnel Arbitrate	ed Loop S	Upload/Download system Interop	d Progress: nerability F	Firmware	Upload/Download	•	Apply	/ Close	e Refresh
Fabric	Virtual Char Instration clos inistration clos inistration clos inistration clos	nnel Arbitrate leap-moursi-za sed): Fri Jul 31 20 ped): Fri Jul 31 20 ped): SF Jul 31 20 ped): SF Jul 31 20	ed Loop S 909 22: 52: 53 909 22: 52: 53 909 22: 53: 63 909 22: 53: 63	Upload/Download system Interop GMT+00:00 GMT+00:00 3 GMT+00:01	d Progress: [perability F	Firmware	Upload/Download	•	Apply	, Close	e Refresh
Fabric	Virtual Char mistration clos nistration clos nistration con- dif Fri Jul 31	ea; mouror 24 ea; mouror 24 ea; Fri Jul 31 21 ead; Fri Jul 31 21 codi 5 Fri Jul 31 22 codi 25 55 3 0 TSO_Bacup_Cfg	ed Loop S 009 22: 52: 53 009 22: 52: 53 009 22: 53: 03 000 20 00000000	Upload/Download ystem Interop GMT+00:00 3 GMT+00:00 3 GMT+00:00 4 GMT+00:00	d Progress: perability F	Firmware	Upload/Download		Apply	Close	e Refresh
Fabric	Virtual Char inistration clos inistration clos inistration con- gli Fri Jul 31 iguration file (i completed su leteral Fri Jul 31	anel Arbitrate ea) Fri Jul 31 21 ped) Fri Jul 31 21 ped) Fri Jul 31 22 ped) Fri Jul 31 22 ped) Fri Jul 31 22 ped Fri Jul 31 20 ped Fri 30 20 ped Fri 30 20 p	ed Loop S 009 22:52:53 009 22:53 009 22:55 009 20 009 20 009 20 009 20 009 20 009 20 009 20 009 20 009 20 009 20 009 20 009 20 0000	Upload/Download ystem Interop GMT+00:00 3 GMT+00:00 3 GMT+00:00	d Progress: perability F	Firmware	Upload/Download	• 	Apply	Close	e Refresh

Figure 12-57 Config Upload completed successfully

6. Unmount the USB device before unplugging it to prevent data corruption, as shown in Figure 12-58.

E IBM_5AN80B_217	- USB
Mount the USB device Unmount the USB devi USB device by selectin	to an online USB port to copy files to/from the switch. ce before disconnecting. Files can be deleted from the ng them and click Delete.
USB Device Details	
Device Status	Mounted
Unmoun <u>t</u> USB Devic	e Refresh

Figure 12-58 Unmount USB device

12.5.3 Downloading a zone configuration from a USB device

Follow these steps:

- 1. See 12.5.2, "Backing up a zone configuration to a Brocade USB device" on page 566 for directions about how to mount the USB device and how to check the status of the USB device after mounting.
- 2. Open the switch Administration window and select the **Switch** tab as shown in Figure 12-59. For the Switch Status, select **Disable** and click **Apply**.

								Show Basic Mode
ritchName: IBM_SAN	80B_217		DomainID: 1(0:	x1) VWWN: 1	0:00:00:05:1e:0	9:97:01	Sun Aug 02	2009 04:03:17 GMT+00
MP Configure	Routing	Extended Fabric	AAA Service	Trace I	FICON CUP	Security Policies		
Switch	Netv	vork	Firmwa	are Download		License	User	Trunking
Switch Name and Do	omain ID							
Name IBM_SAM	N80B_217		Manufa	cturer Serial #	AHX0617D00	1		
Domain ID			Supplier	r Serial #	107700H			
Switch Status					DNS Configura	tion		
🔿 Enable 🔘 Dis	sable				DNS Server 1			
	~				DNS Server 2			
Report					Domain Name			
View Report						Remove	All	
Reboot Fastb	oot							
							Apply	Close Refresh
aung connigoration in	15 111 3020031		9 9				Apply	Close Refresh
ang comgarasorn figupioad complete ad completed). Sun writed started Started fig:Devniced completed	ie (m.sozoosi i successfuli i Aug 02 2003 ie (ITSO2009) ited success suc Aug 02 2	20011000000000000000000000000000000000	0.00 0.00 5.witch				Apply	Close Refresh

Figure 12-59 Switch Disable

3. Select **Yes** in the confirmation window, as shown in Figure 12-60.



Figure 12-60 Confirmation window

4. Next, follow steps that are similar to those described in 12.5.2, "Backing up a zone configuration to a Brocade USB device" on page 566, except that you need to select the *Config Download to Switch* check box in order to download the config from the USB drive (as highlighted in Figure 12-61). Then, select the Configuration File Name, and click **Apply**.

BM_SAN80B_217	- Switch Administration					
						Show Basic Mode
SwitchName: IBM_SAN8	30B_217	DomainID: 1(0×1)	VWVN: 10:00:00:05:1e	:09:97:01	Sun Aug (02 2009 04:19:17 GMT+00:00
SNMP Configure	Routing Extended Fabric	AAA Service	Trace FICON CUP	Security Policies		
Switch	Network	Firmware D	ownload	License	User	Trunking
Function Config Upload Select source of co	Config Download to Swi onfiguration file: O Netwo	ich Inte I USB I <u>nfo</u>				
Configuration File Nar	me ITSO20090801				.	
Fabric ID	128				•	
Template Fabric ID						
Fabric Virtual Cr	nannel Arbitrated Loop	Upload/Download Pro System Interopera	ogress:	Jpload/Download	Apply	Close Refresh

Figure 12-61 Config Download to Switch

5. Select Yes in the confirmation window, as shown in Figure 12-62.



Figure 12-62 Confirm configuration download

6. When the configuration download completes successfully, a message displays as shown in Figure 12-63. Click the **Switch** tab.

IBM_SAN80B_217 -	Switch Ad	Iministration							_
									Show Basic Mod
ritchName: IBM_SAN80	B_217		DomainID: 1(0×	:1) WWN	10:00:00:05:1	e:09:97:01		Sun Aug I	02 2009 04:25:17 GMT
NMP Configure F	Routing	Extended Fabri	c AAA Service	Trace	FICON CUP	Security Policies			
Switch	Netw	vork	Firmwa	re Downloa	ad	License		User	Trunking
Function Config Upload	Config D	ownload to Swi	tch						
Select source of con	figuration f	file: O Netwo	ork 🖲 USB I <u>nf</u>	<u>o</u>					
Configuration File Name	e ITSO200	90801					•		
Fabric ID	128						•		
Template Fabric ID									
			Upload/Download	I Progress:					
Fabric Virtual Cha	nnel Ar	bitrated Loop	System Interop	l Progress: erability	Firmware	Upload/Download			
Fabric Virtual Cha	innel Ar	rbitrated Loop	System Interop	erability	Firmware	Upload/Download			
Fabric Virtual Cha	innel Ar	rbitrated Loop	System Interop	l Progress: erability	Firmware	Upload/Download		Apply	Close Refres
Fabric Virtual Cha	innel Ar	rbitrated Loop	System Interop	I Progress: erability	Firmware	Upload/Download		Apply	Close Refres
Fabric Virtual Cha	innel Ai	rbitrated Loop	System Interop	erability	Firmware	Upload/Download		Apply	Close Refres
Fabric Virtual Cha	Innel Ar	rbitrated Loop 30011 upiloau to 6 7. 3.04:24:17 GMT+ 3.04:24:17 GMT+	System Interop	erability	Firmware	Upload/Download		Apply	Close Refrest
Fabric Virtual Cha aung comparation mer nfigUpload completed st lead completed Sti wind started) Sun A iating configuration file [Innel Ar Insozooso uccessfully ug 02 2009 (ITSO20090	rbitrated Loop 30011 oploaring 9. 101-24-17 GMT+ 3 04:24:17 GMT+ 1801] download	Upload/Download System Interop	erability	Firmware	Upload/Download		Apply	Close Refrest
Fabric Virtual Cha ang comporation men frigUpload completed si (and completed). Sun A ating configuration file [rtigDownload completed]. Sun Vinload completed]. Su	innel Ai uccessfully ug 02 2009 (ITSO20090 (ITSO20090 n Aug 02 20	rbitrated Loop 	System Interop	erability	Firmware	Upload/Download		Apply	Close Refres

Figure 12-63 Config Download completed successfully

7. Select Switch Status Enable as shown in Figure 12-64 and click Apply.

IBM_SAN384B_27 - Switch Administration						
					Show Basic Mode	
SwitchName: IBM_SAN384B_27 D	VW/N: 10:00:00	:05:1e:94:3a:00		Wed Nov 03 2	010 14:52:56 PDT	
Configure Routing Extended Fabric AAA	Service Trace	FICON CUP	Security Policies	L	/	
Switch Network Firmware	Download	License	User	Blade	Trunking	SNMP
Switch Name and Domain ID						
Name IBM_SAN384B_27 Manufacturer Ser		erial # ANN061	6E003			
Domain ID 16	Supplier Serial #	109400W				
Switch Status		DNS Configu	ration			
Enable Disable		DNS Server	1			
		DNS Server	2			
Report		Domain Nam	e			
View Report			Re	nove All		
Reboot/Fastboot						
Reboot Fastboot						
[download started]: Wed Nov 03 2010 14:51:54 PDT Initiating configuration file [SAN384B 27] download to	Switch					
Doing configDownload on switch						333
ConfigDownload completed successfully.						-
Change current switch settings · · · Mode: Advance	ced Free Professio	nal Managemer	t Tool 10.18.22	8.27 AD0	User:admin	Role: admin 🛛 🗶

Figure 12-64 Switch Status Enable

8. Select **Yes** in the confirmation window, as shown in Figure 12-65.



Figure 12-65 Confirm Action

Check that status has changed to Enable Switch and the changes have been saved to the switch, as shown in Figure 12-66.

Changes to [Switch] Panel at: Wed Nov 03 2010 14:57:56 PDT	F
Enabled Switch	
[Warning]: Fabric will reconfigure, use "Refresh" button to update views.	100000
	nin

Figure 12-66 Changes saved to switch

9. Unmount the USB device as shown before in Figure 12-58 on page 571.

12.6 Zoning using CLI

To use the CLI or Telnet to create an alias, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the aliCreate command.
- 3. Enter the cfgSave command to save the change to the defined configuration.

Example 12-1 creates an alias called **DS8000_p1** for WWN 50:05:07:63:04:18:03:16 and another alias called **DS8000_p2** for WWN 50:05:07:63:04:08:c3:16.

Example 12-1 The aliCreate command

```
magic_c1:admin> alicreate DS8000_p1, 50:05:07:63:04:18:03:16
magic_c1:admin> alicreate host_p1, 10:00:00:00:c9:2f:bd:5f
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

12.6.1 Using CLI to create a zone

Attention: Before executing the cfgDisable, cfgEnable, or cfgSave commands, execute the rcsDisabled command to check whether your fabric has Reliable Commit Service (RCS) enabled (rcsDisabled=0). If RCS is disabled (rcsDisabled=1), check for older switches in the fabric. After the older switches are upgraded, RCS is enabled by default.

RCS is available on all switches running Fabric OS v4.1 and later. RCS guarantees that either all or none of the switches receive the new zone configuration. Use RCS to secure a reliable propagation of the latest zone configuration.

If you use non-RCS mode, you must log in to every switch to monitor the status of the zone configuration.

Broadcast: To create a broadcast zone, use the reserved name *broadcast*. Do not give a regular zone the name of *broadcast*.

To create a zone using CLI or Telnet, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the zoneCreate command.

To create a broadcast zone, use the reserved name *broadcast*.

3. Enter the cfgSave command to save the change to the defined configuration.

Example 12-2 creates a zone called host_p1_to_DS8000_p1 and adds alias host_p1 as one of the host_p1_to_DS8000_p1 members.

Example 12-2 The zoneCreate command

```
magic_c1:admin> zonecreate "host_p1_to_DS8000_p1", "host_p1"
magic_c1:admin> cfgsave
you are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
Updating flash ...
magic_c1:admin>
```

Adding devices (members) to a zone

To add a device to a zone, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the zoneAdd command.
- 3. Enter the cfgSave command to save the change to the defined configuration

Example 12-3 adds the alias DS8000_p1 to the host_p1_to_DS8000_p1 zone.

Example 12-3 The zoneAdd and cfgSave commands

```
magic_c1:admin> zoneadd "host_p1_to_DS8000_p1", "DS8000_p1"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
Updating flash ...
magic_c1:admin>
```

Removing devices (members) from a zone

To remove devices (members) from a zone, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the zoneRemove command.
- 3. Enter the cfgSave command to save the change to the defined configuration

Example 12-4 remove DS8000_p1 from the host_p1_to_DS8000_p1 zone.

Example 12-4 The zoneRemove command

```
magic_c1:admin> zoneremove "host_p1_to_DS8000_p1", "DS8000_p1"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

Deleting a zone

To delete a zone, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the **zoneDelete** command.
- 3. Enter the cfgSave command to save the change to the defined configuration.

Example 12-5 deletes **host_p1_to_DS8000_p1** from the configuration.

Example 12-5 The zoneDelete command

```
magic_c1:admin> zonedelete "host_p1_to_DS8000_p1"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

12.6.2 Using CLI to create a zone configuration

To use CLI or Telnet to create a zone configuration, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the cfgCreate command.
- 3. Enter the **cfgSave** command to save the change to the defined configuration (Example 12-6).

Example 12-6 The cfgCreate command

```
magic_c1:admin> cfgcreate "ITS0_Cfg", "host_p1_to_DS8000_p1"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

Adding zones (members) to a zone configuration

To add zones (members) to a zone configuration, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the cfgAdd command.
- Enter the cfgSave command to save the change to the defined configuration (Example 12-7).

Example 12-7 The cfgAdd command

```
magic_c1:admin> cfgadd "ITSO_Cfg", "host_p1_to_DS8000_p2"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

Removing zones (members) from a zone configuration

To remove zones (members) from a zone configuration, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the cfgRemove command.
- Enter the cfgSave command to save the change to the defined configuration (Example 12-8).

Example 12-8 The cfgRemove command

```
magic_c1:admin> cfgremove "ITSO_Cfg", "host_p1_to_DS8000_p2"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

Deleting a zone configuration

To delete a zone configuration, follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the **cfgDelete** command.

 Enter the cfgSave command to save the change to the defined configuration (Example 12-9).

Example 12-9 The cfgDelete command

```
magic_c1:admin> cfgdelete "ITSO_Cfg"
magic_c1:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
```

Clearing changes to a zone configuration

To clear changes to a zone configuration:

- 1. Enter the cfgTransAbort command.
- 2. When this command is executed, all changes since the last save operation (performed with the **cfgSave** command) are cleared.

Example 12-10 clears the removal of a member from zone1, which was done in error with the **zoneRemove** command.

Example 12-10 The cfgTransAbort command (after a zoneRemove command)

```
magic_c1:admin> zoneremove "host_p1_to_DS8000_p1", "host_p1"
magic_c1:admin>
magic_c1:admin> cfgtransabort
```

12.6.3 Backing up a zone configuration using the CLI

You can back up a zone configuration using the **configUpload** command, as follows:

- 1. Verify that the FTP or SCP service is running on the host computer.
- 2. Connect to the switch and log in as admin.
- 3. Enter the **configUpload** command. The command becomes interactive, and you are prompted for the required information.

Respond to the prompts as follows:

 Protocol (SCP or FTP): If your site requires the use of Secure Copy, specify SCP. Otherwise, specify FTP. If you leave this prompt blank, then the default specified in the square brackets ([]) is used.

- Server Name or IP Address: Enter the name or IP address of the server where the file will be stored (for example, 9.155.66.102). You can enter a server name if DNS is enabled.
- User name: Enter the user name of your account on the server (for example, admin).
- File name: Specify a file name for the backup file (for example, magic_c1_bkp20090721). You specify absolute path names using a forward slash (/). Relative path names create the file in the user's home directory on UNIX servers and in the directory where the FTP server is running on Windows servers.
- Password: Enter your account password for the server. The Password field is a required field even if you are logged in as an anonymous user. In such cases, the value can be ignored by the FTP service.

Example 12-11 shows the **configUpload** command run on a switch without Admin Domains.

Example 12-11 The configUpload command to the FTP server

```
magic_c1:admin> configupload
Protocol (scp or ftp) [ftp]: ftp
Server Name or IP Address [host]: 9.155.66.102
User Name [user]: ftpuser
File Name [config.txt]: magic_c1_bkp20090721
Password:
Upload complete
magic_c1:admin>
```

12.6.4 Backing up a zone configuration using a USB drive

Only IBM/Brocade 8 Gbps switches and DCX Backbone, with Fabric OS v6.1x or later support backup of the configuration using the Brocade supplied USB drive.

Here are some points to consider:

- ► In the case of the DCX Backbone, insert the USB drive on the active CP only.
- ► Enable the USB device. An LED lights after a successful enable.
- Disable the device before unplugging it to prevent data corruption on the USB drive, and the indicator LED stops glowing.
- You need to purchase the USB drive separately. The USB drive does not ship with the switch.
- ► Restore the backed up configuration using the **configDownload** command.

Example 12-12 shows how to enable the USB device.

USB: Make sure to plug in the USB device to the switch (the Active CP in the case of the DCX Backbone).

Example 12-12 Enable the USB device

```
magic_c1:admin> usbstorage -e
Trying to enable USB device. Please wait...
USB storage enabled
magic_c1:admin>
```

Example 12-13 shows the commands to back up the configuration to the USB device.

Example 12-13 The configUpload command

```
magic c1:admin> configupload -U ITSO Backup 20090730
configUpload complete: All config parameters are uploaded
magic_c1:admin> usbstorage -1
firmware\
                        0B
                                 2007 Sep 28 15:33
                        23kB
config\
                                 2009 Jul 31 23:15
  ITSO Bacup Cfg 20090722 5kB
                                 2009 Jul 22 21:49
  ITSO_Bacup_Cfg_20090731 5kB
                                 2009 Jul 31 22:56
  ITSO Backup 20090730 12kB
                                 2009 Jul 30 23:15
support\
                        0B
                                 2007 Sep 28 15:33
                        0B
firmwarekey\
                                 2007 Sep 28 15:33
Available space on usbstorage 99%
magic c1:admin>
```

Unmount the USB device before unplugging it to prevent data corruption; see Example 12-14.

Example 12-14 Unmount the USB device

```
magic_c1:admin> usbstorage -d
USB storage disabled
magic_c1:admin>
```

The configuration is now backed up.

12.6.5 Downloading a zone configuration from an FTP server

In case the configuration is lost, unintentional changes have occurred, or replacement of the switch is necessary, you can download the configuration from the latest backup.

Restoring a configuration involves overwriting the configuration on the switch by downloading a previously saved backup configuration file. Make sure that the configuration file that you download is compatible with your switch model, because configuration files from other model switches or firmware versions might cause your switch to fail.

You can download configuration files to a switch while the switch is enabled. You do not need to disable the switch.

Switch: For some Admin Domain configurations, the switch must be disabled.

To download a zone configuration from an FTP server, follow these steps:

- 1. Telnet to the switch and login as admin.
- 2. Enter the configDownload command.
- 3. When prompted, respond as follows:
 - Protocol (SCP or FTP): If your site requires the use of Secure Copy, specify SCP. Otherwise, specify FTP. If you leave this prompt blank, then the default specified in the square brackets ([]) is used.
 - Server Name or IP Address: Enter the name or IP address of the server where the file will be stored (for example, 9.155.66.102). You can enter a server name if DNS is enabled.
 - User name: Enter the user name of your account on the server (for example, admin).
 - File name: Specify the file name for the backup file to be downloaded. You can specify absolute path names using a forward slash (/). Relative path names create the file in the user's home directory on UNIX servers and in the directory where the FTP server is running on Windows servers.
 - Password: Enter your account password for the server. The Password field is a required field even if you are logged in as an anonymous user. In such cases, the value can be ignored by the FTP service.
- 4. When prompted with the message **Do you want to continue** [y/n], enter y.
- 5. Wait for the configuration to be restored.
Example 12-15 shows the **configDownload** command run on a switch without Admin Domains.

Example 12-15 The configDownload command

magic_c1:admin> configdownload
Protocol (scp, ftp, local) [ftp]:
Server Name or IP Address [host]: 9.155.66.102
User Name [user]: admin
File Name [config.txt]: magic_c1_bkp20090720

*** CAUTION ***

This command is used to download a backed-up configuration for a specific switch. If using a file from a different switch, this file's configuration settings will override any current switch settings. Downloading a configuration file, which was uploaded from a different type of switch, may cause this switch to fail. A switch reboot might be required for some parameter changes to take effect.

configDownload operation may take several minutes to complete for large files.

Do you want to continue [y/n]: y Password:

Activating configDownload: Switch is disabled

configDownload complete: All config parameters (except any AD Headers,SFOS and Security parameters) are downloaded to ADO magic_c1:admin>

Reboot: Because some configuration parameters require a reboot in order to take effect, after you download a configuration file, you must reboot to be sure that the parameters are enabled. Before the reboot, this type of parameter is listed in the configuration file, but it is not effective until after the reboot.

12.6.6 Downloading a zone configuration from a USB device

See 12.6.4, "Backing up a zone configuration using a USB drive" on page 582 for directions about how to mount the USB device and how to check the status of the USB device after mounting.

Enter the **configDownload** -U <Filename> command to download the config from the USB device.

Example 12-16 shows the configDownload command from a USB device.

Example 12-16 The configDownload command

magic_c1:admin> switchdisable
magic_c1:admin> configdownload -U ITS0_Backup_20090730

*** CAUTION ***

This command is used to download a backed-up configuration for a specific switch. If using a file from a different switch, this file's configuration settings will override any current switch settings. Downloading a configuration file, which was uploaded from a different type of switch, may cause this switch to fail. A switch reboot might be required for some parameter changes to take effect.

configDownload operation may take several minutes to complete for large files.

Do you want to continue [y/n]: y

Activating configDownload: Switch is disabled

configDownload complete: All config parameters (except any AD Headers,SFOS and Security parameters) are downloaded to ADO magic_c1:admin>

Reboot: Because some configuration parameters require a reboot in order to take effect, after you download a configuration file, you must reboot to be sure that the parameters are enabled. Before the reboot, this type of parameter is listed in the configuration file, but it is not effective until after the reboot.

Unmount the USB device before unplugging it to prevent data corruption see Example 12-14 on page 583.

Example 12-17 Unmount the USB device

```
magic_c1:admin> usbstorage -d
USB storage disabled
magic_c1:admin>
```

13

Multiple switches and fabrics

In this chapter, we discuss the considerations for multiple switch environments, such as merging fabrics, duplicate domain IDs, zoning configuration conflicts, and operating parameter conflicts.

13.1 Multiple switch environments

In this section, we focus on multiple switch environment considerations.

13.1.1 Gateway links

A gateway merges SANs into a single fabric by establishing point-to-point E_Port connectivity between two Fibre Channel switches that are separated by a network with a protocol such as IP or SONET.

Except for link initialization, gateways are transparent to switches; the gateway simply provides E_Port connectivity from one switch to another.

By default, switch ports initialize links using the Exchange Link Parameters (ELP) mode 1. However, gateways expect initialization with ELP mode 2, also referred to as ISL R_RDY mode. Therefore, to enable two switches to link through a gateway, the ports on both switches must be set for ELP mode 2.

Any number of E_Ports in a fabric can be configured for gateway links, provided that you follow these guidelines:

- All switches in the fabric must be upgraded to Fabric OS v5.2.0 or later.
- All switches in the fabric are using the core PID format.
- The switches connected to both sides of the gateway are included when determining switch count maximums.
- Extended links (those created using the Extended Fabrics licensed feature) are not supported through gateway links.

Example 13-1 shows how to enable R_RDY on port 8/47 using the **portcfgis1mode** command. The example is performed on a IBM SAN384B switch. Commands are slightly different for the non-director type switches.

For more detailed information, see the Fabric OS Administrator's Guide, available at the following website:

http://www.brocade.com

IBM_SAN384B_213:FID128:admin> portcfgislmode
Usage: portCfgISLMode [SlotNumber/]PortNumber Mode
Mode: 1 - Enable ISL R_RDY Mode on port
0 - Disable ISL R_RDY Mode on port
IBM_SAN384B_213:FID128:admin> portcfgislmode 8/47 1
ISL R_RDY Mode is enabled for port 239. Please make sure the PID
formats are consistent across the entire fabric.

Example 13-1 Enable ISL R_RDY mode using portcfgisImode

After running the command in the example, the ISL link is now operational.

13.1.2 Buffer credit recovery

This feature is available only with IBM 8 Gbps switches. Buffer recovery credit allows links to recover after frames and R_RDYs are lost when the credit recovery logic is enabled. Buffer credit recovery maintains performance because as soon as one credit is lost, it attempts to recover. During link reset, the frame and credit loss counters are reset without performance degradation. This feature is supported only on long distance E_Ports that are connected between GoldenEye2 and Condor2-based ports. Buffer credit recovery does not require any configuration.

If a long distance E_Port is connected to any other type of Application Specific Integrated Circuit (ASIC), the buffer credit recovery feature is disabled. Virtual E_Ports and Virtual EX_Ports do not support long distance. The buffer credit recovery feature is enabled for Normal and Virtual Channel flow control modes.

A port that supports BB_Credit recovery maintains the following BB_Credit recovery values:

- ► BB_SC_N: The log2 of BB_Credit Recovery modulus.
- BB_RDY_N: Counts the number of R_RDY primitives received modulo 2BB_SC_N.
- BB_FRM_N: Counts the number of frames that are received modulo 2BB_SC_N(VC) mode, and Extended VC mode.

No configuration is required because the configuration is done internally by the Fabric OS and the ASIC.

13.1.3 ISL Trunking

ISL Trunking is an optionally licensed product on the IBM b-type family of switches. ISL Trunking requires you to purchase and install a separate ISL Trunking license key, which has to be installed on all switches that participate in the trunk.

The ISL Trunking feature allows up to eight ISLs to merge logically into a single link. An ISL-link is a connection between two switches through an Expansion Port (E_Port).

When using ISL Trunking to aggregate bandwidth of up to eight ports, the speed of the ISLs between switches in a fabric is multiplied correspondingly up to eight times.

For example, at 4 Gbps speeds, trunking 4 ports between two SAN-24B switches delivers an ISL throughput of up to 16 Gbps. Trunking at 8 Gbps with 8 ISL-links forms 8-port trunks that can deliver up to 64 Gbps. ISL trunking is extended to N_Ports where trunks are formed when the edge switch is running Fabric OS v6.2.0 or later.

Figure 13-1 shows some examples of ISL Trunking.



Figure 13-1 Trunking examples

You can manage ISL Trunking using Telnet commands or the Web Tools interface.

The ISL Trunking feature has many advantages. It supports high-bandwidth, large-scale SANs that include core switches. ISL Trunking provides a high bandwidth path between switches in a fabric, while balancing the traffic across the individual links and maintaining *in-order delivery* of data packets to their destination.

Attention: *In-order delivery* is the preferred setting in an IBM fabric. However, the user can change this setting.

ISL Trunking uses frame-level load balancing. You can use it with Exchange Based Routing, to achieve faster fabric convergence, as well as higher availability.

In the remainder of this section we discuss the distinct advantages of using ISL Trunking.

ISL: The 6-port 10 Gbps blade for the IBM SAN Director type switches can only be used for ISL connectivity. This blade has no support for ISL trunking.

Trunk groups, ports, and masters

ISL Trunking performs load balancing dynamically, at the frame level, across a set of available links between two adjacent switches. Ports on a switch are grouped in port groups. Trunks can only form from port group to port group. When a trunk group is formed, one port is referred to as the *trunk master*. In Fabric OS v5.x and later, if a master link goes offline, a new master is selected automatically with no disruption to traffic. Using trunking with previous versions of Fabric OS or over an EX_Port, if a master goes offline, there is a temporary disruption to traffic as the link is rebuilt.

Trunk groups

A *trunk group* is identified by the trunk master that represents the entire group. The remainder of the group members are referred to as *subordinate links* that help the trunk master direct traffic across ISLs, allowing efficient and balanced in-order communication.

The trunking groups are based on the user port number with contiguous eight ports as one group, such as, 0-7, 8-15, and 16-23. You can enable and disable trunking and set trunk port speeds (for example, 2 Gbps, 4 Gbps, 8 Gbps, or autonegotiate) for entire switches or for individual ports.

Trunk ports

Observe the following criteria for standard distance trunking:

- ► There must be a direct connection between participating switches.
- Trunk ports must reside in the same port group.
- ► Trunk ports must run at the same speed (either 2 Gbps, 4 Gbps, or 8 Gbps).
- ► Trunk ports must be set to the same ISL mode (L0 is the default).
- ► If the switch is in Access Gateway mode, the trunk ports must be F_Ports.
- ► The switch must be set to interopMode 0 for Brocade Native mode.
- ► The port ISL mode must be disabled (using the portCfgIs1Mode command).

Trunk masters

The *trunk master* implicitly defines the trunk group. All ports with the same master are considered to be part of the same group. Each trunk group includes a single trunk master and several trunk subordinate links. The first ISL established in a trunk group is assigned to be the trunk master, also known as the *principal ISL*. After the trunk group is fully established, all data packets that are intended for transmission across the trunk are distributed dynamically at the frame level across the ISLs in the trunk group, while preserving in-order delivery.

Masterless EX port trunking

Fabric OS v6.2.0 implemented dynamic port binding, this was so an area can be dynamically assigned to a port in a virtual fabric. Fabric OS v6.3.0 uses this dynamic binding to reassign the area from a old master to a new master. When the mater goes offline, a slave port becomes the master by assuming the area of the old master. This means that all slave ports will remain online and when the old master becomes online it will be given a new unused area.

Installing an ISL Trunking license

The IBM b-type family of switches require that you install an ISL Trunking license on both switches at either end of an ISL trunk, in order to enable trunking.

Administering ISL Trunking

The ISL Trunking feature is managed by performing some administration tasks. These tasks among other include:

- Enabling or disabling the trunking
- Enabling and disabling ports of a switch
- Setting the speed of a port
- Debugging a trunking link failure

The ISL Trunking feature is administered using Telnet commands.

Enabling an ISL Trunking license

After you unlock the ISL Trunking license, trunking is enabled automatically across all ports, but you must re-initialize the ports that are used for ISLs so that they recognize that trunking is enabled. You perform this procedure only once.

To initialize the ports again, you can either disable and then enable the switch again using switchDisable and then switchEnable, or you can disable and then enable the affected ports again using portDisable [slot/]port and portEnable [slot/]port. By disabling and enabling the switch itself, all ports are available for trunking.

Managing trunking using the CLI

Example 13-2 is an example of how to enable trunking using the Fabric OS v6.2.0 Command Line Interface (CLI). An IBM b-type switch and its ports have trunking enabled by default. As such, trunks will form automatically if more than one ISL is connected within a port group of the switches.

Example 13-2 Enabling and Managing trunking

```
IBM_SAN384B_213:FID128:admin> trunkshow
No trunking links
IBM_SAN384B_213:FID128:admin> switchcfgtrunk 1
Configuration applied to all ports except the following VE/VEX_Ports
(ports 16 - 31).
IBM_SAN384B_213:FID128:admin> portcfgtrunkport 2/18 1
IBM_SAN384B_213:FID128:admin> portcfgtrunkport 2/19 1
IBM_SAN384B_213:FID128:admin> trunkshow
1: 82-> 75 10:00:00:05:1e:09:97:01 2 deskew 15 MASTER
83-> 74 10:00:00:05:1e:09:97:01 2 deskew 15
IBM_SAN384B_213:FID128:admin> trunkdebug 218 219
port 218 and 219 connect to the switch 10:00:00:05:1e:09:97:01
```

IBM_SAN384B_213:FID128:admin>

Managing trunking using the GUI

As an alternative to the CLI, you can select the individual ports from the Web Tools administrative interface and enable ISL Trunking from there.

You disable or enable trunking using the Ports tab, as shown in Figure 13-2. Select either **Enable Trunking** or **Disable Trunking**.

B5000_76 - Port Adminis	stration	Show Bas	sic Mode
FC Ports			
FC Ports Explorer	General SFP Port Stati	stics	
Porto A			_
Port 1	Rename Edit Configuration	on Enable Disable Persistent Enable Persistent Disable (Enable Trunking) Disable Trunking Enable N	PIV
Port 2	Disable MDK/ David Crosen	De Authoritische E Dark DD Graniti Ont Eschlie Ont Dischlie E Dark Trustisce Dark Dessen Fachle	
Port 3	Disable NPTV Port Swap		
Port 4	Port Beacon Disable		
Port 5			
Port 7	General		
Port 8	Port Number	25(0×19)	
- Port 9	Port Name		
Port 10	Port VW/N	20:19:00:05:1e:90:16:57	
Port 11	Port Media	SW	
Port 12	Port Type	E-Port	
Port 12	Port protocol	FC Confirm Action	
Port 14	Allowed Port Type	E-Port,F-Port,L-Port	
Port 15	Speed (Gb/s)	N4 (9) You are about to enable trunk on port 25.	
Port 16	Speed Configured	Auto-Negotiate Are you sure you want to continue?	
- Port 17	Ingress Rate Limit (Gb/s)	Not Available	
Port 18	QOS Status	Enabled Yes No	
- Port 19	Long Distance Mode	L0:Normal	
Port 20	Desired Distance (km)	N/A	
- Port 21	Port Status	Online	
Port 22	Controllable	Yes	
- • Port 23	Licensed	Yes	
- Port 24	Health	Offline	
- O Port 25	Port Index	25(0x19)	
Port 26	Trunking Enabled	false	
- Port 27	FC Fast Write Enabled	false	
Port 28	Trunk Port State		
- • Port 29	Master Port		
- Port 30	Trunk Index		-
Port 31			
	4 <u>1</u>		
		Mode: Advanced Free Professional Management Tool 10.18.229.78 AD0 User: admin 1	Role: admi

Figure 13-2 Enable or disable trunking on port

Figure 13-3 shows the additional items that display in the Ports tab window when you scroll the window. In this example, trunking is enabled on port 24, it is configured as a subordinate (slave) trunk port, and Port 25 is chosen as master trunk port.

	Show Basic Mode
General SFP Port:	Statistics
<u>R</u> ename <u>E</u> dit Configu	uration Enable Disable Pergistent Enable
Persistent Disable	nable Trunking Disable Trunking Enable NPIV
Disable NPIV Port Sy	wap Re-Authenticate F-Port BB Credit QoS Enable
QoS Disable F-Port	Trunking Port Beacon Enable Port Beacon Disable
∋eneral	
Speed (Gb/s)	N4
Speed Configured	Auto-Negotiate
Ingress Rate Limit (Gb/s)) Not Available
QOS Status	Enabled
Long Distance Mode	L0:Normal
Desired Distance (km)	N/A
Port Status	Online
Controllable	Yes
Licensed	Yes
Health	Healthy
Port Index	25(0x19)
Trunking Enabled	true
FC Fast Write Enabled	false
Trunk Port State	Slave
Master Port	24
Trunk Index	
LLOCICEL PORT MIMBI	
	Rename Edit Config Persistent Disable E Disable NPIV Port S QgS Disable F-Port Speed (Gb/s) Speed Configured Ingress Rate Limit (Gb/s) GQOS Status Long Distance Mode Desired Distance (km) Port Status Controllable Licensed Health Port Index Trunking Enabled FC Fast Write Enabled Trunk Port State Master Port Trunk Index Locical Dot XMMM Enabled

Figure 13-3 Web Tools Port tab additional details

13.1.4 Connecting switches over distance

In these sections we show how to connect switches and fabrics over extended distances.

Extended Fabrics

Extended Fabrics software optimizes switch buffering to ensure the highest possible performance on ISLs. When Extended Fabrics is installed on gateway switches, the ISLs (E_Ports) are configured with a large pool of buffer credits.

The enhanced switch buffers help ensure that data transfer can occur at near-full bandwidth to efficiently utilize the connection over the extended links.

The Extended Fabrics feature extends the distance the ISLs can reach over a dark fiber or wave division multiplexing (WDM) connection. This is accomplished by providing enough buffer credits on each side of the link to compensate for latency introduced by the extended distance.

Licensing

A Brocade Extended Fabrics license is required before you can implement long distance dynamic (LD) and long distance static (LS) distance levels. The LD and LS settings are necessary to achieve maximum performance results over Inter-Switch Links (ISLs) that are greater than 10 km.

Distance: Performance can vary depending on the condition of the fiber optic connections between the switches. Losses due to splicing, connectors, tight bends, and other degradation can affect the performance over the link and the maximum distance that is possible.

Configuring Extended Fabrics

You can configure ports to support long distance links through Telnet or using Web Tools interfaces.

There are seven possible long distance levels for a port (shown in Table 13-1). Fabric OS v6.x and later only supports modes L0, LE, LD, and LS.

Ports are arranged in port groups (different than port groups for trunking), with a common pool of buffer credits to draw from. Certain buffers are dedicated for each port, and others are shared among the ports. In L0 mode, which is normal port mode, ports are usually given 8 buffer credits, which satisfies most distances within a data center. In LE mode, ports reserve a set amount of buffer credits depending on link speed to support distances up to 10 km. L0 and LE modes do not require an Extended Fabric license.

In Extended Fabric mode, one port is given an increase of dedicated buffers from this pool. Modes L0.5, L1, and L2 reserve a dedicated number of increased buffer credits depending on link speed to support a defined distance. Mode LD has the port calculate dynamically how many buffer credits to allocate itself based on distance calculated during port initialization. You can set an upper limit on distance. Mode LS calculates a static number of buffer credits to allocate a port based on a desired distance value.

The total number of frame buffers in a port group is limited, and the Extended ISL Modes matrix introduces a combination of long distance modes that are available, as shown in Table 13-1.

Mode	Buffer Allo	cation		Distance	Distance	Distance	Distance	License
	1 Gbps	2 Gbps	4 Gbps	@1 Gbps	@2 Gbps	@4 Gbps	@8 Gbps	Required
LO	5(26)	5(26)	5(26)	10 km	5 km	5 km	5 km	No
LE	11	16	26	10km	10 km	10 km	10 km	No
L0.5	18	31	56	25 km	25 km	25 km	NA	Yes
L1	31	56	106	50 km	50 km	50 km	NA	Yes
L2	56	106	206	100 km	100 km	100 km	NA	Yes
LD	Auto	Auto	Auto	Auto (Max 500 km)	Auto (Max 250 km)	Auto (Max 100 km)	Auto Max 100 Km Depends of Switch Model	Yes
LS	varies	varies	varies	varies (Max 500 km)	varies (Max 250 km)	varies (Max 100 km)	Auto Max 100 Km Depends of Switch Model	Yes

Table 13-1 Extended ISL Modes

Support: Long distance modes L0.5, L1, and L2 are not supported on Fabric OS v6.x.

The buffer allocation and distance vary in this table based upon user specified distances.

For dynamic long distance links using mode LD and LS, you can approximate the number of buffer credits that are reserved using the following formula:

(Reserved Buffer for Distance Y) = (X * LinkSpeed / 2) + 6

Where:

- X = the distance in kilometers.
- LinkSpeed = the link speed in Gbps
- 6 = the number of buffer credits reserved for Fabric Services, Multicast, and Broadcast traffic. This is a static number.

Example 13-3 shows the calculation.

Example 13-3 Calculating reserved buffers for extended links

Distance = 50km Link speed = 4Gbps Formula: (50 * 4 /2) + 6 = 106 106 buffers will be reserved for the given port when a 50km cable is

connected and longdistance mode LD or LS is configured

Distance: For IBM 8 Gbps switches, the number of free or reserved buffers is not the same in all models. So the maximum long distance varies for each switch model. Consult your switch vendor for the maximum distance that is supported for your switch model.

Configuring the port for extended distance using CLI

You can configure a port to support long distance links using the Telnet command **portcfglongdistance** or by using Web Tools as in Example 13-4.

Example 13-4 Setting the port long distance parameter

```
IBM SAN80B 217:FID128:admin> portcfglongdistance 75 LD 1 50
Reserved Buffers =
                         106
IBM SAN80B 217:FID128:admin> portshow 74
portName:
portHealth: HEALTHY
Authentication: None
portDisableReason: None
portCFlags: 0x1
portFlags: 0x103
                        PRESENT ACTIVE E PORT G PORT U PORT
portType: 18.0
POD Port: Port is licensed
portState: 1
               Online
portPhys: 6
               In Sync
portScn: 64 Segmented Flow control mode 0
port generation number:
                          70
portId: 024a00
portIfId:
            43020809
portWwn: 20:4a:00:05:1e:09:97:01
portWwn of device(s) connected:
```

Distance: auto (desired = 50 Km)
portSpeed: 4Gbps

The example set the port for a distance of 50 kilometers at 4Gbps speed.

Configuring the port for extended distance using GUI

As shown in Figure 13-4, the Extended Fabric tab within Web Tools allows you to configure long distance ports. The director type switches have slot subtabs when configuring a given port.

For all other models, you just highlight the given port that you want to configure as long distance.

												Show	Basic Mode
itchName:	B5000_76		Dor	nainID:	98(0×62)	VW/N: 10	:00:00):05:1e:90):16:5	57	Thu Nov (04 2010 00:0	05:03 GMT+I
onfigure	Routing	Extended	Fabric	ААА	Service	Trace	FICO	N CUP	Se	curity Policies			
Switch		Network		Firm	nware Dov	vnload		Lice	nse	User	Tru	unking	SNMP
Extended F	Fabric Admi	nistration											
Port Numb	er	Buffer Limited	Poi Spe	t ed	Bi Needed	uffer I/Allocated	D	Link istance(k	m)	Desired Distance(km)		Long Distance	
19		No	N2		1	0/0		-		N/A	L0: Normal		- 4
20		No	N4		1	0/0		-		N/A	L0: Normal		-
21		No	N4		1	0/0		-		N/A	L0: Normal		-
22		No	N4		1	0/0		-		N/A	L0: Normal		-
23		No	N4		1	0/0		-		N/A	L0: Normal		-
24		No	N4		20	6/26		2		N/A	L0: Normal		-
25		No	N4		20	6/26		2		N/A	L0: Normal		0000
26		No	N4		1	0/0		-		N/A	LE: <= 10 kr LD: Auto	n	388
27		No	N4		1	0/8		-		N/A	LS: Static		
						~~~				\$116	LO. Normal		
										100	Apply	Close	Refres
itch Admi itch Admi itch Admi itch Admi	nistration op nistration cli nistration cli nistration op	oened]: VVed osed]: VVed f osed]: VVed f osed]: VVed	Nov 03 2 Nov 03 2 Nov 03 2 Nov 03 2	:010 23 010 23: 010 23: 010 23	3:45:01 GM 45:01 GMT 45:01 GMT 45:01 GM	T+00:00 `+00:00 `+00:00 T+00:00							

Figure 13-4 Steps to change the Extended Distance Mode

After highlighting the port to configure, go to the Long Distance column on the far right-hand side, and click the down arrow to show the options available for configuration. Table 13-2 lists the details with the Extended Fabric tab.

Port Number	Port Number for all switch models
Buffer Limited	If large distances are set onto various ports within an 8-port block, the remaining ports within that block might have to have their allocated buffer count reduced to enable the long distance configuration.
Port Speed	1G, 2G, 4G, 8G as set speeds. N1, N2 N4 as negotiated speeds.
Buffer Needed/Allocated	Actual buffer usage of port.
Link Distance	Real distance in kilometers.
Desired Distance	Desired distance in kilometers for the port based on port speed.
Long Distance	<ul> <li>L0 = Normal value, long distance disabled</li> <li>LE = Extended normal enabled (up to 10 km)</li> <li>The following items require Extended Fabric License:</li> <li>LD = Dynamic link enabled, operates at distances up to 500 km for 1 Gbps, 250 km for 2 Gbps, or 125 km for 4 Gbps and 100 km for 8 Gbps depending upon frame buffer availability within the port group and the switch model.</li> <li>LS = Static setting enabled. Buffer credits statically configured based on link distance, operates at distances up to 500 km for 4 Gbps and 100 km for 8 Gbps, 250 km for 2 Gbps, or 125 km for 4 Gbps and 100 km for 8 Gbps, depending upon frame buffer availability within the port group and the switch model.</li> </ul>
Slot Number tab	Tab for the slots in the director type switches that display the ports on the given slot for the logical switch.
Apply	Apply and commit changes to the switch.
Close	Close Administrator window.
Refresh	Refresh the view with current data from the switch.

Table 13-2 Extended Fabric configuration

# 13.1.5 Routing policies

This section discusses the routing policies that are available to tune routing performance.

**Attention:** For most configurations, the default routing policy is optimal and provides the best performance. Therefore, change the routing policy *only* if there is a performance issue that is of concern or if a particular fabric configuration requires it.

Routing can be configured and monitored using the GUI or CLI. Next we show an example of how to view the current setting using the GUI as well as CLI.

Figure 13-5 shows the Routing tab with the default Exchange-Based-Routing policy enabled. You can alternatively select Port-Based-Routing. Changing this setting requires the switch to be disabled.

Show Basic Mode           SwitchName:         B5000_76         DomainID:         98(0x62)         WWN:         10:00:00:05:1e:90:16:57         Thu Nov 04 2010 00:20:03 GMT+00:           Configure         Routing         Extended Fabric         AAA Service         Trace         FICON CUP         Security Policies           Switch         Network         Firmware Download         License         User         Trunking         SNMP           Advanced Performance Tuning (APT) Policy         Dynamic Load Sharing         In Order Delivery (IOD)         Loss Less         On         Off         On         Off         On         Off           Port-Based-Routing         Info         Exchange-Based-Routing         Info         Exchange-Based-Routing         Info         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off         On         Off	🔄 B5000_76 - Switch a	Administration								_ 🗆 🗵	
SwitchName:         B5000_76         DomainID:         98(0x62)         WWN:         10:00:00:05:1e:90:16:57         Thu Nov 04 2010 00:20:03 GMT+00:           Configure         Routing         Extended Fabric         AAA Service         Trace         FICON CUP         Security Policies           Switch         Network         Firmware Download         License         User         Trunking         SNMP           Advanced Performance Tuning (APT) Policy         Dynamic Load Sharing         In Order Delivery (IOD)         Loss Less         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         Off         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n         O n <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th></th> <th>Show Basic I</th> <th>Mode</th>									Show Basic I	Mode	
Configure       Routing       Extended Fabric       AAA Service       Trace       FICON CUP       Security Policies         Switch       Network       Firmware Download       License       User       Trunking       SNMP         Advanced Performance Tuning (APT) Policy       Dynamic Load Sharing       In Order Delivery (IOD)       Loss Less         Port-Based-Routing       Info       Exchange-Based-Routing       Info       On       Off       On       Off         Routing Table       In Port       Destination DOut Port       Metric       Hops       Flags       Next Domain       Next Port         In Cost       10       16       24       500       1       D       16       211         In Cost       10       16       24       1000       2       D       16       211         In Cost       10       54       24       1000       2       D       16       211         In Cost       10       56       24       1000       2       D       16       211	SwitchName: B5000_76		DomainID: 98((	0×62) VW/N:	10:00:00:05	:1e:90:16:57		Thu Nov 04	2010 00:20:03 G	MT+00:00	
Switch         Network         Firmware Download         License         User         Trunking         SNMP           Advanced Performance Tuning (APT) Policy         Dynamic Load Sharing         In Order Delivery (IOD)         Loss Less         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off         0 n 0 off	Configure Routing	Extended Fabric	AAA Service	Trace FI	CON CUP	Security Policies					
Advanced Performance Tuning (APT) Policy       Dynamic Load Sharing       In Order Delivery (IOD)       Loss Less         Port-Based-Routing       Info       Exchange-Based-Routing       Info       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       Off       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On       On <td< td=""><th>Switch</th><td>Network</td><td>Firmware</td><td>e Download</td><td></td><td>License</td><td>User</td><td>Trunkin</td><td>g SN</td><td>IMP</td></td<>	Switch	Network	Firmware	e Download		License	User	Trunkin	g SN	IMP	
Routing Table           Port         Destination D Out Port         Metric         Hops         Flags         Next Domain         Next Port           10         5         24         1000         2         D         16         211           10         16         24         500         1         D         16         211           10         23         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211	Advanced Performance Tuning (APT) Policy       Dynamic Load Sharing       In Order Delivery (IOD)       Loss Less         Port-Based-Routing       Info       Exchange-Based-Routing       Info       On       Off       On       Off										
Routing         In Port         Destination D Out Port         Metric         Hops         Flags         Next Domain         Next Port           10         5         24         1000         2         D         16         211           10         16         24         500         1         D         16         211           10         23         24         1000         2         D         16         211           10         23         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211	Routing Table										
Image: FSPF Route         10         5         24         1000         2         D         16         211           10         16         24         500         1         D         16         211           10         16         24         500         1         D         16         211           10         23         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211	Routing	In Port	Destination D	Out Port	Metric	Hops	Flags	Next Domai	in Next Port		
Link Cost         10         16         24         500         1         D         16         211           10         23         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211	FSPF Route	10	5	24	1000	2	D	16	211		
10         23         24         1000         2         D         16         211           10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211	Link Cost	10	16	24	500	1	D	16	211		
10         54         24         1000         2         D         16         211           10         56         24         1000         2         D         16         211		10	23	24	1000	2	D	16	211		
10 56 24 1000 2 D 16 211		10	54	24	1000	2	D	16	211		
		10	56	24	1000	2	D	16	211	38	
11 1 24 1000 2 D 16 211		11	1	24	1000	2	D	16	211		
11 5 24 1000 2 D 16 211		11	5	24	1000	2	D	16	211		
11 16 24 500 1 D 16 211		11	16	24	500	1	D	16	211	-	
Apply Close Refresh Enabled Switch	Enabled Switch							Apply	Close Refr	resh	

Figure 13-5 Routing tab

Example 13-5 is the same setting as viewed from the CLI.

Example 13-5 Viewing the routing policy

```
IBM_SAN80B_217:FID128:admin> aptpolicy
Current Policy: 3 0(ap)
3 0(ap): Default Policy
1: Port Based Routing Policy
3: Exchange Based Routing Policy
0: AP Shared Link Policy
1: AP Dedicated Link Policy
IBM SAN80B 217:FID128:admin>
```

#### **Exchange-based routing**

The choice of routing path is based on the Source ID (SID), Destination ID (DID), and Fibre Channel originator exchange ID (OXID), optimizing path utilization for the best performance.

In exchange-based routing, every exchange can take a different path through the fabric. Exchange-based routing requires the use of the Dynamic Load Sharing (DLS) feature; when this policy is in effect, you cannot disable the DLS feature.

Two additional AP policies are supported under exchange-based routing:

- AP shared link policy (default)
- AP dedicated link policy

The AP dedicated link policy dedicates some links to egress traffic and some to ingress traffic.

#### Port-based routing

The choice of routing path is based only on the incoming port and the destination domain. To optimize port-based routing, DLS can be enabled to balance the load across the available output ports within a domain.

Using port-based routing, you can assign a static route, in which the path chosen for traffic does not change when a topology change occurs unless the path becomes unavailable. If the static route violates FSPF, it is not used. In contrast, Exchange Based Routing policies always employ dynamic path selection.

**Support:** Static routing is a legacy setting and is currently only supported on the SAN40B and SAN80B switches. For other products, as an alternative, you can use the traffic isolation feature to create a dedicated path for interswitch traffic.

## **Dynamic Load Sharing**

Routing is based generally on the incoming port and the destination domain. Thus, all the traffic coming in from a port (either E_Port or EX_Port) directed to the same remote domain is routed through the same output E_Port.

To optimize fabric routing when there are multiple equivalent paths to a remote switch, traffic is shared among all the paths. Load sharing is recomputed when a switch is booted up or every time a change in the fabric occurs. A change in the fabric is defined as an E_Port going up or down, or an EX_Port going up or down.

In an IBM fabric, if Dynamic Load Sharing (DLS) is turned off, load sharing is performed only at boot time or when an E_Port comes up. Optimal load sharing is rarely achieved with DLS disabled.

If DLS is turned on, routing changes can affect working ports. For example, if an E_Port goes down, another E_Port can be rerouted from one E_Port to a different E_Port. The switch minimizes the number of routing changes, but some are necessary in order to achieve optimal load sharing.

Turning on DLS can affect performance when using it in conjunction with the in-order delivery option.

### **In-order delivery**

You can use the in-order delivery option to enforce in-order delivery of frames during a fabric topology change. In a stable fabric, frames are always delivered in-order, even when the traffic between switches is shared among multiple paths. However, when topology changes occur in the fabric (for example, a link goes down), traffic is rerouted around the failure, which can cause frames to be delivered out of order. This option ensures that frames are not delivered out of order, even during fabric topology changes by implementing a timeout value after a fabric change before sending or dropping the next frame.

In an IBM fabric, the in-order delivery option is by default set to on.

Use this option with care, because it can cause a delay in the establishment of a new path when a topology change occurs. Only use this option if there are devices connected to the fabric that cannot tolerate the occasional out of order delivery of frames.

You can change the routing policy using the **aptPolicy** command, but you must disable the switch first.

Example 13-6 shows the steps to change the routing policy from the default Exchange Based Routing to port-based routing.

Example 13-6 shows how to change the routing policy from default to port-based routing.

Example 13-6 Policy check and change

```
IBM_SAN80B_217:FID128:admin> aptpolicy
Current Policy: 3 0(ap)
3 0(ap): Default Policy
1: Port Based Routing Policy
3: Exchange Based Routing Policy
0: AP Shared Link Policy
1: AP Dedicated Link Policy
IBM_SAN80B_217:FID128:admin> switchdisable
IBM_SAN80B_217:FID128:admin> aptpolicy 1
Policy updated successfully.
```

IBM_SAN80B_217:FID128:admin> switchenable

# Lossless

Lossless DLS enables Dynamic Load Sharing for optimal utilization of the ISLs without causing any frame loss. Note that frame loss can be guaranteed only when a new additional path is used to do load rebalancing. Frame loss cannot be guaranteed on an existing data path that encounters failure. FOS v6.4.0 adds support for the Lossless DLS with DPS (Exchange based routing).

The In Order Delivery (IOD) capability can be enabled optionally for both Port Based Routing and Exchange Based Routing policies. In pre-FOS v6.4.0 versions the Lossless DLS feature was supported only for Port Based Routing and IOD was always enabled. This feature is enabled using the Lossless option shown in Figure 13-5 on page 601.

In Virtual Fabrics, lossless DSL can be enabled on a per logical switch basis. It is best that the logical switch be defined at an ASIC boundary so that ports from the same ASIC are not assigned to a different logical switch.

**Restriction:** The entire path in the switching fabric must be 8 Gbps ASIC's and is not supported on the advanced function blades and switches.

# **FSPF Route**

As shown in Figure 13-6, when you select the FSPF Route option (highlighted) under the *Routing* tree, the main area of the window then displays the FSPF routing table, including the destination domain and port, hop count, and the metric being the cost assigned to that link.

									Show Basic Mode
itchName: I	B5000_76		DomainID: 98((	J×62) VWVN	: 10:00:00:05	5:1e:90:16:57		Thu Nov 04 20	)10 00:20:03 GMT+I
onfigure	Routing	Extended Fabric	AAA Service	Trace F	ICON CUP	Security Policies			
Switch		Network	Firmware	e Download		License	User	Trunking	SNMP
Advanced	l Performan	ice Tuning (APT) Pr	blicy		Dynamic	c Load Sharing	In Order Deliv	very (IOD) La	iss Less
O Port-I	Based-Roư	ting I <u>nfo</u> ® E	xchange-Based-Ro	outing <u>Info</u>	) On	O off	⊖ On	• off	⊖ On ● Off
louting Tak	ble								
Routing	j.	In Port	Destination D	Out Port	Metric	Hops	Flags	Next Domain	Next Port
— 🗋 FSF	PF Route	10	5	24	1000	2	D	16	211
🗕 🗋 Lini	k Cost	10	16	24	500	1	D	16	211
		10	23	24	1000	2	D	16	211
		10	54	24	1000	2	D	16	211
		10	56	24	1000	2	D	16	211
		11	1	24	1000	2	D	16	211
		11	5	24	1000	2	D	16	211
		11	16	24	500	1	D	16	211
						000000000000000000000000000000000000000			
								Apply (	Close Refresh

Figure 13-6 FSPF Routing Table Details

Table 13-3 defines the different columns.

Field	Description
In Port	Displays the Port number where the frames enter the switch.
Destination Domain	Displays the destination domain ID for the participating static routes for a particular In Port. The destination domain is the target of the out port.
Out Port	Displays the Out port. It should be within the range of ports that are available for static routes for the current domain. More than one out port can be used for any In port with a different domain ID. Each domain ID requires an out port.
Metric	Displays the calculated cost of reaching the destination domain.
Hops	Displays the number of hops in the "shortest path" route.
Flags	Displays whether the route is Static ( $S$ ) or Dynamic ( $D$ ).
Next Domain	Displays the next domain ID in the routing path. The Next Domain is the switch that the "Out Port" is connected to.
Next Port	Displays the next Port in the routing path. The Next Port is the port number that the "Out Port" is physically connected to.

Table 13-3 FSPF Route field descriptions

### **Static Route**

A *static route* is a route that defines a specific path and does not change when a topology change occurs, unless the path that is defined by the route becomes unavailable.

A static route can be assigned only when the active routing policy is port-based routing. When exchange-based routing is active, you cannot assign static routes.

A reason for configuring static routes is that some devices (can be legacy storage devices) do not tolerate out-of-order exchanges; in such cases, use the port-based routing policy.

**Support:** Static routes are supported only on the IBM SAN40B and SAN80B platforms.

# Link cost

This next option under the Routing tree allows you to view the link cost for a specific link, as shown in Figure 13-7. By double-clicking in the Cost field for the specific port, you can modify the cost. This setting has an effect on the cost value that the local switch has for this link. It uses this value to calculate the lowest cost path to a destination on other switches within the fabric. For a 1 Gbps ISL, the default cost is 1000. For a 2/4/8 Gbps ISL, the default cost is 500. Valid values for link cost are from 1 to 9999.

🛃 B5000_76 - Switc	h Administration									
									Show	Basic Mode
SwitchName: B5000_7	6	DomainID: 98(0	1×62) W	MN: 10:00:00	:05:1e:9	90:16:57		Thu Nov	04 2010 00::	39:05 GMT+00:00
Configure Routing	Extended Fabric	AAA Service	Trace	FICON CUP	Sec	curity Policies				
Switch	Network	Firmware	Downloa	3	Ĺ	icense	User	Trur	nking	SNMP
Advanced Perform	ance Tuning (APT) Po outing I <u>nfo</u>	licy xchange-Based-Ro	uting I <u>n</u>	Dyna	mic Loa On	id Sharing	In Order Delive	ery (IOD)	Loss Les	s Off
Routing Table		_								
Routing	Port Numbe	r				Cost				
FSPF Route		C	)					500		
Link Cost		1						500		
		2	2					500		
		3	}					500		
		4						500		
		e e				500		000		
		7	,			000		500		
								Apply	Close	Refresh
Enabled Switch										-
		Mode: Advanced	Free P	rofessional M	anagen	nent Tool 1	0.18.229.78	ADO Use	er:admin   f	Role: admin 🛛 🖌

Figure 13-7 Routing link cost

# 13.2 Merging fabrics

Merging a fabric occurs where two or more separate fabrics are combined, as shown in Figure 13-8.



Figure 13-8 Two separate SAN fabrics

These separate SAN fabrics can be merged to form a larger SAN fabric by connecting the switches using an ISL, as shown in Figure 13-9.



Figure 13-9 A merged fabric

The zoning information of the different fabric is merged when the different fabrics are connected together, assuming that there are no conflicting definitions.

A merge might occur when an organization acquires another company or when two business units within one company merge. The result is that a SAN fabric is extended through the addition of another complete fabric.

**Important:** A SAN switch should be disabled before adding it to an existing fabric.

Some conflicts might occur when two fabrics are merged. The most common sources of conflict are:

- Duplicate domain ID
- Zoning configuration conflicts
- Operating parameters inconsistency (for example, core PID format)
- ► InteropMode when merging IBM b-type switches with IBM m-type switches

When issues occur, part of the SAN fabric is said to be *segmented*. You can identify a segmentation using the **switchShow** commands or by the flashing orange LED on the ISL port.

The following sections describe these conflicts and possible solutions.

# 13.2.1 Duplicate domain IDs

Domain IDs are used to uniquely identify a switch within a fabric. Therefore, each switch within the same fabric must have a unique domain ID. Duplicate domains causes the ISL between the two switches to be segmented, as shown in Figure 13-10.

Switch Events, Information		
Switch Events Switch Information		
All Events Last Updated: Fri Jul 24 2009 19:5	54:30 GMT+00	:00 (Auto-Refresh interval is 15 seconds)
		Filter Sho
Time Let	vel	Message
Fri Jul 24 2009 18:54:43 GMT+00:00	Warning	Effective Insistent domain ID for the fabric changed from OFF to ON
Fri Jul 24 2009 18:54:46 GMT+00:00 🛛 🔱	Information	Switch status changed from MARGINAL to HEALTHY.
Fri Jul 24 2009 18:54:54 GMT+00:00	Error	Port 8 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.
Fri Jul 24 2009 18:54:54 GMT+00:00	Error	Port 9 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.
Fri Jul 24 2009 18:54:54 GMT+00:00	Error	Port 56 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.
Fri Jul 24 2009 18:54:54 GMT+00:00	Error	Port 57 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.

Figure 13-10 Domain ID segmentation error log

To solve this overlap, change the domain ID of one of the switches participating in the ISL using the Web Tools interface in the Switch Admin tab or using the CLI **configure** command. An overview of used fabric ID's can be retrieved from DCFM or the **fabricshow** CLI command.

You can avoid domain ID overlap easily by disabling the Insistent Domain ID function. This is done with CLI using the **switchDisable** command. When bringing back the switches online, the domain ID automatically is negotiated and set to a valid value as shown in Example 13-7.

Example 13-7 Steps to disable Insistent Domain ID mode

```
IBM_SAN80B_217:FID128:admin> switchdisable
IBM_SAN80B_217:FID128:admin> configure
```

Configure...

Fabric parameters (yes, y, no, n): [no] y

```
Domain: (1..239) [1]
```

```
Allow XISL Use (yes, y, no, n): [no]
    R A TOV: (4000..120000) [10000]
    E D TOV: (1000..5000) [2000]
    WAN TOV: (0..30000) [0]
    MAX HOPS: (7..19) [7]
    Data field size: (256..2112) [2112]
    Sequence Level Switching: (0..1) [0]
    Disable Device Probing: (0..1) [0]
    Suppress Class F Traffic: (0..1) [0]
    Per-frame Route Priority: (0..1) [0]
    Long Distance Fabric: (0..1) [0]
    BB credit: (1..27) [16]
    Disable FID Check (yes, y, no, n): [no]
 Insistent Domain ID Mode (yes, y, no, n): [no] n
 Virtual Channel parameters (yes, y, no, n): [no] CTRL-D to exit
IBM SAN80B 217:FID128:admin> switchenable
IBM_SAN80B_217:FID128:admin> fabricshow
Switch ID Worldwide Name
                                    Enet IP Addr Name
                       _____
 1: fffc01 10:00:00:05:1e:94:3a:00 10.64.210.213 "IBM SAN384B 213"
 2: fffc02 10:00:00:05:1e:09:97:01 10.64.210.217 "IBM SAN80B 217"
 4: fffc04 10:00:00:05:1e:76:68:00 10.64.210.51 >"IBM B32 51"
 10: fffcOa 10:00:00:05:1e:76:86:80 10.64.210.50 "IBM B32 50"
The Fabric has 4 switches
```

The example shows that even if the Domain ID is set to 1 for the SAN80B switch, the Insistent Domain ID function selects Domain ID 2 for the switch, which allows the switch to merge with the other switches in the fabric.

# 13.2.2 Zoning configuration conflicts

When merging two fabrics, zoning information from the two previously separate fabrics is merged into the new fabric (as much as possible). If there are effective configurations active in both fabrics, they must match exactly. In a defined or effective configuration, if zone objects have the same name in each fabric, their type, content, and order of content must also match.

Figure 13-11 shows an example of segmentation due to zoning.

Switch Events, Information										
Switch Events Switch Information										
All Events Last Updated: Fri Jul 24 2009 20:16:44 GMT+00:00 (Auto-Refresh interval is 15 seconds)										
		Filter Shov								
Time	Level	Message								
Fri Jul 24 2009 20:08:18 GMT+00:00	AError	Port § Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.								
Fri Jul 24 2009 20:08:18 GMT+00:00	Error	Port woisabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.								
Fri Jul 24 2009 20:08:18 GMT+00:00	Error	Port 56 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.								
Fri Jul 24 2009 20:08:18 GMT+00:00	Error	Port 57 Disabled: Insistent Domain ID 1 could not be obtained. Principal Assigned Domain ID = 2.								
Fri Jul 24 2009 20:08:24 GMT+00:00	<li>Information</li>	The last fabric change happened at: Fri Jul 24 20:08:18 2009								
Fri Jul 24 2009 20:08:39 GMT+00:00	Information	The last device change happened at : Fri Jul 24 20:08:36 2009								
Fri Jul 24 2009 20:14:43 GMT+00:00	<li>Information</li>	The effective configuration has changed to SiteA_fab1A.								
Fri Jul 24 2009 20:15:14 GMT+00:00	<li>Information</li>	The last fabric change happened at: Fri Jul 24 20:15:12 2009								
Fri Jul 24 2009 20:15:19 GMT+00:00	🔔 Warning	Switch status changed from HEALTHY to MARGINAL.								
Fri Jul 24 2009 20:15:19 GMT+00:00	🔔 Warning	Switch status change contributing factor Switch offline.								
Fri Jul 24 2009 20:15:53 GMT+00:00	🔥 Warning 🍃	Encenve insistent domain ID for the fabric changed from ON to OFF								
Fri Jul 24 2009 20:15:54 GMT+00:00	🔔 Warning	port 9, Zone Conflict.								
Fri Jul 24 2009 20:15:55 GMT+00:00	🔔 Warning	port 57, Zone Conflict.								
Fri Jul 24 2009 20:15:55 GMT+00:00	Information	Switch status changes from MARGINAL to HEALTHY.								
Fri Jul 24 2009 20:16:04 GMT+00:00	Information	The last fabric change happened at: Fri Jul 24 20:15:55 2009								
Fri Jul 24 2009 20:16:24 GMT+00:00	<ol> <li>Information</li> </ol>	The last device change happened at : Fri Jul 24 20:16:13 2009								

Figure 13-11 Zoning conflict

# 13.2.3 Merging fabrics example

In this section we demonstrate how to merge two fabrics, each containing defined zoning configurations. The scenario is that two individual SANs are going to be interconnected and merged into a single fabric.

In our example, we merge fabric 1 in each site. We call the two configurations SiteA_fab1 (SAN80B switch) and SiteB_fab1 (SAN384B switch). We build in a non-valid zone configuration in order to demonstrate segmentation of the switches, and to show the resolution. We start with Example 13-8.

Example 13-8 Configuration SiteA before merge

```
alias: Blade1_hba1

1,21

alias: DS4000 1,22

Effective configuration:

cfg: SiteA_fab1

zone: z1_AIX_hba1_DS4000

1,20

1,22

zone: z1_BL1_DS4000

1,21

1,22
```

IBM_SAN80B_217:FID128:admin>

We have similar alias names in both fabrics, and their content is different. If similar alias names exist in two fabrics to be merged, they must have the same content, or the fabrics will segment and the merge will fail. Example 13-9 shows SiteB configuration before the merge.

Example 13-9 Configuration SiteB before merge

```
IBM SAN384B 213:FID128:admin> cfgshow
Defined configuration:
cfg:
        SiteB fab1
                z1_TSM_DS4000; z1_AIX_DS4000
       z1 AIX DS4000
 zone:
                AIX hba0; DS4000
       z1_TSM_DS4000
 zone:
                TSMserver_hba1; tape_lib_drive1; DS4000
 alias: AIX_hba0
                2,10
 alias: DS4000 2,11
 alias: TSMserver hba1
                2,12
 alias: tape lib drive1
                2,13
Effective configuration:
 cfg:
        SiteB fab1
zone:
       z1 AIX DS4000
                2,10
                2,11
 zone: z1 TSM DS4000
                2,12
```

2,13 2,11

#### IBM_SAN384B_213:FID128:admin

We interconnect the two switches at this point by enabling port 57 on our switch. Port 57 in our example is one end of an ISL-connection between the two switches.

The DS4000 alias exist in both fabrics, hence the two fabrics will segment and merge fails. This can be seen with the output of switchshow or portshow. Example 13-10 is an example of checking with switchshow.

Example 13-10 Switchshow shows segmented port 57

```
IBM SAN80B 217:FID128:admin> switchshow
switchName:
              IBM SAN80B 217
switchType:
              64.3
switchState:
              Online
switchMode:
              Native
switchRole:
              Principal
switchDomain:
              1 (unconfirmed)
switchId:
              fffc01
switchWwn:
              10:00:00:05:1e:09:97:01
              ON (SiteA_fab1)
zoning:
switchBeacon:
              0FF
FC Router:
              0FF
Allow XISL Use: OFF
LS Attributes: [FID: 128, Base Switch: No, Default Switch: Yes]
Area Port Media Speed State
                             Proto
------
 0
     0
       --
              N8
                   No Module
 57 57 id
              N8
                   Online
                                   E-Port segmented, (zone
conflict) (Trunk master)
```

We now have to fix any zoning configuration errors that might exist, and in our example we do this by renaming the DS4000 alias in the Site A fabric as shown in Example 13-11.

Example 13-11 Rename the DS4000 alias

IBM_SAN80B_217:FID128:admin> zoneobjectrename DS4000, DS4000_A

```
IBM_SAN80B_217:FID128:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
Updating flash ...
```

IBM_SAN80B_217:FID128:admin>

Next we have to disable the zoning configuration on one of the switches. By not doing so, the fabrics would segment and the merge would fail. We therefore choose which zoning configuration we want to disable. In Example 13-12 we disable the zoning configuration for SiteA, so that the effective zoning configuration will be the one from SiteB.

Example 13-12 Disable zoning configuration

```
IBM_SAN80B_217:FID128:admin> cfgdisable
You are about to disable zoning configuration. This
action will disable any previous zoning configuration enabled.
Do you want to disable zoning configuration? (yes, y, no, n): [no] y
Updating flash ...
IBM_SAN80B_217:FID128:admin> portenable 57
IBM_SAN80B_217:FID128:admin> switchdisable
IBM_SAN80B_217:FID128:admin> switchenable
IBM_SAN80B_217:FID128:admin> fabricshow
Switch ID Worldwide Name Enet IP Addr Name
1: fffc01 10:00:00:05:1e:09:97:01 10.64.210.217 >"IBM_SAN80B_217"
2: fffc02 10:00:00:05:1e:94:3a:00 10.64.210.213 "IBM_SAN84B_213"
```

The Fabric has 2 switches

Our two fabrics have successfully merged, and the configuration from SiteB is now the effective configuration. The combined configuration is containing all the zoning elements from both fabrics. However, zones from the previously disabled configuration in Site A have to be added to the effective configuration. In Example 13-13 we show the fabric after the merge.

Example 13-13 Fabric after merge

```
IBM SAN384B 213:FID128:admin> cfgshow
Defined configuration:
 cfg:
        SiteA fab1
                z1_BL1_DS4000; z1_AIX_hba1_DS4000
 cfg:
        SiteB fab1
                z1 TSM DS4000; z1 AIX DS4000
       z1 AIX DS4000
 zone:
                AIX hba0; DS4000
 zone: z1 AIX hba1 DS4000
                AIX hba1; DS4000 A
 zone: z1 BL1 DS4000
                Blade1 hba1; DS4000 A
 zone: z1 TSM DS4000
                TSMserver hba1; tape lib drive1; DS4000
 alias: AIX hba0
                2,10
 alias: AIX hbal
                1,20
 alias: Blade1 hba1
                1,21
 alias: DS4000 2,11
 alias: DS4000 A
                1,22
 alias: TSMserver hba1
                2,12
 alias: tape lib drive1
                2,13
Effective configuration:
        SiteB_fab1
 cfg:
 zone: z1 AIX DS4000
                2,10
                2,11
 zone: z1 TSM DS4000
                2,12
                2,13
                2,11
IBM SAN384B 213:FID128:admin>
```

We now add the zoning elements from the disabled configuration SiteA_fab1 to the effective configuration SiteB_fab1. This can be accomplished using Web Tools, or using the CLI as in Example 13-14 on page 617.

Example 13-14 Adding zones to the effective configuration

```
IBM SAN80B 217:FID128:admin> cfgadd SiteB_fab1, "z1_AIX_hba1_DS4000"
IBM SAN80B 217:FID128:admin> cfgadd SiteB fab1, "z1 BL1 DS4000"
IBM SAN80B 217:FID128:admin> cfgdelete SiteA fab1
IBM SAN80B 217:FID128:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
Updating flash ...
IBM SAN80B 217:FID128:admin> cfgenable SiteB fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteB fab1' configuration (yes, y, no, n): [no]
у
zone config "SiteB fab1" is in effect
Updating flash ...
```

IBM_SAN80B_217:FID128:admin>

The two fabrics are now merged into one single configuration. The zone objects in the SiteA_fab1 configuration were added to the SiteB_fab1 configuration, and SiteB_fab1 becomes the effective configuration. Example 13-15 shows the final configuration.

Example 13-15 The final merged configuration

```
IBM_SAN80B_217:FID128:admin> cfgshow
Defined configuration:
    cfg: SiteB_fab1
        z1_TSM_DS4000; z1_AIX_DS4000; z1_AIX_hba1_DS4000;
        z1_BL1_DS4000
```

```
z1 AIX DS4000
 zone:
                AIX hba0; DS4000
       z1 AIX hba1 DS4000
 zone:
                AIX_hba1; DS4000_A
 zone: z1 BL1 DS4000
                Blade1_hba1; DS4000_A
 zone: z1 TSM DS4000
                TSMserver hbal; tape lib drivel; DS4000
 alias: AIX hba0
                2,10
 alias: AIX hbal
                1,20
 alias: Blade1 hba1
                1,21
 alias: DS4000 2,11
 alias: DS4000 A
                1,22
 alias: TSMserver hba1
                2,12
 alias: tape lib drive1
                2,13
Effective configuration:
cfg:
       SiteB_fab1
zone: z1 AIX DS4000
               2,10
                2,11
 zone: z1 AIX hba1 DS4000
                1,20
                1,22
       z1_BL1_DS4000
 zone:
                1,21
                1,22
 zone: z1 TSM DS4000
                2,12
                2,13
                2,11
```

IBM_SAN80B_217:FID128:admin>

**Attention:** When two switches are being interconnected, the zoning configurations on one of the switches must be disabled, or the merge will fail. This includes the default-zone if set to no access. This hidden zone must also be disabled. To do this, use the command **defZone** --allaccess.

The configuration must be applied with the **cfgsave** command.

# 13.2.4 Merging with a configuration cleared switch

Another solution is to make sure that the switch you are adding to the fabric is cleared of any zoning information, by following this process:

- 1. Issue the switchDisable command to disable the switch.
- 2. Disable the active configuration using the cfgDisable command.
- 3. Issue the cfgClear command to clear all zoning information.
- 4. Issue the **defZone** -allaccess command to set the default mode to all access.
- 5. Issue the **switchEnable** command to enable the switch, as shown in Example 13-16.

Example 13-16 Merging the fabric by clearing the configuration of a fabric

IBMIBM_SAN80B_217:FID128:admin> switchdisable

# IBM_SAN80B_217:FID128:admin> cfgdisable

You are about to disable zoning configuration. This action will disable any previous zoning configuration enabled. Do you want to disable zoning configuration? (yes, y, no, n): [no] y Updating flash ... Effective configuration is empty. "No Access" default zone mode is ON.

#### IBM_SAN80B_217:FID128:admin> cfgclear

The Clear All action will clear all Aliases, Zones, FA Zones and configurations in the Defined configuration. cfgSave may be run to close the transaction or cfgTransAbort may be run to cancel the transaction. Do you really want to clear all configurations? (yes, y, no, n): [no] y IBM_SAN80B_217:FID128:admin> defzone --allaccess You are about to set the Default Zone access mode to All Access Do you want to set the Default Zone access mode to All Access ? (yes, y, no, n): [no] y IBM_SAN80B_217:FID128:admin> cfgsave You are about to save the Defined zoning configuration. This action will only save the changes on Defined configuration. Any changes made on the Effective configuration will not take effect until it is re-enabled. Do you want to save Defined zoning configuration only? (yes, y, no, n): [no] y Updating flash ... IBM_SAN80B_217:FID128:admin> switchenable

IBM_SAN80B_217:FID128:admin>

# 13.2.5 Operating parameter conflicts

Conflicts due to fabric-wide operating parameters are less common because default values for these settings suit most requirements. However, conflicts can occur when dealing with a multivendor environment or distance solution installations.

Error log messages can vary quite a bit, depending on the source of the problem. It is beyond the scope of this book to discuss all the possible error log messages; however, Figure 13-12 shows an example.

Switch Events Switch Information								
All Events Last Updated: Tue Jul 28 2009 16:11:12 GMT+00:00 (Auto-Refresh interval is 15 seconds)								
			耳 Actions					
Time	Level	Message						
Tue Jui 20 2009 T0. T0. 43 GWT+00.00		generation of the second second second second second second second second second second second second second se						
Tue Jul 28 2009 16:10:46 GMT+00:00	🔔 Warning	port 84, ELP rejected by the other switch.						
Tue Jul 28 2009 16:10:49 GMT+00:00	<li>Information</li>	The last fabric sharps happened at Two bit 28 16:10:41 2009						
Tue Jul 28 2009 16:10:51 GMT+00:00	<li>Information</li>	Switch status changed from MARGINAL to HEALTHY.						
Tue Jul 28 2009 16:11:09 GMT+00:00	Information	The last device change happened at : Tue Jul 28 16:10:59 2009						

Figure 13-12 ELP conflict
In this example, there is an exchange link parameter mismatch, which has caused the segmentation.

One solution to this problem is to make sure that the fabric-wide operating parameters are consistent throughout all the participating switches.

Use the **configure** command to set the correct R_A_TOV parameter and other specific parameters and ensure that all parameters, except the domain ID, are identical throughout all the switches in the fabric.

With Fabric OS v6.1.x and later, the Core PID mode is set as the default. When connecting 1-Gbps switches to 8 Gbps switches, the core PID mode in the 1 Gbps switch must be in core PID mode. Devices connected to the 1 Gbps switch must be taken offline while changing the PID mode of the switch.

**Reboot:** Rebooting the switch might be required in some cases when changing system parameters. Reboot helps to prevent inconsistencies.

#### 13.2.6 InteropMode

You need to consider InteropMode when connecting IBM m-type switches to IBM b-type switches. The different types of InteropMode that you can select include:

- InteropMode 0: For Brocade Native mode, which supports all stand-alone Brocade fabrics, but no interoperability support
- InteropMode 1: No longer supported; was the original Open Fabric mode; replaced by InteropMode 3
- InteropMode 2: For McDATA Fabric mode, which supports M-EOS switches v9.6.2 and later running in McDATA Fabric mode
- InteropMode 3: For McDATA Open Fabric mode, which supports M-EOS switches v9.6.2 and higher running in Open Fabric mode

Example 13-17 shows the output of the interopmode command.

Example 13-17 Output of interopmode

<pre>IBM_SAN384B_213:FID128:admin&gt; interopmode InteropMode: Off</pre>
<pre>usage: InteropMode [0 2 3 [-z McDataDefaultZone] [-s McDataSafeZone]] 0: to turn interopMode off 2: to turn McDATA Fabric mode on Valid McDataDefaultZone: 0 (disabled), 1 (enabled) Valid McDataSafeZone: 0 (disabled), 1 (enabled) 3: to turn McDATA Open Fabric mode on</pre>

```
IBM_SAN384B_213:FID128:admin>
```

Having a fabric in InteropMode 2 or 3 can exclude some newer features. See the following link for the interoperability guide for your switch model:

https://www-304.ibm.com/systems/support/supportsite.wss/allproducts?tas kind=2&brandind=5000031

To change InteropMode, see Example 13-18. The switch must be disabled using the **switchDisable** command before issuing the **interopmode** command. The switch is rebooted automatically. Therefore, devices that are connected to the switch must be taken offline also.

Example 13-18 Changing InteropMode

```
IBM_SAN384B_213:FID128:admin> switchdisable
IBM_SAN384B_213:FID128:admin> interopmode 2
The switch effective configuration will be lost.
Interop Mode Will Be Changed and switch will be Enabled
Do you want to continue? (yes, y, no, n): [no] y
InteropMode: McDATA Fabric
Default Zone: Off
Safe Zone: Off
```

```
IBM_SAN384B_213:FID128:admin>
```

In this specific situation, reboot is not needed, and InteropMode is now shown as McDATA Fabric.

# 14

## Security

In this chapter we provide information and procedures for configuring basic and advanced Fabric OS v6.4.1 security features such as user account management, Access Control Lists (ACL) policies, authentication policies, and IP Filtering for Brocade's Fibre Channel switches.

**Important:** The Secure Fabric OS licensed feature is no longer supported or available on Fabric Operating System v6.x and later. All the security features are available in the base Fabric OS starting in Fabric OS v5.3.0 and later.

## 14.1 User accounts overview

In addition to the default accounts, root, factory, admin, and user, Fabric OS supports up to 252 additional user-defined accounts in each logical switch (domain). These accounts expand your ability to track account access and audit administrative activities.

Each user-defined account is associated with the following elements:

- Admin Domain list: Specifies the Administrative Domains that a user account is allowed to log in to.
- Home Admin Domain: Specifies the Admin Domain that the user is logged in to by default. The home Admin Domain must be a member of the user's Admin Domain list.
- Virtual Fabric list: Specifies the Virtual Fabric that a user account is allowed to log in to.
- Home Virtual Fabric: Specifies the Virtual Fabric that the user is logged in to by default. The home Virtual Fabric must be a member of the user's Virtual Fabric list.
- Role: Determines functional access levels within the bounds of the user's current Admin Domain.

**Attention:** Admin Domains are mutually exclusive from Virtual Fabrics permissions when setting up user accounts. You will need to set up different user accounts for each feature.

You cannot have Admin Domain mode and Virtual Fabrics mode enabled at the same time.

#### 14.1.1 User authentication

Fabric OS provides three options for authenticating users: remote RADIUS services, remote LDAP service, and the local switch user database. All options allow users to be centrally managed using the following methods:

- Remote RADIUS server: Users are managed in a remote RADIUS server. All switches in the fabric can be configured to authenticate against the centralized remote database.
- Remote LDAP server: Users are managed in a remote LDAP server. All switches in the fabric can be configured to authenticate against the centralized remote database.

Local user database: Users are managed using the local user database. The local user database is manually synchronized using the distribute command to push a copy of the switch's local user database to all other Fabric OS v5.3.0 and later switches in the fabric.

For setting up user authentication through RADIUS or LDAP, we refer you to the *Fabric OS Administrator's Guide*, which is only available through the Partner Network website at the following location (navigate to the Product Documentation and register or login):

http://www.brocade.com/data-center-best-practices/resource-center/index
.page

#### 14.1.2 Role-Based Access Control

Role-Based Action Control (RBAC) defines the capabilities that a user account has, based on the role that the account has been assigned. For each role, there is a set of predefined permissions on the jobs and tasks that can be performed on a fabric and its associated fabric elements. Fabric OS v6.1.0 and later uses RBAC to determine which commands a user can issue.

When you log in to a switch, your user account is associated with a predefined role. The role that your account is associated with determines the level of access you have on that switch and in the fabric. The chassis-role permission is not a role like the other role types, but a permission that is applied to a user account. You can use the **userConfig** command to add this permission to a user account. For clarity, this permission has been added to Table 14-1, which outlines the Fabric OS predefined roles.

Role name	FOS version	Duties	Description
Admin	All	All administration	All administrative commands.
BasicSwitch Admin	v5.2.0 and later	Restricted switch administration	Administrative use with a subset of admin-level commands, mostly for monitoring with limited switch (local) access
FabricAdmin	v5.2.0 and later	Fabric and switch administration	All switch and fabric commands; excludes user management and Admin Domains commands
Operator	v5.2.0 and later	General switch administration	A subset of administrative tasks for routine switch maintenance

Table 14-1 Fabric OS roles

Role name	FOS version	Duties	Description
SecurityAdmin	v5.3.0 and later	Security administration	All switch security and user management functions
SwitchAdmin	v5.0.0 and later	Local switch administration	Administrative use excluding security, user management, and zoning
User	All	Monitoring only	Non-administrative use, such as monitoring system activity
ZoneAdmin	v5.2.0 and later	Zone administration	Zone management commands only

Admin Domain considerations: Legacy users with no Admin Domain specified and whose current role is admin will have access to AD 0 through 255 (physical fabric admin); otherwise, they will have access to AD0 only.

## 14.1.3 Local database user accounts

User add, change, and delete operations are subject to the subset rule: An admin with AD_list 0-10 or LF_list 1-10 cannot perform operations on an admin, user, or any role with an AD_list 11-25 or LF_list 11-128. The user account being changed must have an AD_list or LF_list that is a subset of the account that is making the change.

#### Types of accounts

In addition to the default administrative and user accounts, Fabric OS supports up to 252 user-defined accounts in each logical switch (domain). These accounts expand your ability to track account access and audit administrative activities.

#### **Default accounts**

Table 14-2 is a list of the predefined accounts offered by Fabric OS available in the local switch user database. The password for all default accounts must be changed during the initial installation and configuration for each switch.

Table 14-2 lists the default user-accounts.

Account name	Role	Admin Domain	Logical fabric	Description
admin	admin	AD0-255 home: 0	LF1-128 home: 128	Observe-modify permission.
factory	factory	AD0-255 home: 0	LF1-128 home: 128	Reserved.
root	root	AD0-255 home: 0	LF1-128 home: 128	Reserved.
user	user	AD0 home: 0	LF1-128 home: 128	Observe-only permission.

Table 14-2 Default user accounts

## 14.2 Account management

In the topics that follow, we cover account management.

## 14.2.1 Displaying account information

To display the account information, you can use Web Tools or the CLI.

## Web Tools

From the main Webtools menu select **Switch Admin**; this opens the Switch Administrator window. Select the **User** tab and you get a list of all defined users and roles, as shown in Figure 14-1.

								_	Show Advanced N
itchName: IE	3M_SAN384B_2	7	Domain	ID: 16(0×10)	WWN: 10:00:00:	:05:1e:94:3a:00		Thu M	Nov 04 2010 10:52:
vitch Ne	stwork Firmw	vare Download	License U	lser Blade	Trunking				
witch User	Account								
Add	Modify	Remove Ch	ange Password	I Expire P	assword U	Inlock Password	Set P	assword Rule	
Jser Name	Role	Description	Status	Expiration Date	Expiration St	. Lockout	Home AD	AD List	
oot	root	root	Enabled		No	No	AD0	ALL	
actory	factory	Diagnostics	Enabled		No	No	AD0	ALL	
admin	admin	Administrator	Enabled		No	No	AD0	ALL	
iser	user	User	Enabled		No	No	AD0	AD0	
iser	user	User	Enabled		No	No	ADO	ADO	

Figure 14-1 User tab

#### CLI

Follow these steps:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- 2. Enter the appropriate **show** operands for the account information that you want to display:
  - userConfig --show -a to show all account information for a logical switch
  - userConfig --show username to show account information for the specified account
  - userConfig --showad -a adminDomain_ID to show all accounts permitted to select the specified adminDomain_ID
  - **userConfig** --showlf -1 logicalFabric_ID for each LF in an LF_ID_list, which displays a list of users that include that LF in their LF permissions.

#### 14.2.2 Creating an account

In the next sections we give examples of user management, such as creating, deleting, and modifying a local switch user. To modify or add a user, you can use either Web Tools or the CLI.

#### Web Tools

To create a new user, select the **Add** button in the user window, fill in the user details, and select the role and default admin domain, as shown in Figure 14-2.

🔄 Switch Admin:	Add User Account 🛛 🗙
User Name	dennis
Role	admin 💌
Description	Dennis admin user
Status	Enabled      Disabled
New Password	•••••
Confirm Password	•••••
Admin Domain	
IA II	
🔘 Select Admin Do	omain
AD0	
Physical Fa	ibric
Home AD AD0	▼
ADO	
Physical	rabric
	Ok Cancel Help

Figure 14-2 Add user account

As shown in Figure 14-3, under the **Role** tab, you can select the role of the new user.

Password: The default password minimum length is 8 characters.

user 💌
switchadmin
securityadmin
fabricadmin
admin
basicswitchadmin
zoneadmin
user
operator

Figure 14-3 Role

This user will be displayed in the switch administration user window as shown in Figure 14-4.

	40_21 - SWI	ten Administrati							Show Advanced Mod
itchName: IBN	M_SAN384B_	27	Domair	nID: 16(0x10) 1	AWN: 10:00:00	:05:1e:94:3a:00		Thu M	Nov 04 2010 11:10:19
vitch Net	work Firm	ware Download	License L	Jser Blade	Trunking				
witch User /	Account								
Add	Modify	Remove Ch	ange Password	d Expire P	assword	nlock Password	Set Pa	assword Rule	
Jser Name	Role	Description	Status	Expiration 4	Expiration St	Lockout	Home AD	AD List	
oot	root	root	Enabled		No	No	ADO	ALL	
actory	factory	Diagnostics	Enabled		No	No	AD0	ALL	
dmin	admin	Administrator	Enabled		No	No	AD0	ALL	
iser	user	User	Enabled		No	No	AD0	AD0	
lennis	admin	dennis admin	. Enabled	Default Expir	No	No	AD0	ALL	
itch Administ	tration opened	I): Thu Nov 04 2011	0 10:37:07 PDT					Apply	Close Refresh

Figure 14-4 New user add

Select the **Apply** button to activate the new user, and you will receive a confirmation window with all details on the new user, as shown in Figure 14-5.



Figure 14-5 New user confirmation

Select the Yes button and the new user is active.

#### CLI

Example 14-1 shows the creation of an account using CLI

Example 14-1 Creating an account

IBM_SAN256B_130:admin> userconfig --add dennis -r admin Setting initial password for dennis Enter new password: Re-type new password: Account dennis has been successfully added. IBM_SAN256B_130:admin>

## 14.2.3 Modifying User and Account settings

Figure 14-6 shows the options available for switch user account modification.

IBM_SAN38	348_27 - Swit	ich Administrati	ion						
								Show Adv	anced Mo
vitchName: IE	M_SAN384B_2	27	DomainID: 10	6(0×10) VWM	: 10:00:00:05:1	e:94:3a:00	Th	u Nov 04 2010	) 11:38:29
witch Ne	twork Firm	ware Download	License Us	ser Blade	Trunking				
Switch User	Account								
Add	Modify	Remove Ch	ange Password.	Expire Pa	ssword Ur	nlock Password	Set Passy	word Rule	
User Name	Role	Description	Status	Expiration Date	Expiration St	Lockout	Home AD	AD List	
root	root	root	Enabled		No	No	AD0	ALL	
factory	factory	Diagnostics	Enabled		No	No	ADO A	ALL	
admin	admin	Administrator	Enabled		No	No	ADO A	ALL	
user	user	User	Enabled		No	No	ADO A	AD0	
dennis	admin	dennis admin	. Enabled		No	No	ADO A	ALL	
dennis	admin	dennis admin	. Enabled		No	No	AD0	ALL	Potro
							Abbiy	Close	Refrest
•••••••									
dified passw	ord for user ac	count: dennis							
		1				40.40.000.07	Lune Lu		

Figure 14-6 User modification tabs

Attention: You are not able to modify a default account.

#### Changing the password rules

Select the **Set Password Rule** button from the Web Tools User window. This action will open a window where you can change the password rules for all accounts on this switch, as shown in Figure 14-7.

🛿 Switch Admin:Configure Password Rule						
Switch User Account Passv	vord Rules					
Mi⊓imum Password Age	0	Days				
Maximum Password Age	0	Days				
Password History	1	Previous Passwords				
Minimum Password Length	8	Characters				
Required Uppercase	0	Characters				
Required Lowercase	0	Characters				
Required Digits	0	Digits				
Required Punctuation	0	Characters				
Max Repeat	1	Characters				
Max Sequence	1	Characters				
Lockout Threshold	0	Times				
Lockout Duration	30	Minutes				
Warning Period	0	Days				
Lockout Admin	C Enabled					
	<u>O</u> k	Cancel Help				

Figure 14-7 Password rules

Fill out the dialog box for the password rules you want to enforce. Choose whether to enable or disable the lockout administration features.

**Lockout:** If you choose to disable the lockout administration, the user is never locked out of the system.

Click **OK** to close the dialog box and then click **Apply** and the **Yes** button in the confirmation window to activate your changes. The new user is now active.

#### Changing the password for a user

From the Web Tools User window, select the user that you want to perform the password change on, and press the **Change Password** button. This will open the Set User Account Password window, shown in Figure 14-8.

User Name	admin
Old Password	•••••
New Password	•••••
Confirm Password	•••••
	Ok Cancel Help

Figure 14-8 Change Password

Enter the old password and then the new password, with confirmation. Click **OK** to close the dialog box and then click **Apply** and the **Ye**s button in the confirmation window to activate your changes.

Password: The new password must comply with the password rules set.

#### Modifying an account

Any user defined account can be modified using the **Modify** button. This will bring up the modify user account window, as shown in Figure 14-9.

🕅 Switch /	Admin: Modify User Account	X
User Name	dennis	
Role	admin	
11010	even in the starting	
Description	switchadmin	
~ .	securityadmin	
Status	Tabricadmin	
	admin	
Admin Doma	pasicswitchadmin	
🖲 Al	zoneadmin	
⊖ Select A	user	
U Select A	operator	
ADC		
🗌 🗌 Phy	sical Fabric	
Home AD	AD0	-
		Ok Cancel

Figure 14-9 Modify user

Make the changes to the user and then Click **OK** to close the dialog box and then click **Apply** and the **Ye**s button in the confirmation window to activate your changes.

#### **Removing a user**

From the Web Tools User window, select the user that you want to remove and and press the **Remove** button. This will remove the user from the users list. Click **Apply** and the **Yes** button in the confirmation window to activate your changes.

Attention: You are not able to delete a default account.

#### Expiring a password

From the Web Tools User window, select the user that you want to expire the password and press the **Expire Password button**. This will set the user password to expired. Click **Apply** to activate your changes. The user state will change to expired as shown in Figure 14-10.

ch Network Firmware Download License User Blade Trunking tich User Account Add Modify Remove Change Password Expire Password Unlock Password Set Password Rule r Name Role Description Status Expiration Date Expiration St Lockout Home AD AD List t root root Enabled No No ADO ALL tory factory Diagnostics Enabled No No ADO ALL inin admin Administrator Enabled No No ADO ALL ir user User Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refree	tchName: IBI	M_SAN384B_	27	DomainIE	: 16(0×10) VWVN: 10:00:0	0:05:1e:94:3a:00		Thu	Nov 04 2010 13:37
itch User Account           Modify         Remove         Change Password         Expire Password         Unlock Password         Set Password Rule           er Name         Role         Description         Status         Expire Password         Unlock Password         Set Password Rule           er Name         Role         Description         Status         Expiration Date         Expiration St         Lockout         Home AD         AD List           torry         factory         Diagnostics         Enabled         No         No         ADO         ALL           nin         admin         Administrator         Enabled         No         No         ADO         ALL           inis         admin         dennis admin user Enabled         No         No         ADO         ALL	vitch Net	work Firm	ware Download	cense User	Blade Trunking				
Add         Modify         Remove         Change Password         Expire Password         Unlock Password         Set Password Rule           er Name         Role         Description         Status         Expiration Date         Expiration St         Lockout         Home AD         AD List           t         root         root         Enabled         No         No         ADO         ALL           tory         factory         Diagnostics         Enabled         No         No         ADO         ALL           nin         admin         Administrator         Enabled         No         No         ADO         ALL           ris         user         User         Enabled         No         No         ADO         ALL	witch User a	Account							
er Name Role Description Status Expiration Date Expiration St Lockout Home AD AD List t root root Enabled No No ADO ALL tory factory Diagnostics Enabled No No ADO ALL nin admin Administrator Enabled No No ADO ALL r user User Enabled No No ADO ALL inis admin dennis admin user Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refree	Add	Modify	Remove Change	e Password	Expire Password Un	lock Password	Set Pas	sword Rule	
t root root Enabled No No ADO ALL tory factory Diagnostics Enabled No No ADO ALL nin admin Administrator Enabled No No ADO ALL r user User Enabled No No ADO ALL unis admin dennis admin user Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refree	Jser Name	Role	Description	Status	Expiration Date	Expiration St	Lockout	Home AD	AD List
tory factory Diagnostics Enabled No No AD0 ALL nin admin Administrator Enabled No No AD0 ALL r user User Enabled No No AD0 ALD nis admin dennis admin user Enabled expired(admin enforced) Yes No AD0 ALD Apply Close Refree	oot	root	root	Enabled		No	No	AD0	ALL
nin admin Administrator Enabled No No ADO ALL r user User Enabled No No ADO ADO inis admin dennis admin user Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refree	actory	factory	Diagnostics	Enabled		No	No	AD0	ALL
er user User Enabled No No ADO ADO Inis admin dennis admin user Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refree	dmin	admin	Administrator	Enabled		No	No	AD0	ALL
nnis admin dennis admin user Enabled expired(admin enforced) Yes No ADO ALL Apply Close Refre	ser	user	User	Enabled		No	No	AD0	AD0
Apply Close Refre	ennis	admin	dennis admin user	Enabled 🤇	expired(admin enforced)	Yes	No	AD0	ALL
	ennis	admin	dennis admin user	Enabled 🤇	expired(admin enforced)	Yes	No	AD0 Apply	ALL Close Ret
		CODURT NORPH							

Figure 14-10 Expired user password

At the next login, this user will be requested to change the password before login is accepted. The user password can be changed from the switch administration user menu using the **Change Password** button, or when the user logs in for the first time, as shown in Example 14-2. This option can be used to force a user to change their login password.

Example 14-2 Login

```
IBM_SAN384B_27 login: dennis
Password:
Your password has expired. Please change your password now.
Changing password for dennis
Enter old password:
Enter new password:
Re-type new password:
passwd: all authentication tokens updated successfully
Saving password to stable storage.
Password saved to stable storage successfully.
IBM SAN384B 27:dennis>
```

## 14.3 Security protocols

Security protocols provide endpoint authentication and communications privacy using cryptography. Typically, you are authenticated to the switch while the switch remains unauthenticated to you. This means that you can be sure with whom you are communicating. The next level of security, in which both ends of the conversation are sure with whom they are communicating, is known as two-factor authentication. Two-factor authentication requires public key infrastructure (PKI) deployment to clients.

#### 14.3.1 Security protocol support

Fabric OS supports the security protocols shown in Table 14-3.

Table 14-3 Security protocol support

Protocol	Description
HTTPS	HTTPS is a Uniform Resource Identifier scheme used to indicate a secure HTTP connection. Web Tools supports the use of hypertext transfer protocol over secure socket layer (HTTPS).
LDAPS	Lightweight Directory Access Protocol over SSL uses a certificate authority (CA). By default, LDAP traffic is transmitted unsecured. You can make LDAP traffic confidential and secure by using Secure Sockets Layer (SSL) / Transport Layer Security (TLS) technology in conjunction with LDAP.
SCP	Secure Copy (SCP) is a means of securely transferring computer files between a local and a remote host or between two remote hosts, using the Secure Shell (SSH) protocol. Configuration upload and download support the use of SCP.
SNMP	Supports SNMPv1, v2, and v3. SNMP is used in network management systems to monitor network-attached devices for conditions that warrant administrative attention.
SSH	Secure Shell (SSH) is a network protocol that allows data to be exchanged over a secure channel between two computers. Encryption provides confidentiality and integrity of data. SSH uses public-key cryptography to authenticate the remote computer and allow the remote computer to authenticate the user, if necessary.
SSL	Supports SSLv3, 128-bit encryption by default. Fabric OS uses secure socket layer (SSL) to support HTTPS. A certificate must be generated and installed on each switch to enable SSL.

Table 14-4 describes additional software or certificates that you must obtain to deploy secure protocols.

 Table 14-4
 Items needed to deploy secure protocols

Protocol	Host side	Switch side
SSHv2	Secure shell client	None
HTTPS	No requirement on host side except a browser that supports HTTPS	Switch IP certificate for SSL
SCP	SSH daemon, scp server	None
SNMPv1,SNMPv2,SNMPv3	None	None

The security protocols are designed with the four main use cases in Table 14-5.

Table 14-5 Usage cases

Fabric	Management interfaces	Comments
Nonsecure	Nonsecure	No special setup is needed to use Telnet or HTTP.
Nonsecure	Secure	Secure protocols can be used. An SSL switch certificate must be installed if HTTPS is used.
Secure	Secure	Switches running earlier Fabric OS versions can be part of the secure fabric, but they do not support secure management. Secure management protocols must be configured for each participating switch. Nonsecure protocols can be disabled on nonparticipating switches. If SSL is used, then certificates must be installed. For more information about installing certificates, see "Installing a switch certificate" on page 651.
Secure	Nonsecure	<ul> <li>You must use SSH because Telnet is not allowed with some features. Nonsecure management protocols are necessary under these circumstances:</li> <li>The fabric contains switches running Fabric OS v3.2.0.</li> <li>There are software tools that do not support secure protocols, for example, Fabric Manager v4.0.0.</li> <li>The fabric contains switches running Fabric OS versions earlier than v4.4.0. Nonsecure management is enabled by default.</li> </ul>

## 14.3.2 Secure file copy

In this section we discuss considerations regarding secure file copy.

#### Using the configure command

You can use the **configure** command to specify that secure file copy (SCP) is used for configuration uploads and downloads, as shown in Example 14-3.

#### Setting up SCP for configuration uploads and downloads

Follow these steps for configuration uploads and downloads:

- 1. Log in to the switch as admin.
- 2. Type the **configure** command.
- 3. Type y or yes at the cfgload attributes prompt.
- 4. Type y or yes at the Enforce secure configUpload/Download prompt.

Example 14-3 Example of setting up SCP for configUpload/download

```
switch:admin> configure
Not all options will be available on an enabled switch.
To disable the switch, use the "switchDisable" command.
Configure...
System services (yes, y, no, n): [no] n
ssl attributes (yes, y, no, n): [no] n
http attributes (yes, y, no, n): [no] n
snmp attributes (yes, y, no, n): [no] n
cfgload attributes (yes, y, no, n): [no] y
Enforce secure config Upload/Download (yes, y, no, n): [no] n
```

## 14.4 Simple Network Management Protocol

The Simple Network Management Protocol (SNMP) is a standard method for monitoring and managing network devices. Using SNMP components, you can program tools to view, browse, and manipulate IBM switch variables and set up enterprise-level management processes.

Every IBM switch carries an SNMP agent and management information base (MIB). The agent accesses MIB information about a device and makes it available to a network management station. You can manipulate information of your choice by trapping MIB elements using the Fabric OS command line interface (CLI), Web Tools, or DCFM.

The SNMP access control list (ACL) provides a way for the administrator to restrict SNMP get and set operations to certain hosts and IP addresses. This is used for enhanced management security in the storage area network.

For details on Brocade MIB files, naming conventions, loading instructions, and information about using Brocade's SNMP agent, see the *Fabric OS MIB Reference*, 53-1001156-01.

You can configure SNMPv3 and SNMPv1 for the automatic transmission of SNMP information to management stations.

The configuration process involves configuring the SNMP agent and configuring SNMP traps. Use the **snmpConfig** command to configure the SNMP agent and traps for SNMPv3 or SNMPv1 configurations, and the security level. You can specify no security, authentication only, or authentication and privacy.

The SNMP trap configuration specifies the MIB trap elements to be used to send information to the SNMP management station. There are two main MIB trap choices:

Brocade-specific MIB trap:

Associated with the Brocade-specific MIB (SW-MIB), this MIB monitors IBM/Brocade switches specifically.

► FibreAlliance MIB trap:

Associated with the FibreAlliance MIB (FA-MIB), this MIB manages SAN switches and devices from any company that complies with FibreAlliance specifications.

If you use both SW-MIB and FA-MIB, you might receive duplicate information. You can disable the FA-MIB, but not the SW-MIB.

You can also use these additional MIBs and their associated traps:

FICON-MIB

This MIB is for FICON environments.

SW-EXTTRAP

This MIB includes the Software Serial Number (swSsn) as a part of Brocade SW traps.

For information about Brocade MIBs, see the *Fabric OS MIB Reference*, 53-1001156-01.

For information about the specific commands used in these procedures, see the online help or the *Fabric OS Command Reference*, 53-1001186-01.

The SNMP Agent configuration interface is interactive for all parameters except mibCapability, which can be configured both interactively and with command-line options on platforms running Fabric OS v6.4.0 and later. The enhanced command-line interface supports enabling or disabling a single MIB or all MIBs, configuring a single trap only, and managing traps in excess of 32.

In Fabric OS v6.3.0 and later, the SNMPv3 configuration supports sending inform requests as an alternative to trap requests. Traps are unreliable because the receiver does not send any acknowledgment when it receives a trap. The sender cannot determine if the trap was received. However, an SNMP manager that receives an inform request acknowledges the message with an SNMP response protocol data unit (PDU). If the manager does not receive an inform request, it does not send a response. If the sender never receives a response, the inform request can be sent again. Thus, informs are more likely to reach their intended destination.

All values successfully changed by this command take effect immediately and are persistent across power cycles and reboots.

#### 14.4.1 SNMP and Virtual Fabrics

When an SNMPv3 request arrives with a particular username, it executes in the home Virtual Fabric. From the SNMP manager, all SNMPv3 requests must have a home Virtual Fabric that is specified in the contextName field. Whenever the home Virtual Fabric is specified, it will be converted to the corresponding switch ID and the home Virtual Fabric will be set. If the user does not have permission for the specified home Virtual Fabric, this request fails with an error code of noAccess.

For an SNMPv3 user to have a home Virtual Fabric, a list of allowed Virtual Fabrics, an RBAC role, and the name of the SNMPv3 user should match that of the Fabric OS user in the local switch database. SNMPv3 users whose names do not match with any of the existing Fabric OS local users have a default RBAC role of admin with the SNMPv3 user access control of read/write. Their SNMPv3 user logs in with an access control of read-only. Both user types will have the default switch as their home Virtual Fabrics.

The contextName field should have the format "VF:xxx" where xxx is the actual VF_ID, for example "VF:1". If the contextName field is empty, then the home Virtual Fabric of the local Fabric OS user with the same name shall be used. Because Virtual Fabrics and Admin Domains are mutually exclusive, this field is considered as Virtual Fabrics context whenever Virtual Fabrics is enabled. You cannot specify chassis context in the contextName field.

#### Filtering ports

Each port can belong to only one Virtual Fabric at any time. An SNMP request coming to one Virtual Fabric will only be able to view the port information of the ports belonging to that Virtual Fabric. All port attributes are filtered to allow SNMP to obtain the port information only from within the current Virtual Fabrics context.

#### Switch and chassis context enforcement

All attributes are classified into two categories:

- Chassis-level attributes
- Switch-level attributes

Attributes that are specific to each logical switch belong to the switch category. These attributes are available in the Virtual Fabrics context and are not available in the chassis context. Attributes that are common across the logical switches belong to the chassis level. These attributes are accessible to users having the chassis-role permission. When a chassis table is queried, the context is set to chassis context, if the user has the chassis-role permission. The context is switched back to the original context after the operation is performed.

#### 14.4.2 Security level

Use the **snmpConfig** --set seclevel command as shown in Example 14-4 to set the security level. You can specify no security, authentication only, authentication and privacy, or off. You need to set the security for the GET command and the SET command, for example, to configure for authentication and privacy for both commands.

Example 14-4 Configuring the SNMP GET and SET commands

```
switch:admin> snmpconfig --set seclevel
Select SNMP GET Security Level
(0 = No security, 1 = Authentication only, 2 = Authentication and
Privacy, 3 = No Access): (0..3) [1] 2
Select SNMP SET Security Level
(0 = No security, 1 = Authentication only, 2 = Authentication and
Privacy, 3 = No Access): (2..3) [2] 2
switch:admin> snmpconfig --show seclevel
GET security level = 2, SET level = 2
SNMP GET Security Level: Authentication and Privacy
SNMP SET Security Level: Authentication and Privacy
```

#### 14.4.3 snmpConfig command

Use the **snmpConfig --set** command as shown in Example 14-5 to change either the SNMPv3 or SNMPv1 configuration. You can also change access control, MIB capability, and system group.

In Fabric OS v6.3.0 and later, the **--set snmpv3** command supports an interactive option to enable or disable informs by setting the parameter **SNMP Informs Enabled** to true or false. If informs are enabled, all trap destinations receive inform requests. If informs are disabled, all trap destinations receive trap requests. When informs are enabled, the engine ID must be set to correspond to the management engine IP address. Informs are by default disabled. IPv6 Informs are currently not supported.

Traps can be received at the default port 162; this can be modified from the default port during the setup process.

Example 14-5 Example SNMPv3 configuration

```
IBM SAN384B 27:admin> snmpconfig --set snmpv3
SNMP Informs Enabled (true, t, false, f): [false] f
SNMPv3 user configuration(snmp user not configured in FOS user database
will have physical AD and admin role as the default):
User (rw): [snmpadmin1] adminuser
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 1
New Auth Passwd:
Verify Auth Passwd:
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (1..6) [2] 2
User (rw): [snmpadmin2] shuser
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 1
New Auth Passwd:
Verify Auth Passwd:
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (1..6) [2] 1
New Priv Passwd:
Verify Priv Passwd:
User (rw): [snmpadmin3] nosec
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 3
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (2..2) [2] 2
User (ro): [snmpuser1]
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 3
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (2..2) [2] 2
User (ro): [snmpuser2]
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 3
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (2..2) [2] 2
User (ro): [admin]
Auth Protocol [MD5(1)/SHA(2)/noAuth(3)]: (1..3) [3] 3
Priv Protocol
[DES(1)/noPriv(2)/3DES(3)/AES128(4)/AES192(5)/AES256(6)]): (2..2) [2] 2
SNMPv3 trap recipient configuration:
Trap Recipient's IP address : [0.0.0.0] 10.64.210.103
UserIndex: (1..6) [1] 1
Trap recipient Severity level : (0..5) [0] 4
Trap recipient Port : (0..65535) [162]
Trap Recipient's IP address : [0.0.0.0] 10.64.210.103
UserIndex: (1..6) [2] 2
Trap recipient Severity level : (0..5) [0] 2
Trap recipient Port : (0..65535) [162]
```

```
Trap Recipient's IP address : [0.0.0.0]
Trap Recipient's IP address : [0.0.0.0]
Trap Recipient's IP address : [0.0.0.0]
Trap Recipient's IP address : [10.127.140.95] 0.0.0.0
Committing configuration....done.
IBM_SAN384B_27:admin>
```

Example 14-6 shows how to set the SNMP access list configuration.

Example 14-6 Example of accessControl configuration

```
IBM SAN384B 27:admin> snmpconfig --set accessControl
SNMP access list configuration:
Access host subnet area : [0.0.0.0] 10.64.210.0
Read/Write? (true, t, false, f): [true]
Access host subnet area : [0.0.0.0] 10.64.210.0
Read/Write? (true, t, false, f): [true]
Access host subnet area : [0.0.0.0]
Read/Write? (true, t, false, f): [true]
Access host subnet area : [0.0.0.0] 10.64.210.0
Read/Write? (true, t, false, f): [true]
Access host subnet area : [0.0.0.0]
Read/Write? (true, t, false, f): [true]
Access host subnet area : [0.0.0.0]
Read/Write? (true, t, false, f): [true]
Committing configuration....done.
IBM SAN384B 27:admin>
```

Example 14-7 demonstrates how to show MIB capability.

Example 14-7 Example of mibCapability configuration

```
IBM_SAN384B_27:admin> snmpconfig --show mibcapability
FE-MIB: YES
SW-MIB: YES
FA-MIB: YES
FICON-MIB: YES
HA-MIB: YES
ISCSI-MIB: YES
ISCSI-MIB: YES
BD-MIB: YES
SW-TRAP: YES
        swFault: YES
        swSensorScn: YES
```

```
swFCPortScn: YES
        swEventTrap: YES
                DesiredSeverity:None
        swFabricWatchTrap: YES
                DesiredSeverity:None
        swTrackChangesTrap: YES
        swIPv6ChangeTrap: YES
        swPmgrEventTrap: YES
        swFabricReconfigTrap: NO
        swFabricSegmentTrap: NO
        swExtTrap: NO
FA-TRAP: YES
        connUnitStatusChange: YES
        connUnitDeletedTrap: YES
        connUnitEventTrap: YES
        connUnitSensorStatusChange: YES
        connUnitPortStatusChange: YES
FICON-TRAP: YES
        linkRNIDDeviceRegistration: YES
        linkRNIDDeviceDeRegistration: YES
        linkLIRRListenerAdded: YES
        linkLIRRListenerRemoved: YES
        linkRLIRFailureIncident: YES
HA-TRAP: YES
        fruStatusChanged: YES
        cpStatusChanged: YES
        fruHistoryTrap: YES
ISCSI-TRAP: YES
        iscsiTgtLoginFailure: YES
        iscsiIntrLoginFailure: YES
        iscsiInstSessionFailure: YES
IF-TRAP: YES
        linkDown: YES
        linkUp: YES
BD-TRAP: YES
        bdTrap: YES
        bdClearTrap: YES
IBM SAN384B 27:admin>
```

Example 14-8 shows how to reset the system group configuration.

Example 14-8 Example of systemGroup configuration (default)

IBM_SAN384B_27:admin> snmpconfig --default systemGroup
*****

```
This command will reset the agent's system group configuration back to
factory default
*****
sysDescr = MCC_A_BB_DCX
sysLocation = 1320 Denison Street, Markham, Tile: 1L41
sysContact = Conntact Name: 416-956-6886 dlitssan@cibc.ca
authTraps = 0 (OFF)
*****
Are you sure? (yes, y, no, n): [no] y
IBM SAN384B 27:admin>
```

## 14.5 Secure Sockets Layer protocol

Secure Sockets Layer (SSL) protocol provides secure access to a fabric through Web-based management tools like Web Tools. SSL support is a standard Fabric OS feature.

Switches configured for SSL grant access to management tools through hypertext transfer protocol over SSL links (which begin with https://) instead of standard links (which begin with http://).

SSL uses public key infrastructure (PKI) encryption to protect data transferred over SSL connections. PKI is based on digital certificates obtained from an Internet Certificate Authority (ICA) that acts as the trusted key agent.

Certificates are based on the switch IP address or fully qualified domain name (FQDN), depending on the issuing CA. If you change a switch IP address or FQDN after activating an associated certificate, you might have to obtain and install a new certificate. Check with the ICA to verify this possibility, and plan these types of changes accordingly.

#### 14.5.1 Browser and Java support

Fabric OS supports the following Web browsers for SSL connections:

- Internet Explorer v7.0 (Microsoft Windows)
- Mozilla Firefox v2.0 (Solaris and Red Hat Linux)

In countries that allow the use of 128-bit encryption, use the latest version of your browser. For example, Internet Explorer 7.0 and later supports 128-bit encryption by default. You can display the encryption support (called "cipher strength") using the Internet Explorer **Help**  $\rightarrow$  **About** menu option. If you are running an earlier version of Internet Explorer, you might be able to download an encryption patch from the Microsoft website at http://www.microsoft.com.

Preferably, upgrade to the Java 1.6.0 Plug-in on your management workstation. To find the Java version that is currently running, open the Java console and look at the first line of the window.

#### 14.5.2 SSL configuration overview

You configure for SSL by obtaining, installing, and activating digital certificates for SSL support. Certificates are required on all switches that are to be accessed through SSL. Also, you must install a certificate in the Java Plug-in on the management workstation, and you might need to add a certificate to your Web browser.

Configuring for SSL involves the following main steps, which we describe in detail in the next topics:

- 1. Choose a certificate authority (CA).
- 2. Generate the following items on each switch:
  - a. A public and private key, by using the secCertUtil genkey command
  - b. A certificate signing request (CSR), by using the **secCertUtil gencsr** command
- 3. Store the CSR on a file server by using the secCertUtil export command.
- 4. Obtain the certificates from the CA (Table 14-6).

You can request a certificate from a CA through a Web browser. After you request a certificate, the CA either sends certificate files by email (public) or gives access to them on a remote host (private). Typically, the CA provides the certificate files listed in Example 14-3 on page 638.

Certificate file	Description
<i>name</i> .crt	The switch certificate.
<i>name</i> Root.crt	The root certificate. Typically, this certificate is already installed in the browser, but if not, you must install it.
nameCA.crt	The CA certificate. It must be installed in the browser to verify the validity of the server certificate, or server validation fails.

Table 14-6 SSL certificate files

- 5. On each switch, install the certificate. After the certificate is loaded on the switch, HTTPS starts automatically.
- 6. If necessary, install the root certificate to the browser on the management workstation.
- 7. Add the root certificate to the Java Plug-in keystore on the management workstation.

## 14.5.3 Certificate authorities

To ease maintenance and allow secure out-of-band communication between switches, consider using one certificate authority (CA) to sign all management certificates for a fabric. If you use different CAs, management services operate correctly, but the DCFM Master Log is unable to retrieve events for the entire fabric.

Each CA (for example, Verisign or GeoTrust) has slightly different requirements; for example, some generate certificates based on IP address, while others require an FQDN, and most require a 1024-bit public/private key, while others might accept a 2048-bit key. Consider your fabric configuration, check CA websites for requirements, and gather all the information that the CA requires.

#### Generating a public and private key

Perform this procedure on each switch:

- 1. Connect to the switch and log in as admin.
- 2. Enter the **seccertutil genkey** command to generate a public/private key pair as shown in Example 14-9.

Example 14-9 genkey

```
IBM_SAN384B_27:admin> seccertutil genkey
Generating a new key pair will automatically do the following:
1. Delete all existing CSRs.
2. Delete all existing certificates.
3. Reset the certificate filename to none.
4. Disable secure protocols.
Continue (yes, y, no, n): [no] y
Select key size [1024 or 2048]: 1024
Generating new rsa public/private key pair
Done.
IBM_SAN384B_27:admin>
```

The system reports that this process will disable secure protocols, delete any existing CSR, and delete any existing certificates. Respond to the prompts to continue and select the key size. Because CA support for the 2048-bit key size is limited, select 1024 in most cases.

#### Generating and storing a CSR

After generating a public/private key, perform this procedure on each switch:

- 1. Connect to the switch and log in as admin.
- 2. Enter the command **seccertutil gencsr** and enter the requested information as shown in Example 14-10:

Example 14-10 gencsr

```
IBM_SAN384B_27:admin> seccertutil gencsr
Country Name (2 letter code, eg, US):US
State or Province Name (full name, eg, California):California
Locality Name (eg, city name):San Jose
Organization Name (eg, company name):IBM
Organizational Unit Name (eg, department name):STG
Common Name (Fully qualified Domain Name, or IP address):ibm.com
Generating CSR, file name is: 10.18.228.27.csr
Done.
IBM_SAN384B_27:admin>
```

Your CA might require specific codes for Country, State or Province, Locality, Organization, and Organizational Unit names. Make sure that your spelling is correct and matches the CA requirements. If the CA requires that the Common Name be specified as an FQDN, make sure that the fully qualified domain name is set on the domain name server. The IP address or FQDN will be the server on which the certificate will be put.

- 3. Enter the command seccertutil export to store the CSR:
- 4. Enter the requested information. You can use either FTP or SCP, as shown in Example 14-11.

Example 14-11 export

```
IBM_SAN384B_27:admin> seccertutil export
Select protocol [ftp or scp]: scp
Enter IP address: 10.18.228.36
Enter remote directory: ./
Enter Login Name: root
root@10.18.228.36's password:
Success: exported CSR.
IBM_SAN384B_27:admin>
```

If you are set up for secure file copy protocol, you can select it; otherwise, select **ftp**. Enter the IP address of the switch on which you generated the CSR. Enter the remote directory name of the FTP server to which the CSR is to be sent. Enter your account name and password on the server.

#### Obtaining certificates

Check the instructions on the CA website; then, perform this procedure for each switch:

- 1. Generate and store the CSR as described in "Generating and storing a CSR" on page 648.
- 2. Open a Web browser window on the management workstation and go to the CA website.

Follow the instructions to request a certificate. Locate the area in the request form into which you are to paste the CSR.

- 3. Through a Telnet window, connect to the switch and log in as admin.
- 4. Enter the command seccertutil showcsr as shown in Example 14-12.

Example 14-12 showcsr

```
IBM SAN384B 27:admin> seccertutil showcsr
verify OK
Certificate Request:
   Data:
        Version: 0 (0x0)
        Subject: C=US, ST=California, L=San Jose, O=IBM, OU=STG,
CN=ibm.com
        Subject Public Key Info:
            Public Key Algorithm: rsaEncryption
            RSA Public Key: (1024 bit)
                Modulus (1024 bit):
                    00:bc:bd:59:56:17:d8:8b:b9:cf:8c:ce:2d:48:17:
                    ec:15:28:70:61:08:89:71:74:d9:45:b6:b5:8b:b9:
                    f9:3c:d4:18:97:68:fc:8a:17:55:b3:e7:f5:00:d5:
                    52:ff:da:cd:fc:ae:ae:a2:90:ec:1c:b4:0e:f2:26:
                    43:6c:e2:e4:f5:5d:3c:de:82:ab:9d:b0:41:c2:09:
                    91:73:05:40:59:22:a1:a5:bc:23:03:de:ce:d9:04:
                    ed:0c:0e:cf:25:d8:b8:aa:c0:c5:19:7e:51:74:4b:
                    d4:c5:5e:55:c0:c9:2a:2c:03:d0:9f:af:93:95:88:
                    95:f2:e0:d4:3e:5d:35:a9:61
                Exponent: 65537 (0x10001)
        Attributes:
            serialNumber
                                     :10:00:00:05:1e:94:3a:00
        Requested Extensions:
```

```
X509v3 Subject Alternative Name:
DNS:ibm.com, IP Address:10.18.228.27
Signature Algorithm: shalWithRSAEncryption
83:75:30:90:09:73:f4:d9:ec:b7:bb:6f:c0:b7:74:49:77:da:
8b:a4:28:b2:41:82:8c:b3:d3:7b:22:47:57:82:48:87:69:8e:
80:05:4e:43:57:bb:45:dc:54:15:a6:16:2d:ac:f3:a4:b3:de:
05:65:10:d3:92:23:34:f9:ab:6f:d3:3e:ed:63:fb:ad:99:8c:
03:37:5b:6c:25:4b:e2:41:ed:cb:2a:8b:51:45:61:af:43:1d:
b7:6a:f8:84:af:43:17:ae:d1:08:00:59:33:fa:8c:bd:90:d3:
94:f1:a0:af:0f:45:76:af:2d:a3:2b:fb:dd:74:7b:97:0b:49:
0c:5e
```

CSR contents in base64 format

-----BEGIN CERTIFICATE REQUEST----MIIB8DCCAVkCAQAwYzELMAkGA1UEBhMCVVMxEzARBgNVBAgTCkNhbG1mb3JuaWEx ETAPBgNVBAcTCFNhbiBKb3N1MQwwCgYDVQQKEwNJQkOxDDAKBgNVBAsTA1NURzEQ MA4GA1UEAxMHaWJtLmNvbTCBnzANBgkqhkiG9w0BAQEFAAOBjQAwgYkCgYEAvL1Z VhfYi7nPjM4tSBfsFShwYQiJcXTZRba1i7n5PNQY12j8ihdVs+f1ANVS/9rN/K6u opDsHLQ08iZDbOLk9V083oKrnbBBwgmRcwVAWSKhpbwjA9702QTtDA7PJdi4qsDF GX5RdEvUxV5VwMkqLAPQn6+T1YiV8uDUP101qWECAwEAAaBNMCAGA1UEBTEZExcx MDowMDowNToxZTo5NDozYTowMDApBgkqhkiG9w0BCQ4xHDAaMBgGA1UdEQQR MA+CB21ibS5jb22HBAoS5BswDQYJKoZIhvcNAQEFBQADgYEAg3UwkA1z9Nnst7tv wLd0SXfai6QoskGCjLPTeyJHV4JIh2m0gAVOQ1e7RdxUFaYWLazzpLPeBWUQ05Ij NPmrb9M+7WP7rZmMAzdbbCVL4kHtyyqLUUVhr0Mdt2r4hK9DF67RCABZM/qMvZDT 1PGgrw9Fdq8toyv73XR71wtJDF4= -----END CERTIFICATE REQUEST-----

IBM_SAN384B_27:admin>

The contents of the CSR are displayed.

- 5. Locate the section that begins with "BEGIN CERTIFICATE REQUEST" and ends with "END CERTIFICATE REQUEST".
- 6. Copy and paste this section (including the BEGIN and END lines) into the area provided in the request form; then, follow the instructions to complete and send the request.

It might take several days to receive the certificates. If the certificates arrive by email, save them to an FTP server. If the CA provides access to the certificates on an FTP server, make note of the path name and make sure that you have a login name and password on the server.

#### Installing a switch certificate

Perform this procedure on each switch:

- 1. Connect to the switch and log in as admin.
- 2. Enter the command seccertutil import.
- 3. Select a protocol, enter the IP address of the host on which the switch certificate is saved, and enter your login name and password, as shown in Example 14-13.

Example 14-13 import

```
IBM_SAN384B_27:admin> seccertutil import
Select protocol [ftp or scp]: scp
Enter IP address: 10.18.228.36
Enter remote directory: ./
Enter certificate name (must have ".crt" or ".cer" ".pem" or ".psk"
suffix)::SAN384B.crt
Enter Login Name: root
root@10.18.228.36's password:
Success: imported certificate [SAN384B.crt].
IBM_SAN384B_27:admin>
```

After the certificate is loaded on the switch, HTTPS starts automatically.

#### The browser

If the root certificate is not already installed on your browser, you must install it. To see whether it is already installed, check the certificate store on your browser.

The next procedures are guides for installing root certificates to Internet Explorer and Mozilla Firefox browsers. For more detailed instructions, see the documentation that came with the certificate.

#### Checking and installing root certificates on Internet Explorer

Follow these steps:

- 1. Select **Tools**  $\rightarrow$  **Internet Options**.
- 2. Click the Content tab.
- 3. Click Certificates.
- 4. Click the **Intermediate** or **Trusted Root** tabs and scroll the list to see if the root certificate is listed. Take the appropriate following action based on whether you find the certificate:
  - If the certificate is listed, you do not need to install it. You can skip the rest of this procedure.
  - If the certificate is not listed, click Import.
- 5. Follow instructions in the Certificate Import wizard to import the certificate.

#### Checking and installing root certificates on Mozilla Firefox

Follow these steps:

- 1. Select **Tools**  $\rightarrow$  **Options**.
- 2. Click Advanced.
- 3. Click the **Encryption** tab.
- Click View Certificates → Authorities tab and scroll the list to see if the root certificate is listed.

For example, its name might have the form *name*Root.crt. Take the appropriate following action based on whether you find the certificate:

- If the certificate is listed, you do not need to install it. You can skip the rest of this procedure.
- If the certificate is not listed, click Import.
- 5. Browse to the certificate location and select the certificate. For example, select *name*Root.crt.
- 6. Click **Open** and follow the instructions to import the certificate.

#### Root certificates for the Java Plug-in

For information about Java requirements, see 14.5.1, "Browser and Java support" on page 645.

#### Java plug-in considerations

This procedure is a guide for installing a root certificate to the Java Plug-in on the management workstation. If the root certificate is not already installed to the plug-in, then install it. For detailed instructions, see the documentation that came with the certificate and to the Sun Microsystems website: http://www.sun.com

#### Installing a root certificate to the Java plug-in

Follow these steps to install the certificate:

1. Copy the root certificate file from its location on the FTP server to the Java Plug-in bin. For example, the bin location might be:

C: \program files\java\j2re1.6.0\bin

- 2. Open a Command Prompt window and change the directory to the Java Plug-in bin.
- 3. Enter the keytool command and respond to the prompts:

```
C:\Program Files\Java\j2re1.6.0\bin> keytool -import -alias RootCert
-file RootCert.crt -keystore ..\lib\security\RootCerts
Enter keystore password: changeit
```

Owner: CN=Brocade, OU=Software, O=Brocade Communications, L=San Jose, ST=California, C=US Issuer: CN=Brocade, OU=Software, O=Brocade Communications, L=San Jose, ST=California, C=US Serial number: O Valid from: Thu Jan 15 16:27:03 PST 2007 until: Sat Feb 14 16:27:03 PST 2007 Certificate fingerprints: MD5: 71:E9:27:44:01:30:48:CC:09:4D:11:80:9D:DE:A5:E3 SHA1: 06:46:C5:A5:C8:6C:93:9C:FE:6A:C0:EC:66:E9:51:C2:DB:E6:4F:A1 Trust this certificate? [no]: **yes** Certificate was added to keystore

In the example, **changeit** is the default password and **RootCert** is an example root certificate name.

#### Summary of certificate commands

Table 14-7 summarizes the commands for displaying and deleting certificates. For details about the commands, see the *Fabric OS Command Reference*, 53-1001186-01.

Command	Description
secCertUtil show	Displays the state of the SSL key and a list of installed certificates.
<pre>secCertUtil show filename</pre>	Displays the contents of a specific certificate.
secCertUtil showcsr	Displays the contents of a CSR.
<pre>secCertUtil delete filename</pre>	Deletes a specified certificate.
secCertUtil delcsr	Deletes a CSR.

 Table 14-7
 Commands for displaying and deleting SSL certificates

## 14.6 Secure Shell protocol

To ensure security, Fabric OS supports secure shell (SSH) encrypted sessions. SSH encrypts all messages, including the client transmission of the password during login. The SSH package contains a daemon (sshd) that runs on the switch and supports a wide variety of encryption algorithms, such as Blowfish-Cipher block chaining (CBC) and Advanced Encryption Standard (AES). **Security:** To maintain a secure network, avoid using Telnet or any other unprotected application when you are working on the switch.

The File Transfer Protocol (FTP) is also not secure. When you use FTP to copy files to or from the switch, the contents are in clear text. This includes the remote FTP server's login and password. This limitation affects the following commands: saveCore, configUpload, configDownload, and firmwareDownload.

Commands that require a secure login channel must originate from an SSH session. If you start an SSH session, and then use the login command to start a nested SSH session, commands that require a secure channel will be rejected.

Fabric OS v6.2.0 supports SSH protocol v2.0 (ssh2). For more information about SSH, see the SSH IETF website:

http://www.ietf.org/ids.by.wg/secsh.html

#### 14.6.1 SSH public key authentication

OpenSSH public key authentication provides password-less logins, known as SSH authentication, which use public and private key pairs for incoming and outgoing authentication. This feature allows only one *allowed-user* to be configured to utilize OpenSSH public key authentication.

#### Authentication protocols

Using OpenSSH RSA and DSA, the authentication protocols are based on a pair of specially generated cryptographic keys, called the private key and the public key. The advantage of using these key-based authentication systems is that in many cases, it is possible to establish secure connections without having to manually type in a password. RSA and DSA asynchronous algorithms are FIPS-compliant.

#### Allowed-user

The default admin user must set up the allowed-user with the admin role. By default, the admin is the configured *allowed-user*. While creating the key pair, the configured *allowed-user* can choose a passphrase with which the private key is encrypted. Then the passphrase must always be entered when authenticating to the switch. The *allowed-user* must have an admin role that can perform OpenSSH public key authentication, import and export keys, generate a key pair for an outgoing connection, and delete public and private keys. After the *allowed-user* is changed, all public keys related to the old *allowed-user* are lost.

## 14.6.2 Configuring SSH authentication

Incoming authentication is used when the remote host needs to authenticate to the switch. Outgoing authentication is used when the switch needs to authenticate to a server or remote host, more commonly used for the **configUpload** command. Both password and public key authentication can coexist on the switch.

#### Setup steps

After the *allowed-user* is configured, the remaining setup steps must be completed by the *allowed-user*:

- 1. Log in to the switch as the default admin.
- 2. Change the allowed-user's role to admin, if applicable:

switch:admin> userconfig --change username -r admin

Where *username* is the name of the user you want to perform SSH public key authentication, import, export, and delete keys.

3. Set up the *allowed-user* by typing the following command:

switch:admin> sshutil allowuser username

Where *username* is the name of the user you want to perform SSH public key authentication, import, export, and delete keys.

4. Generate a key pair for host-to-switch (incoming) authentication by logging in to your host as admin, verifying that SSH v2 is installed and working (see your host's documentation as necessary), and typing the following command (see Example 14-14):

```
sshutil -keygen -t dsa
```

If you need to generate a key pair for outgoing authentication, skip steps 4 and 5 and proceed to step 6.

Example 14-14 Example of RSA/DSA key pair generation

```
alloweduser@mymachine: ssh-keygen -t dsa
Generating public/private dsa key pair.
Enter file in which to save the key (/users/alloweduser/.ssh/id_dsa):
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Your identification has been saved in /users/alloweduser/.ssh/id_dsa.
Your public key has been saved in /users/alloweduser/.ssh/id_dsa.pub.
The key fingerprint is:
32:9f:ae:b6:7f:7e:56:e4:b5:7a:21:f0:95:42:5c:d1 alloweduser@mymachine
```

5. Import the public key to the switch by logging in to the switch as the allowed-user and entering the following command to import the key (Example 14-15):

sshUtil importpubkey

Respond to the prompts as follows:

IP Address	Enter the IP address of the switch. IPv6 is supported by sshUtil.
Remote directory	Enter the path to the remote directory where the public key is stored.
Public key name	Enter the name of the public key.
Login name	Enter the name of the user granted access to the host.
Password	Enter the password for the host.

Example 14-15 Example of adding the public key to the switch

```
switch:alloweduser> sshutil importpubkey
Enter IP address:10.64.210.130
Enter remote directory:~auser/.ssh
Enter public key name(must have .pub suffix):id_dsa.pub
Enter login name:auser
Password:
Public key is imported successfully.
```

6. Generate a key pair for switch-to-host (outgoing) authentication by logging in to the switch as the allowed user and entering the following command (see Example 14-16):

sshUtil genkey

Enter a passphrase for additional security.

Example 14-16 Example of generating a key pair on the switch

```
switch:alloweduser> sshutil genkey
Enter passphrase (empty for no passphrase):
Enter same passphrase again:
Key pair generated successfully.
```

7. Export the public key to the host by logging in to the switch as the allowed-user and entering the following command to export the key (see Example 14-17):

sshUtil exportpubkey
Respond to the prompts as follows:

IP Address	Enter the IP address of the remote host. IPv6 is supported by sshUtil.
Remote directory	Enter the path to the remote directory where the public key will be stored.
Login name	Enter the name of the user granted access to the remote host.
Password	Enter the password for the remote host.

Example 14-17 Example of exporting a public key from the switch

```
switch:alloweduser> sshutil exportpubkey
Enter IP address:10.64.210.103
Enter remote directory:~auser/.ssh
Enter login name:auser
Password:
public key out_going.pub is exported successfully.
```

8. Append the public key to a remote host by logging in to the remote host, locating the directory where authorized keys are stored, and appending the public key to the file.

You might have to refer to the host's documentation to locate where the authorized keys are stored.

9. Test the setup by using a command that uses SCP and authentication, such as **firmwareDownload** or **configUpload**.

#### Deleting keys on the switch

Follow these steps to delete the keys when necessary:

- 1. Log in to the switch as the allowed-user.
- 2. Use the sshUtil delprivkey command to delete the private key.

or

Use the **sshUtil delpubkeys** command to delete all public keys.

For more information about IP Filter policies, see 14.9.26, "IP Filter policy" on page 686.

## 14.7 Telnet protocol

Telnet is enabled by default. To prevent passing clear text passwords over the network when connecting to the switch, you can block the Telnet protocol using an IP Filter policy.

**Important:** Before blocking Telnet, make sure that you have an alternate method of establishing a connection with the switch.

## 14.7.1 Blocking Telnet

Follow these steps for blocking Telnet:

1. Connect to the switch and log in as admin.

Connect through some means other than Telnet: for example, through SSH.

2. Create a policy by typing the following command (see Example 14-18):

```
ipfilter --create policyname -type < ipv4 | ipv6 >
```

Where *policyname* is the name of the new policy and **-type** specifies an IPv4 or IPv6 address.

Example 14-18 Example of creating a policy

ipfilter	create	block	telnet	v4	-type	ipv4

3. Add a rule to the policy, by typing the following command (see Example 14-19):

ipfilter --addrule <policyname> -rule rule_number -sip source_IP -dp
dest_port -proto protocol -act <deny>

Where the **-sip** option can be given as **any**, **-dp** is the port number for Telnet (23), and **-proto** is **TCP**.

Example 14-19 Example of adding a rule

```
ipfilter --addrule block_telnet_v4 -rule 1 -sip any -dp 23 -proto
tcp -act deny
```

4. Save the new ipfilter policy by typing the following command (see Example 14-20 on page 659):

ipfilter --save policyname

Where *policyname* is the name of the policy and is optional.

Example 14-20 Example of saving a policy

```
ipfilter --save block_telnet_v4
```

5. Activate the new ipfilter policy by typing the following command: (Example 14-21):

ipfilter --activate policyname

Where *policyname* is the name of the policy that you created in step 2.

```
Example 14-21 Example of activating a policy
```

```
ipfilter --activate block_telnet_v4
```

## 14.7.2 Unblocking Telnet

Follow these steps:

- 1. Connect to the switch through a means other than Telnet (for example, SSH) and log in as admin.
- 2. Type the following command:

ipfilter --delete telnet_policyname

Where *telnet_policyname* is the name of the Telnet policy.

3. To permanently delete the policy, type the following command:

ipfilter --save

## 14.7.3 Listener applications

Brocade switches block Linux subsystem listener applications that are not used to implement supported features and capabilities. Table 14-8 lists the listener applications that Brocade switches either block or do not start.

Listener Application	IBM SAN256B, IBM SAN768B and IBM SAN384B	IBM SAN04BR, SAN18BR, SAN24B, SAN40B and SAN80B switches and FA4-18, FC10-6, FC4-48, FC4-16IP, FC8-16/32/48, and FR4-18i blades
chargen	Disabled	Disabled
echo	Disabled	Disabled

Table 14-8Blocked listener applications

Listener Application	IBM SAN256B, IBM SAN768B and IBM SAN384B	IBM SAN04BR, SAN18BR, SAN24B, SAN40B and SAN80B switches and FA4-18, FC10-6, FC4-48, FC4-16IP, FC8-16/32/48, and FR4-18i blades
daytime	Disabled	Disabled
discard	Disabled	Disabled
ftp	Disabled	Disabled
rexec	Block with packet filter	Disabled
rsh	Block with packet filter	Disabled
rlogin	Block with packet filter	Disabled
time	Block with packet filter	Disabled
rstats	Disabled	Disabled
rusers	Disabled	Disabled

# 14.8 Ports and applications used by switches

If you are using the FC-FC Routing Service, be aware that the **secModeEnable** command is not supported in Fabric OS v6.0.0 and later.

## 14.8.1 Access defaults

Table 14-9 lists the defaults for accessing hosts, devices, switches, and zones.

ltem	Access default	
Hosts	Any host can access the fabric by SNMP.	
	Any host can Telnet to any switch in the fabric	
	Any host can establish an HTTP connection to any switch in the fabric.	
	Any host can establish an API connection to any switch in the fabric.	
Devices	All devices can access the management server.	

Table 14-9 Access defaults

Item	Access default
	Any device can connect to any FC port in the fabric.
Switches	Any switch can join the fabric.
	All switches in the fabric can be accessed through a serial port.
Zoning	No zoning is enabled.

## 14.8.2 Port configuration

Table 14-10 provides information about ports that the switch uses. When configuring the switch for various policies, take into consideration firewalls and other devices that might sit between switches in the fabric and your network or between the managers and the switch.

Port	Туре	Common use	Comment
22	TCP	SSH	
23	TCP	Telnet	Use the <b>ipfilter</b> command to block the port.
80	TCP	HTTP	Use the <b>ipfilter</b> command to block the port.
111	TCP	sunrpc	This port is used by Platform API. Use the <b>ipfilter</b> command to block the port.
123	TCP	NTP	
161	UDP	SNMP	Disable the SNMP service on the remote host if you do not use it, or filter incoming UDP packets going to this port.
443	TCP	HTTPS	Use the <b>ipfilter</b> command to block the port.
	ТСР	exec	
	ТСР	login	
	ТСР	shell	
	ТСР		
			This port is used by the Platform API. Disable this port using the <b>configure</b> command.

Table 14-10 Switch port usage

# 14.9 Security policies

In the following topics we discuss security policies and their management.

#### 14.9.1 ACL policies overview

Each supported Access Control List (ACL) policy listed here is identified by a specific name, and only one policy of each type can exist, except for DCC policies. Policy names are case-sensitive and must be entered in all uppercase. Fabric OS provides the following policies:

- Fabric configuration server (FCS) policy: Used to restrict which switches can change the configuration of the fabric.
- Device connection control (DCC) policies: Used to restrict which Fibre Channel device ports can connect to which Fibre Channel switch ports.
- Switch connection control (SCC) policy: Used to restrict which switches can join with a switch.
- ► IP filter policy (IPFilter) policy: Used to filter traffic based on IP addresses.

### 14.9.2 ACL policy management

All policy modifications are temporarily stored in volatile memory until those changes are saved or activated. You can create multiple sessions to the switch from one or more hosts. Make changes from one switch only to prevent multiple transactions from occurring. Each logical switch will have its own access control list.

#### ACL policy considerations

The FCS, SCC, and DCC policies in Secure Fabric OS are not interchangeable with Fabric OS FCS, SCC, and DCC policies. Uploading and saving a copy of the Fabric OS configuration after creating policies is highly desirable.

You can view the active and defined policy sets at any time. Additionally, in a defined policy set, policies created in the same login session also display, but these policies are automatically deleted if you log out without saving them.

### **Displaying ACL policies**

Follow these steps to display the policies:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- 2. To display all security policies, type the **secPolicyShow** command as shown in Figure 14-22 on page 663.

Example 14-22 Display all policies

BDPOC01L01:admin> secPolicyShow

ACTIVE POLICY SET

DEFINED POLICY SET

BDPOC01L01:admin>

## 14.9.3 FCS policies

Fabric Configuration Server (FCS) policy in base Fabric OS can be performed on a local switch basis and can be performed on any switch in the fabric with Fabric OS v6.0.0 or later. Any switch with a pre-v5.3.0 version of Fabric OS cannot be included in the FCS list.

### **FCS policy creation**

The FCS policy is not present by default, but must be created. When the FCS policy is created, the WWN of the local switch is automatically included in the FCS list. Additional switches can be included in the FCS list. The first switch in the list becomes the Primary FCS switch.

Only the Primary FCS switch is allowed to modify and distribute the database within the fabric. Automatic distribution is supported and you can either configure the switches in your fabric to accept the FCS policy or manually distribute the FCS policy. Changes made to the FCS policy are saved to permanent memory only after the changes have been saved or activated; they can be aborted later if you have set your fabric to distribute the changes manually. See Table 14-11.

Policy state	Characteristics
No active policy	Any switch can perform fabric-wide configuration changes.
Active policy with one entry	A Primary FCS switch is designated (local switch), but there are no backup FCS switches. If the Primary FCS switch becomes unavailable for any reason, the fabric is left without an FCS switch.

Table 14-11 FCS Policy states

Policy state	Characteristics
Active policy with multiple entries	A Primary FCS switch and one or more backup FCS switches are designated. If the Primary FCS switch becomes unavailable, the next switch in the list becomes the Primary FCS switch.

The FCS policy is designed to accommodate mixed fabric environments that contain switches with pre-v5.3.0 and later versions of Fabric OS. By setting the configuration parameters to accept fabric distribution, Fabric OS v6.0.0 and later switches can enforce FCS policy and perform database distribution among v5.3.0 and v6.0.0 and later switches while still allowing pre-v5.3.0 switches to join the fabric. The following items describe distribution behavior for pre-Fabric OS v5.3.0:

► Distribution to pre-v5.3.0 switches with specific domain IDs:

When specific domain IDs are given for the distribution, all domains must be on a switch with Fabric OS v5.3.0 or later. If one of the domains is pre-v5.3.0 the distribution operation will fail.

► Distribution to pre-v5.3.0 switches using the wild card (*) character:

When the wild card character is specified, distribution succeeds even if the fabric contains pre-v5.3.0 switches. However, the FCS database will be sent only to switches with a Fabric OS of v5.2.0 or later in the fabric and not to pre-v5.2.0 switches. Fabric OS v5.2.0 switches receive the distribution and will ignore the FCS database.

#### **FCS policy restrictions**

The backup FCS switches normally cannot modify the policy. However, if the Primary FCS switch in the policy list is not reachable, then a backup FCS switch is allowed to modify the policy.

After an FCS policy is configured and distributed across the fabric, only the Primary FCS switch can perform certain operations. Operations that affect fabric-wide configuration are allowed only from the Primary FCS switch. Backup and non-FCS switches cannot perform security, zoning and AD operations that affect the fabric configuration. The following error message is returned if a backup or non-FCS switch tries to perform these operations:

Can only execute this command on the Primary FCS switch.

Operations that do not affect the fabric configuration, such as show or local switch commands, are allowed on backup and non-FCS switches.

FCS enforcement applies only for user-initiated fabric-wide operations. Internal fabric data propagation because of a fabric merge is not blocked. Consequently, a new switch that joins the FCS-enabled fabric can still propagate the AD and zone database.

## 14.9.4 Overview of FCS policy management

Whether your intention is to create new FCS policies or manage your current FCS policies, you must follow certain steps to ensure that the domains throughout your fabric have the same policy.

The local-switch WWN cannot be deleted from the FCS policy.

Follow these steps:

- 1. Set the pre-v5.3.0 switches in the fabric to accept the FCS policy using the fddCfg --localaccept or fddCfg --localreject command.
- 2. Create the FCS policy using the **secPolicyCreate** command.
- 3. Activate the policy using the **secPolicyActivate** command.

If the command is not entered, the changes are lost when the session is logged out.

4. To distribute the policies, enter the distribute -p policy_list -d switch_list command to either send the policies to intended domains, or enter the distribute -p policy_list -d wild_card (*) command to send the policies to all switches.

## 14.9.5 Creating an FCS policy

To create an FCS policy, follow these steps:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- 2. Type secPolicyCreate "FCS_POLICY", "member;...;member".

Where member indicates a switch that is eligible to become a primary or backup FCS switch. Specify switches by WWN, domain ID, or switch name. Enter the wild card (*) character to indicate all the switches in the fabric.

Example 14-23 shows how to create an FCS policy that allows a switch with domain ID 3 to become a primary FCS and domain ID 5 to become a backup FCS.

Example 14-23 Domain ID 3 becomes primary and 5 become backup FCS

```
BDPOC01L01:admin> secpolicycreate "FCS_POLICY", "3; 5"
    FCS POLICY has been created.
```

 To save or activate the new policy, enter either the secPolicySave or the secPolicyActivate command. After the policy has been activated, you can distribute the policy.

**Attention:** FCS policy must be consistent across the fabric. If the policy is inconsistent in the fabric, then you will not be able to perform any fabric-wide configurations from the primary FCS.

#### 14.9.6 Modifying the order of FCS switches

To modify the order of FCS switches, follow these steps:

- 1. Log in to the Primary FCS switch using an account assigned to the admin role.
- 2. Type secPolicyShow "Defined", "FCS_POLICY".

This displays the WWNs of the current Primary FCS switch and backup FCS switches.

3. Type **secPolicyFCSMove**; then provide the current position of the switch in the list and the desired position at the prompts.

Alternatively, enter **secPolicyFCSMove** [From, To] command. *From* is the current position in the list of the FCS switch and *To* is the desired position in the list for this switch.

To move a backup FCS switch from position 2 to position 3 in the FCS list, using interactive mode do the following, see Example 14-24.

Example 14-24 Moving a backup switch

```
BDPOC01L01:admin> secpolicyfcsmove

PosPrimary WWN DId swName.

IYes 10:00:00:60:69:10:02:181 switch5.

2No 10:00:00:60:69:00:00:5a2 switch60.

3No 10:00:00:60:69:00:00:133 switch73.

Please enter position you'd like to move from : (1..3) [1] 2

Please enter position you'd like to move to : (1..3) [1] 3
```

```
DEFINED POLICY SET
FCS POLICY
```

PosPrimaryWWN DId swName

1Yes	10:00:00:60:69:10:02:181	switch5.
2No	10:00:00:60:69:00:00:133	switch73.
3No	10:00:00:60:69:00:00:5a2	switch60.

4. Type the secPolicyActivate command to activate and save the new order.

#### 14.9.7 FCS policy distribution

The FCS policy can be automatically distributed using the fddCfg --fabwideset command or it can be manually distributed to the switches using the distribute -p command. Each switch that receives the FCS policy must be configured to receive the policy.

**Distributions:** The default value for the distribution configuration parameter is *accept*, which means that the switch accepts all database distributions and is able to initiate a distribute operation for all databases.

To verify that a switch is configured to receive the policy, do the following steps:

- 1. Log in to the switch using an account assigned to the admin role.
- Type fddcfg --showall to list the local switch configuration as shown in Example 14-25.

Example 14-25 List local switch configuration

```
BDPOC01L01:admin> fddcfg --showall
Local Switch Configuration for all Databases:-
   DATABASE - Accept/Reject
-----
       SCC - reject
       DCC -
                 accept
       PWD -
                  accept
       FCS –
                 accept
       AUTH -
                  accept
   IPFILTER -
              accept
Fabric Wide Consistency Policy:- ""
```

3. In Example 14-25, you can see that SCC is rejected. To accept SCC, enter the commands shown in Example 14-26.

Example 14-26 Accept SCC

BDPOC01L01:admin>

Switches in the fabric are designated as either a Primary FCS, backup FCS, or non-FCS switch. Only the Primary FCS switch is allowed to distribute the database. The FCS policy might need to be manually distributed across the fabric using the command **distribute** -**p** if there is no support for automatic distribution in a mixed environment with v5.3.0 and pre-v5.3.0 switches. Because this policy is distributed manually, the command **fddCfg** --**fabwideset** is used to distribute a fabric-wide consistency policy for FCS policy in an environment consisting of only Fabric OS v6.0.0 and later switches.

FCS enforcement for the **distribute** command is handled differently for FCS and other databases in an FCS fabric:

- For an FCS database, the enforcement allows any switch to initiate the distribution. This is to support FCS policy creation specifying a remote switch as Primary.
- For other database distributions, only the Primary FCS switch can initiate the distribution.

There is an FCS enforcement at the receiving switch, so the switch will verify whether the distribution is coming from the Primary FCS switch before accepting it. Distribution is accepted only if it is coming from a Primary FCS switch. Distribution of FCS policy can still be accepted from a backup FCS switch if the Primary is not reachable or from a non-FCS switch if the Primary FCS and none of the backup FCS switches are reachable.

## 14.9.8 DCC policies

Multiple DCC policies can be used to restrict which device ports can connect to which switch ports. The devices can be initiators, targets, or intermediate devices such as SCSI routers and loop hubs. By default, all device ports are allowed to connect to all switch ports; no DCC policies exist until they are created.

Each device port can be bound to one or more switch ports; the same device ports and switch ports can be listed in multiple DCC policies. After a switch port is specified in a DCC policy, it permits connections only from designated device ports. Device ports that are not specified in any DCC policies are allowed to connect only to switch ports that are not specified in any DCC policies.

When a DCC violation occurs, the related port is automatically disabled and must be re-enabled using the **portEnable** command. See Table 14-12.

Policy state	Characteristics
No policy	Any device can connect to any switch port in the fabric.
Policy with no entries	Any device can connect to any switch port in the fabric. An empty policy is the same as no policy.
Policy with entries	If a device WWN is specified in a DCC policy, that device is only allowed access to the switch if connected by a switch port listed in the same policy. If a switch port is specified in a DCC policy, it only permits connections from devices that are listed in the policy. Devices with WWNs that are not specified in a DCC policy are allowed to connect to the switch at any switch ports that are not specified in a DCC policy. Switch ports and device WWNs can exist in multiple DCC policies. Proxy devices are always granted full access and can connect to any switch port in the fabric.

Table 14-12 DCC policy state

**Virtual Fabric considerations:** The DCC policies that have entries for the ports that are being moved from one logical switch to another will be considered stale and will not be enforced. You can choose to keep stale policies in the current logical switch or delete the stale policies after the port movements. Use the **secPolicyDelete** command to delete stale DCC policies.

## 14.9.9 DCC policy restrictions

The following restrictions apply when using DCC policies:

- Some older private-loop HBAs do not respond to port login from the switch and are not enforced by the DCC policy. This does not create a security problem because these HBAs cannot contact any device outside of their immediate loop.
- DCC policies cannot manage or restrict iSCSI connections, that is, an FC Initiator connection from an iSCSI gateway.
- You cannot manage proxy devices with DCC policies. Proxy devices are always granted full access, even if the DCC policy has an entry that restricts or limits access of a proxy device.

## 14.9.10 Creating a DCC policy

DCC policies must follow the naming convention "DCC_POLICY_nnn," where nnn represents a unique string. The maximum length is 30 characters, including the prefix DCC_POLICY_.

Device ports must be specified by port WWN. Switch ports can be identified by the switch WWN, domain ID, or switch name followed by the port or area number. To specify an allowed connection, enter the device port WWN, a semicolon, and the switch port identification.

The following methods of specifying an allowed connection are possible:

- deviceportWWN;switchWWN (port or area number)
- deviceportWWN;domainID (port or area number)
- deviceportWWN;switchname (port or area number)

Follow these steps:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- Type the secPolicyCreate "DCC_POLICY_nnn", "member;...;member" command.

DCC_POLICY_nnn is the name of the DCC policy; nnn is a string consisting of up to 19 alphanumeric or underscore characters to differentiate it from any other DCC policies.

The member contains device or switch port information: *deviceportWWN;switch(port)* as shown in Table 14-13.

Table 14-13 Switch port information

deviceportWWN	The WWN of the device port
switch	The switch WWN, domain ID, or switch name. The port can be specified by port or area number. Designating ports automatically includes the devices currently attached to those ports. The ports can be specified using any of the following syntax methods: (*) Selects all ports on the switch. (1-6) Selects ports 1 through 6. [*] Selects all ports and all devices attached to those ports. [3, 9] Selects ports 3 and 9 and all devices attached to those ports. [1-3, 9] Selects ports 1, 2, 3, 9, and all devices attached to those ports. "*" This method can be used to indicate DCC lockdown. It creates a unique policy for each port in the fabric, locking it down to the device connected or creating an empty policy to disallow any device to be connected to it. This method can be done only when there are no other DCC policies defined on the switch.

- 3. To save or activate the new policy, enter the appropriate command:
  - To save the policy, enter the **secPolicySave** command.
  - To save and activate the policy, enter the **secPolicyActivate** command.
  - If neither of these commands is entered, the changes are lost when the session is logged out.

## 14.9.11 Creating a device policy

You can create a device policy to allow a DS8000® storage port and an AIX® host port to attach to Domain 97 ports 5 and 6, as shown in Example 14-27.

Where:

- The port WWN of the DS8000 port is 50:05:07:63:04:03:03:16
- The port WWN of the DIX host port is 10:00:00:c9:2a:f3:d5

Example 14-27 Creating a device policy

```
BDPOC01L01:admin> secpolicycreate "DCC_POLICY_Storage01", \
"50:05:07:63:04:03:03:16;10:00:00:00:c9:2a:f3:d5;97(5,6)"
DCC_POLICY_Storage01 has been created.
```

BDPOC01L01:admin> secPolicyShow

#### ACTIVE POLICY SET

BDPOC01L01:admin>

### 14.9.12 Deleting a device policy

To delete the policy you just created, follow Example 14-28.

Example 14-28 Deleting the policy

```
BDPOC01L01:admin> secPolicyDelete DCC_POLICY_Storage01
About to delete DCC_POLICY_Storage01
ARE YOU SURE (yes, y, no, n): [no] y
BDPOC01L01:admin>
```

BDPOC01L01:admin> secPolicyShow

ACTIVE POLICY SET

DEFINED POLICY SET

BDPOC01L01:admin>

## 14.9.13 Activating policy changes

To activate the policy changes on all switches in the fabric, issue the commands shown in Example 14-29.

Example 14-29 Activate policy

BDPOC01L01:admin> secpolicyactivate
About to overwrite the current Active data.
ARE YOU SURE (yes, y, no, n): [no] <b>y</b>
secpolicyactivate command was completed successfully.
BDPOC01L01:admin>

## 14.9.14 SCC policies

The switch connection control (SCC) policy is used to restrict which switches can join the fabric. Switches are checked against the policy each time an E_Port-to-E_Port connection is made. The policy is named SCC_POLICY and accepts members listed as WWNs, domain IDs, or switch names. Only one SCC policy can be created.

By default, any switch is allowed to join the fabric; the SCC policy does not exist until it is created. When connecting a Fibre Channel router to a fabric or switch that has an active SCC policy, the front domain of the Fibre Channel router must be included in the SCC policy (see Table 14-14).

Policy state	SCC policy enforcement
No active policy	All switches can connect to the switch with the specified policy.
Active policy that has no members	All neighboring switches are segmented.
Active policy that has members	The neighboring switches not specified in the SCC policy are segmented.

Table 14-14 SCC policy states

**Virtual Fabric considerations:** In a logical fabric environment, the SCC policy enforcement is not done on the logical ISL. For a logical ISL-based switch, the SCC policy enforcement is considered as the reference and the logical ISL is formed if the SCC enforcement passes on the extended ISL. The following functionality changes:

- A logical switch supports an SCC policy. You can configure and distribute an SCC policy on a logical switch.
- SCC enforcement is performed on an ISL based on the SCC policy present on the logical switch.

## 14.9.15 Creating an SCC policy

Follow these steps to create the policy:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- 2. Type secPolicyCreate "SCC_POLICY", "member;...;member".

Where *member* indicates a switch that is permitted to join the fabric. Specify switches by WWN, domain ID, or switch name. Enter an asterisk (*) to indicate all the switches in the fabric.

Example 14-30 shows how to create an SCC policy that allows switches that have domain IDs 97 and 4 to join the fabric:

Example 14-30 Create policy

```
BDPOC01L01:admin> secpolicycreate "SCC_POLICY", "97;4"
SCC_POLICY has been created.
BDPOC01L01:admin>
```

3. Save or activate the new policy by entering either the **secPolicySave** or the **secPolicyActivate** command. If neither of these commands is entered, the changes are lost when the session is logged out.

#### 14.9.16 Authentication policy for fabric elements

By default, Fabric OS v6.1.0 and later use DH-CHAP or FCAP protocols for authentication. These protocols use shared secrets and digital certificates, based on switch WWN and public key infrastructure (PKI) technology, to authenticate switches. Authentication automatically defaults to FCAP if both switches are configured to accept FCAP protocol in authentication. To use FCAP on both switches, PKI certificates have to be installed.

You can configure a switch with Fabric OS v5.3.0 or later to use DH-CHAP for device authentication. Use the **authUtil** command to configure the authentication parameters used by the switch. When you configure DH-CHAP authentication, you also must define a pair of shared secrets known to both switches as a secret key pair. Figure 14-11 illustrates how the secrets are configured. A secret key pair consists of a local secret and a peer secret. The local secret uniquely identifies the local switch. The peer secret uniquely identifies the local switch authenticates. Every switch can share a secret key pair with any other switch or host in a fabric.

To use DH-CHAP authentication, a secret key pair has to be configured on both switches. You can use the command **authUtil** --set -a <fcap|dhchap> to set the authentication protocol, which can then be verified using the command **authUtil** --show CLI.



Figure 14-11 DH-CHAP authentication

If you use DH-CHAP authentication, then a secret key pair must be installed only in connected fabric elements. However, as connections are changed, new secret key pairs must be installed between newly connected elements. Alternatively, a secret key pair for all possible connections can be initially installed, enabling links to be arbitrarily changed while still maintaining a valid secret key pair for any new connection.

The switch authentication (AUTH) policy initiates DH-CHAP/FCAP authentication on all E_Ports. This policy is persistent across reboots, which means authentication will be initiated automatically on ports or switches brought online if the policy is set to activate authentication. The AUTH policy is distributed using the **distribute** command. The automatic distribution of the AUTH policy is not supported.

The default configuration directs the switch to attempt FCAP authentication first, DH-CHAP second. The switch can be configured to negotiate FCAP, DH-CHAP, or both.

The DH group is used in the DH-CHAP protocol only. The FCAP protocol exchanges the DH group information, but does not use it.

The AUTH policy is designed to accommodate mixed fabric environments that contain Fabric OS v6.0.0 and later along with pre-v6.0.0 switches. The policy states that PASSIVE and OFF allow connection from Fabric OS v6.0.0 and later switches to pre-v6.0.0 switches. These policy states do not allow switches to send the authentication negotiation and therefore continue with the rest of port initialization.

FOS v6.4.0 adds support for FCAP authentication using third-party self signed certificates. Starting with FOS v6.4.0 both Brocade issued certificates and/or third-party self signed certificates can be used for FCAP authentication. Prior to FOS v6.4.0 only Brocade issued certificates were supported.

**Virtual Fabric considerations:** If a Virtual Fabric is enabled, all AUTH module parameters such as shared secrets, as well as shared switch and device policies, are logical switch-wide. This means that you must configure shared secrets and policies separately on each logical switch, and the shared secrets and policies must be set on each switch prior to authentication. On logical switch creation, authentication takes default values for policies and other parameters.

#### 14.9.17 E_Port authentication

The authentication (AUTH) policy allows you to configure DH-CHAP authentication on the switch. By default, the policy is set to PASSIVE and you can change the policy using the **authUtil** command. All changes to the AUTH policy take effect during the next authentication request. This includes starting authentication on all E_Ports on the local switch if the policy is changed to ON or ACTIVE, and clearing the authentication if the policy is changed to OFF. The authentication configurations will be effective only on subsequent E_ and F_Port initialization.

#### Virtual Fabric considerations:

- The switch authentication policy applies to all E_Ports in a logical switch. This includes ISLs and extended ISLs. Authentication of extended ISLs between two base switches is considered peer-chassis authentication. Authentication between two physical entities is required, so the extended ISL which connects the two chassis needs to be authenticated. The corresponding extended ISL for a logical ISL authenticates the peer-chassis, therefore the logical ISL authentication is not required.
- Because the logical ISLs do not carry actual traffic, they do not need to be authenticated. Authentication on re-individualization is also blocked on logical ISLs. The following error message is printed on the console when you execute the authUtil --authinit command on logical-ISLs:

```
Failed to initiate authentication. Authentication is not supported on logical ports <port#>.
```

A secret key pair has to be installed prior to changing the policy. The policy can be configured as shown in Example 14-31.

Example 14-31 Configuring the policy

```
switch:admin> authutil --policy -sw <ON|ACTIVE|PASSIVE|OFF>
```

The command arguments are explained in Table 14-15.

#### Status of data if failover occurs:

- If data input has not been completed and a failover occurs, the command is terminated without completion, and your entire input is lost.
- If data input has completed, the Enter key was pressed, and a failover occurs, data might or might not be replicated to the other CP depending on the timing of the failover. Log in to the other CP after the failover is complete and verify that the data was saved. If the data was not saved, run the command again.

Table 14-15 authuil command reference

authutil policy -sw Parameter	Explanation:
ON	Setting the AUTH policy to ON means that strict authentication is enforced on all E_Ports. If the connecting switch does not support authentication or the policy is switched to the OFF state, the ISL is disabled. During switch initialization, authentication begins automatically on all E_Ports. To enforce this policy fabric-wide, the fabric needs to have Fabric OS v5.3.0 and later switches only. The switch disables the port if it is connected to a switch that does not support authentication. Regardless of the policy, the E_Port is disabled if the DH-CHAP or FCAP protocol fails to authenticate the attached E_Port.
OFF	This setting turns off the policy. The switch does not support authentication and rejects any authentication negotiation request from another switch. A switch with the policy turned OFF cannot be connected to a switch with the policy turned ON. The ON state is strict and disables the port if any switch rejects the authentication. DH-CHAP shared secrets must be configured before changing the policy from the OFF to the ON state. The behavior of the policy between two adjacent switches is defined as follows. If the policy is ON or active, the switch sends an authentication negotiation request to the connecting switch. If the connecting switch does not support authentication or the policy is OFF, the request is rejected. After the authentication negotiation succeeds, the DH-CHAP authentication is initiated. If DH-CHAP authentication fails, the port is disabled and this is applicable in all modes of the policy.

authutil policy -sw Parameter	Explanation:
ACTIVE	In this state the switch is more tolerant and can connect to a switch with any type of policy. During switch initialization, authentication begins on all E_Ports, but the port is not disabled if the connecting switch does not support authentication or the AUTH policy is turned to the OFF state. The authentication begins automatically during the E_Port initialization. A switch with this policy can safely connect to pre-v6.0.0 switches, because it continues E_Port initialization if the connecting switch does not support authentication. The switches with firmware pre-v3.2.0 do not support FCAP or DH-CHAP authentication, so an E_Port initializes without authentication. The switches with firmware version v3.2.0 and later respond to authentication negotiation and participate in FCAP and DH-CHAP handshaking. Regardless of the policy, the E_Port is disabled if the DH-CHAP or FCAP protocol fails to authenticate the attached E_Port.
PASSIVE	In the PASSIVE state, the switch does not initiate authentication, but participates in authentication if the connecting switch initiates authentication. The switch does not start authentication on E_Ports, but accepts the incoming authentication requests, and does not disable if the connecting switch does not support authentication or the policy is turned to the OFF state. This is the safest policy for switches connecting to pre-v5.3.0 switches. That means v5.3.0 and later switches can have authentication enabled and this will not impact the pre-v5.3.0 switches. By default, the pre-v5.3.0 switches act as passive switches, because they accept incoming authentication requests. Regardless of the policy, E_Port is disabled if the DH-CHAP or FCAP protocol fails to authenticate the attached E_Port.

**Virtual Fabric considerations:** Because the device authentication policy has switch and logical switch-based parameters, each logical switch is set when Virtual Fabrics is enabled. Authentication is enforced based on each logical switch's policy settings.

## 14.9.18 AUTH policy restrictions

Fabric OS v5.1.0 implementation of DH-CHAP/FCAP does not support integration with RADIUS. All fabric element authentication configurations are performed on a local switch basis.

Device authentication policy supports devices that are connected to the switch in point-to-point manner and is visible to the entire fabric. The following devices are not supported:

- Public loop devices
- Single private devices
- Private loop devices
- Mixed public and private devices in loop
- NPIV devices
- ► FICON channels
- Configupload and download will not be supported for the following AUTH attributes: auth type, hash type, group type.

#### **Supported HBAs**

The following HBAs support authentication:

- ► Emulex LP11000 (Tested with Storport Miniport v2.0 windows driver)
- Qlogic QLA2300 (Tested with Solaris v5.04 driver)

#### Authentication protocols

Use the authUtil command to perform the following tasks:

- Display the current authentication parameters.
- Select the authentication protocol used between switches.
- ► Select the DH (Diffie-Hellman) group for a switch.

Run the **authUtil** command on the switch you want to view or change. Here are the different options to specify which DH group you want to use:

- ▶ 00 DH Null option
- ▶ 01 1024 bit key
- ▶ 02 1280 bit key
- ▶ 03 1536 bit key
- ▶ 04 2048 bit key

This section illustrates using the **authUtil** command to display the current authentication parameters and to set the authentication protocol to DH-CHAP. For more details about the **authUtil** command, see the *Fabric OS Command Reference*, 53-1001186-01.

# 14.9.19 Viewing current authentication parameter settings for a switch

- 1. Log in to the switch using an account assigned to the admin role.
- 2. On a switch running Fabric OS v6.0.0 or later, type **authUti1 --show** as demonstrated in Example 14-32.

Example 14-32 Viewing current auth parameters

```
BDPOCO1LO1:admin> authUtil --show
AUTH TYPE HASH TYPE GROUP TYPE
fcap,dhchap sha1,md5 0,1,2,3,4
Switch Authentication Policy: PASSIVE
Device Authentication Policy: OFF
BDPOCO1LO1:admin>
```

# 14.9.20 Setting authentication protocol used by the switch to DH-CHAP

Follow these steps to set the authentication protocol:

- 1. Log in to the switch using an account assigned to the admin role.
- On a switch running Fabric OS v4.x or v5.x, type authUtil --set -a dhchap. On a switch running Fabric OS v3.x, type authUtil "--set -a dhchap". (See Example 14-33.)

Example 14-33 Setting the authentication protocol

#### **DH-CHAP considerations:**

- When using DH-CHAP, make sure that you configure the switches at both ends of a link.
- If you set the authentication protocol to DH-CHAP, you have not yet configured shared secrets, and authentication is checked (for example, you enabled the switch), then switch authentication fails.

#### 14.9.21 Re-authenticating E_Ports

Use the command **authUti1** to re-initiate the authentication on selected ports. It provides flexibility to initiate authentication for specified E_Ports, a set of E_Ports, or all E_Ports on the switch. This command does not work on private, loop, NPIV, and FICON devices. The command **authUti1** can re-initiate authentication only if the device was previously authenticated. If the authentication fails because shared secrets do not match, the port is disabled.

This command works independently of the authentication policy; this means you can initiate the authentication even if the switch is in PASSIVE mode. This command is used to restart authentication after changing the DH-CHAP group, hash type, or shared secret between a pair of switches.

**Important:** This command might bring down E_Ports if the DH-CHAP shared secrets are not installed correctly.

Follow these steps:

- 1. Log in to the switch using an account assigned to the admin role.
- 2. On a switch running Fabric OS v5.3.0 and later, type the following commands as shown in Example 14-34, Example 14-35, and Example 14-36.

Example 14-34 Example for specific ports on the switch

```
BDPOC01L01:admin> authutil --authinit 2,3,4
BDPOC01L01:admin>
```

Example 14-35 Example for all E_Ports on the switch

```
BDPOC01L01:admin> authutil --authinit allE
BDPOC01L01:admin>
```

Example 14-36 Example for enterprise-class platforms using the slot/port format

BDPOC01L01:admin> authutil --authinit 1/1, 1/2

#### 14.9.22 Secret key pairs

When you configure the switches at both ends of a link to use DH-CHAP for authentication, you must also define a secret key pair—one for each end of the link. Use the **secAuthSecret** command to perform the following tasks:

- View the WWN of switches with a secret key pair.
- Set the secret key pair for switches.
- Remove the secret key pair for one or more switches.

Notice the following characteristics of a secret key pair:

- The secret key pair must be set up locally on every switch. The secret key pair is not distributed fabric-wide.
- If a secret key pair is not set up for a link, authentication fails. The "Authentication Failed" (reason code 05h) error will be reported and logged.
- The minimum length of a shared secret is 8 bytes and the maximum length is 40 bytes.

This section illustrates using the **secAuthSecret** command to display the list of switches in the current switch's shared secret database and to set the secret key pair for the current switch and a connected switch. For more details about the **secAuthSecret** command. see the *Fabric OS Command Reference*, 53-1001186-01.

**Security:** When setting a secret key pair, note that you are entering the shared secrets in plain text. Use a secure channel (for example, SSH or the serial console) to connect to the switch on which you are setting the secrets.

# 14.9.23 Viewing a list of secret key pairs in the current switch database

Follow these steps:

- 1. Log in to the switch using an account assigned to the admin role.
- On a switch running Fabric OS v4.x or later, type secAuthSecret --show. On a switch running Fabric OS v3.x, type secAuthSecret "--show". See Example 14-37.

Example 14-37 Viewing key pairs

BDPOC01101:admin>secauthsecret --show

WWN	DId	Name	
10:00:00:60:69:80:07:52 10:00:00:60:69:80:5b:e8 BDPOC01L01:admin>	1	Unknown BDPOC01L01	

The output displays the WWN, domain ID, and name (if known) of the switches with defined shared secrets.

#### 14.9.24 Setting a secret key pair

Follow these steps to set the secret key pair:

- 1. Log in to the switch using an account assigned to the admin role.
- 2. On a switch running Fabric OS v4.x or later, type **secAuthSecret** --set, see Example 14-38 on page 684. On a switch running Fabric OS v3.x, type **secAuthSecret** "--set".

The command enters interactive mode. The command returns a description of itself and the necessary input; then it loops through a sequence of switch specification, peer secret entry, and local secret entry. To exit the loop, press Enter for the switch name; then type **y**. See Example 14-38.

Example 14-38 Setting a secret pair

BDPOC01L01:admin>secAuthSecret --set

This command sets up secret keys for the DH-CHAP authentication. The minimum length of a secret key is 8 characters and maximum 40 characters. Setting up secret keys does not initiate DH-CHAP authentication. If switch is configured to do DH-CHAP, it is performed whenever a port or a switch is enabled.

Warning: Please use a secure channel for setting secrets. Using an insecure channel is not safe and may compromise secrets.

Following inputs should be specified for each entry.

- 1. WWN for which secret is being set up.
- 2. Peer secret: The secret of the peer that authenticates to peer.
- 3. Local secret: The local secret that authenticates peer.

Press Enter to start setting up shared secrets >
Enter WWN, Domain, or switch name (Leave blank when done):
10:00:00:60:69:80:5b:e8
Enter peer secret: <hidden>
Re-enter peer secret: <hidden>
Enter local secret: <hidden>
Re-enter local secret: <hidden>
Enter WWN, Domain, or switch name (Leave blank when done):
Are you done? (yes, y, no, n): [no] y

3. Disable and enable the ports on a peer switch using the **portDisable** and **portEnable** commands.

## 14.9.25 Distributing the local ACL policies

Follow these steps:

- 1. Connect to the switch and log in using an account assigned to the admin role.
- 2. Use the following command (see Example 14-39) to distribute the policies:

```
distribute -p <database_id> -d <switch_list>
```

3. Table 14-16 describes the arguments for the command.

Table 14-16Distribute policies command

Saving data to key store... Done.

database_id	A semicolon-separated list of the local databases to be distributed: SCC, DCC, or both.
switch_list	A semicolon-separated list of switch Domain IDs, switch names, or switch WWN addresses of the target switches that will receive the distribution.
	Use an asterisk (*) to distribute the database to all Fabric OS v5.2.0 and later switches in the fabric. For example, entering the command <b>distribute -p SCC -d "*"</b> distributes the SCC policy to all v5.2.0 and later switches in the fabric.

To distribute the Switch Connection Control Policy and Device Connection Control Policy to domains 3 and 5 in the fabric, use the command shown in Example 14-39. Example 14-39 Using the distribute command

BDPOC01L01:admin> distribute -p "SCC;DCC" -d "3;5"

To distribute SCS, FCS, and the Password database to all domains in the fabric that support the distribute feature, use the command in Example 14-40.

Example 14-40 Using the distribute command with wildcard

```
BDPOC01L01:admin> distribute -p "SCC;FCS;PWD" -d "*"
Wildcard domains are:
1 3 5
```

#### 14.9.26 IP Filter policy

The IP Filter policy is a set of rules applied to the IP management interfaces as a packet filtering firewall. The firewall permits or denies the traffic to go through the IP management interfaces according to the policy rules.

Fabric OS supports multiple IP Filter policies to be defined at the same time. Each IP Filter policy is identified by a name and has an associated type. Two IP Filter policy types, IPv4 and IPv6, exist to provide separate packet filtering for IPv4 and IPv6. It is not allowed to specify an IPv6 address in the IPv4 filter, or specify an IPv4 address in the IPv6 filter. There can be up to six different IP Filter policies defined for both types. Only one IP Filter policy for each IP type can be activated on the affected management IP interfaces.

Audit messages will be generated for any changes to the IP Filter policies.

The rules in the IP Filter policy are examined one at a time until the end of the list of rules. For performance reasons, the most import rules must be specified at the top.

On a chassis system, changes to persistent IP Filter policies are automatically synchronized to the standby CP when the changes are saved persistently on the active CP. The standby CP will enforce the filter policies to its management interface after policies are synchronized with the active CP.

**Virtual Fabric considerations:** Each logical switch cannot have its own different IP Filter policies. IP Filter policies are treated as a chassis-wide configuration and are common for all the logical switches in the chassis.

## 14.9.27 Creating an IP Filter policy

You can create an IP Filter policy specifying any name and using type IPv4 or IPv6. The policy created is stored in a temporary buffer, and is lost if the current command session logs out. The policy name is a unique string composed of a maximum of 20 alpha, numeric, and underscore characters. The names default_ipv4 and default_ipv6 are reserved for default IP filter policies. The policy name is case-insensitive and always stored as lowercase. The policy type identifies the policy as an IPv4 or IPv6 filter. There can be a maximum of six IP Filter policies created for both types. Follow these steps:

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Use the following command:

```
ipfilter --create <policyname> -type < ipv4 | ipv6 >
```

**Tip:** To set a IP filter, IPSEC must be enabled. This is done using the **ipsecconfig --enable** command.

3. Table 14-17 describes the arguments for the command.

Table 14-17 IP filter policy

policyname	The name of the new policy
-type	Specified as an IPv4 or IPv6 address.

### 14.9.28 Cloning an IP Filter policy

You can display the IP Filter policy content for the specified policy name, or all IP Filter policies if a policy name is not specified.

For each IP Filter policy, the policy name, type, persistent state and policy rules are displayed. The policy rules are listed by the rule number in ascending order. There is no pagination stop for multiple screens of information. Pipe the output to the **|more** command to achieve this result.

If a temporary buffer exists for an IP Filter policy, the **--show** subcommand displays the content in the temporary buffer, with the persistent state set to no.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, **ipfilter** --**show** [policyname] where [policyname] is the name of the policy.

## 14.9.29 Saving an IP Filter policy

You can save one or all IP Filter policies persistently in the defined configuration. The policy name is optional for this subcommand. If the policy name is given, the IP Filter policy in the temporary buffer is saved; if the policy name is not given, all IP Filter policies in the temporary buffer are saved. Only the CLI session that owns the updated temporary buffer can run this command.

Modification to an active policy cannot be saved without being applied. So, the **--save** subcommand is blocked for the active policies. Use **--activate** instead.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, **ipfilter** --save [policyname] where [policyname] is the name of the policy and is optional.

### 14.9.30 Activating an IP Filter policy

IP Filter policies are not enforced until they are activated. Only one IP Filter policy per IPv4 and IPv6 type can be active. If there is a temporary buffer for the policy, the policy is saved to the defined configuration and activated at the same time. If there is no temporary buffer for the policy, the policy existing in the defined configuration becomes active. The activated policy continues to remain in the defined configuration. The policy to be activated replaces the existing active policy of the same type. Activating the default IP Filter policies returns the IP management interface to its default state. An IP Filter policy without any rule cannot be activated. This subcommand prompts for a user confirmation before proceeding.

Follow these steps to activate the policy:

- 1. Log in to the switch using an account assigned to the admin role.
- Type the following command, ipfilter --activate <policyname> where <policyname> is the name of the policy.

### 14.9.31 Deleting an IP Filter policy

You can delete a specified IP Filter policy. Deleting an IP Filter policy removes it from the temporary buffer. To permanently delete the policy from the persistent database, run **ipfilter --save**. An active IP Filter policy cannot be deleted.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, **ipfilter** -delete <policyname> where <policyname> is the name of the policy.
- 3. To permanently delete the policy, type the following command: ipfilter --save

## 14.9.32 IP Filter policy rules

An IP Filter policy consists of a set of rules. Each rule has an index number identifying the rule. There can be a maximum of 256 rules within an IP Filter policy. Each rule contains the following elements:

- Source Address: A source IP address or a group prefix.
- Destination Port: The destination port number or name, such as: Telnet, SSH, HTTP, HTTPS.
- ► Protocol: The protocol type. Supported types are TCP or UDP.
- ► Action: The filtering action taken by this rule, either Permit or Deny.

For an IPv4 filter policy, the source address has to be a 32-bit IPv4 address in dot decimal notation. The group prefix has to be a CIDR block prefix representation. For example, 208.130.32.0/24 represents a 24-bit IPv4 prefix starting from the most significant bit. The special prefix 0.0.0.0/0 matches any IPv4 address. In addition, the keyword any is supported to represent any IPv4 address.

For an IPv6 filter policy, the source address has to be a 128-bit IPv6 address, in a format acceptable in RFC 3513. The group prefix has to be a CIDR block prefix representation. For example, 12:AB:0:0:CD30::/64 represents a 64-bit IPv6 prefix starting from the most significant bit. In addition, the keyword any is supported to represent any IPv6 address.

For the destination port, a single port number or a port number range can be specified. According to IANA (http://www.iana.org), ports 0 to 1023 are well-known port numbers, ports 1024 to 49151 are registered port numbers, and ports 49152 to 65535 are dynamic or private port numbers. Well-known and registered ports are normally used by servers to accept connections, while dynamic port numbers are used by clients.

For an IP Filter policy rule, you can only select port numbers in either the well-known or the registered port number range, between 0 and 49151, inclusive. This means that you have the ability to control how to expose the management services hosted on a switch, but not the ability to affect the management traffic that is initiated from a switch. A valid port number range is represented by a dash, for example, 7-30. Alternatively, service names can also be used instead of port numbers.

Table 14-18 lists the supported service names and the corresponding port number for each.

Service name	Port number
http	443
rpcd	897
securerpcd	898
snmp	161
ssh	22
sunrpc	111
telnet	23
www	80

Table 14-18 Supported service names

TCP and UDP protocols are valid selections. Fabric OS v5.3.0 and later do not support configuration to filter other protocols. Implicitly, ICMP type 0 and type 8 packets are always allowed to support ICMP echo request and reply on commands such as **ping** and **traceroute**. For the action, only **permit** and **deny** are valid.

For every IP Filter policy, the two rules listed in Table 14-19 on page 690 are always assumed to be appended implicitly to the end of the policy. This ensures that TCP and UDP traffic to dynamic port ranges is allowed, so that management IP traffic initiated from a switch, such as syslog, radius, and ftp, is not affected.

Table 14-19 Implicit IP Filter rules

Source address	Destination port	Protocol	Action
Any	1024-65535	ТСР	Permit
Any	1024-65535	UDP	Permit

A switch with Fabric OS v5.3.0 or later will have a default IP Filter policy for IPv4 and IPv6. The default IP Filter policy cannot be deleted or changed. When an alternative IP Filter policy is activated, the default IP Filter policy becomes deactivated.

Table 14-20 lists the rules of the default IP Filter policy.

Rule number	Source address	Destination port	Protocol	Action
1	Any	22	ТСР	Permit
2	Any	23	ТСР	Permit
3	Any	897	ТСР	Permit
4	Any	898	ТСР	Permit
5	Any	111	ТСР	Permit
6	Any	80	ТСР	Permit
7	Any	443	ТСР	Permit
9	Any	161	UDP	Permit
10	Any	111	UDP	Permit
11	Any	123	UDP	Permit
12	Any	600-1023	UDP	Permit

Table 14-20 Default IP policy rules

### 14.9.33 IP Filter policy enforcement

An active IP Filter policy is a filter applied to the IP packets through the management interface. IPv4 management traffic passes through the active IPv4 filter policy, and IPv6 management traffic passes through the active IPv6 filter policy. The IP Filter policy applies to the incoming (ingress) management traffic only. When a packet arrives, it is compared against each rule, starting from the first rule. If a match is found for the source address, destination port, and protocol, the corresponding action for this rule is taken, and the subsequent rules in this policy are ignored. If there is no match, then it is compared to the next rule in the policy. This process continues until the incoming packet is compared to all rules in the active policy.

If none of the rules in the policy match the incoming packet, the two implicit rules are matched to the incoming packet. If the rules still do not match the packet, the default action, which is to deny, is taken.

When the IPv4 or IPv6 address for the management interface of a switch is changed through the **ipAddrSet** command or manageability tools, the active IP Filter policies automatically become enforced on the management IP interface with the changed IP address.

**NAT server:** If a switch is part of a LAN behind a Network Address Translation (NAT) server, depending on the NAT server configuration, the source address in an IP Filter rule might have to be the NAT server address.

### 14.9.34 Adding a rule to an IP Filter policy

There can be a maximum of 256 rules created for an IP Filter policy. The change to the specified IP Filter policy is not saved to the persistent configuration until a save or activate subcommand is run.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, ipfilter --addrule <policyname> -rule
   <rule_number> -sip <source IP> -dp <dest port> -proto <protocol> -act
   <permit | deny>
- 3. Table 14-21 describes the arguments for the ipfilter addrule command.

policyname	Specifies the policy name which is a unique string composed of a maximum of 20 alphanumeric and underscore characters. The names default_ipv4 and default_ipv6 are reserved for the default IP Filter policies. The policy name is case-insensitive and always stored as lowercase.
-rule rule number	Specifies a valid rule number between 1 and the current maximum rule number plus one.
- <b>sip</b> source IP	Specifies the source IP address. For IPv4 filter type, the address must be a 32-bit address in dot decimal notation, or a CIDR block IPv4 prefix. For IPv6 filter type, the address must be a 128-bit IPv6 address in any format specified by RFC, or a CIDR block IPv6 prefix.
-dp destination port	Specifies the destination port number, or a range of port numbers, or a service name.
-proto protocol	Specifies the protocol type, either TCP or UDP.
-act <permit deny=""  =""></permit>	Specifies the permit or deny action associated with this rule.

Table 14-21 IP filter add rule
#### 14.9.35 Deleting a rule in an IP Filter policy

Deleting a rule in the specified IP Filter policy causes the rules following the deleted rule to shift up in rule order. The change to the specified IP Filter policy is not saved to persistent configuration until a save or activate subcommand is run.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, ipfilter --delrule <policyname> -rule
   <rule number>

#### 14.9.36 Aborting a transaction associated with IP Filter

A transaction is associated with a command line or manageability session. It is opened implicitly when the --create, --addrule, --delrule, --clone, and --delete subcommands are run. The --transabort, --save, or --activate subcommands explicitly end the transaction owned by the current command line or manageability session. If a transaction is not ended, other command line or manageability sessions are blocked on the subcommands that would open a new transaction.

- 1. Log in to the switch using an account assigned to the admin role.
- 2. Type the following command, ipfilter --transabort

#### 14.9.37 IP Filter policy distributions

The IP Filter policy is manually distributed using the **distribute -p** "IPFILTER" command. The distribution includes both active and defined IP Filter policies. All policies are combined as a single entity to be distributed and cannot be selectively distributed. However, you can choose the time at which to implement the policy for optimization purposes. If a distribution includes an active IP Filter policy, the receiving switches activate the same IP Filter policy automatically. When a switch receives IP Filter policies, all uncommitted changes left in its local transaction buffer are lost, and the transaction is aborted.

Switches with Fabric OS v5.3.0 or later have the ability to accept or deny IP Filter policy distribution, through the commands fddCfg --localaccept or fddCfg --localaccept or fddCfg Wide Consistent Policy is not supported in Fabric OS v6.2.0.

#### 14.9.38 IP Filter policy restrictions

In a mixed fabric with Fabric OS v5.3.0 or later and pre-v5.3.0 switches, IP Filter policies cannot be distributed from a Fabric OS v6.2.0 switch to a pre-v5.3.0 switch. This means that the sending switch will fail a **distribute -p** "IPFILTER" operation, if the specified receiving domain list contains switches with Fabric OS v5.2.0 and earlier. When the asterisk (*) is used as the receiving domain, the sending switch distributes the IP Filter policies only to switches with Fabric OS v5.3.0 or later.

# 15

# **Adaptive Networking**

Adaptive Networking is a suite of tools and capabilities that enables you to ensure optimized behavior in the SAN. Even under the worst conditions of congestion, Adaptive Networking features can maximize the fabric behavior and provide necessary bandwidth for high-priority, mission-critical applications, and connections.

Adaptive Networking is not a single feature but a suite of tools and capabilities provided for the SAN optimization.

In this chapter we discuss the following features in the Adaptive Networking suite:

- Traffic Isolation
- Quality of service (QoS) Ingress Rate Limiting
- QoS SID/DID Traffic Prioritization

Top Talkers, which is another Adaptive Networking feature, requires the Advanced Performance Monitoring license, and is described in Chapter 16, "Performance monitoring" on page 739.

# **15.1 Traffic Management**

Traffic Management consists of Ingress Rate Limiting and Traffic Isolation (see Table 15-1). One feature allows you to control the flow of interswitch traffic and the second restricts the speed of traffic on a particular port. Only Ingress Rate Limiting requires Adaptive Networking License.

Table 15-1 Traffic Management

Service	Service name	Licence required
Traffic Management	Ingress Rate Limiting	Adaptive Networking
	Traffic Isolation	None

Licensing: With Fabric OS v6.4.0 it is possible to have slot-based licensing.

#### 15.1.1 Committed rate considerations on FCIP

Starting with Fabric OS v6.4.0 in the case of an FCIP configuration, when you are configuring the traffic limit, you must have the same committed rate configuration on each end of a circuit. In previous releases you can have different committed rates on each side. This committed rate will be enforced at circuit initialization, and if the committed rates do not match, an error will be shown in the CLI or log.

Figure 15-1 illustrates this configuration.



Figure 15-1 Committed rates at both ends must match

This includes tunnels that exist already and are upgraded to Fabric OS v6.4.0. After upgrade, the tunnel will not be able to go online, and an error will be generated.

**Validation:** Remember to validate the committed rates in your configuration, especially in the case of a Fabric OS update.

#### 15.1.2 Adaptive Rate Limiting considerations

When using Adaptive Rate Limiting (ARL), consider the following guidelines:

- ► The maximum committed rate cannot be larger than five times the minimum committed rate, as an example, this would mean:
  - A minimum of 100 Mbps and a maximum of 500 Mbps is allowed.
  - A minimum of 10 Mbps and a maximum of 500 Mbps will not be allowed.
- The CLI will produce an error if the configuration request does not meet the preceding guidelines.



Figure 15-2 shows an example of this ARL guidelines.

Figure 15-2 ARL limits

When updating an existing tunnel, the tunnel will continue to function using an invalid configuration. The administrator will not be able to make additional changes to the tunnel configuration until the ARL delta is compliant. Consider this factor when updating and later validating your configuration to avoid compliance issues.

#### 15.1.3 Trunking across multiple FCIP circuits

When trunking across multiple FCIP circuits, the delta bandwidth between the circuits must be no greater than a factor of four. As an example, this would mean:

- Trunking between a circuit running on an OC3 (155.52 Mbps) and another running on an OC12 (622.08 Mbps) is allowed.
- ► Trunking between a 10 Mbps circuit and a 500 Mbps circuit is *not* desirable.

This rule will not be enforced with the CLI, but it is not supported, so consider it when defining your trunking. If the factor is greater than four, the tunnel might not fully utilize all the bandwidth available for the circuits, and you will not be using the optimal configuration.

This restriction only includes circuits with the same metric values (standby circuits, metric 1, are not included in this calculation).

In general, the minimum committed rate of a circuit will be 10 Mbps, and will be enforced by the CLI. A configuration attempt lower than this will fail.

Rate: With Fabric OS v6.3, the minimum committed rate was of 1.544 Mbps.

When upgrading an existing tunnel, the tunnel will continue to function using an invalid configuration. The administrator will not be able to make additional changes in the tunnel configuration until the minimum commit rate is compliant. Remember that some configurations are not supported, even if they seem to work.

#### 15.1.4 Supported packet loss and delay

In certain cases, the tunnel might have tolerance to packet loss, and support a certain delay. This is well documented, and in Table 15-2 we can see the supported values for the latest two releases of FabricOS.

The following table shows the supported packet loss and delay in the two latest releases of FabricOS.

Tunnels	Fabric OS v6.3	Fabric OS v6.4.0
Both ends 1GbE	<ul><li>200 ms latency</li><li>1% packet loss</li></ul>	<ul><li>200 ms latency</li><li>1% packet loss</li></ul>
One or both ends 10GbE	<ul> <li>50 ms latency</li> <li>0.1% packet loss</li> </ul>	<ul> <li>100 ms latency</li> <li>0.1% packet loss</li> </ul>

Table 15-2 Supported packet loss and delay

#### 15.1.5 Scalability considerations

When planning your network, scalability should be considered. It is very common to start with a small to medium configuration, and plan an upgrade in the future. In Fabric OS release 6.4.0, there is support for up to four FCoE 10GbE blades in a chassis.

**Important:** Downgrading to Fabric OS v6.3 will fail if there are more than two FCoE 10 GbE blades in the chassis.

### 15.2 Ingress rate limiting

Ingress rate limiting restricts the speed of traffic from a particular device to the switch port:

- It allows you to reduce existing congestion in the network or proactively avoid congestion.
- It enables you to offer flexible bandwidth limit services based on requirements.
- It allows you to let more important devices use the network bandwidth during specific services, such as network backup.

This feature is only available on 8 Gbps platforms/blades, which can be running at any supported speed (8,4,2,1 Gbps). By restriction of the speed from a particular device, we mean the following characteristics:

- ASIC delays the return of R_RDYs to external device by throttling back the ingress speed.
- ► The throughput is limited on the ingress side of the port.

The usage limitation is that it is restricted to F/FL_Ports only.

**Support:** Ingress Rate Limiting is supported on F/FL ports on the SAN24B-4, SAN40B-4, SAN06B-R, SAN80B-4, SAN 768B, or SAN384B switches. It is not supported on E/EX_Ports.

Ingress Rate Limiting will help you if you will experience "choke points" in the fabric, which can be caused by:

- Slow draining devices
- Congested ISLs

**Virtual Fabrics:** If the Virtual Fabrics feature is enabled, the rate limit configuration on a port is on a per-logical switch basis. That is, if a port is configured to have a certain rate limit value, and the port is then moved to a different logical switch, it would have no rate limit applied to it in the new logical switch. If that same port is moved back to the original logical switch, it would have the original rate limit take effect again.

Figure 15-3 shows the configuration of two servers sending and receiving traffic from one storage device.



Figure 15-3 Two servers and one storage configuration

Referring to Figure 15-3 only the following ports can participate in Ingress Rate Limit settings:

- Port 0 switch 1
- Port 1 switch 1
- Port 14 switch 2
- Port 15 switch 2

It cannot be enabled for port 15 switch 1, and port 0 switch 2.

The settings for Ingress Rate Limiting are unidirectional. We describe what we mean by this in the following example:

- ► Ingress Rate Limiting is enabled only on port 0 switch 1 in Figure 15-3.
- Traffic returning from the target (port 14 and 15 on switch 2) would travel at full line speed to both servers, unless the ingress side of the target's ports (port 14 and 15 on switch 2) are also limited if both ports are in the same zone with port 0 server 1.
- When the ingress side of the target's ports are also throttled back, then traffic would be rate limited in both directions. In that case it can affect the transmission back to server 2 as well.

#### 15.2.1 Ingress Rate limiting with the CLI

To set Ingress Rate Limiting on a given port, use the command in Example 15-1. The *rate* parameter of the command in Example 15-1 is set in Mbps.

Example 15-1 Setting Ingress Rate Limiting on a port

portcfgqos -setratelimit [slot/]port rate

To set the Ingress rate limit from a given port, use the command in Example 15-2.

Example 15-2 Setting Ingress Rate Limiting from a port

```
portcfgqos --resetratelimit [slot/]port
```

To show a port with Ingress Rate Limiting, use the command in Example 15-3.

Example 15-3 Showing Ingress Rate Limiting

portcfgshow 2/28

Example 15-4 shows real values when setting and displaying port speed limit.

Example 15-4 Setting Ingress rate Limiting on a port 2/28

IBM_SAN384B_213:FID128:adm	nin> portcfgqossetratelimit 2/28 200
IBM_SAN384B_213:FID128:adm	nin> <b>portcfgshow 2/28</b>
Area Number:	92
Speed Level:	AUTO(HW)
Fill Word:	O(Idle-Idle)
AL_PA Offset 13:	OFF
Trunk Port	ON
Long Distance	OFF
VC Link Init	OFF
Locked L_Port	OFF
Locked G_Port	OFF
Disabled E_Port	OFF
ISL R_RDY Mode	OFF
RSCN Suppressed	OFF
Persistent Disable	OFF
NPIV capability	ON
QOS E_Port	ON
Port Auto Disable:	OFF
Rate Limit	0.2G
EX Port	OFF
Mirror Port	OFF
Credit Recovery	ON
F_Port Buffers	OFF

To set the Ingress Rate Limit *from* port 2/28, issue the command shown in Example 15-5.

Example 15-5 Setting Ingress Rate Limiting from port 2/28

IBM_SAN384B_213:FID128:adm	nin> portcfgqosresetratelimit 2/28
IBM_SAN384B_213:FID128:adm	nin> portcfgshow 2/28
Area Number:	92
Speed Level:	AUTO(HW)
Fill Word:	O(Idle-Idle)
AL_PA Offset 13:	OFF
Trunk Port	ON
Long Distance	OFF
VC Link Init	OFF
Locked L_Port	OFF
Locked G_Port	OFF
Disabled E_Port	OFF

ISL R_RDY Mode	OFF
RSCN Suppressed	OFF
Persistent Disable	OFF
NPIV capability	ON
QOS E_Port	ON
Port Auto Disable:	OFF
Rate Limit	OFF
EX Port	OFF
Mirror Port	OFF
Credit Recovery	ON
F_Port Buffers	OFF

#### 15.2.2 Ingress Rate Limiting with Web Tools

You can set up Ingress Rate Limiting for a particular port using WebTools. Click the port, then **Edit Configuration** (see Figure 15-4).

C Ports Explorer	View Details	Rename	Edit Configuration	E <u>n</u> able <u>D</u> i	isable Per <u>s</u> ister	it Enable Pers	istent Disable
Port 0	Port# 🔺	Port Id	Port Name	Port Type	Speed (Gb/s)	Port Status	Health
Port 1	0(0×0)	0×050000		U-Port	N8	No_Module	Offline
Port 2	1(0x1)	0×050100		U-Port	N8	No_Module	Offline
Port 3	2(0×2)	0×050200		U-Port	N8	No_Module	Offline
Port 4	3(0×3)	0×050300		U-Port	N8	No_Module	Offline
- 🖲 Port 5	4(0×4)	0×050400		E-Port	N8	Online	Healthy
Port 6	5(0×5)	0×050500		U-Port	N8	No_Module	Offline
Port 7	6(0×6)	0×050600		E-Port	N8	Online	Healthy
	7(0x7)	0×050700		U-Port	N8	No_Module	Offline

Figure 15-4 Port Administration in Web Tools

The dialog box in Figure 15-5 displays.

FC Port Configuration Wizard	×
Steps	Specify Ports Parameters
1. Specify Ports Parameters	Select Allowed Port Types - <ul> <li>Normal</li> </ul>
2. Specify FC Parameters	🗹 E Port
3. Confirmation	F Port     Fort
	O EX-Port
4. Report	Fabric ID: 1
	Interop Mode
	Brocade Native Mode
	O McDATA Fabric Mode
	O Open Mode
	O McDATA Fabric Legacy
<u>C</u> ancel	Previous

Figure 15-5 FC Port Configuration Wizard

Click **Next**, and on the next page of the dialog box, you see a list box with the possible changes of the speed on a port, as shown in Figure 15-6.

. IBM_SA	N80B_217 - Port Administration		
		Show B	as
EC Ports	]		
EC Ports Ex	plorer (Occount OFF)		
	General SPP Po	on statistics	
- D Port	t 20 <u>R</u> ename <u>E</u> dit Con	nfiguration Enable Disable Persistent Enable Persistent Disable	
- 🔍 Por	+21	htica	te
- D P -	L Port Lonfiguration Wizard	×	
- • Pi	Steps	Specify FC Parameters	
— 🖲 Pi			
- 🔍 Pi	<ol> <li>Specify Ports Parameters</li> </ol>		
- 🔍 Pi	2. specify FC Parameters		_
- 🕑 Pi	3 Confirmation		
- • Pi	5. Commination	Speed Auto	
- 🖲 Pi	4. Report	Ingress Rate Limit/Mb/s)	_
- 🔍 Pi	1	Not Initialized	
P P		Long Distance Mode 200	
- • P		400	
— 🖲 Pi		Desired Distance (km)	
- 🔍 Pi		1000	
		1500	
- 🖲 Pi		2000	
			-
		nin	F
- ΨΨΨ αγΤ			
Role	Cancel	Previous Next	

Figure 15-6 Ingress Rate Limiting with WebTools

# **15.3 Traffic Isolation**

The second subject in Traffic Management is Traffic Isolation.

You can start to consider Traffic Isolation when:

- ► The host/target pair needs to have high priority traffic with no interruptions.
- The host/target pair is exchanging very high volumes of data and the data flow should have a low priority to avoid congestion in the SAN.
- ► The host/target pair needs to have a dedicated connection.

Traffic isolation is implemented using special zones called Traffic Isolation zones (TI zones). TI zones have the following characteristics:

- They use special zoning commands:
  - They control the routing of frames between zone members.
  - They do not control access to devices.
- They use a standard zoning configuration that must be in effect:
  - TI zones do not modify the routing table.
  - Routes are not being modified.
  - Existing routes are being dedicated for use by host/target pairs.
- The TI zone contains the set of N_Ports and E_Ports to be used for a specific traffic flow.

Figure 15-7 shows a TI zone configuration that consists of the following ports:

- ▶ N_Ports 1,0; 3,15
- E_Ports 1,14; 2,0; 2,14; 3,0



Figure 15-7 TI zone

The dotted line in Figure 15-7 indicates the dedicated path from Server 1 to Storage 2:

- ► Traffic entering Domain 1 from N_Port 0 is routed through E_Port 14.
- Traffic entering Domain 2 from E_Port 0 is routed to E_Port 14
- Traffic entering Domain 3 from E_Port 0 is routed to N_Port 15
- Traffic coming from port 1 in Domain 1 would not use E_Port 14, but would use E_Port 15 instead.

**Traffic Isolation:** The new features of the Traffic Isolation zones have been explained in Chapter 4, "Fabric Operating System" on page 91. Consider them when implementing Traffic Isolation.

#### 15.3.1 TI zone failover

A TI zone can have failover enabled or disabled. In Table 15-3 we show the comparison of traffic behavior when failover is enabled and disabled in TI zone.

Zones	Failover enabled	Failover disabled	
TI zones	If the dedicated path cannot be used, the TI zone traffic will use a non-dedicated path instead.	If the dedicated path cannot be used, traffic for that TI zone is halted until the dedicated path is fixed, but the communication is maintained.	
Non - TI Zones	Non-TI zone traffic will use the dedicated path if no other paths through the fabric exist, or if the non-dedicated paths are not the shortest paths.	Non-TI zone traffic will never use the dedicated path, even if there are no other paths through the fabric.	

Table 15-3 Comparison of traffic behavior - failover disabled and enabled

We assume the following conditions for Figure 15-3:

- The dedicated ISL between Domain 1 and Domain 2 goes offline, then the following events occur, depending on the failover option:
  - If failover is enabled for the TI zone:
    - The traffic is routed from Domain 1 to Domain 2 through E_Ports "1,15" and "2,1".
    - When the failed TI zone is restored, traffic will be automatically failed back to the original route.

Failback: Failback is not a configurable feature.

- If failover is disabled for the TI zone:
  - The traffic is halted until the ISL between Domain 1 and Domain 2 is back online.

RSCN: An RSCN will be generated noting the failure of a path.

• When the TI zoned route is restored, traffic will be automatically rerouted back onto the TI zone route.

**RSCN:** An RSCN will be generated noting the restoration of a path.

- If the non-dedicated ISL between Domain 1 and Domain 2 goes offline, then the following events occur, depending on the failover option:
  - If failover is enabled for the TI zone, non-TI zone traffic is routed from Domain 1 to Domain 2 through the dedicated ISL.
  - If failover is disabled for the TI zone, non-TI zone traffic is halted until the non-dedicated ISL between Domain 1 and Domain 2 is back online.

#### **Disabled failover considerations**

When disabling failover, keep in mind the following considerations:

- Ensure that there are non-dedicated paths through the fabric for all devices that are not in a TI zone.
- Ensure that there are multiple paths between switches.
- Disabling failover locks the specified route so that only TI zone traffic can use it. Non-TI zone traffic, including domain controller frames, are excluded from using the dedicated path.

In Figure 15-8, if failover is disabled, Domain 4 cannot send domain controller frames to Domain 2 and 3. Domain controller frames include zone updates and Name Server queries.



Figure 15-8 Failover disabled - Isolating Domain 4

#### **Zoning considerations**

Take the following considerations into account with zoning:

- Ensure that regular zone definitions match the TI zone definition. This is because the routing rules imposed by TI zones with failover disabled, will override regular zone definitions.
- Regular zone definitions should use Domain, Index (D,I) notation and not WWN notation; otherwise, RSCN notifications are not sent to the devices if the dedicated path is broken.
- Ensure that the insistent Domain ID feature is enabled; if a switch changes its active domain ID, the route is broken.
- A given port (N_Port or E_Port) used in a TI zone should not be a member of more than one TI zone.
- TI zones reside only in the defined configuration and not in the effective configuration. When you make any changes to TI zones, including creating or modifying them, you must enable the effective configuration for the changes to take effect, even if the effective configuration is unchanged.

#### 15.3.2 FSPF routing rules and traffic isolation

FSPF, or Fabric Shortest Path First, is a path selection protocol for Fibre Channel Fabrics.

Table 15-4 shows the FSPF actions with TI zones failover.

Dedicated ISL	Failover enabled	Failover disabled
dedicated ISL is not the shortest path ISL	If failover is enabled, the traffic path for the TI zone is broken, and TI zone traffic uses the lowest cost path instead.	If failover is disabled, the TI zone traffic is blocked.
dedicated ISL is the only shortest path ISL	If failover is enabled, non-TI zone traffic as well as TI zone traffic uses the dedicated ISL.	If failover is disabled, non-TI zone traffic is blocked because it cannot use the dedicated ISL, which is the lowest cost path.

Table 15-4 FSPF actions

The considerations described in Table 15-4 are illustrated in the following figures.

Figure 15-9 shows the situation when the dedicated path is the only shortest path:

- There is a dedicated path between Domain 1 and Domain 2 and a non-dedicated, path that passes through Domain 4:
  - If failover is enabled:
    - All traffic will use the dedicated path, because the non-dedicated path is not the shortest path.
    - Server 2 can reach Storage 1 using dedicated path 1,14; 2,0.
  - If failover is disabled:
    - Non-TI zone traffic is blocked because the non-dedicated path is not the shortest path.
    - Server 2 cannot reach Storage 1 at all.



Figure 15-9 Dedicated path is the only shortest path

Figure 15-10 shows the situation when the dedicated path is not the shortest path:

- The dedicated path between Domain 1 and Domain 4 exists, but is not the shortest path.
  - If failover is enabled:
    - The TI zone traffic uses the shortest path, even though the E_Ports are not in the TI zone.
    - Server 1 reaches Storage 2 using the non-dedicated path 1,14; 2,0.

- If failover is disabled:
  - The TI zone traffic stops until the dedicated path is configured to become the shortest path.
  - Server 1 cannot reach Storage 1 at all.

Figure 15-10 shows the situation when the dedicated path is not the shortest path.



Figure 15-10 Dedicated path is not the shortest path

#### 15.3.3 TI zone misconfiguration example

Figure 15-11 shows the following configurations:

- Two servers: Server 2 and Server 3 share the non-dedicated link to both storage devices: Storage 1 and Storage 2.
- To ensure that we have maximum throughput from Server 1 to both storage devices (Storage 1 and Storage 2), a dedicated link is used.
- ► The E_Port 0 in Domain 2 switch was erroneously omitted from the TI zone.
- The Domain 2 switch assumes that traffic coming from E_Port 9 is not part of the TI zone:
  - If failover is enabled:
    - Traffic is routed to E_Port 7 to reach Storage 2 and to port 15 to reach Storage 1.
  - If failover is disabled:
    - The route is broken and traffic stops.

The net result is that we have three servers on non-dedicated paths and only after we have enabled the failover.



Figure 15-11 Misconfiguration of TI zones

**Topology:** Each TI zone is interpreted by each switch and each switch considers only the routing required for its local ports. No consideration is given to the overall topology.

#### 15.3.4 Supported configurations

TI zones are supported on the following platforms:

- IBM SAN24B-4, SAN40B-4, SAN80B-4, Brocade 7500, 7500E, 7600 switches, IBM SAN256B, and Backbone platforms, all configured in Brocade Native Mode (interopmode 0)
- Switches running Fabric OS v6.0 or later

#### **15.3.5 Virtual Fabric configuration**

TI zones can be created in a logical fabric as in regular fabrics, except that:

► The disable failover option is not supported in logical fabrics that use XISLs.

To create a TI zone for a logical fabric that uses XISLs, you must create two TI zones: one in the logical fabric and one in the base fabric. The combination of TI zones in the base fabric and logical fabric sets the path through the base fabric for logical switches.

#### 15.3.6 TI zones using CLI

The general command syntax for TI zones is as follows:

Synopsis <b>zone</b>	copy [source_AD.] source_zone_object [dest_zone_object][-f]
	expunge "zone_object"
	validate [[-f  ] [-m mode] ["zone_object"]]]

To create and manage traffic Isolation zones:

--create -t objecttype [-o optlist] name -p portlist

- --add [-o optlist] name -p portlist
- --remove name -p portlist
- --delete name
- --activate name
- --deactivate name
- --show [name]
- --operation -t objtype [-o optlist] name -p portlist

Operands:

*-t objecttype* - Specifies the zone object type. This operand is supported only with the *--create* option. To create a TI zone, the value is ti.

*-o optlist* - Specifies list of options to control activation, deactivation, and failover mode.

If this option is not specified, the zone is created, by default, with failover enabled, and the zone will be activated. This operand is supported only with the --*create* and --*add* options.

Valid values for optlist are:

- a Activates the specified zone.
- *d* Deactivates the specified zone.
- *n* Disables failover mode.

**Commands:** The cfgenable command is required to commit all commands.

Example 15-6 shows the creation of a TI zone called "bluezone."

Example 15-6 Creation of TI zone

```
IBM SAN384B 213:FID128:admin> zone --create -t ti "bluezone" -p "1,19;
1,56; 1,57; 2,92; 2,85; 2,21"
IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA fab1" is in effect
Updating flash ...
IBM SAN384B 213:FID128:admin> zone --show
Defined TI zone configuration:
TI Zone Name:
               bluezone
Port list:
                1,19; 1,56; 1,57; 2,92; 2,85; 2,21
Configured Status: Activated / Failover-Enabled
Enabled Status: Activated / Failover-Enabled
The zone -- remove command allows the removal of previously defined ports in
```

Example 15-7 Removing ports from the TI zone "bluezone"

the TI zone (see Example 15-7).

IBM SAN384B 213:FID128:admin> zone --remove bluezone -p "2,92; 1,57"

```
IBM_SAN384B_213:FID128:admin> cfgenable SiteA_fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteA_fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA fab1" is in effect
```

Updating flash ...

IBM_SAN384B_213:FID128:admin> zone --show
Defined TI zone configuration:

TI Zone Name: bluezone Port List: 1,19; 1,56; 2,85; 2,21

Configured Status: Activated / Failover-Enabled Enabled Status: Activated / Failover-Enabled

To add ports to the TI zone, use **zone** --add (see Example 15-8).

Example 15-8 Adding ports to TI zone

IBM_SAN384B_213:FID128:admin> zone --add bluezone -p "2,92; 1,57" IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1 You are about to enable a new zoning configuration. This action will replace the old zoning configuration with the current configuration selected. If the update includes changes to one or more traffic isolation zones, the update may result in localized disruption to traffic on ports associated with the traffic isolation zone changes Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no] у zone config "SiteA fab1" is in effect Updating flash ... IBM SAN384B 213:FID128:admin> zone --show Defined TI zone configuration: TI Zone Name: bluezone Port List: 2,92; 1,57; 1,19; 1,56; 2,85; 2,21 Configured Status: Activated / Failover-Enabled Enabled Status: Activated / Failover-Enabled

If you want to disable failover, use the commands in Example 15-9.

Example 15-9 Adding ports to TI zone and disabling failover

```
IBM_SAN384B_213:FID128:admin> zone --add -o n "bluezone" -p "2,92"
IBM_SAN384B_213:FID128:admin> zone --show
Defined TI zone configuration:
```

TI Zone Name: bluezone Port List: 2,92; 1,19; 1,56; 2,85; 2,21 Configured Status: Activated / Failover-Disabled Enabled Status: Activated / Failover-Enabled IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1 You are about to enable a new zoning configuration. This action will replace the old zoning configuration with the current configuration selected. If the update includes changes to one or more traffic isolation zones, the update may result in localized disruption to traffic on ports associated with the traffic isolation zone changes Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no] y zone config "SiteA fab1" is in effect Updating flash ... IBM SAN384B 213:FID128:admin> zone --show Defined TI zone configuration: TI Zone Name: bluezone Port List: 2,92; 1,19; 1,56; 2,85; 2,21 Configured Status: Activated / Failover-Disabled Enabled Status: Activated / Failover-Disabled

In Example 15-8 on page 715 we can see that before enabling zoning we had **"Failover-Enabled"** even though we disabled it in the previous command.

This is correct behavior. Remember to issue the **cfgenable** command always after the **zone** command to force enabled configuration changes.

To enable the failover, run the command with the **zone** --**add** with the option -**o f** as shown in Example 15-10.

Example 15-10 Adding ports to TI zone and enabling failover

```
IBM_SAN384B_213:FID128:admin> zone --add -o f "bluezone" -p "1,57"
IBM_SAN384B_213:FID128:admin> zone --show
Defined TI zone configuration:
```

TI Zone Name: bluezone

Port List: 1,57; 2,92; 1,19; 1,56; 2,85; 2,21

```
Configured Status: Activated / Failover-Enabled
Enabled Status: Activated / Failover-Disabled
```

IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1 You are about to enable a new zoning configuration. This action will replace the old zoning configuration with the current configuration selected. If the update includes changes to one or more traffic isolation zones, the update may result in localized disruption to traffic on ports associated with the traffic isolation zone changes Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no] V zone config "SiteA fab1" is in effect Updating flash ... IBM SAN384B 213:FID128:admin> zone --show Defined TI zone configuration: TI Zone Name: bluezone Port list: 1,57; 2,92; 1,19; 1,56; 2,85; 2,21

```
Configured Status: Activated / Failover-Enabled
Enabled Status: Activated / Failover-Enabled
```

To deactivate the TI zone, use the commands shown in Example 15-11.

Example 15-11 Deactivating the TI zone

```
IBM_SAN384B_213:FID128:admin> zone --deactivate bluezone
IBM_SAN384B_213:FID128:admin> cfgenable SiteA_fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteA_fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA_fab1" is in effect
Updating flash ...
IBM_SAN384B_213:FID128:admin> zone --show
Defined TI zone configuration:
```

TI Zone Name: bluezone
Port List: 1,57; 2,92; 1,19; 1,56; 2,85; 2,21
Configured Status: Deactivated / Failover-Enabled
Enabled Status: Deactivated

To activate the TI zone, use the commands shown in Example 15-12.

Example 15-12 Activating TI zone

IBM SAN384B 213:FID128:admin> zone --activate bluezone IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1 You are about to enable a new zoning configuration. This action will replace the old zoning configuration with the current configuration selected. If the update includes changes to one or more traffic isolation zones, the update may result in localized disruption to traffic on ports associated with the traffic isolation zone changes Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no] у zone config "SiteA fab1" is in effect Updating flash ... IBM SAN384B 213:FID128:admin> zone --show Defined TI zone configuration: TI Zone Name: bluezone Port List: 1,57; 2,92; 1,19; 1,56; 2,85; 2,21 Configured Status: Activated / Failover-Enabled Enabled Status: Activated / Failover-Enabled

Finally, to delete the TI zone, use the commands in Example 15-13.

Example 15-13 Deleting TI zone "bluezone"

IBM_SAN384B_213:FID128:admin> zone --delete bluezone
IBM_SAN384B_213:FID128:admin> cfgenable SiteA_fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with

```
the traffic isolation zone changes
Do you want to enable 'SiteA_fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA_fab1" is in effect
Updating flash ...
IBM_SAN384B_213:FID128:admin> zone --show
Defined TI zone configuration:
no TI zone configuration defined
```

#### 15.3.7 Other zoning CLI commands

**Attention:** Because the TI zone is only part of the defined configuration, the following commands will generate an error if used with a TI zone:

- cfgadd and cfgcreate
- > zonecreate, zoneadd, zonedelete, and zoneremove

Example 15-14 shows the usage of the command zoneshow with the TI zone.

Example 15-14 Usage of zoneshow command with a TI zone

```
IBM_SAN384B_213:FID128:admin> zone --create -t ti "bluezone" -p "1,19;
1,56; 1,57; 2,92; 2,85; 2,21"
IBM SAN384B 213:FID128:admin> cfgenable SiteA fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA fab1" is in effect
Updating flash ...
IBM SAN384B 213:FID128:admin> zone --show
Defined TI zone configuration:
TI Zone Name: bluezone
Port List:
                1,19; 1,56; 1,57; 2,92; 2,85; 2,21
Configured Status: Activated / Failover-Enabled
Enabled Status: Activated / Failover-Enabled
```

#### IBM SAN384B 213:FID128:admin> zoneshow **Defined configuration:** cfg: SiteA fab1 AIX 1 DS4000 A; serverX 1 DS4000 cfg: t_r_a_f_f_i_c_i_s_o_c__fg bluezone zone: AIX_1_DS4000_A AIX 1; DS4000 A zone: bluezone 1,19; 1,56; 1,57; 2,92; 2,85; 2,21 zone: serverX 1 DS4000 serverX 1; DS4000 A zone: t_r_a_f_f_i_c_i_s_o_prop__zn 1,3 alias: AIX 1 10:00:00:00:c9:4c:8c:1c alias: DS4000 A 20:06:00:a0:b8:48:58:a1 alias: serverX 1 10:00:00:05:1e:53:10:8b

#### Effective configuration:

cfg: SiteA_fab1 zone: AIX_1_DS4000_A 10:00:00:00:c9:4c:8c:1c 20:06:00:a0:b8:48:58:a1 zone: serverX_1_DS4000 10:00:00:05:1e:53:10:8b 20:06:00:a0:b8:48:58:a1

As you can see, there is no TI zone in the effective configuration as shown by the **zoneshow** command.

#### Notes:

- The existing commands cfgshow and zoneshow can be used to display TI zones and their members.
- Failover attributes and status will not be displayed.

#### 15.3.8 TI zones with DCFM

You can configure TI zones with DCFM. Click the zoning icon in the DCFM Main Toolbar (see Figure 15-12).

View All - DCFM 10.4.2	
<u>S</u> erver <u>E</u> dit <u>V</u> iew <u>D</u> iscover <u>C</u> o	nfigure <u>M</u> onitor <u>R</u> eports <u>T</u> ools <u>H</u> elp
😰 🖸 🍕 🚳 🎪	Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: Image: I
SAN	oning
View All	0 5 7
All Levels	Name 🕶 🛛 🗸 Firmware 🖉 Devi
🖽 🔘 l EDGE_IBM_B32	EDGE_IBM_B32
E 😑 🔘 🕹 Back Bone_SAN384B	Back Bone_SAN384B

Figure 15-12 Zoning icon in DCFM Main Toolbar

The zoning window displays as shown in Figure 15-13. As you can see, the **New TI Zone** is grayed out and cannot be chosen because of the Alias with WWN which is displayed on the left.

Tip: The TI zone can only be created using D,I (Domain, Index) notation.

nning Scope Back Bone SAN384B	Zone DB Eabric Zone DB ▼ Zone DB 0	neration Zone DB Edit
Image Scope         Back Bone_SAN384B           Discovered fabric data of the selected zoning scope has be           Zone DB         Active Zone Configuration           Allas         Type           Conel_win         Find	Zone DB Fabric Zone DB  Zone DB Zone DB Zone DB Zone DB Zone DB O In changed. Re-open this dialog to obtain the latest information.  Zones Zones Zone DS4700_B_ITSOCLS11  Zone_DS4700_B_ITSOCLS11  ONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOCLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11 ZONE_DS4700_B_ITSOLS11	Zone DB Edit
FCDC 621600] (VWN 20:06:00:A0:B8     DS4700 B_75     FCDC 171600] (VWN 20:07:00:A0:B8     TSO_BTYPE     GFCDC 171300] (VWN 10:00:00:05:1E5     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1     TSO_DS5100_A1      TSO_DS5100_A1     TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1      TSO_DS5100_A1	Image: Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second Second	Report

Figure 15-13 Grayed out menu option, New TI Zone

To create a TI zone, use the notation D,I (Domain, Index) in Figure 15-14.

💱 Zoning									
Zoning Scope	Back Bone_SAN384B	•		Zone DB	Fabric Zone DB	-		Zone DB Operation	Zone DB Edit
Zoning Scope	Back Bone_SAN384B Active Zone Configure Type Do Switch Group B6000_75 B5000_75 B5000_76 ■ BM_2498_R06 BM_2498_R06 BM_SAN384B_27 SAN328-E4-1 ■ E Port Trunk 16 ■ E Port Trunk 17 360100 □ 360200 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500 □ 360500	Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second           Second	Find	Zone DB tones tones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones cones	Pabric Zone DB nthis dialog to obtain D:0517011 (WWN) D:0517011 (WWN) D:05 J:00 A_DS5100A B_WN2K_DS4K SAN384B K_38_d54KEN4st K_38_d54KEN4st K_38_d54KEN4st C_38_d54KEN4st C	Find	st information.	st S4K	Zone DB Edit
Brocade Nativ	e Mode		d	New Zone		:	0	K Cancel	Apply Help

Figure 15-14 Creation of TI zone

We created a TI zone named *Test_TI_zone* based on the D,I notation (adding E_Ports and F_Ports).

A TI zone has its own set of operations and properties. By right-clicking a TI zone, the menu is displayed as in Figure 15-15.

Zoning			_ O ×
Zoning Scope SiteA_fabric1	¥	Zone DB Fabric Zone DB	Zone DB Operation Zone DB Edit
1 The selected ZoneDB has been up	dated. From the ZoneDB Op	perations dropdown menu, use Comp	are to view the details or Refresh to obtain the latest informa
Zone DB Active Zone Config			
Alias Type	Domain,Port Index 💌	∢ P Zones	∢ Zone Configs
All Levels All Levels All Levels All Levels All Levels Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Black Alkoba 217 Bl	Port Type A U-Port U-Port U-Port U-Port U-Port U-Port U-Port U-Port E-Port E-Port E-Port F-Port	a         Image: Aix_1_DS4000_A           Image: Aix_1_DS4000_A         Image: Aix_1_DS4000_A           Image: Aix_1_DS400_A         Image: Aix_1_DS400_A           Image: Aix_1_DS400_A	00_A     Find       SteA_fab1       Activate       ACtivate       Activate       QOSH_ser       QOSL_ADX

Figure 15-15 TI zone menu

The menu shows the possible choices:

- Configured Enabled
- Configured Failover
- Rename
- Delete
- Port Label (port # or port name)
- Properties
- ► Tree (showing options)

The properties dialog box is shown in Figure 15-16.

💱 TI Zone Properties	×
Property	Value
Zone Name	TEST_TI_zone
Total Zone Members	5
Configured Status	Enabled
Configured Failover	Enabled
	OK Cancel Help

Figure 15-16 Properties Dialog Box

The TI zone cannot be added to zone config. A DCFM Message box is displayed as shown in Figure 15-17.



Figure 15-17 Adding TI zone to Zone config

# 15.4 QoS: SID/BID traffic prioritization

SID/DID traffic prioritization allows you to categorize the traffic flow between a given host and target as having a high or a low priority. This feature is based on the IBM/Brocade Virtual Channel Model, which is shown in Figure 15-18.



Figure 15-18 Original Virtual Channel Model(pre condor2/GoldenEye2 ASICs

The key features of this model are as follows;

- It consists of 8 channels (from 0 to 7).
- It applies only to ISLs:
  - Each channel has its own buffer-to-buffer credits.
  - ISL can be part of the trunk group.
- There are four priority levels (0 to 3):
  - Level 0 is the highest priority.
  - Level 3 is the lowest priority.

In this channel, all data of different priorities (channel 2, 3, 4 and 5) can travel the link at the same time. In reality it means that:

- Traffic is not disrupted.
- Traffic will not disrupt other traffic.

For the new 8 Gbps platform/blades, we can also prioritize the traffic on the link by assigning to it priority levels.



The new ASIC (Condor2/GoldenEye2) has 16 Virtual Channels as shown in Figure 15-19.

Figure 15-19 New Virtual Channel Model

The new model in Figure 15-19 has these key features:

- 16 Virtual Channels
- Three priority levels (low, medium, high)
  - High priority gets 60% of total data bandwidth
  - Medium priority gets 30% of total data bandwidth
  - Low priority gets 10% of total data bandwidth

The new Virtual Channel model is used for QoS SID/DID Traffic Prioritization.

#### **Considerations:**

- The switch must run Fabric OS v6.0 or later.
- Hosts and targets must be connected to 8 Gbps capable switches.
- QoS enabled E_Port will form a QoS capable ISL with the neighboring switch only if the connecting E_Port on the neighboring switch is also QoS capable.

The data flow with the priority of high, medium or low depends on the numbers of SID/DID pairs in the Virtual Channel link.

For example, if there is a single low priority flow to a destination ID (DID) and several medium priority flows to that same DID, then it is possible that the medium priority flows would have less bandwidth.

#### 15.4.1 QoS zones

Prioritization is accomplished by the use of QoS zones. A QoS zone is a special zone that indicates the priority of the traffic flow between a given host/target pair:

- ► The members of a QoS zone are WWNs of the host/target pairs.
- QoS zones can contain only WWN members.
- To distinguish the QoS zones from normal WWN zones, special prefixes are used:
  - QOSH_ is used to set high priority.
  - QOSL_ is used to set low priority.
  - The switch automatically sets the priority for the "host, target" pairs specified in the zones based on the priority level in the zone name.
- ► The default setting is medium priority:
  - This setting is used when no QoS zones are specified.

Figure 15-20 shows the QoS zones.



Figure 15-20 QoS zones

Assuming that you want to have a low priority from Server 1 to Storage, and high priority from Server 2 to Storage (as shown in Figure 15-20), set the QoS zones as follows:

- QOSL_Server1_Storage (with members Server1, Storage)
- QOSH_Server2_Storage (with members Server2, Storage)

Where:

QOSL_Server1_Storage, QOSH_Server2_Storage are the names of the zones.

Path selection between the *host, target* pairs is governed by FSPF rules, which means that switch 3 will not take part in the data flow. The considerations for switch 3 are covered in 15.4.2, "QoS E_Ports" on page 728.

**QoS:** QoS can be used for device pairs that exist within the same fabric only. QoS priority information is not passed over EX_ or VEX_Ports and should not be used for devices in separate fabrics.

#### 15.4.2 QoS E_Ports

QoS zoning enables zoning between a given host/target pair that are connected to  $F_Ports$ .

In addition to configuring the hosts and targets in a zone, you must also enable QoS on individual  $E_Ports$  that might carry traffic between the given host and target pairs.

Figure 15-21 shows that two E_Ports are enabled for QoS traffic.



Figure 15-21 QoS with E_Ports enabled

With reference to Figure 15-20:

- You need to enable QoS on the E_Ports on ISL between switch 1 and switch 2.
- You do not need to enable QoS on the E_Ports on the ISLs between switch 1 and switch 3, and between switch 3 and switch 2, because these are not the shortest paths between the hosts and the targets.
  - However, if the ISL between switch 1 and switch 2 is broken, then the path through switch 3 would be used.

This is why you need to enable QoS on all possible E_ports (including ports 0 and 15 on switch 3, port 14 on switch 1 and port 1 on switch 2 (not shown) if you want to guarantee traffic priority.
A QoS enabled E_Port will form a QoS capable ISL with the neighboring switch only if the connecting E_Port on the neighboring switch is also QoS capable. Otherwise, the fabric module will negotiate down or up to non_QoS mode which is medium priority.

For Figure 15-21 on page 728, if the QoS will be not enabled on port 15 of switch 1 or port 0 of switch 2 (or both), the traffic will look as follows:

- Low priority from server 1 to switch 1
- High priority from server 2 to switch 1
- Medium priority from switch 1 to the target devices on Storage.

#### **Considerations:**

- If QoS is not enabled on an E_Port, the traffic prioritization stops at that point and the default of medium priority is used instead.
- You can prioritize flows between devices in a logical fabric. The rules for enabling QoS on E_Ports are the same as for physical fabrics.

# 15.4.3 Supported configurations and limitations

The supported configuration includes the following settings:

- ► Hosts and targets must be connected to 8 Gbps switches:
  - SAN24B-4
  - SAN40B-4
  - SAN80B-4
  - FC8-16, FC8-32, or FC8-48 port blade in the SAN768B and SAN384 backbone switches
- ► For larger fabrics with the intermediate switches:
  - All intermediate switches should be 8 Gbps capable OR
  - Must be running Fabric OS v6.0 or later
- If a host and target are included in two or more QoS zones with different priorities, the zone with the lowest priority takes precedence.
- ► Traffic prioritization is not supported on 10 Gbps ISLs.
- ► Traffic prioritization is not supported on mirrored ports.
- Traffic prioritization is enforced on the egress ports only, not on the ingress ports.

The supported configuration is shown in Figure 15-22. The circled QoS zone will have low or high priority traffic preserved across the fabric.



Figure 15-22 Supported configuration of QoS traffic prioritization

#### 15.4.4 QoS with CLI

Because the QoS zones differ from normal zones only with the prefix in the zone name, use the CLI zoning commands to create QoS zones as described in Chapter 12, "Basic zoning" on page 513.

#### Commands

To enable QoS on a given port, use the command in Example 15-15.

Example 15-15 Enabling QoS on a given port

```
portcfgqos --enable [slot/]<port>
```

To disable QoS on a given port use the command in Example 15-16.

Example 15-16 Disabling QoS on a given port

```
portcfgqos --disable [slot/]<port>
```

To set the configuration to default, use the command in Example 15-17.

Example 15-17 Setting QoS on a given port to default

portcfgqos --default [slot/]<port>

To show the E_Port with QoS enabled, use the command in Example 15-18.

Example 15-18 Showing the port wit QoS enabled

portcfgshow [slot/]/<port>

#### **Real life example**

We disabled the configuration and deleted all zones as shown in Example 15-19.

Example 15-19 Zoneshow

#### Effective configuration:

```
No Effective configuration: (No Access)
```

Now we are adding new zones as shown in Example 15-20.

Example 15-20 Adding QoS zones

```
IBM SAN80B 217:FID128:admin> zonecreate
"QOSH_serverX_1_DS4000_A","10:00:00:05:1e:53:10:8b;
20:06:00:a0:b8:48:58:a1"
IBM SAN80B 217:FID128:admin> zonecreate
"QOSL_AIX_1_DS4000_A","10:00:00:00:c9:4c:8c:1c;
20:06:00:a0:b8:48:58:a1"
IBM SAN80B 217:FID128:admin> zoneshow
Defined configuration:
 zone: QOSH_serverX_1_DS4000_A
                10:00:00:05:1e:53:10:8b; 20:06:00:a0:b8:48:58:a1
 zone: QOSL_AIX_1_DS4000 A
                10:00:00:00:c9:4c:8c:1c; 20:06:00:a0:b8:48:58:a1
               10:00:00:00:c9:4c:8c:1c
 alias: AIX 1
 alias: DS4000 A
                20:06:00:a0:b8:48:58:a1
 alias: serverX 1
                10:00:00:05:1e:53:10:8b
Effective configuration:
No Effective configuration: (No Access)
```

We are adding config "SiteA_fab1" with QoS zones (see Example 15-21).

Example 15-21 Adding config with Qos zones

```
IBM SAN80B 217:FID128:admin> cfgcreate
"SiteA fab1", "QOSH serverX_1_DS4000_A; QOSL_AIX_1_DS4000_A"
IBM SAN80B 217:FID128:admin> zoneshow
Defined configuration:
cfg:
       SiteA fab1
                QOSH serverX 1 DS4000 A; QOSL AIX 1 DS4000 A
 zone: QOSH serverX 1 DS4000 A
                10:00:00:05:1e:53:10:8b; 20:06:00:a0:b8:48:58:a1
 zone: QOSL AIX 1 DS4000 A
                10:00:00:00:c9:4c:8c:1c; 20:06:00:a0:b8:48:58:a1
 alias: AIX 1
               10:00:00:00:c9:4c:8c:1c
 alias: DS4000 A
                20:06:00:a0:b8:48:58:a1
 alias: serverX 1
                10:00:00:05:1e:53:10:8b
Effective configuration:
```

No Effective configuration: (No Access)

The configuration is saved as shown in Example 15-22.

Example 15-22 Saving Configuration

```
IBM_SAN80B_217:FID128:admin> cfgsave
You are about to save the Defined zoning configuration. This
action will only save the changes on Defined configuration.
Any changes made on the Effective configuration will not
take effect until it is re-enabled.
Do you want to save Defined zoning configuration only? (yes, y, no,
n): [no] y
Updating flash ...
```

The configuration is enabled in Example 15-23.

Example 15-23 Cfgenable

```
IBM SAN80B 217:FID128:admin> cfgenable SiteA_fab1
You are about to enable a new zoning configuration.
This action will replace the old zoning configuration with the
current configuration selected. If the update includes changes
to one or more traffic isolation zones, the update may result in
localized disruption to traffic on ports associated with
the traffic isolation zone changes
Do you want to enable 'SiteA fab1' configuration (yes, y, no, n): [no]
y
zone config "SiteA fab1" is in effect
Updating flash ...
IBM SAN80B 217:FID128:admin> zoneshow
Defined configuration:
 cfg:
       SiteA fab1
                QOSH serverX 1 DS4000 A; QOSL AIX 1 DS4000 A
 zone: QOSH serverX 1 DS4000 A
                10:00:00:05:1e:53:10:8b; 20:06:00:a0:b8:48:58:a1
 zone: QOSL AIX 1 DS4000 A
                10:00:00:00:c9:4c:8c:1c; 20:06:00:a0:b8:48:58:a1
                10:00:00:c9:4c:8c:1c
 alias: AIX 1
 alias: DS4000 A
                20:06:00:a0:b8:48:58:a1
 alias: serverX 1
                10:00:00:05:1e:53:10:8b
Effective configuration:
 cfg:
       SiteA fab1
 zone: QOSH serverX 1 DS4000 A
                10:00:00:05:1e:53:10:8b
                20:06:00:a0:b8:48:58:a1
 zone: QOSL AIX 1 DS4000 A
                10:00:00:00:c9:4c:8c:1c
                20:06:00:a0:b8:48:58:a1
```

# 15.4.5 Web Tools and QoS Zones

You can check the status and enable/disable QoS on the port as shown in Figure 15-23.

BM_SAN384B_213 - Po	rt Administration	
		Show Basic Mode
FC Ports   GigE Ports	·	
FC Ports Explorer	General SFP Port St	atistics
- 🖲 Port 18	Denema Della Confirme	ation Could Disable Deviatory Could Deviated Disable
- 🖲 Port 19		
- 🖲 Port 20	Enable Trunking Disab	le Trunking Enable NPIV Disable NPIV Port Swap Re-Authenticate
Port 21		
Port 22	<u>Q</u> oS Enable Q <u>o</u> S Disa	ble F-Port Trunking
Port 23	General	
Port 24	Port Number	8/20(0×1D)
Port 25	Port Name	0/23(0/10)
Port 26	Port WWN	20:dd:00:05:1e:94:3e:00
Dert 28	Port Media	sw
Port 29	Port Type	E-Port
- • Port 30	Port protocol	FC
- • Port 31	Allowed Port Type	E-Port,F-Port
- • Port 32	Speed (Gb/s)	N8
- 🖲 Port 33	Speed Configured	Auto-Negotiate
- 🖲 Port 34	Ingress Rate Limit (Gb/s)	Not Initialized
- 🖲 Port 35	QOS Status	Enabled
- 🗩 Port 36	Long Distance Mode	L0:Normal
- 🖲 Port 37	Desired Distance (km)	N/A
— 🖲 Port 38	Port Status	Online
<ul> <li>Port 39</li> </ul>	Controllable	Yes
- 🔍 Port 40	Licensed	Yes
- 🕑 Port 41	Hearth David Instance	Heatthy 2014(0-DD)
- 🕑 Port 42	Trucking Epobled	221(0x00)
- 🕑 Port 43	EC Fact Write Epobled	false
-  Port 44	Trunk Port State	Macter
Port 45	Master Port	221
Port 46	Trunk Index	
Port 4/		
1999999999999999999		

Figure 15-23 Enabling QoS on the port

To create QoS zones, choose **Manage**  $\rightarrow$  **Zone admin** and follow the rules for zone administration (see Figure 15-24). Zone administration is covered in Chapter 12, "Basic zoning" on page 513.

Zanin u Marlan	Basic Zones	
Pagia Zapag	Print Edit View Zoning Actions	
Basic Zones		
Traffic Isolation Zones	New * Resource view * * * Refresh * Enable Config s	save config Clear All
	Alias Zone Zone Config	
	Name QOSH_serverX_1_DS4000_A   New Zone Delete I	Rename Clone
	AIX_1_DS4000_A	Zone Members
	I I I I I I I I I I I I I I I I I I I	2 Members.
	UWWNs (6 Devices)	E 🔯 WWNs (2 Members)
	I ⊡ Aliases(3 Members)	Symbios Logic Inc.
		Brocade commanie
	Add Member >>	1
	<< <u>R</u> emove Member	
	Add Other	
		-

Figure 15-24 Creating QoS zones with Web Tools

# 15.4.6 DCFM and QoS zones

DCFM provides convenient access to change the priority of the QoS zone, which can be set with a right-click menu option, as shown in Figure 15-25.



Figure 15-25 QoS priority With DCFM

You can change the priority of the normal zone. In this case, DCFM adds the prefix QOSX to the zone name, where X denotes the priority:

- ► H for High priority
- L for Low priority

As you can see in Figure 15-26, we changed the priority to *Low* for the zone AIX_1_DS4000_A_Test. The zone name was changed to QoSLAIX_1_DS4000_A_Test.



Figure 15-26 Changing priority to low for normal zone "AIX_1_DS4000_A_Test"

# 16

# **Performance monitoring**

Basic performance monitoring tasks are available on all IBM/Brocade SAN products. These tasks include basic statistics, such as port throughput, switch throughput, utilization, and error count. With the purchase of the Advanced Performance Monitoring licensed feature, you can perform more advanced tasks, such as:

- End-to-end monitoring
- Filter-based monitoring
- ► ISL monitoring
- Top Talkers monitoring
- Tracking the SCSI commands rate
- SCSI versus IP traffic statistics

You can administer performance monitoring through either Telnet commands, Web Tools, or DCFM. However, many of the advanced monitoring tasks are only available through the command-line interface CLI (Telnet).

In this chapter we provide an overview of performance monitoring and how to use Basic and Advanced Performance Monitoring features.

# 16.1 Performance monitoring with Web Tools

The Web Tools Performance Monitor task provides real-time information about basic performance parameters, such as switch and port throughput, switch utilization, and port error rate. The Advanced Performance Monitor licensed feature adds additional monitoring capabilities in Web Tools, such as SID/DID throughput, SCSI read and write statistics, SCSI versus IP traffic, and AL_PA error rate.

To access Performance Monitor, click the **Performance Monitor** task in the Tasks panel (see Figure 16-1).



Figure 16-1 Performance Monitor task

The Performance Monitoring window opens, as shown in Figure 16-2.



Figure 16-2 Performance Monitoring window

When the window opens, the Switch Throughput Utilization graph displays on the canvas. You can add the performance monitors in which you are interested. In Figure 16-3, several performance graphs are added. The canvas holds a maximum of eight graphs. All the graphs show real-time information and are updated every 30 seconds.

You can print the graph by right-clicking inside it and selecting **Print** on the pop-up menu (see Figure 16-3).



Figure 16-3 Printing Canvas

When you add the graphs that you want to monitor, it is possible to save the current layout of canvas to the switch by selecting **File**  $\rightarrow$  **Save Current Canvas Configuration** on the menu bar. Provide the name and description for canvas configuration (Figure 16-4), and then click **Save Canvas**.

Save Canva	s Configuration	×		
Name	IBM_SAN384B			
Deservition		_		
Description	DN BM_SAN384B_30.07.2009			
	Save Canvas Cancel			

Figure 16-4 Save canvas configuration

The canvas configuration is saved to the switch.

You can load the saved canvas configurations by selecting File  $\rightarrow$  Display Canvas Configurations on the menu bar. The Canvas Configuration List opens, as shown in Figure 16-5.

🕌 Canvas Configuration	List for IBM_SAN384B_213	
Canvas Name	Description	
IBM_SAN384B	IBM_SAN384B_30.07.2009	
	Lood Edit Come Dome	Class

Figure 16-5 Canvas Configuration List

Select one of the saved canvas configurations, then click **Load**. The graphs display on the canvas.

Apart from loading the canvas configuration, you can also **Edit** or **Copy** it, as shown in Figure 16-6.

🕌 Performance M	onitor Canvas: IBM	_SAN384B		×	
Please select a Gra	aph that you wish to	edit:			
Port Throughput,SI	ot=2,Port=28				
Port Throughput,Sl	ot=2,Port=20				
Blade Aggregate Th	nroughput,Slot=2				
SCSI Read/Write p	er port,Slot=2,Port=2	8			
SCSI Read per por	t,Slot=8,Port=28				
<u>S</u> ave	Edit	<u>A</u> dd	<u>R</u> emove	<u>C</u> ancel	

Figure 16-6 Edit canvas configuration

# 16.2 Basic Performance Monitoring

With Basic Performance Monitoring, you can measure the parameters according to Table 16-1.

Basic performance	Description
Port Throughput	Displays the performance of a port in bytes/second for frames received and transmitted
Switch Aggregate Throughput	Displays the aggregate performance of all ports on a switch
Switch Throughput Utilization	Displays the port throughput at the time the sample is taken
Port Error	Displays a line of CRC errors for a given port
Switch Percent Utilization	Displays the percentage of usage of a chosen switch at the time the sample is taken
Port Snapshot™ Error	Displays the CRC error count between sampling periods for all the ports on a switch

Table 16-1 Basic performance monitoring parameters

# 16.2.1 Basic Performance Monitoring with Web Tools

The Basic Performance Monitors are standard in Web Tools and do not require any additional license. You can access these monitors by clicking **Performance Graphs**  $\rightarrow$  **Basic Monitoring** on the menu bar (Figure 16-7).

🔤 S	Switch1 - Performance Monitoring			
<u>F</u> ile	Performance Graphs Window			
	Basic Monitoring	₽	Port Throughput	
	Advanced Monitoring	•	Switch Aggregate Throughput	
			Switch Throughput Utilization	
			Port Error	
			Switch Percent Utilization	
			Port Snapshot Error	

Figure 16-7 Basic performance monitors

The following graphs are available:

- Port Throughput
- Switch Aggregate Throughput
- Switch Throughput Utilization
- Port Error
- Switch Percent Utilization
- Port Snapshot Error

The SAN768B, SAN384B backbones and SAN256B director contain one additional option: the Blade Aggregate Throughput graph.

We explain these graphs in the following sections.

#### 16.2.2 Throughput examples

In this section we describe several types of throughput.

#### **Port Throughput**

For the Port Throughput graph, you first need to specify the port to monitor (see Figure 16-8). Either enter the port number in the field, or drag and drop it from the port selection list on the left. Then, click **OK** to continue.

Port Throughput Setup	×
Slot/Port Selection List         ● Port27 - index # 91         ● Port28 - index # 92         ● Port29 - index # 93         ● Port30 - index # 94         ● Port31 - index # 95         ● Slot3         ● Slot6         ● Slot8	Enter/drag slot,port
	<u>O</u> K <u>C</u> ancel

Figure 16-8 Port Throughput Setup

The Port Throughput graph displays on the canvas, as shown in Figure 16-9.



Figure 16-9 Port Throughput graph

We are copying files to the storage and the port 2/28 is connected to storage. As you can see, the rate of Bytes Transmitted are much bigger than the rate of Bytes Received which is correct.

#### **Blade Aggregate Throughput**

The Blade Aggregate Throughput graph is only available on the SAN768B, SAN384B, and SAN256B. It allows you to display a graph of total throughput for a certain blade. To use this graph, you need to select the blade, and then the graph displays on the canvas as shown in Figure 16-10.



Figure 16-10 Blade Aggregate Throughput for slot 2

We still copy the file to storage and the blade is on the core switch, which is connected to storage. There is no difference in Bytes Transmitted and Bytes Received, which is also correct (comparing to port throughput). The explanation is as follows:

- We have two switches in the fabric:
  - Edge switch with the servers connected
  - Core switch with the storage connected

- We have two trunked connections between two switches but only one of the connection goes to slot number 2.
  - This is why we are receiving on blade 2, 50 MBps from our servers.
  - The other 50 MBps is received by blade number 8 (see Figure 16-11).



Figure 16-11 Blade Aggregate Throughput for slot 8

The storage is connected only to slot 2, which causes the following results:

- ▶ In Figure 16-11 you can see:
  - Transmit rate to Storage 100 MB
  - Receive rate from Servers 50 MB
- You can observe that the receive rate from servers is 50 MB but all the traffic from slot 8 is routed to storage connected to slot 2.

Keep in mind that this is the overall Blade Throughput so it counts *all* the traffic to/from a particular blade. This is why graphs for the total blade throughput differ from port throughput.

We describe this situation in further detail in 16.3, "Advanced Performance Monitoring" on page 753.

# Switch Aggregate Throughput

The Switch Aggregate Throughput graph shows the real-time total throughput on all switch ports, as shown in Figure 16-12.



Figure 16-12 Switch Aggregate Throughput graph

The RX and TX values are the same because they are gathered for the overall switch, and are not split between blades in slot 2 and 8.

#### **Switch Throughput Utilization**

Figure 16-13 shows an example of the Switch Throughput Utilization graph on a SAN32B-3. This graph shows the throughput on each switch port at the time the sample is taken. Because the SAN256B and the SAN768B can have a very large number of ports, the graph displays the throughput for each slot on these two products.



Figure 16-13 Switch Throughput Utilization graph

You can customize the graph by right-clicking inside it and choosing **Select Ports**. A window displays (shown in Figure 16-14) that allows you to select the ports that you want to see on the graph.

Edit Switch Throughput Utilization			×
Port Selection List	Add > < <u>Remove</u> ADD ALL Ports >> << <u>Remove ALL Ports</u> Add all availat < <u>Searcn</u>	Port Selection List	
	Reset To Default	Cancel Apply	

Figure 16-14 Edit Switch Throughput Utilization

# Port Error

The Port Error graph shows the number of CRC errors for the selected port. To use the graph, you must select the port. Then, the actual graph displays. You can use the graph to detect and troubleshoot ports that are not performing up to expectations.

#### **Switch Percent Utilization**

The Switch Percent Utilization graph looks similar to the Switch Throughput Utilization graph, but the utilization information is displayed in percentages. You can select the ports to be displayed on the graph by right-clicking in the graph, then choosing **Select Ports**.



Figure 16-15 shows an example of the Switch Percent Utilization graph.

Figure 16-15 Switch Percent Utilization graph

#### **Port Snapshot Error**

The Port Snapshot Error graph shows the number of CRC errors that have occurred in the last sampling period for all the ports. On the SAN256B, SAN768B, and SAN384B, the number of CRC errors per slot is displayed. As with other similar graphs, you can customize the ports that you want to see displayed.



Figure 16-16 shows the Port Snapshot Error graph for SAN384B.

Figure 16-16 Port Snapshot Error graph for SAN384B

# 16.3 Advanced Performance Monitoring

Advanced Performance Monitoring is the licensed feature that provides comprehensive tools for monitoring the performance of the networked storage resources. This feature provides the following benefits:

- ► Supports direct-attach, loop, and switched FC SAN topologies
- Monitors transaction performance from source to destination (end-to-end monitoring)
- ► Reports Cyclic Redundancy Check (CRC) error measurement statistics
- ► Measures ISL performance and resource usage

# 16.3.1 Virtual Fabrics considerations

**Attention:** For Virtual Fabrics, each logical switch can have its own set of performance monitors. The installation of monitors is restricted to the ports that are present in the respective logical switch.

The number of logical switches that can be configured with monitors is also restricted, as we can see in Table 16-2.

Platform	Maximum number of logical switches supported	Maximum number of logical switches on which monitors are supported
SAN768B	8	4
SAN384B	8	4
SAN40B-4	3	3
SAN80B-4	4	3

Table 16-2 Number of logical switch that supports performance monitors

# **16.3.2 Performance Monitors**

Advanced Performance Monitoring provides the following monitors:

- ► End-to-End monitors measure the traffic between a host/target pair.
- Filter-based monitors measure the traffic transmitted through a port with specific values in the first 64 bytes of the frame.
- ISL monitors measure the traffic transmitted through an Inter Switch Link (ISL) to different destination domains.
- Top Talkers monitors measure the flows that are major consumers of bandwidth on a switch or port.

The type of monitors supported depends on the ASIC. Table 16-3 shows the monitors supported on different switches.

Product	EE	FILTER	ISL	Top Talker
SAN24B-4,SAN80B-4	YES	YES	NO	YES
SAN256B	YES	YES	YES	YES
SAN40B-4, SAN768B, SAN384B	YES	YES	NO	YES

 Table 16-3
 Monitors to Product support table

We describe each of these monitors in the following sections.

# 16.3.3 Displaying Performance Monitors with the CLI

The command **perfmonitorshow** with the syntax shown in Example 16-1 displays end-to-end (EE), filter-based (FLT), and inter switch link (ISL) performance monitors on a port.

Example 16-1 perfmonitorshow command

perfmonitorshow --class monitor_class [slotnumber/]portnumber [interval]

We refer to this command when we describe each of the performance monitors.

#### 16.3.4 SID/DID Performance Monitor

End-to-end performance monitoring counts the number of words in Fibre Channel frames for a specified Source ID (SID) and Destination ID (DID) pair. An end-to-end performance monitor includes these counts:

- RX_COUNT (words in frames received at the port)
- TX_COUNT (words in frames transmitted from the port)

An end-to-end monitor must be configured on the specific port, specifying the SID-DID pair (in hexadecimal).

Frames: The monitor counts only those frames with matching SID and DID.

Each SID or DID has the following three fields:

- ► Domain ID (DD)
- Area ID (AA)
- ► AL_PA (PP)

For example, the SID 0x213000 denotes: DD=0x21, AA=0x30, PP=0x00.

**Traffic:** End-to-end performance monitoring looks at traffic on SID/DID pairs in any direction.

In Figure 16-17 we show where to add end-to-end monitors on a port.



Figure 16-17 Setting end-to-end monitors on a port

The rules are as follows:

- ► For direction of traffic on SID/DID pairs:
  - Traffic on SID/DID pairs can be in any direction.
  - If the traffic is monitored in both directions, the Tx/Rx counters are reversed.
- ► When monitoring the traffic from Server to Storage:
  - Add monitor 0 on port 0 on switch 1.
  - Specify SID as 0x021300 and DID as 0x015c00.
  - For monitor 0,RX_COUNT is the number of words from Server to Storage, and TX_COUNT is the number of words from Storage to Server.

**Word counts:** It can be confusing as to why RX_COUNT is the number of words from Server to Storage. RX_COUNT means received words. But we are sending the words from Server to Storage. When you look from the point of view of port 0, it becomes clear. Port 0 is receiving the words from the server, and port 0 is the one from which you need to look at your traffic.

- When monitoring the traffic from Storage to Server:
  - Add monitor 1 on port 15 on switch 2.
  - Specify SID as 0x015c00 and DID as 0x021300.
  - For monitor 1, RX_COUNT is the number of words from Storage to Server, and TX_COUNT is the number of words from Server to Storage.

In Figure 16-18 we show the RX/TX dependency for the Server to Storage monitor.



Figure 16-18 RX/TX dependency for Server to Storage monitor

We have monitor 0 established for port 0 switch 1 for Server to Storage traffic as shown in Figure 16-18:

- The Server transmits frames.
- Port 0 receives frames (RX_COUNT)
  - For frames received at the port with the end-to-end monitor installed, the frame SID is the same as "SourceID" and the frame DID is the same as "DestID".
  - The RX_COUNT is updated accordingly.
- Port 0 transmits frames(TX_COUNT)
  - For frames transmitted from the port with the end-to-end monitor installed, the frame DID is the same as "SourceID" and the frame SID is the same as "DestID".
  - The TX_COUNT updated accordingly.

For our simple scenario as shown in Figure 16-18, when we copy one large file from Server to Storage with Monitor 0 enabled, we can observe the following numbers:

- ► RX_COUNT = 100 MB: Sending file from Server to Storage.
- ► TX_COUNT = 100 KB: Receiving confirmations from Storage to Server.

You can see the graphs of the previous example in "SID/DID Performance using Web Tools" on page 758.

If we have more than two switches, Figure 16-19 shows the correct placement of the end-to-end performance monitors.



Figure 16-19 Placement of the end-to-end monitors

As we can see, the rules are the same as for the two-switch configuration.

#### SID/DID Performance using Web Tools

Prior to displaying the actual graph, the SID/DID Performance Setup window opens, as shown in Figure 16-20.

SID/DID Performance Setup			
Port or Sid/Did Selection List		Enter/drag port number	
Ports All Devices		Port Number 19	
Port6 - index # 6			
Port7 - index # 7		<u>F</u>	≀etri
Port8 - index # 8		Current EE monitors set for Port19 - index # 19	
Port9 - index # 9		Source ID 🔺 Destination ID	_
Port10 - index # 10		021300 015-00	
Port11 - index # 11		021300 013000	
Port12 - Index # 12			
Port13 - Index #13			
Port14 - Index # 14			
Port15 - Index # 15     Port16 index # 16			
Port17 - index # 17		[1	_
Port18 - index #11			
F- Port19 - index # 19	Add Sid>	Enter/drag SID number(Hex)	
- (1) Id(021300)			
Port20 - index # 20		SID Number 021300	
Port21 - index # 21			
Port22 - index # 22	Add Did>	Enter/drag DID number(Hex)	
🗕 💿 Port23 - index # 23 💌		DID blumber 015e00	
·]			
			_

Figure 16-20 SID/DID Performance Setup window

Complete the Port, SID, and DID number fields as appropriate by either entering the values or dragging them from the selection list on the left. Then, click **OK**.

Alternatively, you can display a list of currently configured end-to-end (EE) monitors for the selected port by clicking **Retrieve preset EE monitors**. You can use the list of current EE monitors to select one or more EE SID/DID pairs. If you select multiple pairs, then a separate graph displays for each pair.

Next, in Figure 16-21, you can see the implementation of the scenario shown in Figure 16-18 on page 757, when we copy one large file from Server to Storage, having Monitor enabled as shown in Figure 16-20 on page 758.

The peaks on the graph Figure 16-21 show the time when the file is transmitted from Server to Storage.



Figure 16-21 SID/DID Performance graph (Server to Storage monitor)

Figure 16-22 shows that TX/RX counters are reversed because we measure the traffic from Storage to Server on the storage site FC switch and we exchanged SID/DID ports. The command to do this is shown in Example 16-3 on page 761.



Figure 16-22 SID/DID Performance graph (Storage to Server monitor)

#### SID/DID using the CLI Adding SID/DID monitors

To add the Performance Monitor, do the following steps:

- 1. Connect to the switch and log in as admin.
- 2. Monitor the traffic from Server to Storage as shown in Example 16-2.

Example 16-2 Adding SID/DID monitor from Server to Storage

```
IBM_SAN80B_217:FID128:admin> perfaddeemonitor 19 0x021300 0x015c00
End-to-End monitor number 0 added.
IBM_SAN80B_217:FID128:admin> perfmonitorshow --class EE 19
There are 1 end-to-end monitor(s) defined on port 19.
KEY SID DID OWNER_APP TX_COUNT RX_COUNT OWNER_IP_ADDR
0 0x021300 0x015c00 TELNET 0x0000000000000b 0x0000000000423 N/A
```

 To monitor the traffic from Storage to Server enter the command as shown in Example 16-3. Example 16-3 Adding SID/DID monitor from Storage to Server

IBM_SAN384B_213:FID128:admin> perfaddeemonitor 2/28 0x015c00 0x021300 End-to-End monitor number 0 added.

IBM_SAN384B_213:FID128:admin> perfmonitorshow --class EE 2/28

There are 1 end-to-end monitor(s) defined on port 92.

KEY SID DID OWNER_APP TX_COUNT RX_COUNT OWNER_IP_ADDR

0 0x015c00 0x021300 TELNET 0x000000000000429 0x0000000000001b N/A

**Monitor:** The monitor must be placed properly for the **perfAddEEMonitor** command to work successfully.

#### **Deleting SID/DID monitors**

We show how to delete the monitor in Example 16-4.

Example 16-4 Deleting SID/DID monitor

```
IBM_SAN80B_217:FID128:admin> perfdeleemonitor 19 0
End-to-End monitor number 0 deleted
```

#### 16.3.5 End-to-end monitoring with DCFM

End-to-end monitors persist in the database and are enabled on one of the F_ports on the connected switch.

You can use these monitors to view both real time and historical performance data.

**Licenses:** Both the initiator switch and the target switch must have Performance Monitor licenses configured to create an end-to-end monitor.

To establish End-to-end monitors, choose **Select Monitor**  $\rightarrow$  **Performance**  $\rightarrow$  **End-to-End Monitors**.

The Set End-to-End Monitors dialog box displays (see Figure 16-23).



Figure 16-23 End-to-End Monitors dialog

An End-to-end Monitor consists of two pairs (see rounded rectangles in Figure 16-23).

You can select either an Initiator or Target and DCFM will automatically search for its counterpart.

You can display end-to-end monitors pairs in a real-time graph, historical time graph, and refresh them (see the rounded rectangles in the right corner in Figure 16-23). If you deleted end-to-end monitors with CLI or Web Tools, you can rewrite them back to the switch by using the **Refresh** button.

#### 16.3.6 Filter-based performance monitoring

Filter-based monitoring allows you to count the number of frames with a particular pattern on a certain port. There is a set of predefined standard filters, and you can also configure custom-defined filters. Examples of standard filter-based monitors are the SCSI read or write commands count and the IP traffic frames count.

The maximum number of filters on most IBM/Brocade SAN products is 12 per port, in any combination of standard filters and user-defined filters. Some exceptions include certain entry-level SAN switches (where the maximum is eight filters per port) and the FC4-48 port blade on SAN256B. FC4-48 supports the following maximum values:

- Ports 0 through 15 support a maximum of 12 filter monitors per port, and 15 offsets per port for used defined monitors.
- Ports 16 through 31 have a maximum of 6 filter monitors per port, and 11 offsets per port for used defined monitors.
- ► Ports 32 through 47 do not support filter monitors.

#### Notes:

- ► For trunked ports, the filter is configured on the trunk master.
- For Virtual Fabrics, filter-based monitors are not supported on logical ISLs (LISLs), but are supported on ISLs and extended ISLs (XISLs).

#### Adding standard filter-based monitors using CLI

This section describes how to add standard filter-based monitors to a port. Use the Telnet commands listed in Table 16-4 to define filter-based monitors on a port.

Command	Description	
perfAddReadMonitor	Count the number of SCSI Read commands	
perfAddWriteMonitor	Count the number of SCSI Write commands	
perfAddRWMonitor	Count the number of SCSI Read and Write commands	
perfAddSCSIMonitor	Count the number of SCSI traffic frames	
perfAddIPMonitor	Count the number of IP traffic frames	

 Table 16-4
 Add filter-based monitor commands

Example 16-5 adds several filter monitors to port 19 on the switch SAN80B.

Example 16-5 Adding filter monitors to a port on switch SAN80B

```
IBM_SAN80B_217:FID128:admin> perfaddreadmonitor 19
SCSI Read filter monitor #0 added
IBM_SAN80B_217:FID128:admin> perfaddwritemonitor 19
SCSI Write filter monitor #1 added
IBM_SAN80B_217:FID128:admin> perfaddrwmonitor 19
SCSI Read/Write filter monitor #2 added
IBM_SAN80B_217:FID128:admin> perfaddscsimonitor 19
```

SCSI traffic frame monitor #3 added IBM_SAN80B_217:FID128:admin> perfaddipmonitor 19 IP traffic frame monitor #4 added

In Example 16-6 we add several filter monitors to port 19 on the switch SAN384B.

Example 16-6 Adding filter monitors to a port on switch SAN384B

```
IBM_SAN384B_213:FID128:admin> perfaddreadmonitor 2/28
SCSI Read filter monitor #0 added
IBM_SAN384B_213:FID128:admin> perfaddwritemonitor 2/28
SCSI Write filter monitor #1 added
IBM_SAN384B_213:FID128:admin> perfaddrwmonitor 2/28
SCSI Read/Write filter monitor #2 added
IBM_SAN384B_213:FID128:admin> perfaddscsimonitor 2/28
SCSI traffic frame monitor #3 added
IBM_SAN384B_213:FID128:admin> perfaddipmonitor 2/28
IBM_SAN384B_213:FID128:admin> perfaddscsimonitor 2/28
SCSI traffic frame monitor #4 added
```

#### **Displaying filter-based monitors**

Use the **perfMonitorShow** --class FLT command to see the list of configured filters on a switch port, as shown in Example 16-7 through Example 16-10.

Example 16-7 Displaying a list of filter-based monitors on switch SAN80B

IBM_SAN80B_217:FID128:admin> perfMonitorShow --class FLT 19

There are 5 filter-based monitors defined on port 19.

KEY	ALIAS	OWNER_APP	FRAME_COUNT	OWNER_IP_ADDR
0	SCSIRead	TELNET	0x00000000000000000	N/A
1	SCSIWrite	TELNET	0x0000000000000000	N/A
2	SCSIR/W	TELNET	0x0000000000000000	N/A
3	SCSIFrame	TELNET	0x00000000008ed45	N/A
4	IPFrame	TELNET	0x00000000007fa9c	N/A

Example 16-8 Displaying a list of filter-based monitors on switch SAN80B with 5 second interval

IBM_SAN80B_217:FID128:admin> perfMonitorShow --class FLT 19 5

Showing filter monitors 19, 5
0	1	2	3	4
#Frames	#Frames	#Frames	#Frames	#Frames
0	0	0	0	0
0	0	0	12k	12k
0	0	0	12k	12k
0	0	0	12k	12k
0	0	0	12k	12k
0	0	0	12k	12k
0	0	0	12k	12k
0	0	0	13k	13k
0	0	0	12k	13k
0	0	0	12k	13k
0	0	0	12k	12k

Example 16-9 Displaying a list of filter-based monitors on switch SAN384B

IBM_SAN384B_213:FID128:admin> perfMonitorShow --class FLT 2/28

There are 5 filter-based monitors defined on port 92.

KEY	ALIAS	OWNER_APP	FRAME_COUNT	OWNER_IP_ADDR
0	SCSIRead	TELNET	0x0000000000026c31	N/A
1	SCSIWrite	TELNET	0x000000000024f18	N/A
2	SCSIR/W	TELNET	0x000000000022c08	N/A
3	SCSIFrame	TELNET	0x000000000836664	N/A
4	IPFrame	TELNET	0x00000000007eef7a	N/A

Example 16-10 Displaying a list of filter-based monitors on switch SAN384B with 5 second interval

IBM_SAN384B_213:FID128:admin> perfMonitorShow --class FLT 2/28 5

Showing filter monitors 92, 5

0	1	2	3	4
#Frames	#Frames	#Frames	#Frames	#Frames
0	0	0	0	0
6.3k	6.3k	6.3k	202k	208k
6.5k	6.5k	6.5k	210k	217k
6.4k	6.4k	6.4k	207k	214k
6.2k	6.2k	6.2k	201k	207k
6.4k	6.4k	6.4k	206k	213k

6.4k	6.4k	6.4k	206k	212k
6.9k	6.9k	6.9k	223k	230k
6.5k	6.5k	6.5k	210k	217k
6.4k	6.4k	6.4k	207k	214k
6.4k	6.4k	6.4k	207k	214k

#### **Custom filter-based monitors**

In addition to the standard filters (SCSI read or write, SCSI, or IP frame count), you can create custom filters to qualify frames for statistics gathering to fit your own special requirements.

When using the custom filter-based monitors, you need to have knowledge of the FC frame structure because you must specify a series of *offsets, masks, and values*. We show the FC frame in Figure 16-24.

4	24	0-2112	4	4
Start of Frame	Frame Header	Data	CRC	End of Frame

Figure 16-24 FC frame

The rules are as follows:

- ► The value of the offset must be between 0 and 63, in decimal format.
- ► Byte 0 indicates the first byte of the Start of Frame (SOF),
- Byte 4 is the first byte of the frame header,
- Byte 28 is the first byte of the payload (Data).

Only the following items can be selected as part of a filter definition:

- ► SOF
- Frame header
- First 36 bytes of payload (Data)

The following actions are performed by switch for all transmitted frames:

- 1. The byte in the frame at the specified offset is located.
- 2. The mask is applied to the byte found in the frame.

- 3. The value is compared with the given values in the **perfAddUserMonitor** command.
- 4. If a match is found, the filter counter is incremented.

On most IBM/Brocade SAN products, you can specify up to 15 different offsets for each port, and up to four values to compare against each offset. Certain entry level switches support up to seven different offsets per port.

# Adding custom filter-based monitors using the CLI

Follow these steps:

- 1. Connect to the switch and log in as admin.
- 2. Enter the perfaddusermonitor command as shown in Example 16-11.

Example 16-11 perfaddusermonitor command syntax

```
perfaddusermonitor [slotnumber/]portnumber "grouplist" [ alias ]
```

Where:

- ► Slotnumber for bladed systems only; specifies the slot number of the port.
- Portnumber specifies the port number.
- Grouplist specifies up to six sets of offset, mask, and value.
- ► Alias is an optional name for the monitor.

Example 16-12 shows how to add a filter-based monitor for SOFi3 to a port.

Example 16-12 Adding a filter-based monitor

```
switch:admin> perfaddusermonitor 1/4 "0, 0xff, 6"
User monitor #1 added
```

Where:

- ► 1/4 slot/port number
- 0 offset
- 0xff mask
- ► 6 value

The predefined values for SOF for Example 16-12 (offset 0) are described in Table 16-5.

Table 16-5 Predefined values at offset 0

Value	Start Of Frame (SOF)	Description
0	SOFf	SOF Fabric
1	SOFc1	SOF Connect Class 1
2	SOFi1	SOF Initiate Class 1
3	SOFn1	SOF Normal Class 1
4	SOFi2	SOF initiate Class 2
5	SOFn2	SOF Normal Class 2
6	SOFi3	SOF Initiate Class 3
7	SOFn3	SOF Normal Class 3

#### **Deleting filter-based monitors**

To delete a filter-based monitor, first list the valid monitor numbers using the **perfMonitorShow** --class FLT command, then use the **perfDelFilterMonitor** command to delete a specific monitor. If you do not specify the monitor number to delete, you are asked if you want to delete all entries as shown in Example 16-13 and Example 16-14.

Example 16-13 Deleting monitors on switch SAN384B

```
IBM_SAN384B_213:FID128:admin> perfdelfiltermonitor 2/28
This will remove ALL monitors on port 92, continue? (yes, y, no, n):
[no] y
IBM_SAN384B_213:FID128:admin> perfMonitorShow --class FLT 2/28
Filter Monitor is not present
```

Example 16-14 Deleting monitors on switch SAN80B

```
IBM_SAN80B_217:FID128:admin> perfdelfiltermonitor 19
This will remove ALL monitors on port 19, continue? (yes, y, no, n):
[no] y
```

# 16.3.7 ISL performance monitoring

ISL monitoring counts traffic to all reachable destination domains through an ISL. You can use the output to identify the destination domain consuming the largest portion of bandwidth. In contrast with end-to-end and filter-based monitors, you do not have to add these monitors because Fabric OS v4.4.0, ISL monitoring is enabled on E_Ports automatically. **Support:** ISL monitoring is not supported on the newer ASIC, which includes the SAN24B-4, SAN40B-4, SAN80B-4, SAN768B, and SAN384B.

Use the **perfMonitorShow** --class ISL command to display the ISL traffic counters, as shown in Example 16-15.

Example 16-15 ISL monitor display

SAN32B_3:admin> per	fMonitorShow	class ISL	1	
Total transmit cour Number of destinati Number of ports in	t for this IS on domains mo this ISL: 1	L: 16904 nitored: 2		
Domain 2:	16904	Domain	4:	0

You can clear the ISL counters with the **perfMonitorClear** --class ISL command.

# 16.3.8 Top Talker monitors

The Top Talker feature is an enhancement to Advanced Performance Monitoring end-to-end monitors. They differ from end-to-end monitors in the following ways:

- ► End-to-end monitors cannot determine the "busiest" SID/DID pairs.
- Top Talkers monitors determine which SID/DID pairs are the major users of switch F_Port bandwidth.
- ► Top Talkers can be enabled on specific switch E_Ports or F_Ports.

The comparison between Top Talkers and end-to-end monitors is shown in Table 16-6.

Top Talkers	End-to-End Monitors
All possible SID/DID flow on a given port.	Single SID/DID pair.
Can monitor up to 10000 flows. If there are more flows than the H/W resources can support, the Top Talker samples traffic by looking at a new 256/2048 flows every second and extrapolates the measurement.	Can fail if number of flows exceeds the hardware resources: Condor - 256 flows Condor2 - 2048 flows

Table 16-6 Top Talker versus End-to-End Monitors

**Data:** Top Talkers data is available after an initial stabilization period, which is the time taken by a flow to reach the maximum bandwidth:

- 14 seconds in the SAN384B, SAN768B, SAN40B-4, SAN80B-4, and SAN24B-4
- ▶ 82 seconds in the SAN256B

You use the Top Talkers monitors to identify the SID/DID pairs that consume the highest amount of bandwidth across a particular port or the entire switch. If the total amount of traffic is within acceptable limits, then this information might not be that important. However, when the traffic amount exceeds the acceptable bandwidth, then the information from Top Talkers monitors can be effectively used to take actions such as these:

- Traffic can be routed to less busy ports, in order to reduce the load on a particular port.
- The SID/DID pairs identified as the top bandwidth consumers can be configured with appropriate Quality of Service (QoS) attributes, so that their communication flow will receive adequate priority.

The Top Talkers monitors were introduced in Fabric OS v6.0.0. When you enable the Top Talkers monitor on a port, it remains persistent across switch power cycles.

Top Talkers monitoring operates in one of the following two mutually exclusive modes:

- Port mode: In port mode, the Top Talkers monitor is installed on an F_Port and counts the traffic through that port. You can monitor either incoming (ingress) or outgoing (egress) traffic.
- Fabric mode: In fabric mode, the Top Talkers monitors are installed on all E_Ports in the fabric. They monitor and count the traffic of all possible SID/DID pairs and can therefore identify the top bandwidth consumers on a switch.

#### **Top Talkers:**

- ► The Top Talkers monitors measure the ingress E_Port traffic only.
- For Administrative Domains, the Top Talkers monitors are always installed in AD255.

# 16.3.9 Top Talkers monitors in port mode

A set of commands is available to add, delete, and display Top Talkers monitors operating in port mode. They are explained in the following sections.

### Adding a Top Talkers monitor

To add a Top Talkers monitor to an F_Port, use the perfttmon --add command:

► For incoming traffic (receive, or RX) see Example 16-16.

Example 16-16 Adding Top Talkers for ingress traffic

perfttmon --add ingress [slot/]/<port>

► For outgoing traffic (transfer, or TX) see Example 16-17.

Example 16-17 Adding Top Talkers for egress traffic

```
perfttmon --add egress [slot/]/<port>
```

#### **Deleting a Top Talkers monitor**

To delete a Top Talkers monitor, use the **perfttmon** --delete command. See Example 16-18.

Example 16-18 Deleting Top Talkers Monitor

```
perfttmon --delete [slot/]<port>
```

### **Displaying Top Talkers monitor information**

Use the **perfttmon** --show command to display Top Talkers information for a particular slot/port. See Example 16-19.

Example 16-19 Showing Top Talkers Monitors

```
perfttmon --show [slot]/<port> [ww|pid] [# of TT flows]
where:
wwn|pid - Specifies the output display as either WWN or PID format.
This operand is optional. If omitted, the command displays in WWN
format.
```

# of TT flows - Specifies "n" top talking flows. Valid values are between 1 and 32. If a value greater than 32 is entered, Top Talker displays counters for only 32 flows and a warning message. This operand is optional; if omitted, the command displays the top 8 flows. **Installation:** Top Talkers is installed on an F_Port to measure the traffic originating from the F_Port and flowing to different destinations. The output displays the data in a sorted order based on the data rate of each flow.

## **Real life example**

See Figure 16-25 and follow the scenario that we have implemented.



Figure 16-25 Real life example

Figure 16-25 shows the configuration with two servers and one storage device:

- Server 1 (WWWN of HBA:10:00:00:c9:4c:8c:1c)
- Server 2 (WWWN of HBA:10:00:00:05:1e:53:10:8b)
- Storage (WWWN of HBA: 20:06:00:a0:b8:48:58:a1)

In this configuration, Top Talkers Monitors can be configured differently, although not every configuration will bring the desired results:

- On the port 19 Domain 1 Switch, it will not bring the desired results because on port 19 there is only one talker (server 1).
- ► On the port 63 Domain 1 switch, there is also only one talker (server 2).
- On the port 2/28 Domain 2 switch, there is the proper placement of Top Talker; on that port both servers are talking to the storage.

Both servers are copying files to Storage 1. First we added the monitor for egress traffic on slot 2 port 28. This is very important to properly choose ingress/egress settings. See Example 16-20.

Example 16-20 Setting Top Talkers Monitors for egress traffic on a port

perfttmon --add egress 2/28

Example 16-21 shows the TopTalkers members on port 2/28.

Example 16-21 Showing Top Talkers on port (WWN and PID

IBM_SAN384B_	_213:FID128:ad	min> perfttmonshow 2/28		
Src_WWN		Dst_WWN	MB/sec	
20:06:00:a0: 20:06:00:a0	:b8:48:58:a1 :b8:48:58:a1	10:00:00:00:c9:4c:8c:1c 10:00:00:05:1e:53:10:8b	87.859 52.106	
IBM_SAN384B_	_213:FID128:ad	min> perfttmonshow 2/28	pid	
Src_PID	Dst_PID	MB/sec		
0x025c00 0x025c00 IBM SAN384B	0x011300 0x013f00 213:FID128:ad	90.353 49.585 min>		

The SID/DID numbers shown in Example 16-21 are described in detail in 16.3.4, "SID/DID Performance Monitor"

To delete the monitor, enter the command in Example 16-22.

Example 16-22 Deleting Top Talkers monitor

```
IBM_SAN384B_213:FID128:admin> perfttmon --delete 2/28
IBM_SAN384B_213:FID128:admin> perfttmon --show 2/28 5
TT Monitor is not present
```

If you enable Top Talkers monitor on port 2/28 for Incoming traffic, the results might not be the ones you are expecting (see Example 16-23).

Example 16-23 Setting Top Talkers monitor for ingress traffic on a port

IBM_SAN384B_213:FID128:admi IBM_SAN384B_213:FID128:admi	n> perfttmonadd ingress 2 n> perfttmonshow 2/28	2/28
Src_WWN D	st_WWN	MB/sec

20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1 IBM_SAN384B_213:FID128:ad	10:00:00:00:c9:4c:8c:1c 10:00:00:05:1e:53:10:8b min> perfttmonshow 2/28	0.072 0.002
Src_WWN	Dst_WWN	MB/sec
20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1	10:00:00:00:c9:4c:8c:1c 10:00:00:05:1e:53:10:8b	0.073 0.003

The traffic rate is correct because we are measuring the traffic from the storage, and the storage only sends the confirmation to both servers. We still copy files from servers to storage in this example.

# 16.3.10 Top Talkers monitors in fabric mode

Top Talkers monitors in fabric mode are mutually exclusive with Top Talkers monitors in port mode. When you enable fabric mode, you cannot add any Top Talkers monitor to F_ports. In addition, fabric mode Top Talkers monitors cannot coexist with any end-to-end monitors. Therefore, make sure that you delete the End-to-end monitors first.

#### Adding Top Talkers monitors on all switches in the fabric

To add fabric mode Top Talkers monitoring, use the command in Example 16-24.

Example 16-24 Adding Top Talkers Monitor on all E_Ports in the fabric

perfttmon --add fabricmode

You are reminded to remove all end-to-end monitors with the following message:

Before enabling fabric mode, please remove all EE monitors in the fabric.

continue? (yes, y, no, n):

If there are no end-to-end monitors in the fabric, continue by typing **y**. The command completes successfully if the local switch has no end-to-end monitors defined. If a remote switch does have end-to-end monitoring enabled, the command stills work on the local switch, but fabric mode fails on remote switch.

If you add a new switch to the fabric, the fabric mode Top Talkers configuration is not applied on it automatically. There is no automatic propagation. You must use the **perfTTmon --add fabricmode** command on the new switch.

#### Deleting Top Talkers monitors in fabric mode

To delete all E_Ports Top Talkers monitors, use the command in Example 16-25.

Example 16-25 Delete all E-Port Top Talkers monitors in the fabric

perfttmon --delete fabricmode

#### Displaying Top Talkers monitors on a switch

To display a list of Top Talkers on a switch, use the command in Example 16-26.

Example 16-26 Displaying Top Talkers Monitors in fabric mode

```
perfttmon --show dom domainid [n] [wwn|pid]
where:
dom - Specifies the domain ID for the flow display
```

n - Specifies "n" Top Talking flows. Valid values are between 1 and 32. If a value greater than 32 is entered, Top Talker displays counters for only 32 flows and a warning message. This operand is optional; if omitted, the command displays the top 8 flows.

wwn|pid - Specifies display as either WWN or PID format. This operand is optional; if omitted, the command displays in WWN format.

#### Real life example continued

Example 16-27 shows how to enable fabric mode Top Talkers monitoring.

Example 16-27 Fabric mode TopTalkers

<pre>continue? (yes, y, no, n): [no] y IBM_SAN384B_213:FID128:admin&gt; perfttmonshow dom 1 IBM_SAN384B_213:FID128:admin&gt; perfttmonshow dom 1 Src_WWN Dst_WWN MB/sec Potential E-Ports 20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000 57 56 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 57 56</pre>	IBM_SAN384B_213:FID128:admin> perfttmonadd fabricmode Before enabling fabric mode, please remove all EE monitors in t fabric	he	
<pre>IBM_SAN384B_213:FID128:admin&gt; perfttmonshow dom 1 IBM_SAN384B_213:FID128:admin&gt; perfttmonshow dom 1 Src_WWN Dst_WWN MB/sec Potential E-Ports 20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000 57 56 20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 57 56</pre>	continue? (yes, y, no, n): [no] y		
<pre>IBM_SAN384B_213:FID128:admin&gt; perfttmonshow dom 1 Src_WWN Dst_WWN MB/sec Potential E-Ports 20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000 57 56 20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 57 56</pre>	IBM_SAN384B_213:FID128:admin> perfttmonshow dom 1		
Src_WWN Dst_WWN MB/sec Potential E-Ports20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.00057 5620:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000920:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000920:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.00057 56	IBM_SAN384B_213:FID128:admin> perfttmonshow dom 1		
20:06:00:a0:b8:48:58:a110:00:00:05:1e:53:10:8b0.000575620:06:00:a0:b8:48:58:a110:00:00:05:1e:53:10:8b0.000920:06:00:a0:b8:48:58:a110:00:00:00:c9:4c:8c:1c0.000920:06:00:a0:b8:48:58:a110:00:00:00:c9:4c:8c:1c0.0005756565756	Src_WWN Dst_WWN MB/sec Potential E-Ports		
20:06:00:a0:b8:48:58:a1       10:00:00:05:1e:53:10:8b       0.000       9         20:06:00:a0:b8:48:58:a1       10:00:00:00:c9:4c:8c:1c       0.000       9         20:06:00:a0:b8:48:58:a1       10:00:00:00:c9:4c:8c:1c       0.000       57       56	20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000	57	56
20:06:00:a0:b8:48:58:a1 10:00:00:c9:4c:8c:1c 0.000 9 20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000 57 56	20:06:00:a0:b8:48:58:a1 10:00:00:05:1e:53:10:8b 0.000	9	
20:06:00:a0:b8:48:58:a1 10:00:00:c9:4c:8c:1c 0.000 57 56	20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000	9	
	20:06:00:a0:b8:48:58:a1 10:00:00:00:c9:4c:8c:1c 0.000	57	56

In Example 16-28 you can see the results for traffic for the Domain 2 switch, which is a core switch.

Example 16-28 Showing core switch Top Talkers

IBM_SAN384B_213:FID128:ad	min> perfttmonshow dom	n 2
Src_WWN Potential E-Ports	Dst_WWN	MB/sec
10:00:00:00:c9:4c:8c:1c 10:00:00:00:c9:4c:8c:1c 10:00:00:05:1e:53:10:8b 10:00:00:05:1e:53:10:8b	20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1 20:06:00:a0:b8:48:58:a1	53.474 2/20 2/21 53.471 8/29 10.885 8/29 9.604 2/20 2/21

You can delete the monitor as shown in Example 16-29.

Example 16-29 Deleting Fabric Mode Tap Talkers monitor

```
IBM_SAN384B_213:FID128:admin> perfttmon --delete fabricmode
IBM_SAN384B_213:FID128:admin> perfttmon --show dom 2
TT Monitor is not present
```

For this simple example, we can see that the results are different for the particular domains:

- Domain 1 switch has a very low transfer on E_Ports, because there is no data passing through to the E_Ports in Domain 1.
- Domain 2 has a large data flow on the E_Ports, because this is a core switch and the E_Ports receive data from the edge switch.

Remember: Top Talkers monitors measure ingress E_Port traffic only.

#### 16.3.11 Top Talkers monitoring considerations

Be aware of the following considerations regarding Top Talkers monitoring:

- Top Talker monitors cannot detect transient surges in traffic through a given flow.
- You cannot install a Top Talker monitor on a mirrored port.
- A Top Talker can monitor only 10,000 flows at a time.
- ► A Top Talker is not supported on VE_Ports, EX_Ports, and VEX_Ports.
- The maximum number of F_Port Top Talker monitors on an ASIC is 8. If Virtual Fabrics is enabled, the maximum number of F_Port Top Talker monitors on an ASIC is 4.

# 16.3.12 Trunk monitoring

If you want to monitor trunks, you can set the monitor only on the master port. The monitor will automatically move to a new master port, if it changes. Also, if a monitor is installed on a port which later becomes a subordinate port in the trunk, that monitor will move to the master port.

Note the following considerations:

- End-to-end monitors are not supported for ISLs.
- For F_Port trunks, end-to-end masks are allowed only on the F_Port trunk master. Unlike the monitors, if the master changes, the mask does not automatically move to the new master port.
- SAN24B-4 supports eight filter-based monitors for trunks.
- The SAN40B-4, SAN80B-4, SAN256B, SAN384B, SAN768B platforms support 12 filter-based monitors for trunks.

Recent enhancements in Web Tools provides the trunk bidirectional bandwidth, throughput and utilization of trunk as shown in Figure 16-26.

	ch Administration						
							Show Advanced Mo
witchName: hell	lo	DomainID: 2	00(0xC8) WWN:	10:00:00:05:1e:55:66:	85	Tue Mar	09 2010 14:48:35 GMT+
Switch Netv	vork Firmware Down	nload License Us	er Trunking				
Trunk Group	Master Port	Member Ports	Trunk Index	Trunk Type	Bandwidth	Throughput	Utlization (%)
1	8	8,9,11,10	N/A	E Trunk	64 Gbps	2.1432 Gbps	3.8985
							Close Refresh
							Close Refresh
vitch Administr	ation opened]: Tue Mar	09 2010 14:47:35 GMT+0	10:00				Close Refresh

Figure 16-26 Trunk enhancements

# 16.3.13 Saving and restoring the monitoring configuration

You can save the current setup of end-to-end and filter monitors in the non-volatile memory on the switch by using the **perfCfgSave** command. This action overwrites the previously saved performance monitoring settings, so you are asked for confirmation.

If you want to apply the saved configuration, enter the **perfCfgRestore** command. This command overwrites the currently active performance monitoring configuration, and you are again asked to confirm the action.

Finally, you can clear the saved performance monitoring configuration in the non-volatile memory using the **perfCfgClear** command.

As the space in non-volatile memory is limited, the number of monitors saved is also limited as follows:

- Up to 16 end-to-end monitors per port can be saved.
- Up to 16 filter monitors per port can be saved.
- ▶ Up to 512 monitors per switch will be saved.
- If there are more than 512 monitors configured on the switch, the end-to-end monitors are saved first.

Memory: Monitors created by Web Tools are not saved in persistent memory.

# 16.4 SCSI commands with Web Tools

The SCSI Commands monitor shows the total number of read or write commands per switch port or per specific LUN on switch port. Figure 16-27 shows the available graph choices.



Figure 16-27 SCSI Commands monitor

If you select a graph showing the number of commands per port, you are prompted to specify the port number, as shown in Figure 16-28.

SCSI Read/Write per port Setup	×
Slot/Port Selection List         Port27 - index # 91         Port28 - index # 92         Port29 - index # 93         Port30 - index # 94         Port31 - index # 95         Slot6         Slot7         Slot8	Enter/drag slot,port
	<u>O</u> K <u>C</u> ancel

Figure 16-28 SCSI Read/Write per port Setup window

If you select any of the graphs displaying the number of commands on a LUN per port, then you need to enter the port number and also the LUN number (see Figure 16-29).

Figure 16-29 SCSI Read/Write on a LUN per port Setup

# 16.4.1 SCSI versus IP traffic

The SCSI versus IP Traffic graph monitor is accessible by selecting **Performance Graphs**  $\rightarrow$  **Advanced Monitoring**  $\rightarrow$  **SCSI vs. IP Traffic**.

First, you select the ports that you want to monitor, as shown in Figure 16-30. You add the ports that you want to monitor to the list on the right, and then click **Apply**.

Figure 16-30 SCSI versus IP Traffic Setup window

The graph displays as shown in Figure 16-31.



Figure 16-31 SCSI vs. IP Traffic graph

This graph shows the percentage of IP and SCSI traffic on the current switch on a port basis.

# 16.4.2 ALPA error

This feature is available only on the older switches based upon the Bloom Application Specific Integrated Circuit (ASIC). Thus, we do not discuss it here.

# 16.5 Bottleneck detection

A bottleneck in the fabric is where frames cannot get through as fast as they should. In other words, a bottleneck is a port where the offered load is greater than the achieved egress throughput. These features detect two types of bottleneck detection.

# 16.5.1 Latency bottleneck

A port at which the offered load exceeds the rate at which the other end of the link can continuously accept the traffic, even if the physical link capacity is not exceeded. This can impact the other devices in the fabric sharing the link.

# 16.5.2 Congestion bottleneck

A port that is unable to transmit the frames at the offered rate because the offered rate is greater than physical data rate of the link.

In Fabric OS v6.3.x, bottleneck detection was configured on a per-port basis. Starting in Fabric OS v6.4.0, you configure bottleneck detection on a per-switch basis, with per-port exclusions. This bottleneck feature detects latency and congestion bottlenecks and reports the bottlenecks through RASlog alerts and SNMP traps. You can set alert thresholds for the severity and duration of the bottleneck.

Example 16-30 shows steps to enable bottleneck monitoring, disables alerts on port 1, excludes ports 2, 3, and 4 from bottleneck monitoring, and changes the alert settings on ports 2 and 3. The **bottleneckmon** --status command shows the settings for these ports. Note that this example changes the alert settings on ports 2 and 3, even though they are excluded from bottleneck detection Bottleneck Detection

Example 16-30 Bottleneck monitoring

```
switch:admin> bottleneckmon --enable
switch:admin> bottleneckmon --config -noalert 1
switch:admin> bottleneckmon --exclude 2-4
switch:admin> bottleneckmon --config -alert -lthresh .99 -cthresh .9
-time 4000 -atime 600 2-3
switch:admin> bottleneckmon --status
Bottleneck detection - Enabled
Switch-wide alerting parameters:
_____
Alerts - Yes
Latency threshold for alert - 0.100
Congestion threshold for alert - 0.800
Averaging time for alert - 300 seconds
Quiet time for alert - 300 seconds
Per-port overrides for alert parameters:
Slot Port Alerts? LatencyThresh CongestionThresh Time(s) QTime(s)
```

# 17



In this chapter, we overview the steps that you can take to ascertain the health of the storage area network (SAN) fabric and to troubleshoot problems. We discuss SAN Health, a powerful tool that allows you to collect data and analyze this data for potential issues.

# 17.1 SAN Health

SAN Health is a very powerful tool that helps a SAN administrator or SAN user optimize the existing SAN. The tool allows you to collect data and to analyze this data for potential issues.

SAN Health provides a full status report on your SAN environment by the use of two mechanisms: a back-end reporting processor, and a front-end data collection agent. When the Front End (FE) has completed a scan of the SAN and collected all the appropriate data, the Back End (BE) analyzes this information for potential issues, and produces a Visio topology diagram of the SAN. The BE report covers fabrics, switches individual ports, and historical performance graphs. It also presents some best practice procedures.

# 17.1.1 New features of SAN Health

SAN Health 3.2.0b includes the following new features:

- Improved reporting for all Brocade M-series SAN solutions, including the Brocade Mi10k
- ► The ability to audit switches managed by Brocade EFCM
- Enhanced topology diagram layouts
- More detailed diagnostics information obtained from switches
- A redesign of the report content and layout
- ► FICON enhancements for mainframe environments

# 17.1.2 Implementing SAN Health

In this section, we explain how to download, install, and use SAN Health.

#### **Installing Brocade SAN Health**

To install Brocade SAN Health:

1. Go to the following link and download SAN Health Diagnostic Capture:

http://www.brocade.com/services-support/drivers-downloads/san-health
-diagnostics/index.page

- 2. Unzip InstallSANHealth322.zip and run the file InstallSANHealth322.exe.
- 3. Follow the step-by-step instructions. Figure 17-1 shows the first step to install San Health. Click **Next**.

SAN Health Diagnostics Capture 3.2.2						
Brocade SAN Health	SAN Health Diagnostics Capture 3.2.2					
	Publisher: Brocade Communications Web site: <u>www.brocade.com</u> Email address: <u>SHAdmin@brocade.com</u>					
	Brocade Installer will install or upgrade SAN Health Diagnostics Capture on your computer.					
	Click Next to continue.					
	(c) Brocade, 2001-2010. All Rights Reserved.					
	This program is protected by copyright law and international treaties. Unauthorized reproduction or distribution of this program, or any portion of it, is a violation of applicable laws.					
	< Back Next > Cancel					

Figure 17-1 SAN Health Diagnostics Capture Installation panel

4. The license agreement displays, as shown in Figure 17-2. Read the license agreement. If you agree to the terms of the license, select **I agree to these terms and conditions**, and click **Next**. Otherwise, click **Cancel**.

SAN Health Diagnostics Capture 3.2.2	X
License agreement	Brocade   🤝
Please read the license agreement carefully before continuing.	SAN Health
BROCADE END USER LICENSE AGREEMENT PLEASE READ THIS END USER LICENSE AGREE BEFORE DOWNLOADING, INSTALLING, OR USIN ACCOMPANYING DOCUMENTATION ("Software"), OR USING THE SOFTWARE, YOU ARE AGREEIN AGREEMENT, IF YOU DO NOT AGREE TO ALL O AGREEMENT, PROMPTLY RETURN AND DO NO Single User License. Subject to the terms and condit the applicable license fees, Brocade Communication suppliers grant to you ("End User") a non-exclusive, I Software in object code form solely for the purpose o networking switches. End User may make such bac necessary for End User's lawful use, provided End U copyright, patent, and notices of other proprietary right License in these terms and conditions	MENT ("Agreement") CAREFULLY IG THIS SOFTWARE AND BY DOWNLOADING, INSTALLING, G TO BE BOUND BY THIS IF THE TERMS OF THIS IF THE TERMS OF THIS IT USE THE SOFTWARE. itions of this Agreement and payment of s Systems, Inc. ("Brocade") and its non-transferable license to use the if operating Brocade storage area skup copies of the Software as may be ser affixes to such copies all trademark, hts that appear on the original.

Figure 17-2 SAN Health license agreement

5. In the next panel, you select the installation folder and the audit and working folder. Check if you have enough space (10 MB) to load SAN Health. Click **Install** to install San Health as shown in Figure 17-3.

🛃 SAN Health Diagnostics Capto	ure 3.2.2		X
Installation options		Brocade	
These options determine how the app installed.	olication will be	SAN Heal	th 🖊
Installation folder:			
C:\Program Files\Brocade\SAN Heal	lth		Browse
Completed audit and working folder:			
C:\SAN Health Audits			Browse
Required disk space: Available disk space:	7,696 KB 9,302,832 KB	1	
Brocade Installer	<	Back Install	Cancel

Figure 17-3 SAN Health installation options

**SAN Health:** If there is a previous version of SAN Health installed, the installation wizard will recognize this and will ask for permission to uninstall the older version.

6. Figure 17-4 shows the Installation completed panel. Select **Start the application** to start SAN Health as soon as you click **Finish**.

🛃 SAN Health Diagnostics	Capture 3.2.2
Brocade SAN Health	Installation completed
	SAN Health Diagnostics Capture has been successfully installed on your computer.
	Start the application
	Click Einish to close Brocade Installer
	< Back Finish Cancel

Figure 17-4 SAN Health installation complete

# **Using Brocade SAN Health**

After you have downloaded, decompressed, and installed SAN Health, you can execute it using the desktop icon. The startup panel displays as shown in Figure 17-5. Click **New**.



Figure 17-5 SAN Health startup panel

The interface might ask you to discard the current Audit Set if you are upgrading from a previous version. Depending on your needs, answer **Yes** or **No**.

To use SAN Health:

1. First you have to answer some basic questions in the **Site Details** tab. The information provided will be used on the title page of the SAN Health report. Mandatory fields are marked with an *. See Figure 17-6.

Σ	SAN	N Health Ve	ersion 3	.2.2								- 🛛
	New	📄 🗁 Open	- 🛃 -	5ave	🗈 Options	🗾 FICON		Exit		No Switches S	elected For Audit	🛛 🕐 Help
<b>e</b>	To con	mplete a SAN H	lealth audi	t, first yc	ou need to crea	ate an audit se	et.					
	Step 1) Enter the Site Details, these are used on the title page of the SAN Health report.											
	Step	) 2) Enter the R	eport Retu	rn detail	ls, report proce	ssing is centra	alized at B	rocade	and rep	orts are returned via a secu	ure single sign on web page	e.
	Step	) 3) Name the S	AN that yo	ou are ai	uditing, this is u	used as a title (	on the SA	N Healt	h repor	t and in the report file name		
	Step	4) Enter Switc	h or EFCM	server l	IP Address and	l login credent	tials to ad	d fabrics	to the	audit set.		
	Step	) 5) Click on the	e fabric(s) ir	n the tre	e view to name	e the fabric, er	nter perfor	mance	apture	duration and specify the su	upport provider for the fabri	o. 🔰
	Step	) 6) Ensure that	switch log	in crede	entials are corre	ect and option	ally set th	e Visio ti	pology	diagram position for each :	switch.	
	Step	7) Start the A	udit, click o	on the ''l	Preflight Check	" button. If th	e audit se	t details	have b	een entered correctly the "	'Start Audit'' button is enabl	ed.
	Click o During	on the "Test Co g the connectiv <b>Details</b>	innectivity ity test, fab <b>Report R</b>	and Gel pric mem <b>łeturn</b>	t Switch Detail: bership is dete	s'' button at th rmined and the etails	e SAN, fa e switch i Add Swi	abric or ir s automa it <b>ches</b>	ndividu. atically	al switch levels to gather th moved into the appropriate Fabric Details 28 Sw	is information. fabric container. itch Details    Start	Audit
		1	Salutation*	💿 Mr	OMs∗			Address	1* Gra	in Via, 1	] 💡 Site details are used	d on the title
		F	First Name*	J				Address	2		page of the SAN H	ealth report
		L	.ast Name*	Lainer	n			Ci	ty* Ma	drid		
			Job Title*	IT Arc	hitect		State.	/Provinc	e* No	t Applicable 🛛 👻	-	
			Phone*	0344			Zip/Po	stal Coo	e* 280	)01	1	
		Comp	any Name*	IBM				Count	y* Sp	ain 💌	]	
1	(1) 4:36:02 PM> New SAN Audit Set Started Using SAN Health Version 3.2 (2) 0 Warnings (2) 0 Errors (3) 1 Elnet Activity (2) (2) (2) (2) (2) (2) (2) (2) (2) (2)											

Figure 17-6 SAN Health Diagnostics Capture Site Details tab

2. Go to the **Report Return** tab and fill in an email Address for the report return as in Figure 17-7.

SAN Health Version 3.2.2	
🎦 New 🗁 Open 🛛 🛃 Save 🗈 Options 🛃 FICON 🖾 Exit 🛛 🛛 No Switches Selected For Audit	🕐 Help
💡 To complete a SAN Health audit, first you need to create an audit set.	
Step 1) Enter the Site Details, these are used on the title page of the SAN Health report.	
Step 2) Enter the Report Return details, report processing is centralized at Brocade and reports are returned via a secure single sign on web page.	
Step 3) Name the SAN that you are auditing, this is used as a title on the SAN Health report and in the report file name.	
Step 4) Enter Switch or EFCM server IP Address and login credentials to add fabrics to the audit set.	
Step 5) Click on the fabric(s) in the tree view to name the fabric, enter performance capture duration and specify the support provider for the fabric.	
Step 6) Ensure that switch login credentials are correct and optionally set the Visio topology diagram position for each switch.	
Step 7) Start the Audit, click on the "Preflight Check" button. If the audit set details have been entered correctly the "Start Audit" button is enabled.	
While creating an audit set, SAN Health needs to connect to each switch to determine the switch model number and communication capabilities.	
Click on the "Test Connectivity and Get Switch Details" button at the SAN, fabric or individual switch levels to gather this information.	
During the connectivity test, fabric membership is determined and the switch is automatically moved into the appropriate fabric container.	
🔲 Ciu, Dura Ja, 🔯 Banari Bahwa 💭 Cali Dura Ja 🖉 Add Curin Lau 🖤 Eulais Dura Ja 🔊 Curint Dura Ja 📐 Chura A	
Site Details 🗗 Treport Tretuin   💯 SAN Details   🎤 Add Switches   🌇 Fabric Details   Z Switch Details   🕨 Start At	1010   
Optional - Send a duplicate of the completed report to the following people?	
A Brocade staff member you are working with Email Address	
Email* lainen@ibm.com	
Retype Email* lainen@ibm.com	
👔 4:36:02 PM> New SAN Audit Set Started Using SAN Health Version 3.2 🍂 0 Warnings 👩 0 Errors 🕮 Telnet Activitu 💋	
	الكار التكر
1	

Figure 17-7 Report Return tab

**Reports:** You can also send the report to additional readers by checking one of the check boxes to the right. If no check box is checked, only the email address provided will be used for returning the report.

3. Now, add the switches or fabrics into the data collection engine. Start by naming the SAN on the *SAN Details* tab as shown in Figure 17-8.

SAN Health Version 3.2.2	
🎦 New 🛛 🗁 Open 🛛 🚽 Save 🛛 🖹 Options 🛛 💆 FICON 🛛 🖾 Exit 🔹 💦 No Switches Selected For Audit	🕐 Help
SAN Name Fabric Name Switch IP Address Switch World Wide Name Visio Layer Model Number Domain Switch Name	
📕 Site Details   🔂 Report Return 😂 SAN Details   🔎 Add Switches   🎬 Fabric Details   😕 Switch Details   🕨 Start Au	ıdit
Name the SAN being Audited IBM SAN	
LEGEND: W Fabric - A group of one or more Fabrics W Fabric - A group of one or more interconnected switches Incomplete Data - One or more values is missing - An audit can NOT be conducted Complete Data - All required data has been entered - An Audit may proceed Tested - Connectivity and Login Credentials have been tested - An Audit may proceed	and stails
1 4:36:02 PM> New SAN Audit Set Started Using SAN Health Version 3.2 🔥 0 Warnings 🐼 0 Errors 🐴 Telnet Activity	

Figure 17-8 SAN Health Diagnostics Capture SAN Details

New       Open       Save       Options       FICON       Exit       No Switches Selected For Audit       Image: Help         SAN Name       Fabric Name       Switch IP Address       Switch World Wide Name       Visio Layer       Model Number       Domain       Switch Name         SAN Name       Fabric Name       Switch IP Address       Switch World Wide Name       Visio Layer       Model Number       Domain       Switch Name         IBM       SAN       SAN       San       San       San       San
SAN Name Fabric Name Switch IP Address Switch World Wide Name Visio Layer Model Number Domain Switch Name
I Site Details 🕥 Benort Beturn 😳 SAN Details 🔑 Add Switches 😾 Fabric Details 🎘 Switch Details 🕨 Start Audit
Connect Directly To Switches     Switch IP address     10     18     228     17
Connect to Switches Via an EFCM Server Login Name admin
Password Connect to the switch to add it to the Audit set
the Options menu.
👔 4:36:02 PM> New SAN Audit Set Started Using SAN Health Version 3.2 🧥 0 Warnings 🛛 8 0 Errors 🖣 Telnet Activity 🖉 🔲 🗊

4. Next, add your switches using the *Add Switches* tab (Figure 17-9).

Figure 17-9 SAN Health Diagnostics Capture Add Switches



The software will start looking for the switches, as show in Figure 17-10.

Figure 17-10 Adding a switch

5. On the *Fabric* tab, provide details about the fabric. Then test the connectivity as shown in Figure 17-11.

SAN Health Version 3.2.2			<b>I</b>
🌇 New   🗁 Open   🛃 Save   🗈 Options   🖉	写 FICON 🛛 🔯 Exit	8 Switches Se	lected For Audit 🛛 😢 Help
SAN Name Fabric Name Switch IP Address Swit	itch World Wide Name	/isio Layer Model Number	Domain Switch Name
E			
E VOW Test Fabric 1			
2 10.18.228.17 10:	:00:00:05:1e:76:86:80	Automatic 8000	10 B8000_17
🖃 🐨 🐨 🏧 Test Fabric 2			
<b>₩₩₩</b> 10.18.228.31 10:	:00:00:05:1e:c3:be:29	Automatic 7800	1 IBM_2498_R06
<b>₩₩</b> 2 10.18.228.18 10:	:00:00:05:1e:b0:81:80	Automatic 8000	5 switch
10.18.228.27 10:	:00:00:05:1e:94:3a:00	Automatic DCX-4S	16 IBM_SAN384B_27
10.18.229.77 10:	:00:00:05:1e:90:16:e9	Automatic Unknown	23 B5000_75
10.18.235.54 10:	:00:00:05:1e:54:17:10	Automatic Unknown	54 SAN32B-E4-1
	:00:00:05:1e:54:16:53	Automatic Unknown	56 SAN32B-E4-2
	:00:00:05:1e:90:16:57	Automatic Unknown	98 B5000_76
📔 Site Details 🔐 Report Return 🖾 SAN Deta	ails 🔎 Add Switches 🏼	🛛 Fabric Details 🛛 😕 Swi	itch Details 📔 🕨 Start Audit 📗
Fabric	Name Test Fabric 1		Test Fabric
Vendor Who Sold or Supports These Sv	witches IBM	~	Connectivity and Get Switch Details
Capture Performance D	ata for 12 Hours	×.	
	8 Hours		Set All Switches To The Same
	12 Hours	*	Password
	18 Hours		
A 50.22 DVA 10.10.220.27 Discoursed Socia-b Nerroy/DM	CANOO 36 Hours		
4:50:32 FM> 10.18.228.27 Discovered Switch Name:IBM_	48 Hours		
9 4.50.32 FM7 logout	Do Not Capture Perfor	mance Data 🚽 🚽 CANDO	MR 27 Model/DCV-49
4.50:33 PMS Telest Activity Complete Hiploching Program	Menus	M28/N36	
<ul> <li>4.30.33 FM2 Teme: Activity complete, onitiocking Program</li> </ul>	monus		×

Figure 17-11 SAN Health Diagnostics Capture Fabric Details

# 6. Go to the Start Audit tab and run the *Preflight check* as shown in Figure 17-12.

SAN Health Version 3.2.2					<b></b>
🎦 New   🗁 Open   🛃 Save   🗈 Option	ns 📑 FICON 🛛 🖾 Exit		8 Switches Se	lected Fo	r Audit 🕜 Help
SAN Name Fabric Name Switch IP Address	Switch World Wide Name	Visio Layer	Model Number	Domain	Switch Name
- VOW Test Fabric 1	10.00.00.05.10.76.96.	on Automotic		10	P0000 17
- V . Test Fabric 2	10.00.00.03.12.76.66.	SO AUCOMACIC	. 8000	10	B0000_17
	10:00:00:05:1e:c3:be:	29 Automatic	. 7800	1	IBM 2498_R06
	10:00:00:05:1e:b0:81:	80 Automatic	8000	5	switch
	10:00:00:05:1e:94:3a:	00 Automatic	DCX-4S	16	IBM_SAN384B_27
	10:00:00:05:1e:90:16:	e9 Automatic	. Unknown	23	B5000_75
	10:00:00:05:1e:54:17:	10 Automatic	unknown	54	SAN32B-E4-1
	10:00:00:05:1e:54:16:	53 Automatic	. Unknown	56	SAN32B-E4-2
	10:00:00:05:1e:90:16:	57 Automatic	unknown	98	B5000_76
📓 Site Details 🛐 Report Return 🖾 SAN	Details	🛛 🎬 Fabric D	etails 🛛 😕 Sw	itch Detai	is 🕨 Start Audit
1) Click on "Preflight Check"					Preflight Check
2) If the check passes Click on "	Start Audit"				
Any items that fail the pre-flight check	k will be displayed with a yellow w	aming icon in the	activitu log		~~~~
Once an audit set has passed the pro-	aflight check, it is a good idea to r	anning iconnin and	dourny log.		Start Audit
	enigric check, icis a good idea (o :	ave the additiset.			
SAN Health can be scheduled of run audit set as a command line argumen	i unattended by using the path an it. For more information on this pla	a name or a previ ease see the help	file.		
(i) 4:50:32 PM> 10.18.228.27 Discovered Switch Name	:IBM_SAN384B_2	<u>∧</u> 4 ₩.	arnings 🛛 🙁 1 E	rors 🏝	Telnet Activity 🕢 🖵 💽 🔼
🎽 🐴 4:50:32 PM> logout					
1:0.18.228.2 (i) 4:50:33 PM> Updating Switch Details IP:10.18.228.2	27 WWN:10:00:00:05:1e:94:3a:0	D Type:Brocade N	lame:IBM_SAN38	34B_27 Mo	del:DCX-4S
4:50:33 PM> Telnet Activity Complete, Unlocking Pro	ogram Menus				~

Figure 17-12 SAN Health Diagnostics Capture Start Audit

If the *Preflight check* did not pass, correct any error and rerun the check until it passes. Normally, you'll get a "green smiley icon" is all the tests are OK, as show in Figure 17-13.

SAN Health Version 3.2.2						- X
🎦 New 🛛 🗁 Open 🛛 🛃 Save 🛛 🖹 Option	is   🛃 FICON   🔯 Exit		8 Switches Se	lected For A	udit	🛛 🕐 Help
SAN Name Fabric Name Switch IP Address	Switch World Wide Name	Visio Layer	Model Number	Domain S	witch Name	в
E IBM SAN						
- VOW Test Fabric 1						
<b>VO2</b> 10.18.228.17	10:00:00:05:1e:76:86:80	Automatic	8000	10 BS	000_17	
	10:00:00:05:le:c3:be:29	Automatic	7800	1 IE	M 2498	R06
10.18.228.18	10:00:00:05:1e:b0:81:80	Automatic	8000		ritch	
₩ 28.27	10:00:00:05:1e:94:3a:00	Automatic	DCX-4S	16 IE	M_SAN38	4B_27
₩ 229.77	10:00:00:05:1e:90:16:e9	Automatic	5000	23 B5	000_75	
₩₩₩₩ 10.18.235.54	10:00:00:05:1e:54:17:10	Automatic	Encrypt:	ion Switch5	4	SAN32B-E4-1
202 10.18.235.56	10:00:00:05:1e:54:16:53	Automatic	Encrypt:	ion Switch5	6 :	SAN32B-E4-2
	10:00:00:05:1e:90:16:57	Automatic	5000	98 BS	000_76	
1						
	[ ]		. [	(	A	• m l
📔 Site Details   🖭 Report Return   😂 SAN	Details   🎤 Add Switches   }	Fabric De	etails   😕 Swi	itch Details	Start	Audit
📿 Ta shad an andi						
1) Click on "Preflight Check"					Preflight (	Check
2) If the check passes Click on "	Start Audit"				ricingit	
Any items that fail the pre-flight check	will be displayed with a vellow warn	ina icon in the	activity log.	_		
Once an audit set has passed the pre	flight check, it is a good idea to say	e the audit set			Start A	udit
SAN Health can be scheduled or run	unattended by using the path and n	ame of a previo	haves ulsus			
audit set as a command line argumen	t. For more information on this please	e see the help l	file.			
A MEC 07 DMs. In a second star (administration of the fee the fee	Lis Tala Falsis O	A 104	(	(B. T. I.	an Alaman II	
4:00.27 PM> Incomplete rabric values exist for the fa     4:56:27 PM> The preflight check failed places see if	ono i estitabrio 2 be activitu log for details	TP IP M	ramings   🛃 I E	nois <b>-</b> Teir	iet Activity	
4:56:49 PM> Starting preflight check failed, please see to	to details					
4:56:49 PM> The preflight check passed.						~

Figure 17-13 Preflight test successfully passed

7. The audit begins when you select Start Audit.

SAN Health gathers data. How long this process takes depends on the *capture performance data interval* that you set on the *Fabric* tab. You can watch the progress of the tool as it completes the checks.

8. Right-clicking a specific switch allows you to view its status details, as shown in Figure 17-14.

SAN Health Version 3.2.2	
🚹 New 📄 Open 🛛 🖬 Save 🔹 Options 🚽 FICON 🔤 Exit 🔹 🚺 Auditing 8 Switches	Help
Click on a switch in this list to view its progress or to stop the audit for that switch.	
8 Sessions started - O Completed - O Failed	
1018 229.78       Diagnostic 5 (Show Details For This Switch         10.18 225.56       Diagnostic 5 (Stop Capture For This Switch         10.18 229.77       Diagnostic 5 (Stop Capture For This Switch         10.18 229.77       Diagnostic 5 (Stop Capture For This Switch         10.18 229.77       Diagnostic 1 of 87 adselect 255         10.18 228.17       Diagnostic 1 of 87 adselect 255         10.18 228.17       Diagnostic 1 of 87 adselect 255         10.18 228.17       Diagnostic 1 of 87 adselect 255         10.18 228.17       Diagnostic 1 of 87 adselect 255	
(1) 4:55:32 PM> 10.18.235.56 Diagnostic 4 of 87 agtorg5how [Stop Telnet Activity] /// 16 Warnings 🔀 1 Errors 🐴 Telnet Activity /// (1) 4:59:32 PM> 10.18.235.54 Diagnostic 5 of 87 aptpolicy	
(1) 4:59:32 PM> 10.18.229.77 Diagnostic 4 of 87 agtcfgShow (1) 4:59:32 PM> 10.18.228.31 Starting Diagnostics	~

Figure 17-14 SAN Health Diagnostics Capture Show Details
If you decide to configure the audit for a long period, you'll see a status of the different checkpoints configured, as you can see in Example 17-15.



Figure 17-15 Status of the audit

9. When this process has completed, the output is an encrypted and compressed file that can be found in the C:\SAN Health Audits\ directory. You can also see the data file in Figure 17-16.



Figure 17-16 SAN Health Diagnostics Capture BSH File created

**Error messages:** In the screen capture, you can see one error message. In our test we stopped the audit in one of the switches to show this screen, and what would happen in case of an error. In a normal audit, you will not see this error message.

10. To complete the process, you have to send the encrypted SAN Health file (.BSH) to the Brocade report generator. You can ether do that by clicking **Send to diagnostic data file to the report generation queue via HTTPS**, sending it as email attachment to SHUpload@brocade.com, or by uploading it manually to the Brocade URL as shown in Figure 17-17.



Figure 17-17 SAN Health Diagnostics Capture where to send the output

11.By return you will receive a link where you can download your analyzed data at the Brocade site as a.zip file. If you have an account at Brocade it will be stored there. If you do not have an account it will be generated automatically. The .zip file will contain two files. One is a Visio connection diagram of the SAN Layout, and the other is a thorough SAN analysis captured into an Excel spreadsheet. You must have Excel loaded on your workstation in order to view this report.

Zip file: Be aware that the .zip file is only available for download for 30 days.

The following figures show a selection of screen captures from this report.

		S	AN S	ими	IAR	ΥD	ETA	ILS F	OR	IBI	M FA	BRIC	>				Table Of Contents
					SWI	TCHE	IS IN S	AN IBN	l Fab	ric							
Fabric Name	9	iwitch Nar	ne	Domair	ı II	P Add	ress	Wa	orld Wi	de Na	ame	Mod	el Sp	beed	OS Ver	Port	s Unused
IBM Fabric	IB	M_2498_B	340	4	10.	.64.21	0.183	10:00	:00:05	:1e:0	9:73:fd	5100	) 8	3G	6.1.0	40	38
	SU	MMARY	FOR 1	I SWIT	CHE	s to	TALIN	G 40 P	ORTS	5 TH	iat ar	E 5%	UTIL	IZE	D		
		Swi	itch Cou	int				Port Co	ount					Port	Use Met	rics	
Fabric Name	16	2G	- 40	G	Fotal	1	G	2G	4G	Т	otal	ISL Port:	s D	evice	es Un	used	Utilization
IBM Fabric	0	0	0	)	1	(	)	0	0		40	2		0		38	5%
				D	EVIC	e co	UNT F	OR ALL	. FAB	RICS	<b>i</b>						
Device Description						C	ount	Device	Descrij	ption							Count
NO DEVICES IN SAN																	
							PORT	USE									
		_	Po	rt Use	_				Fan Ou	ut Rat	tios		P	Port Lo	ong Dista	ince Mo	odes
Fabric Name	Disk	Tape	Host	ISL	Fr	ee	Total	Host: Dis	k Por	tISL	. Device	EISL 10	)km	25kr	n 50kr	n 100	km Auto
IBM Fabric	0	U	0	2		8	40	0:0	1	9:1	0:	2 4	40	0	0	0	0
				BAN	DWIL	лні	JTILIZ	ATION	SIAI	1511	ICS			1			
		Dev 0.05%	/ice Bar	idwidth I	Utilizal	tion (p	er portj				0. 0E8	SL Bandy	vidth l	Utiliza	ation (per	portj	
Estain Marra	Dev.	0 - 25%	25	-/5%	/5-1	00%	Average MD2.	je Max			0 - 25%	25	/5%		5-100% . M	Average MD2.	je Max
IPM Esbrio	Count				0					uni A	<u>2   3</u>					0	
IDM Fablic		0 0			0		NGE G		ev 4	-	2 2	.   0	0			0	0
Eull Eabric	1	L.	/ER TO(	ni si	0	LIGE	MUL U	Zonina	0			Trunking	0			S	
Perf Monitoring	0	E/	abrie Wa	atch	1	F	vtended	Eabric	1		Bernot	e Switch			Se	ecure El	
Quick Loop	0		L2 Upar	ade	0		VL4 U	porade	0		1101110	0 0 1 1 1 0 1				Joaron	
d another apply	-				-	Z0	NING	IETRIC	S _				L				
	Z	one		Aliase	s Stat	istics			Zo	ne St	tatistics				Confia	Statistic	s:
Fabric Name	Datab	ase Use	Aliases	AvMer	n Max	Mem	Hanging	Zones	AvM	em N	MaxMen	n Hangin	q Cor	nfigs	AvMem	MaxMe	em Hanging
IBM Fabric	0.3% (	of 1045k	27	1.3		5	27	8	2.2	2	6	8		4	3.8	6	4

#### Figure 17-18 shows the SAN Health Summary.

Figure 17-18 SAN Health Summary

Figure 17-19 shows a copy of the Visio diagram.



Figure 17-19 SAN Health Visio diagram

If you do not have Visio installed in your workstation, you can download a version called *Visio Viewer* that is free from:

http://www.microsoft.com/downloads/details.aspx?familyid=D88E4542-B174-4198-AE31-6884E9EDD524&displaylang=en

Figure 17-20 shows a fabric-specific summary.

		SW	<b>/ITCH</b>	SUM	MARY	DET	AILS	FOR	IBM_	2498_	B40			Table Of Contents
_				IBM	_2498_	340 IN	FABRIC	IBM FA	BRIC					
Switch Name IE	3M_2498_	B40		Broc	ade Mode	Brocad	e 5100 Sv	vitch		FOS Ver	sion 6.1	.0		
IP Address 1	0.64.210.1	183			WWN	10:00:0	)0:05:1e:0	9:73:fd		FOS Build D	Date Tue	e Mar 11 2	3:05:38 20	)08
FC IP address -					Domain ID	4				Port C	ount 40			
Vendor IE	3M			Ser	ial Number	ALM06	17D001			Unused F	Ports 38			
Switch Status D	OWN			MAI	C Address	-				ISL F	Ports 2			
Active Config F	abricA_Cfg	g		Eth	nernet Port	AUTO				Switch Sp	eed 8G			
Zone DB Use 0.	.3 % of 10	45 kbyte:	s	S	witch Date	Fri May 2 17:18:40 2008 Switch State Online					line			
POST E	nabled			(	QuickLoop	Disable	:d			Switch M	ode Na	tive		
Telnet Timeout 1	0 minutes			Fat	oric Watch	Alarms	are enable	ed		Role in Fa	abric Sub	bordinate		
						CENSE	SUMMA	RY						
Full Fa	bric Yes		WEB T	OOLS No	)		Zoning	No		Trunking	No		SES	No
Perf. Monito	ring No		Fabric \	Watch Ye	es 📃	Extende	ed Fabric	Yes	Ren	note Switch	No	S	ecure FOS	Yes
Quick L	oop No		VL2 Up	igrade -		VL4	Upgrade -							
	P 4.0		B . E .	1.01	1/	U PAR	AMETER	15	_	<b>T</b> : .	10000			
Buffer Cre	edits 16		Data Fiel	d Size 21	12 1	Error Det	ect lime	2000	Resour	ce l imeout	10000		JD Setting	Enable
Port ID M	ode 1		Distance	Mode U		Inter	op Mode	NO	Trans	ative Mode	U	U	LS Setting	NotSel
0.01	11 T				ENVIE	UNME	NTAL SI	ATUS	10.5					
Switch	Uplime			Last B	oot Up At			Powe	red Un F	or		Last Heb	oot Heaso	n
	Days		Caractin	DDM	•	_				- Au CDU Land Dúas ta Audit				
- · -	Fan Statu	SOLITON	speed in	RPM F	-	~   _	n d	ower Su	ppiy Stat	us – Do 4	. L . ⁶	AV LPU LO	ad Prior to	Audit
Fan I Far	12 F	ans	Fan 4	Fan 5	Fan	6 F	13 I	PS Z	P5 3	PS 4		Min t	) Min	15 Min
	N Tee	-	Concern		· ·		UN	Faulty	- Diada T	-	C	.34	0.32	0.27
о С-и 1	Car 2	nperature	Cere 4	C E	0-1-1	01-1-0	01-1-0	Clask	r blade i Clave	emperature	Sensor:	S CI-10	01-1-0	CI-110
C 25	Sen Z	Sen 3	Sen 4	Sens	31001	5100 2	5101.5	51004	5100 3	0 3100.6	51007	3101.8	3100.9	5100 10
L 30	71	00	21	•	· ·	•			· ·	· ·			•	-
F 30	Enulty	Derte	03 Missin	- CED-	Dower C		Temp			dhu Eana	- Derk	Chabus		-
Alerting Policy	Marginal	Down	Marginal	Down	Marginal	Down	Marginal	Doum	Marain	atyrans al Down	Margina	J Down	Marginal	Down
Alerting Folicy	Marginar	10	maryinar	0	1 1 1	1	i Maryinar 1	2000	- Margin				Maryinar	DOWN
Thesholds	4	10	0	0	моміт	BING	AND AL	BUN	G		4	10	-	-
EABBIC WATCH					MONT	Jinna	SYSL OG	SETTIN	22					
Statue	Suelog	Statue	IP Ada	trace 1	IP Add	lease 2	IP Add	JETTIN Trace 2		ddraee A	ID A/	Hdraee 5	ID Add	ross E
enabled	Jysiog	lea			II Add	11633 2		11633 J	1 1 4					1635 0
citablea	1 111	0.96		-		SNMPS	ETTINGS	-	_					
S	witch Des	cription				Switch	Location				Cont	act Informa	ation	
Fib	reChanne	Switch				Endlis	erPremise				F	ieldSunnor	1	
Community St	rings : Se	cretC0de	irw) [	DriaE auio	Mfrfrwi	Inrivatel	rw)	Dubl	ic(ro)	COL	nmon(ro)	F	 ibreChann	elfro)
Access Contro	I ist No	t Configu	red 1	Vot Confir	nured	Not Co	nfigured	Not	Configure	ad Not	t Configu	red N	lot Configu	iied
14 4 🕨 🕅 🖊 🔳	troduction	n 🔏 Sun	nmary 🖌	SAN Port	s 🖌 Visio	) Topolog	gy Diagran	n 🔏 F	_IBM Fa	bric-468a00	) <u>/</u> Z	IBM Fabric	-468a00	<mark>∖s_</mark> IE

Figure 17-20 A fabric-specific summary

## 17.2 Error logs

The b-type family of switches provide multiple sources of error logs and debug data. You can collect these logs from Web Tools or CLI or using automated tools that run when the switch experiences a critical problem. In addition there is also the possibility to collect data to analyze problems related to the DCFM server or client.

Some of these logs are:

- TraceDump: Dumps a copy of its memory and pointers into a trace file.
- ► **RASLOG:** Contains debug data from the switch.
- **supportShow:** Gathers configuration and status information from the switch.

### 17.2.1 Capturing a trace dump

When a switch "panics," depending upon the circumstances, it might produce a trace dump, which can be uploaded automatically to an FTP server when the switch recovers from this failure.

From within Web Tools select the **Switch Admin** interface and expand the view to the switch with **Show Advanced Mode**. The Trace tab allows you to view and configure the FTP host target, enable or disable automatic trace uploads, and update a trace dump manually as shown in Figure 17-21.

Tracing is always on and generates a trace dump whenever there are certain actions within the switch, for example:

- Tracing is triggered manually through the traceDump command.
- A critical level log message occurs.
- A particular log message occurs because the traceTrig command has been used.
- ► A kernel panic occurs.
- A hardware watchdog timer expires.

The trace dump is maintained on the switch until it is uploaded through FTP, or until another trace dump is generated. Be aware that a new trace dump overwrites the previous trace dump.

IS SANDA	2B-E4-2 - S	Switch Ad	ministration								
										Show Ba	sic Mode
SwitchNam	ne: SAN32B-	E4-2		DomainID: 56(0×3	8) VWVN:10	:00:00:05:1e	:54:16:53		Fri Nov (	05 2010 15:54:	31 GMT+00:00
SNMP	Configure	Routing	Extended Fabric	AAA Service	Trace F	CON CUP	Security Po	licies			
Swi	vitch	Ne	rtwork	Firmwa	are Download		Lie	cense	User	Trur	iking
Trace FT	TP Host										
Host IP	10.18.2	235.1			Remote Direct	ory <i>l</i> logs					
User Na	ame joselair	nen			Password	••••	•••••				
Trace Dr	ump Availabi	lity									
Trace di	lumn denerati	ion time: Tue	Oct 19 18:27:00 20	140							
indee de	amp general		0011010.21.0020								
Trace A	Auto FTP Uplo	oaded:									
Auto FTF	P Upload										
🖲 Ens	able 🔿 Dis	able									
									Apply	Close	Refresh
A 7											
[Switch Ad	ministration of	opened]: Fri I	Nov 05 2010 15:53:	31 GMT+00:00							
Enable Auto	- ETP unload			Mode: Advanced	Free Profes	sional Mana	rement Tool	10 18 235 56	AD0 User	r admin   Role	eradmin 🖌 🖌

Figure 17-21 Trace

## 17.2.2 The supportsave command

This command **supportsave** allows the manual upload of the following logs to an FTP server:

- ► RASLOG
- ► TRACEdump
- ► supportshow
- ► zone log
- RCS command log
- ► NS event log
- ► FSPF status log
- Any memory CORE files

The command structure, from the CLI, is as follows:

supportsave [-n] [-c] [-k] [-u] user_name [-p] password] [-h] host_ip
[-d] remote_dir [-I] protocol [-R] [-U] [-t] timeout-multiplier

With the new option **-t** you now have the possibility to extend the timeout value of the command **supportsave**.

Example 17-1 shows partial output from the supportsave command.

Example 17-1 Output from supportsave command

```
SAN32B-E4-1:admin> supportsave
This command collects RASLOG, TRACE, supportShow, core file, FFDC data
and then transfer them to a FTP/SCP server or a USB device.
This operation can take several minutes.
NOTE: supportSave will transfer existing trace dump file first, then
automatically generate and transfer latest one. There will be two trace
dump
files transferred after this command.
OK to proceed? (yes, y, no, n): [no] yes
Host IP or Host Name: 10.18.228.151
User Name: Uwe
Password:
Protocol (ftp or scp): ftp
Remote Directory: .
Saving support information for switch: SAN32B-E4-1, module: RAS...
Saving support information for switch:SAN32B-E4-1, module:CTRACE OLD...
Saving support information for switch:SAN32B-E4-1, module:CTRACE NEW...
Saving support information for switch:SAN32B-E4-1, module:FABRIC...
. . . . . . . . . .
..... (some line delete for a better overview)
. . . . . . . . . .
Saving support information for switch:SAN32B-E4-1, module:MAPS...
Saving support information for switch:SAN32B-E4-1,
module:FABRIC WATCH...
Saving support information for switch:SAN32B-E4-1,
module:DM FTR FFDC...
Saving support information for switch:SAN32B-E4-1, module:PSDUMP...
Saving support information for switch:SAN32B-E4-1, module:CORE_FFDC...
No core or FFDC data files found!
Saving support information for switch:SAN32B-E4-1, module:ENC LOGGER...
Saving support information for switch:SAN32B-E4-1, module:RAS POST...
SupportSave completed.
```

All files will be saved to the directory that you choose during the **supportsave** command as an ftp directory. You have to pack all files in a .zip file and upload it to the support center when needed.

To capture technical support information using DCFM, follow these steps:

1. Select Monitor  $\rightarrow$  Technical Support  $\rightarrow$  Switch / Host Supportsave (Figure 17-22).

💱 IBM Fabric - DCFM 10.4.2		
Server Edit View Discover Configure	Monitor Reports Tools	Help
🔬 🕽 🍕 🗞 🔶 🗃	Performance	Name 🔻 Name 🔻
	Technical Support	Client SupportSave
SAN	Event Policies	Switch / Host SupportSave
IBM Fabric 🔻	Event Notification	Upload Failure Data Capture 🛛 💿 💧
All Levels A	SNMP Setup	⊻iew Repository
🗉 💿 🔿 🎭 Back Bone_SAN384BBack Bo	Syslog Configuration	
🖸 🔳 Host Group	Logs 🕨	
🗄 🔮 崣 Routed Products Grou	I Track Fabric Changes	
🗈 😃 Storage Group	Accept Change(s)	
E 🥯 Switch Group	Port Connectivity	
B5000_75 B5000_	Port Optics (SEP)	v6.4.1 17ff
H	Events	v6.4.1 62ff
- 18M_2498_R06 IBM_249		v6.4.1 01ff

Figure 17-22 Technical Support

2. Select a switch, (as shown in Figure 17-23). You can also choose whether to collect data from more then one switch.

Switches Hosts								Selected Swite	ches and Hosts		
Vailable Switches								IP Address	Name	VWWN	Туре
All Levels	Name	Device Type	Tag	Serial #	www	IP Address I	Dor	10.18.235.56	BES1	10:00:00:05:	Switch
🖃 😳 🔵 🧆 Back Bone_SAN3848	Back B										
- <> B5000_75	B5000	Switch	1	AGF0	10:	10.18.22					
- <> B5000_76	B5000	Switch	6	AGF0	10:	10.18.22					
- 🤭 IBM_2498_R06	IBM_24	Switch	0	ASS0	10:	10.18.22					
- 🗊 IBM_SAN384B_27	IBM_S	Switch	1	ANNO	10:	10.18.22					
SAN32B-E4-1	SAN32	Switch	3	ALVO	10:	10.18.23					
- <>> SAN32B-E4-2	SAN32	Switch	3	ALV0	10:	10.18.23					
switch 🦥	switch	Switch	0	AVS	10:	10.18.22					
							•			REFERENCE	

Figure 17-23 Select switch

3. A confirmation panel displays, as shown in Figure 17-24, and warns that the capture might be time intensive. Click **OK**.



Figure 17-24 Confirmation panel

4. To see if the process has completed successfully, go to the Master log tab and look for the information message, as shown in Figure 17-25.

Master Log	Eitter Only event	s for current view	< Page 1 of	1 >
Level	Source Name	Source Address	Туре	Descr
<u> </u>	DCX-10:00:00:05:1e:		Fabric	WWN 🔺
1	ibm_b200e_148	10.64.210.148	Tech Support	(Swit 💆
<u> </u>	DCX-10:00:00:05:1e:		Fabric	WWN
1	ibm_48k_133	10.64.210.133	Tech Support	(Swit
<u> </u>	DCX-10:00:00:09.1e:		Fabric	VW/N 🖵

Figure 17-25 Information message

These logs can now be sent to the SAN hardware support team at IBM for further diagnosis.

5. Viewing technical support information:

To view the captured information, select Monitor  $\rightarrow$  Technical Support  $\rightarrow$  View Repository.

The repository window opens (see Figure 17-26) and shows the captured data in zip files.

Available Support and Failure Data Capture Files File Name ▲ Size(MB) Last Modified Supportinfo 14.64 Fri Nov 05 1 Supportinfo 9.32 Thu Nov 04 Supportinfo 6.76 Tue Oct 19 1 View Delete	Repository Switches	Hosts		
File Name ▲       Size(MB)       Last Modified         Supportinfo       14.64       Fri Nov 05 1         Supportinfo       9.32       Thu Nov 04         Supportinfo       6.76       Tue Oct 19 1         View       Delete	Available Supp	ort and Failur	e Data Capture Files	
Supportinfo 14.64 Fri Nov 05 1 Supportinfo 9.32 Thu Nov 04 Supportinfo 6.76 Tue Oct 19 1 View Delete	File Name 🔺	Size(MB)	Last Modified	E mail
Supportinfo 9.32 Thu Nov 04 Supportinfo 6.76 Tue Oct 19 1 Delete	Supportinfo	14.64	Fri Nov 05 1	L-IIIdii
Supportinfo 6.76 Tue Oct 191 View Delete	Supportinfo	9.32	Thu Nov 04	FTP
View Delete	Supportinfo	6.76	Tue Oct 19 1	
Delete				View
				Delete

Figure 17-26 Repository window

## 17.2.3 DCFM support information

As already mentioned you can collect data to analyze a problem related to DCFM itself. Select **Monitor**  $\rightarrow$  **Technical Support**  $\rightarrow$  **Client SupportSave** as shown in Figure 17-27.

💱 View All - DCFM 10.4.2		
Server Edit View Discover Configure	Monitor Reports Tools Help	
😰 📄 🍕 😋 🚳 📾	Performance Name Vame	•
	Technical Support 🜔 Client SupportSave	
SAN	Event Policies Switch / Host SupportSave	
View All	Event Notification	
	SNMP Setup View Repository	<b>T</b> =
	Syslog Configuration	Tag
EDGE_IBM_B32 EDGE_IE	Logs 🕨	
E Sack Bone_SAN384B Back Bo		
🕀 🚳 Host Group	L Track Fabric Changes	
🗈 🖑 Storage Group	Accept Change(s)	
🗈 🧇 Switch Group	Port Connectivity	
B5000_75 B5000_75	Port Optics (SFP) Switch	17ff
🗈 🧼 B5000_76 B5000_7	Events	62ff
⊡ ☺ IBM_2498_R06 IBM_249	s_rusvo.4.1 Switch	01ff
IBM_SAN384B_27 IBM_SAI	1384B_27 v6.4.1 Switch	10ff

Figure 17-27 Support data from DCFM server

Be aware that this option is also available on the DCFM client side.

You will get an information message as to where the .zip file is stored as shown in Figure 17-28. You can now upload the file if needed.



Figure 17-28 DCFM location message

# 17.3 General troubleshooting

You can perform the following operations using FC troubleshooting:

Trace Route (Path Information and FC Ping): Use to obtain the detailed routing information for any two selected device ports. Device Connectivity Troubleshooting: Use to identify any problems that might be preventing communication between the two selected device ports. The device ports can be selected from the same fabric or from two different fabrics.

## 17.3.1 Troubleshooting device connectivity

 Select Configure → FC Troubleshooting → Device Connectivity. The Device Connectivity Troubleshooting dialog box displays as shown in Figure 17-29.

💱 IBM Fabric - DCFM 10.4.2							
Server Edit View Discover	Configure Monitor R	eports Tools Help					
	Element M <u>a</u> nager S <u>wi</u> tch	Decimal  Name	Name	T		▼ 🔶 Search	?
SAN	Firmware Managemen	t					
IBM Fabric 🔻	Routing	•		0 5 0 5			Export 🔍 🔍 🎇 🗖 💕
All Levels A	Logical Switches	vpe Class Fin	mware Tag	Se			
🗉 💿 😔 Back Bone_SAN3	Encryption						
🗈 🔩 Host Group	Zoning	•			Ģ	SAN32B-E4-2	
E 0 🍮 Routed Products	<u>N</u> ames						
E 🖑 Storage Group	FCIP Tunnels				sw	vitch	
E Switch Group	High Integrity Fabric	au	4.4 17#	AC			
B5000_75	Fabric Binding	v6	.4.1 62ff	AC			
BM 2498 R06	Port Fencing	v6	.4.1 01ff	AS		Switch Group	
IBM_SAN384B_2	Port Auto Disable	v6	.4.1 10ff	AN		-	
🗈 🦢 switch	FICON	V6	.4.1 05ff	A١			
SAN32B-E4-1	Allow/Prohibit Matrix	v6	.4.1 36ff	AL			
- 🤝 SAN32B-E4-2	Port Groups	V6	.4.1 38ff	AL		Hast Group	
	FC Troubleshooting	<u>Trace Route</u>				[nost Group]	,
	IP Troubleshooting	Eabric Device Sharing	<b>)</b>			Back Bone, SAN38	
	LIST ZUNC WEINDUS	Eauric Device Sharing				Daux Done_ownoo	
					4		
A <b>v</b>							
Master Log 🗌 Filter 🗌 Only	vevents for current view	Page 1	of 1 📐	Legend			Minimap 🍢 🤁
Level Source Name	Source Address	Туре	Descriķ				A
SAN32B-E4-2	10.18.235.56	Tech Support Event	(Switc 📤	.	>	80 to 100	
SAN32B-E4-2	10.18.235.56	Product Event	support	.	>	40 to 80	
SAN32B-E4-2	10.18.235.56	Tech Support Event	(Switc	.	>	1 to 40	-
SAN32B-E4-1	10.18.235.54	Product Event	support	.	0	to 1	
SAN32B-E4-1	10.18.235.54	Security Event	Login ir	.	c	Collection Disabled (or)	
administrator	10.18.228.61	Authentication Event	Server		P	ending	
SAN328-E4-1	10.18.235.54	Security Event			Legend %	6 Utilization	
SANJZD-E4-Z	10.10.235.56	Security Event			change		-
🕫 🗣 🕹	0 <u>6</u> ℃ win-303X4iG	BOR8 Clients 1 Administra	ator				

Figure 17-29 Selecting Device Connectivity

- 2. The wizard opens, as shown in Figure 17-30. The dialog is self explanatory. Select the device ports you want to troubleshoot, and click **OK**.
- 3. A panel displays, as shown in Figure 17-31, showing the Checks performed.

Device Connectivity Troublesho	ooting							>
Select two device ports from one fabr to see the diagnosis report.	ic or two differ	ent fabrics from	n left sid	e table,	move the ports	to the right side	e table and click (	OK button
<ul> <li>Enter port FC Address Source</li> <li>Select two device ports</li> </ul>	Des	tination	s	earch a	nd Add			
Available Device Ports					Selected Devic	ce Ports		
All Levels	Name	Device Type	Class		Device Port	Port WWN	Fabric Name	Switch N
🖽 🔾 🧆 Base - test-10:00:00:05:1	test-10:00:0					20:07:00:A0:	test-10:00:0	SAN768E
	DCX-4S-10:0				[43] "Emulex	. 10:00:00:00:	. test-10:00:0	SAN80B
	DCX-4S-10:0							
📙 🗕 🧿 🌭 test-10:00:00:05:1e:46:8a	test-10:00:0							
🗄 🕒 🥥 💩 test-10:00:00:05:1e:46:8a	test-10:00:0							
E 🥯 Switch Group								
E- SAN768B switch 1	SAN768B_s	Switch						
20:07:00:A0:B8:	4							
- 👗 10:00:00:00:09:	,							
	5							
E SAN80B switch 10	r SAN80B sw	. Switch						
	, ,							
	-							
□ 10:00:00:00:00:00:00:00:00:00:00:00:00:0	1 stest_10:00:0							
	1001-10.00.0							
							88	
	4 888		•		Add Detach	ied		
						ок	Cancel	Help

Figure 17-30 Wizard start



Figure 17-31 Performing Diagnosis

4. The next panel displays a summary of the tests performed and their results, see Figure 17-32. You can either rerun the Checks, Trace Route the same ports, or Close to finish Troubleshooting.

summary	Port	Port Name	Connected S	Fabric
Device Port 1	1:07:00:A0:B8:48:58:A1		768B switch 100	10:00:00:05:1e:46:8a:0
Device Port 2	):00:00:00:C9:28:EC:1A		040" \\80B_switch_100	0:00:00:05:1e:46:8a:0
Diagnosis Time	Sun Jun 07 00:38:41 PD	DT 2009		
ailure	2			
Warning	0			
Success	4			Ν
				N
nformation	6			
nformation otal	6 12			
nformation otal petails	6 12			·
nformation otal ⊳etails _evel ▲ I	6 12 Diagnosis Test	Result	Suggested Resolution	-
nformation iotal Level A I 2	6 12 Diagnosis Test Zone configuration check	Result The zone configuration is not defined properly and the device port(s) are found to be members of different zones.	Suggested Resolution The device ports should same zone in the effect	t be members of the ive zone config.
nformation otal Level A I S S	6 12 Diagnosis Test Zone configuration check Zone configuration check	Result The zone configuration is not defined properly and the device port(s) are found to be members of different zones. The zone configuration is not defined properly and the device port(s) are found to be members of different zones.	Suggested Resolution The device ports should same zone in the effect The device ports should same zone in the effect	t be members of the ive zone config. t be members of the ive zone config.
nformation otal Level A 1 X 2 X 2 X 2 X 2 X 2 X 2 X 2 X 2 X 2 X 2	6 12 Diagnosis Test Zone configuration check Zone configuration check _SAN zone configuration check.	Result The zone configuration is not defined properly and the device port(s) are found to be members of different zones. The zone configuration is not defined properly and the device port(s) are found to be members of different zones. Selected Devices are from same fabric - test-10:00:00:05:1e:46:8a:01. No need for LSAN check.	Suggested Resolution The device ports should same zone in the effect The device ports should same zone in the effect None.	t be members of the ive zone config. t be members of the ive zone config.

Figure 17-32 Troubleshooting Results

**Tip:** The errors shown previously were forced by choosing devices not in the same zone.

### 17.3.2 Trace route

The trace route feature of DCFM combines the functionality of the **pathInfo** and **fcPing** commands.

#### **Trace route information**

Trace route displays detailed routing information from a source port or area on the local switch to a destination port or area on another switch. This routing information describes the exact path that a user data stream takes to go from the source port to the destination port, including all intermediate switches.

**Attention:** DCFM cannot capture the routing information if any of the switches in the path are running Fabric OS v2.x or XPath OS.

The route information depends on the state of the intermediate switches and their ports. The path obtained for two ports might not be the same at all times. Also, the reverse path might not be the same as the forward path.

If one of the ports is inactive, the path shown is the path if the port was active.

Trace route performs a zoning check between the source and destination ports and displays whether the selected device port worldwide names (WWNs) are part of an active zone configuration. Note that if the selected device port WWNs are part of a zone that is not active, then the trace route displays that the device ports are not zoned.

Trace route also displays the maximum, minimum, and average round trip time for the data between the device port WWNs and the domain controller.

**Support:** Trace route is only supported on Fabric OS switches running Fabric OS v5.2 or later.

### Capturing trace route information

Follow these steps:

1. Select Configure  $\rightarrow$  FC Troubleshooting  $\rightarrow$  Trace Route, as shown in Figure 17-33.

💱 IBM Fabric - DCFM 10.4.2							
Server Edit View Discover	Configure Monitor R	eports <u>T</u> ools <u>H</u> elp					
<b>\$ \$ \$ \$ \$</b>	Element M <u>a</u> nager S <u>wi</u> tch	Decimal  Name	Name	T		▼ ★ Search	?
SAN	Firmware Management	t					
IBM Fabric 🔻	Routing	•					Export 🔍 🔍 🎇 💭 💕
All Levels A	Logical Switches	vpe Class Firm	ware Tag	Se			
E O O SAN3	Encryption	,,					
🗉 💐 Host Group	<u>Z</u> oning	•				CAN220 54 0	
🗈 🛯 🍮 Routed Products 🤇	Names					SAN32D-E4-2	
E 😃 Storage Group	FCIP Tunnels					witch	
E Switch Group	High Integrity Fabric		4 474				
B5000_75	Fabric Binding	v6.4	1 62ff	AC			
- BS000_10	Port Fencing	v6.4	.1 01ff	AS		Switch Group	
IBM_SAN384B_2	Port Auto Disable	v6.4	.1 10ff	AN			
🗈 🧔 switch	EICON	V6.4	.1 05ff	A١		~	
- 🧼 SAN32B-E4-1	Allow/Prohibit Matrix	v6.4	.1 36ff	AL			<u></u> _
- SAN32B-E4-2	Port Groups	v6.4	.1 38ff	AL			
	FC Troubleshooting	Irace Route				Host Group	7
	P Troubleshooting	Device Connectivity     Eabria Davias Sharing				Paak Paaa, C/(N)22	40
L	LIST ZUITE Members	Eablic Device Sharing				Dack Done_SANSO	*••
				•	•		
A <b>v</b>							
Master Log 🗌 Filter 🗌 Only e	events for current view	< Page 1	of 1 📃	Legend			Minimap 🍢 💽
Level Source Name	Source Address	Туре	Descriț				<b>A</b>
SAN32B-E4-2	10.18.235.56	Tech Support Event	(Switc 🔺			> 90 to 100	
SAN32B-E4-2	10.18.235.56	Product Event	support			> 40 to 80	
SAN32B-E4-2	10.18.235.56	Tech Support Event	(Switc			> 40 to 30	
SAN32B-E4-1	10.18.235.54	Product Event	support			0 to 1	
SAN32B-E4-1	10.18.235.54	Security Event	Login ir			Collection Disabled (or)	
administrator	10.18.228.61	Authentication Event	Server	· · · ·		Pending	
SAN32B-E4-1	10.18.235.54	Security Event	Login ir		Legend	% Utilization	
SAN32B-E4-2	10.18.235.56	Security Event			change		-
수수 🐻 🗢 👶 🔕		B0R8 Clients 1 Administrate	or	2			

Figure 17-33 Trace route

2. The *Trace Route* dialog box opens, as shown in Figure 17-34. Select two devices from the *Available Device Ports* panel and move them to the *Selected devices Ports* panel. Alternatively, you can search for devices either by device port WWN or device port name using the *Search and Add* panel. Click **OK** to start Trace Routing.

Trace Route							
Enter or select two ports from the selected fat	oric or routing sc	ope and cliq	k OK to	view the route	information.		
Trace Route Scope		·					
Eabric test-10:00:00:05:1e:46:8a:02	(10.64.210.210)	•					
	(10.01.210.210)						
O Routing		T					
Device Ports							
Enter part EC Addresse Source	Dectinction		Seereb	and it da			
Enter port FC Address Source [			Search	and Add			
<ul> <li>Select two device ports</li> </ul>							
N							
vailable Device Ports			1	Selected Devic	ce Ports		
I Levels	Name	Device T		Port Name	Node WWN	Port WWN	FC Add
- <mark>0</mark> 崣 test-10:00:00:05:1e:46:8a:02	test-10:00:0				20:06:00:A0:.	20:06:00:A0:.	. 69ebc0
🖻 🥯 Switch Group					20:00:00:00:	. 10:00:00:00:	. 013800
🖻 🏭 SAN768B_switch_105	SAN768B_s.	Switch					•
— 💩 20:06:00:A0:B8:48:58:A1							
- 💩 10:00:00:00:C9:28:EB:A5							
🖢 💩 10:00:00:05:1E:53:10:8B							
E 🥮 SAN80B_switch_105	SAN80B_sw	Switch					
- 🍐 10:00:00:00:C9:28:EB:77							
🖵 💩 10:00:00:00:C9:4C:8C:1C							
	1995						
	• 1992	•	] =				
					OK	Cancel	Help
					ON		neip

Figure 17-34 Select devices

3. The Trace Route Summary dialog box displays Figure 17-35 with the following information about the different tabs:

Trace Route Summary tab: This tab shows a brief summary of the trace including the port WWN, port name, FC address, switch name, whether ping was successful, round trip time (minimum, maximum, and average) and whether the device ports are in active zones.

Forward Route tab: This tab shows the path taken by data packets from the port belonging to the switch on which the trace route has been invoked (source port) to the port on the other switch (destination port).

Reverse Route tab: This tab shows the path from the destination port to the source port.

Port VW/N Port Name FC Address	So 10:00:00:00:C9:4C:8C:	ource Port		Destination Port		
Port VWVN Port Name FC Address	10:00:00:00:C9:4C:8C:*			Destination Fort		
Port Name FC Address		1C	20:06:00:A0:E	88:48:58:A1		
C Address					100	
	013800		69ebc0		000	
Switch Name	SAN80B_switch_105		SAN768B_sv	/itch_105		
ing Succeeded	Yes		No		0000	
Avg Round Trip Time	131 usec		0 usec			
/in Round Trip Time	108 usec		0 usec			
Aax Round Trip Time	210 usec		0 usec			
n Active Zones	Yes		Yes			
iop I	56(0×38)/56(0×38)	1 (0~01)	SANSOR switch 10	5 81(0×51)/81(0×51)	16	
Family Parks		i=				
qol	In Port Area ID(Hex)/	Domain ID	Switch Name	Out Port Area ID(He	Bandwidth (Gb/	
	56(0x38)/56(0x38)	1 (0x01)	SAN80B switch 10:	5 81(0x51)/81(0x51)	16	
	449(0x1c1)/449(0x	105 (0x69)	SAN768B_switch_1.	38B_switch_1 80(0x50)/80(0x50)		
◀ Forward route is from	n switch SAN80B_swit	ch_105 to switch	SAN768B_switch_105		Þ	

Figure 17-35 Trace Route Summary dialog box

# 17.4 Port Fencing

Fabric Operating System v6.1 (Fabric OS) adds a new feature called Port Fencing, which disables a port automatically when it is operating outside the bounds of normal operation.

Port Fencing allows you to protect your SAN from repeated operational or security problems experienced by ports. Use Port Fencing to set threshold limits for the number of specific port events permitted during a given time period on the selected object.

Port Fencing objects include the SAN, Fabrics, Directors, Switches (physical), Virtual Switches, Ports, as well as Port Types (E_port, F_port, and FX_port). Use Port Fencing to directly assign a threshold to these objects. When a switch does not support Port Fencing, a No Fencing Changes message displays in the Threshold field in the Ports table.

If the port detects more events during the specified time period, the device firmware blocks the port, disabling transmit and receive traffic until you investigate, solve the problem, and manually unblock the port.

The Port Fencing requirements include:

- Based on Fabric Watch Event Monitoring
- Requires Fabric Watch license to configure and use

### 17.4.1 Port Fencing using DCFM

In DCFM you can create thresholds, which you can then assign to available objects in the tree.

Port Fencing threshold types include these:

Invalid CRCs (Fabric OS only):

Used to block a port when an Invalid CRCs violation meets the Fabric OS switch threshold.

Invalid Words (Fabric OS only):

Use to block a port when an Invalid Words violation meets the Fabric OS switch threshold.

► Link (M-EOS and Fabric OS):

Used to block a port when a Link Level (Hot I/O) error meets the threshold. A Link Level (Hot I/O) occurs when an active loop port repeatedly receives a loop initialization primitive sequence error or an active non-loop port repeatedly receives a line repeater, offline sequence, or not operational sequence error.

Link Reset (Fabric OS only):

Used to block a port when the link timeout errors meet the threshold.

Protocol Errors (M-EOS and Fabric OS):

Used to block a port when one of these protocol errors meets the threshold:

- ISL Bouncing-ISL has repeatedly become unavailable due to link down events.
- ISL Segmentation (M-EOS only)-ISL has repeatedly become segmented.
- ISL Protocol Mismatch-ISL has been repeatedly put into the Invalid Attachment state due to a protocol error.

► Security (M-EOS):

Used to block a port when one of the following security violations occurs:

- Authentication: The switch has repeatedly become unavailable due to authentication events.
- Fabric Binding: The switch has repeatedly become unavailable due to fabric binding events.
- Switch Binding: The switch has repeatedly become unavailable due to switch binding events. Switch Binding is enabled through a product's Element Manager.
- Port Binding: The switch has repeatedly become unavailable due to port binding events.
- ISL Security: (Generic Security Error) the switch on the other side of the ISL has detected a specific security violation, but is only able to indicate that a generic security violation has occurred or a security configuration mismatch was detected.
- N_port Connection Not Allowed-the switch has repeatedly become unavailable due to N_port connection not allowed events.
- Sync Loss (Fabric OS only):

Used this type of threshold to block a port when a sync loss violation type meets the Fabric OS switch threshold.

### Adding Thresholds for Port Fencing

In this example we set a *CRC Threshold* of 1 CRC error per minute to the E-ports of a Fabric.

 Select Configure → Port Fencing as shown in Figure 17-36. The Port Fencing dialog box displays.



Figure 17-36 Select Port Fencing

2. Select **Invalid CRCs (FOS only)** from the Violation Type list in the The Port Fencing dialog box (see Figure 17-37). Click **Add**.

Port Fencing								
violation Type	Invalid CRCs (FOS only)	•		4			0 ports l	olocked by thresholds
nvalid CRCs Th	Invalid CRCs (FOS only)	25	Į		Porte			
Vame 🔺	Invalid Words (FOS only) Link Link Reset (FOS only) Protocol Error Security (m-EOS only) Sync Loss (FOS only)	.04	ected	Find >	Ports All Fabrics E Ports Fx Ports SAN80B E Ø DCX-4s	Port Type	Directly Assigned	Changed Invalid CRC
				► ◀				
								▲  . ▶
Add	Edit Delete				Unblock Prope	rties		
							ок	Cancel Help

Figure 17-37 Port Fencing dialog box

The *Add Invalid CRCs Threshold* dialog box displays Figure 17-38. Enter a name for the threshold in the Name field (in our example *TEST ITSO CRC*) and select one of the following options:

- ► Default: Uses device defaults
- Custom: Uses your selections

Enter the number of invalid CRCs allowed for the threshold in the Threshold errors field. We use Custom in our example and use 1 error per minute.

Click **OK** to add the Invalid CRCs threshold to the table and close the *Add Invalid CRCs Threshold* dialog box.

🗱 Add Invalid CRCs Threshold 🛛 🔀						
Block a port v	when Invalid CRCs violation type meets the FOS switch threshold					
Name	TEST ITSO CRC					
Policy Type	◯ Default					
	Threshold 1 errors per Minute 💌					
	0 to 999999999					
	OK Cancel Help					

Figure 17-38 Add Invalid CRCs Threshold dialog box

3. In the *Port Fencing* dialog box (Figure 17-39) select the threshold you want to assign from the Thresholds table (in our example TEST ITSO CRC). Select the objects (All Fabrics, Fabric, Director, Switch, Port Type, and/or Port, we choose All E-Ports) to which you want to assign the threshold from the Ports table.

🌄 Port Fencing X 0 ports blocked by thresholds. Violation Type Invalid CRCs (FOS only) Ŧ Invalid CRCs Thresholds Ports Name 🔺 Limit (... Period ... Ports Affected Port Type Directly Assigned Changed Invalid CRCs Find > Ports TEST ITSO CRC 1 Minute 0 E All Fabrics E Ports Fx Ports 🗄 🍣 SAN80B 🗄 🌏 DCX-4s 24 Assign the selected threshold ▲ 200 Add Edit Delete 0K Cancel Help

Click the right arrow to assign the Thresholds to the ports.

Figure 17-39 Port Fencing dialog box

As shown in Figure 17-40, an arrow icon displays next to the objects you selected in the Ports table to show that the threshold was applied at this level and was inherited by every subordinate object below it in the tree.

Also notice that the green plus sign icon displays next to every object in the tree to which the new threshold is applied.

Click **OK** to close the Port Fencing dialog box.

Port Fencing							
Violation Type Invalid CRC	s (FOS only) 🔻	4			0 ports k	locked by	thresholds
nvalid CRCs Thresholds			Ports				
Name 🔺 Limit (	Period Ports Affected	Find >	Ports	Port Type	Directly Assigned	Changed	Invalid CRC
TEST ITSO CRC 1	Minute 208		All Fabrics     E Ports     Fx Ports     SAN80B     E Ports		Þ	0	TEST I
			Fx Ports BM_ E Port Fx Ports Block			0	TESTI
		4	E OCX-4s E Ports Fx Ports			0	TEST
			E IBM_ E Poi Fx Pi Block			0	TEST I
							4    ] ▶
Add Edit	Delete		Unblock Proper	ties	OK	Cancel	Help

Figure 17-40 Port Fencing dialog box

### **Removing Thresholds for Port Fencing**

In this example we remove Port Fencing thresholds:

- 1. Select **Configure**  $\rightarrow$  **Port Fencing**. See Figure 17-36 on page 822. The Port Fencing dialog box displays.
- 2. Select a threshold type from the Violation Type list. See Figure 17-37 on page 823.
- 3. Select the object with the threshold that you want to remove in the Ports table of the Port Fencing dialog box (Figure 17-41). Click the left arrow.

Port Fencing										
Violation Type Inva	ilid CRCs (	FOS onl	y) 🔻	\$				0 ports k	blocked by	/ thresholds
Invalid CRCs Thresh	olds				Ports					
Name 🔺	Limit (	Period .	Ports Affecte	Find >	Ports	Port Type	Directly	Assigned	Changed	Invalid CRC
TEST ITSO CRC	1	Minute	208		E All Fabrics					
					E Ports			▶	•	TEST I
					- Fx Ports					
					🖻 🍣 SAN80B					
					- E Ports				•	TEST
					- Fx Ports					
					🖻 🥯 IBM_	:			-	
					- E Poi	·			e	TEST
					- Fx P	-				
						۲.				
					EF 🌑 DCX-4s				•	TEST
				Remove t	he threshold from the	selected obj	ects		•	IESI
									•	TEST
					- Ex Pi				-	
					Block					
										L 1996
			-							1993
Add Ed	lit	Delete			Unblock Proper	ties				
								OK	Cancel	Help

Figure 17-41 Port Fencing dialog box

4. Click OK.

### **Unblocking a Fenced port**

The management application allows you to unblock a port (only if it was blocked by Port Fencing) after the problem that triggered the threshold is fixed. When a port is blocked, an Attention icon displays next to the port node:



To unblock a port, complete the following steps:

- 1. Select **Configure**  $\rightarrow$  **Port Fencing** (see Figure 17-36 on page 822). The Port Fencing dialog box displays.
- 2. Right-click anywhere in the Ports table and select **Expand**.
- 3. Select a blocked port from the Ports table and click **Unblock**.
- 4. Click **OK** on the message. If you did not solve the root problem, the threshold will trigger again.
- 5. Click **OK** on the Port Fencing dialog box.

### 17.4.2 Port Fencing using CLI

In the examples that follow, we show the steps to configure Port Fencing for Link Loss on the E-Port class:

- 1. Telnet to the switch.
- 2. Enter fwconfigure as shown in Example 17-2.

Example 17-2 Step 1 to configure Port Fencing

```
b5000_147:admin> fwconfigure
1 : Environment class
2 : SFP class
3 : Port class
4 : Fabric class
5 : E-Port class
5 : E-Port class
6 : F/FL Port (Optical) class
7 : Alpa Performance Monitor class
8 : EE Performance Monitor class
9 : Filter Performance Monitor
10 : Security class
11 : Resource class
12 : Quit
Select a class => : (1..12) [12]
```

3. Type 5 to select E_Port Class as shown in Example 17-3.

Example 17-3 Step 3 to configure port fencing

b5000 147:admin> fwconfigure

```
1 : Environment class
2 : SFP class
3 : Port class
4 : Fabric class
5 : E-Port class
6 : F/FL Port (Optical) class
7 : Alpa Performance Monitor class
8 : EE Performance Monitor class
9 : Filter Performance Monitor class
10 : Security class
11 : Resource class
12 : Quit
Select a class => : (1..12) [12] 5
```

Entered into the swthcfgEPort

```
1 : Link loss(E-port)
2 : Sync loss(E-port)
3 : Signal loss(E-port)
4 : Protocol error(E-port)
5 : Invalid words(E-port)
6 : Invalid CRCS(E-port)
7 : RXPerformance(E-port)
8 : TXPerformance(E-port)
9 : State Changes(E/VE-port)
10 : Link reset(E-port)
11 : Utilization(VE-port)
12 : Packet Loss(VE-port)
13 : C3 Discard(E-port)
14 : return to previous page
Select an area => : (1..14) [14]
```

4. Type 1 to select the Link Loss as shown in Example 17-4.

```
Example 17-4 Step 4 to configure port fencing
```

Entered into the swthcfgEPort

```
1 : Link loss(E-port)
2 : Sync loss(E-port)
3 : Signal loss(E-port)
4 : Protocol error(E-port)
5 : Invalid words(E-port)
6 : Invalid CRCS(E-port)
7 : RXPerformance(E-port)
8 : TXPerformance(E-port)
9 : State Changes(E/VE-port)
10 : Link reset(E-port)
11 : Utilization(VE-port)
12 : Packet Loss(VE-port)
13 : C3 Discard(E-port)
14 : return to previous page
Select an area => : (1..14) [14] 1
Index ThresholdName Port
                                  CurVal
                                              Status
     LastEvent
                 LasteventTime
                                  LastVal
                                               LastState
0 0 Error(s)/min
0 eportLink000
                                                  enabled
inBetween
           Tue May 6 16:44:19 2008 0 Error(s)/min
                                                  In_Range
```

```
1 eportLink001 1 0 Error(s)/min enabled
inBetween Tue May 6 16:46:25 2008 0 Error(s)/min In_Range
1 : refresh
2 : disable a threshold
3 : enable a threshold
4 : advanced configuration
5 : return to previous page
Select choice => : (1..5) [5]
```

5. Type 4 to select advanced configuration as shown in Example 17-5.

Example 17-5 Step 5 to configure port fencing

```
1 : refresh
2 : disable a threshold
3 : enable a threshold
4 : advanced configuration
5 : return to previous page
Select choice => : (1..5) [5] 4
Index ThresholdName
                       BehaviorType
                                        BehaviorInt
    0 eportLink000
                          Triggered
                                                  1
                                                  1
    1 eportLink001
                          Triggered
Threshold boundary level is set at : Default
                 Default
                                Custom
      Unit
                Error(s)
                              Error(s)
 Time base
                  minute
                                minute
       Low
                       0
                                     0
                       5
                                     5
      High
                       0
                                     0
   BufSize
Threshold alarm level is set at : Default
Errlog-1, SnmpTrap-2, PortLogLock-4
RapiTrap-8, EmailAlert-16, PortFencing-32
Valid alarm matrix is 63
                 Default
                                Custom
   Changed
                       0
                                     0
                       0
                                     0
     Below.
                       0
     Above
                                     0
```

InBetween

0

1	:	change	behavior type	11	:	change threshold alarm level	
2	:	change	behavior interval	12	:	change changed alarm	
3	:	change	threshold boundary level	13	:	change below alarm	
4	:	change	custom unit	14	:	change above alarm	
5	:	change	custom time base	15	:	change inBetween alarm	
6	:	change	custom low	16	:	apply threshold alarm	
cha	ıng	ges					
7	:	change	custom high	17	:	cancel threshold alarm	
cha	ıng	ges					
8	:	change	custom buffer	18	:	return to previous page	
9	9 : apply threshold boundary changes						
10 : cancel threshold boundary changes							
Sel	Select choice => : (118) [18]						

6. Type 14 to enable port fencing as shown in Example 17-6.

0

Example 17-6 Step 6 to enable the port fencing

```
1 : change behavior type
                                     11 : change threshold alarm level
2 : change behavior interval
                                     12 : change changed alarm
3 : change threshold boundary level 13 : change below alarm
4 : change custom unit
                                     14 : change above alarm
5 : change custom time base
                                     15 : change inBetween alarm
6 : change custom low
                                     16 : apply threshold alarm
changes
7 : change custom high
                                     17 : cancel threshold alarm
changes
8 : change custom buffer
                                     18 : return to previous page
9 : apply threshold boundary changes
10 : cancel threshold boundary changes
Select choice => : (1..18) [18] 14
Errlog-1, SnmpTrap-2, PortLogLock-4
RapiTrap-8, EmailAlert-16, PortFencing-32
Valid alarm matrix is 63
Enter above alarm matrix = : (0..63) [0]
```

7. Type 32 to enable port fencing as shown in Example 17-7.

Example 17-7 Step 7 to enable port fencing

1	: change behavior type	11 : change threshold alarm level
2	: change behavior interval	12 : change changed alarm
3	: change threshold boundary level	13 : change below alarm

```
4 : change custom unit
                                     14 : change above alarm
5 : change custom time base
                                     15 : change inBetween alarm
6 : change custom low
                                     16 : apply threshold alarm
changes
7 : change custom high
                                     17 : cancel threshold alarm
changes
8 : change custom buffer
                                     18 : return to previous page
9 : apply threshold boundary changes
10 : cancel threshold boundary changes
Select choice => : (1..18) [18] 14
Errlog-1, SnmpTrap-2, PortLogLock-4
RapiTrap-8, EmailAlert-16, PortFencing-32
Valid alarm matrix is 63
Enter above alarm matrix => : (0..63) [0] 32
```

8. Type 3 to change the threshold boundary level to custom by selecting 2 as shown in Example 17-8.

Example 17-8 Step 8 to configure port fencing

Select choice => : (118) [18] 3								
1 : Default								
2 : custom								
Enter boundary level type => : (12) [1] 2								
Index Threshold	Name Beha	viorType	BehaviorInt					
0 eportLin	k000 T	riggered	1					
1 eportLin	k001 T	riggered	1					
Threshold boundary level is set at : Custom								
	Default	Custon	n					
Unit	Error(s)	Error(s)						
Time base	minute	minute	9					
Low	0	(	)					
High	5	Ę	5					
BufSize	0	(	)					
Threshold alarm level is set at : Custom								
Errlog-1, SnmpTrap-2, PortLogLock-4 RapiTrap-8, EmailAlert-16, PortFencing-32								
Valid alarm matrix is 63								

		Default	Cust	om		
Ch	anged	0		0		
	Below	0		0		
	Above	0		32		
InBe	tween	0		0		
1:	change	behavior type		11	:	change threshold alarm level
2:	change	behavior interval		12	:	change changed alarm
3:	change	threshold boundary	/ level	13	:	change below alarm
4 :	change	custom unit		14	:	change above alarm
5:	change	custom time base		15	:	change inBetween alarm
6:	change	custom low		16	:	apply threshold alarm
chang	es					
7:	change	custom high		17	:	cancel threshold alarm
chang	es					
8 :	change	custom buffer		18	:	return to previous page
9 :	apply t	hreshold boundary	change	S		
10 :	cancel	threshold boundary	, chang	es		
Selec	t choic	e => : (118) [18	3]			

9. Type 9 to apply the threshold boundary changes as shown in Example 17-9.

Example 17-9 Step 9 to configure port fencing

1 :	change behavior type	11	:	change threshold alarm level		
2 :	change behavior interval	12	:	change changed alarm		
3:	change threshold boundary level	13	:	change below alarm		
4 :	change custom unit	14	:	change above alarm		
5:	change custom time base	15	:	change inBetween alarm		
6:	change custom low	16	:	apply threshold alarm		
chan	iges					
7:	change custom high	17	:	cancel threshold alarm		
chan	iges					
8:	change custom buffer	18	:	return to previous page		
9 : apply threshold boundary changes						
10 :	cancel threshold boundary changes	S				
Sele	ect choice => : (118) [18] 9					

10.Now press Enter until you reach the admin prompt.

### 17.4.3 Enabling Port Fencing for E_Port class link loss

To enable Port Fencing for E_Port class link loss, proceed as follows:

- 1. Telnet to the switch.
- 2. Enter the fwconfigure command.
- 3. Type 5 to select E_Port class.
- 4. Type 1 to select Link Loss (E_Port).
- 5. Type 4 to select advanced configuration.
- 6. Type 14 to select change alarm.
- 7. Type 32 to enable Port Fencing.
- 8. Type 3 to change the threshold boundary level, and type 2 to set the threshold boundary level to custom.
- 9. Type 9 to apply the threshold boundary level changes.
- 10. Press Enter until you reach the admin prompt.

### 17.4.4 Testing the configuration

You can simulate the link loss manually by unplugging the ISL cable multiple times. After the threshold has been reached/exceeded, the E_Port is disabled automatically.

Example 17-10 shows output for the **switchshow** command where port 1 is disabled automatically with the following error message:

"Disabled (Port Link Loss threshold exceeded)"

Now, you need to enable the port manually using the **Portenable <portnumber>** command.

Example 17-10 The switchshow command after the port is disabled automatically

b5000_147:admi	n> switchshow
switchName:	b5000_147
switchType:	58.1
switchState:	Online
switchMode:	Native
switchRole:	Principal
switchDomain:	4
switchId:	fffc04
switchWwn:	10:00:00:05:1e:90:14:c7
zoning:	OFF

switchBeacon: ON Area Port Media Speed State Proto 0 0 id N4 No_Light 1 1 id N4 No_Sync Disabled (Port Link Loss threshold exceeded) 2 2 id N4 No_Light 3 3 id N4 No Light 4 4 --N4 No_Module 5 5 N4 No_Module --6 6 N4 No_Module --7 7 --N4 No_Module 8 8 N4 No Module --9 9 N4 No_Module --10 10 N4 No_Module --No_Module 11 11 N4 --12 12 id N4 **Online** F-Port 20:06:00:a0:b8:48:58:a1 13 13 id N4 **Online** F-Port 20:06:00:a0:b8:48:58:a2

### 17.4.5 Basic troubleshooting commands

You can use the following commands to perform basic troubleshooting of the SAN switch. Most of the commands are self-explanatory:

chassisShow	Displays all Field Replaceable Units (FRU).and their status.
diagShow	Displays diagnostics status for the switch port.
errDump	Dumps the external error log messages.
errshow	Displays the error log message.
fabStatsShow	Displays the fabric statistics information. Can be used to troubleshoot the Fabric merging issues
fanShow	Displays fan status and speed.
fcPing	Performs a zoning check between the source and destination WWN.
islShow	Displays ISL information.
portCfgShow	Displays port configuration settings.
portErrShow	Displays a summary of port errors.
portLogShow	Displays the port log with page breaks.
portShow	Displays the status of the specified port.
portStatsShow	Displays port hardware statistics.

psShow	Displays power supply status.
supportshow	Prints switch information for debugging purposes.
supportsave	Generate files for the support center for debugging purposes.
switchShow	Displays switch and port status.
topologyShow	Displays the fabric topology.

You can find more help with these commands by using **help <command name>** when logged in to the switch.

#### Example portErrShow

The **portErrShow** command is a good tool for a quick analysis of switch ports, as it provides an overview of useful (error-) counters.

The counters shown in Example 17-11 reflect the increased values over history of a port.

Example 17-11 output portErrShow

MagicC_1:admin> porterrshow														
	fra	ames	enc	crc	too	too	bad	enc	disc	link	loss	loss	frjt	fbsy
	tx	rx	in	err	shrt	long	eof	out	c3	fail	sync	sig		
٥.	====== 3/I	====== 37	 ^	===== 10		·===== 0	===== 0	108		 0	===== 2	:===== 3	·==== 0	 0
1:	9.6m	5.4m	0 0	0	0	0	0	54	0	1	2	3	0	0
2:	10m	144m	4	0	4	0	9	211k	7	1	3	4	0	0
3:	34	37	0	100k	0	0	0	109	0	0	3	5	0	0
4:	8.1m	2.2m	0	0	0	0	0	85k	0	2	127	210	0	0
5:	80k	51k	0	0	0	0	0	91k	0	0	1	2	0	0
6:	112k	341k	0	0	0	0	0	3.4k	0	16	26	33	0	0
7:	134k	327k	0	0	0	0	0	1	0	8	9	10	0	0
8:	0	0	0	0	0	0	0	0	0	0	142k	284k	0	0
9:	15	15	0	0	0	0	0	4	0	0	43	82	0	0
10:	1.3k	1.0k	0	0	0	0	0	0	0	4	6	7	0	0
11:	1.9m	103k	0	0	0	0	0	31	0	6	7	8	0	0

Therefore these counters are not to be used for problem determination because they show errors since the counters have been cleared the last time.

To have a clear **baseline**, first all the counters have to be cleared.

- 1. Telnet to the switch.
- 2. Enter the command **statsclear** to clear all counters reflected by the **porterrshow** command. The counters should look similar to those in Example 17-12.
| MagicC_1:admin> |       |        | stat        | sclea | ır   |      |       |       |      |      |      |      |      |      |
|-----------------|-------|--------|-------------|-------|------|------|-------|-------|------|------|------|------|------|------|
| Magic           | C_1:a | dmin>  | porterrshow |       |      |      |       |       |      |      |      |      |      |      |
|                 | fr    | frames |             | crc   | too  | too  | bad   | enc   | disc | link | loss | loss | frjt | fbsy |
|                 | tx    | rx     | in          | err   | shrt | long | eof   | out   | c3   | fail | sync | sig  |      |      |
| =               | ===== | =====  | =====       | ===== |      |      | ===== | ===== |      |      |      |      |      | ==== |
| 0:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 1:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 2:              | 56    | 32     | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 3:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 4:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 5:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 6:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 7:              | 3     | 3      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 8:              | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 9:              | 2     | 2      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 10:             | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |
| 11:             | 0     | 0      | 0           | 0     | 0    | 0    | 0     | 0     | 0    | 0    | 0    | 0    | 0    | 0    |

Example 17-12 output portErrShow after counters are cleared

3. With this baseline, the ports should be monitored over a proper amount of time (2-3 hours) without any maintenance action on it (such as resetting the link or setting it offline/online).

#### Explanation of porterrshow counters and their causes

Here we explain the **porterrshow** counters and their causes:

► frames tx

The number of transmitted frames of this port.

► frames rx

The number of received frames of this port.

► enc_in

Encoding error inside frame. The words inside a frame are encoded with the 8bit/10bit encoding scheme. Every 8 bit data byte can be represented by multiple 10 bit characters. If there is a corruption in this encoding in a received frame, the error rises. As the frames are newly encoded every time before they are sent out through a cable, the increasing of this counter means that you have physical problems between this port and the port at the other side of the cable.

► crc_err

CRC means *Cyclic Redundancy Check* and is a mechanism to detect corruptions in a frame. The CRC value is calculated in the source device (for example, the HBA) when the frame is composed and will not be altered until it reaches the destination device. Because of that, a corrupted frame

(calculated CRC does not match the CRC value in the frame) will cause an increasing of the crc_err counter of every switch it passes on its way to the destination device.

If there are increased crc_err on an ISL port without enc_in errors, there should be no physical problem on this ISL (at least on the direction towards this port). The action plan, then, is to look for increased crc_err on the connected switch and apply the same rule there.

▶ too_long

FC frames are 2148 byes maximum. If an EOF (end of frame) is corrupted or data generation is incorrect, a too_long error is generated.

▶ too_short

The too_short is an error statistics counter that is incremental whenever a frame, bounded by an SOF (start of frame word) and EOF, is received and the number of words between the SOF and EOF is less than seven words (six words in the header plus a one word CRC), that is to say 38 bytes (not 48) including the SOF and EOF. This might be caused by the transmitter or an unreliable link.

▶ bad_eof

After a loss-of-synchronization error, continuous-mode alignment allows the receiver to reestablish word alignment at any point in the incoming bit stream while the receiver is Operational. Such realignment is likely (but not guaranteed) to result in Code Violations and subsequent loss of Synchronization. Under certain conditions, it might be possible to realign an incoming bit stream without loss of Synchronization. If such a realignment occurs within a received frame, detection of the resulting error condition is dependent upon higher-level function (for example, invalid CRC, missing EOF Delimiter).

▶ enc_out

This counter is similar to enc_in, but for transmission words outside normal FC frames. This error rises for 8 bit/10 bit encoding errors (invalid encoding, invalid disparity, and so on) in ordered sets such as IDLEs or R_RDYs. This counter can increase in huge amounts during speed negotiation and so should not used alone for problem determination without clearing the statistics before. If you created a baseline first, an increased enc_out counter points to probable physical problems. It can be used even if no user-I/O is transferred over the port.

► disc_c3

The Discard class 3 counter should increase every time the switch has to drop (discard) a frame because of various reasons. Increases of this counter can point to congestion in the fabric, time-outs, busy destination devices,

unknown devices (for example, if a host sends to an address known to it but not to the fabric), a device sending frames without FLOGI first, an invalid destination address, or others. To determine the reason for the discards, the Fabric OS command **portstatsshow** command can be used on current platforms and code versions.

▶ link_fail

If a Port remains in the LR Receive State (for example within the link reset or link initialization phase) for a period of time greater than R_T_TOV (Receiver-Transmitter Timeout Value, 100ms per default), a Link Reset Protocol Timeout will be detected that results in a Link Failure condition and the port enters the NOS (Not Operational State) Transmit State. The link failure also indicates that loss of signal or loss of sync lasting longer than the R_T_TOV value was detected while not in the Offline state. As for loss_sync, verify that the link was not brought down manually after setting the baseline.

Ioss_sync

Synchronization failures on either bit or Transmission-Word boundaries are not separately identifiable and cause loss-of synchronization errors. There is an internal counter that rises with every invalid transmission word. An invalid transmission word is a word with an encoding error (-> enc_in and/or enc_out will be increased). If the port receives two consecutive valid transmission words, this internal counter is decreased by 1 (to a minimum of 0). If the internal counter reaches 4, a loss-of-synchronization error will be triggered and the loss-of-synchronization procedure will be started. If this happens after a baseline is set and without any maintenance action on the link/switch or on the device (such as reboot of the host), this counter indicates an unstable link and therefore physical problems.

Ioss_sig

This occurs when a signal is transmitted but nothing is being received on the same port. Check if the connected device is powered on and cabled correctly. The Fabric OS command **switchshow** shows if there is no light on the port, **sfpshow** reveals the exact receive power values. Be aware that many devices require a configuration activation of their HBA in order to send light.

► frjt

If the fabric cannot process a class 2 frame, a F_RJT (fabric reject) is returned. Possible reasons can be (among others): class not supported, invalid source id, invalid destination id, N_Port permanently not available, N_Port temporary not available, Login required.

► fbsy

If the fabric cannot deliver a class 2 frame within  $E_D_TOV$  (Error Detect Timeout Value), the frame will be discarded and a  $F_BSY$  (fabric busy) is returned.

# **Related publications**

The publications listed in this section are considered particularly suitable for a more detailed discussion of the topics covered in this book.

### **IBM Redbooks publications**

For information about ordering these publications, see "Help from IBM" on page 843. Note that some of the documents that we reference here might be available in softcopy only.

- ► Introduction to Storage Area Networks, SG24-5470
- ► IBM TotalStorage: SAN Product, Design, and Optimization Guide, SG24-6384
- IBM System Storage/Brocade Multiprotocol Routing: An Introduction and Implementation, SG24-7544
- ► FICON Implementation Guide, SG24-6497

#### **Other resources**

These publications are also relevant as further information sources:

- Clark, Tom. IP SANs: An Introduction to iSCSI, iFCP, and FCIP Protocols for Storage Area Network. Addison-Wesley Professional, first edition, December 2001. ISBN 0201752778.
- Farley, Marc. Building Storage Networks. McGraw-Hill/Osborne Media, first edition, January 2000. ISBN 0072120509.
- ► Fabric OS Administrator's Guide, 53-1000448
- Secure Fabric OS Administrator's Guide, 53-1000244

#### **Referenced websites**

These websites are also relevant as further information sources:

- IBM System Storage hardware, software, and solutions: http://www.storage.ibm.com
- IBM System Storage, Storage Area Network: http://www.storage.ibm.com/snetwork/index.html
- Brocade:

http://www.brocade.com

- Finisar: http://www.finisar.com
- Veritas: http://www.veritas.com
- Tivoli: http://www.tivoli.com
- JNI: http://www.Jni.com
- ► IEEE:

http://www.ieee.org

- Storage Networking Industry Association: http://www.snia.org
- SCSI Trade Association: http://www.scsita.org
- Internet Engineering Task Force: http://www.ietf.org
- American National Standards Institute:

http://www.ansi.org

- Technical Committee T10: http://www.t10.org
- Technical Committee T11: http://www.t11.org

## Help from IBM

IBM Support and downloads

ibm.com/support

**IBM Global Services** 

ibm.com/services

# Index

#### Numerics

 10-Gbps interoperability
 115

 2005-B16
 41, 87

 2109-F16 License Administration
 268

 2109-M48
 41, 78, 85

 2498-B40
 87

 2498-B80
 88

 2499-192
 73

 8 Gbps Fibre Channel connectivity
 12

 8 Gbps license
 171

#### A

AAA 17, 289 AAA Service 288 AAA Service tab 287 Aborting a transaction associated with IP Filter 693 Accelerator for FICON 96 Access Control List (ACL) 291 Access Gateway 93-94, 115, 196 Access Gateway mode 4 Access Gateway-mode switches 357 access level 280 account information 627 account management 627 ACL 638 ACL policies 662 ACL policy management 662 Activate policy changes 673 Activating an IP Filter policy 688 activating discovery 360 activation key 270 active configuration 517 active CP 137, 148 active CP blade 136-137, 139-140, 148, 151-152 Active Directory 287-288 Active Directory Services 17 Active Directory/LDAP 17 AD 474 AD255 770 Adaptive Networking 97, 114, 170, 172, 695 Adaptive Networking Services 13 AD-aware switch 221 Adding a rule to an IP Filter policy 692

Adding devices (members) to a zone 578 adding filter-based monitors 763 adding new users 276 Adding zones (members) to a zone configuration 580 additional logical switches 501 addresses assigned 126 adjacent ISLs 43 admin 198 Admin access level 280 Admin Domain 195–196, 199, 220, 223, 225, 474, 500, 519 AD-aware switch 221 Admin Domain creation wizard 226 Admin Domain list 624 Admin Domain task 220 admin login 140 administration 17 Administration tools window 251 Administrative Domains 474 administrative privileges 274, 517 Advanced Encryption Standard 653 Advanced Feature 36 Advanced Feature summary 37 advanced mode 176, 236 Advanced Performance Monitoring 14–15, 78, 96, 118, 173, 739-740, 753 ALPA Error 781 SCSI commands 778 SCSI versus IP Traffic 780 SID/DID Performance 755 Advanced Zoning 13–15, 118 Advanced Zoning license 514 aggregate bandwidth 590 aging scheme 374 AL PA (PP) 283 Alarm Notifications tab, Fabric Watch View 299 alerts 349 alias 218, 517, 528, 550 creating 523-525, 547-549, 576 Alias Selection List 518 alias server 42-43 aliCreate command 576 ALPA Error monitor 781

analog telephone line 149 analyzing a zone configuration 539, 557, 559 ANSI standard-based implementation 470 Application Specific Integrated Circuit. See ASIC aptPolicy command 604 Arbitrated Loop 40, 283 ASIC 6, 40-42, 44-46, 50-51, 62, 78, 83-84, 88, 97, 589, 781 ASIC interrupts 43 Assigning ports 504 ATM gateways 282 attributes 641 audit 799 audit trail log file 395 AUTH policy restrictions 679 authentication 395, 635 authentication parameter settings 681 Authentication policy for fabric elements 674 authentication protocol used by the switch 681 Authentication protocols 680 authentication requests 395 authentication traps 265 Authentication, Authorization, and Accounting. See AAA automated tools 806 Automatic Distribution 115 Automatic Port Configuration 115 automatic trace dump 290 automatically enabled 483 auto-sensing 3, 41 auto-sensing capability 40 auto-sensing speed negotiation 41

#### В

back up zone configuration 561–564 zone configuration, CLI 581 zone configuration, USB device 566–567, 569–570 zone configuration, USB drive 582 backbone 23, 25, 27, 33, 112, 257, 745 Backbone Fabric ID change 114 backbone models 27 backbone-class 33 backing up a zone configuration 561 backplane 83 backup copy 561–562 backup FCS switches 293 backup files 393 backup options 393 balanced paths 76 bandwidth 33, 43-44, 96, 173, 590, 695, 726, 768, 770 bandwidth utilization 471 bandwidth, sharing 40 base logical switch 473 base switch 491, 494, 507 Basic Performance Monitoring 745 basic processor memories 45 basic setup functions 128 basic support software 92 Basic Zoning using Web Tools 543 basics of zoning 513 BasicSwitchAdmin 280 basicswitchadmin 199 BB Credit 282 BB_Credit Recovery 589 BE data processor 802 BE processor 802 Beacon button 215 beaconing 215 Blade Aggregate Throughput 745, 747 Blade Aggregate Throughput graph 747 BladeCenter 171 block chaining 653 Blocking Telnet 658 Bloom ASIC 781 Blowfish-Cipher 653 bottleneck identification 173 broadcast address 42 broadcast frames 561 broadcast packets 561 broadcast zone 561 Brocade 561, 566, 582, 786–787, 791 Native Fabric Mode 284 Native mode 621 Brocade HBA 93 browser, Web 201 BSH File 802 buffer allocation 597 buffer credits 596-597 buffer recovery credit 589 buffers 257, 282 buffer-to-buffer 282 burstv 82

#### C

CA 647 canvas loading 743 saving 742 canvas configuration 743-744 capacity 173 Capturing technical support information 396 carbon emissions 26 CEE 7, 26–27, 37 Certificate authorities 647 certificate authority 647 cfgAdd command 580 cfgClear command 619 cfoCreate command 579 cfgDelete command 580 cfgDisable command 619 cfgRemove command 580 cfgSave command 576-581 cfgTransAbort command 581 Change Discovery Switch 360 change the seed switch 357 Changing a logical switch to a base switch 491 Changing account parameters 631 Changing server port numbers 392 Changing the fabric ID 490 Changing the password 632 chassis-level attributes 640 chassis-role permission 625 class F interswitch frames 282 Class of Service 218 clearing changes from a zone configuration 581 Clearing changes to a zone configuration 581 Cloning an IP Filter policy 687 CNA 7 color coded connector 32 color coding 204 command-line interface (CLI) 43, 45, 131, 171, 290, 577, 579, 581 alias, creating 576 zone configuration, adding members 580 zone configuration, clearing changes 581 zone configuration, creating 579 zone configuration, deleting 580 zone configuration, removing members 580 zone, adding members 578 zone, creating 577 zone, deleting 579 zone, removing members 578

commands aliCreate 576 aptPolicy 604 cfgAdd 580 cfoClear 619 cfgCreate 579 cfgDelete 580 cfgDisable 619 cfgRemove 580 cfgSave 576-581 cfgTransAbort 581 configDownload 582, 584-586 configShow 143 configUpload 142, 581 configure 131, 141, 144, 610 date "MMDDhhmmYY" 144 defZone 619 fabricShow 141 fanShow 212 fastboot 144 fcPing 816 firmwareDownload 146 firmwareShow 147 haShow 137 help 836 interopmode 622 ipAddrSet 137 ipAddrShow 138 killTelnet 515 licenseAdd 171, 275 licenseldShow 269 licenseShow 274 pathInfo 816 portCfgIsIMode 588 portDisable 593 portEnable 171, 593 rcsDisabled 577 snmpConfig 266-267 switchDisable 141, 144, 593, 610, 619, 622 switchEnable 141, 144, 593, 619 switchName 131, 141 switchShow 142, 610 switchStatusPolicySet 311, 313 switchStatusShow 208, 311 tempShow 211 traceDump 290 traceTrig 290 version 147 zoneAdd 578

zoneCreate 577 zoneDelete 579 zoneRemove 578 communications privacy 635 community string 263, 265 Condor 41, 46, 84 Condor ASIC 55 Condor2 4, 87, 725 Condor2 ASIC 11, 36, 51, 53, 55, 61, 80 configDownload command 582, 584-586 configShow command 143 configUpload command 142, 581 configuration information 806 configuration parameters 126 configuration procedure, SAN768B 136 configuration upload 284, 571 configure command 131, 141, 144, 610 configure RADIUS 288 Configuring a logical switch for XISL 492 Configuring Authentication 395 Configuring SSH authentication 655 Configuring the port for extended distance 599 Configuring Virtual Fabrics 475 congested ISLs 172, 700 congestion 43, 97, 172, 695 connection utilization 384-385 Connectivity Map 344 connectors 596 console port 136 consolidated SAN design 25 consumers of bandwidth 754 context enforcement 640 control processor 13, 52 control processor blade 52 Converged Enhanced Ethernet (CEE) 7, 50 converged network adapter 7 cooling 26 copper pin 31 core 22-23, 30 core blades 13, 53 core PID 144, 621 core PID format 144, 609 core switching 11 core switching blades 76 core-to-edge 22 cost 605 counters 17, 112, 836 CP blade 148 CP8 52

CP8 blade 53 CR8 317 CR8 blade 53 CRC 48 CRC errors 751-752 creating a DCC policy 670 creating a device policy 671 creating a logical fabric 494 creating a logical switch 481 creating a zone 528-529, 550, 552, 577 creating a zone configuration 533, 553-554, 579 creating an account 628 creating an Admin Domain 225 creating an alias 523-525, 547-549, 576 creating an FCS policy 665 creating an IP Filter policy 687 creating an SCC policy 674 creating logical switches 502 creating the base switch 507 credentials 197 credit recovery 589 cryptographic keys 654 cryptography 635 CUP 78, 296 CUP statistics 112 current members 16 current product range 46 current switches 43 custom filters 766 cut-through 84

#### D

Data Center Fabric 21, 25, 323 Data Center Fabric Manager 121, 323 Data Center Fabric Manager Enterprise 121 data collection engine 794 data field size 282 data packets 590, 592 data protection 50 data traffic 560 date "MMDDhhmmYY" command 144 DCC 662 DCC policy 291, 293-294, 669 DCC policy name 294 DCC policy restrictions 670 DCC policy, defining 294 DCC violation 669 DCF 323

DCFM 117, 121, 182 DCFM and QoS zones 736 DCFM architecture 323 DCFM Compatibility 98 DCFM Enterprise 184, 324 DCFM Enterprise Edition 325 DCFM Fabric Discovery 356 DCFM GUI Orientation 337 DCFM Installation 327 DCFM Operating System Support 327 DCFM Professional 184, 324 DCFM Reports 363 DCFM scalability 326 DCFM server and 336 DCFM Server Management Console 390 DCFM to create a zone 529 DCFM view 346 debug data 806 dedicated connection 705 dedicated ISL 707 default accounts 626 default cost 607 default IP address 131 default logical switch 473 default Web Server port number 392 defined configuration 515, 709 defZone command 619 degraded 204 deleting zone 579 zone configuration 580 Deleting a device policy 672 Deleting a fabric 361 Deleting a rule in an IP Filter policy 693 Deleting a zone 579 Deleting a zone configuration 580 Deleting an account 633 Deleting an IP Filter policy 688 deleting user accounts 276 Desired Distance 239 destination domain 603 Device connection control 662 Device Connection Control policy. See DCC policy Device Connectivity Troubleshooting 813 Device Information 366 device level zoning 42 device ports 559 DH-CHAP 674-675, 681 diagnostic commands 45

diagnostics 45, 92, 126, 326 DID mode 95 digital certificates 646 director model types 40 director type 27 Disable Device Probing 282 Disabled Configuration 515 disabling a port 819 disabling failover 708 disabling Virtual Fabrics 479 discovered devices 340 Discovery 356, 358 Discovery Status 359 Discovery switch 357 **Discovery Verification** 362 Displaying ACL 662 disruption 44 distance value 596 Distributing the local ACL policies 685 DLS 603 DNS maps 200 DNS name 200 domain 76, 78, 110, 126, 131, 141 Domain ID 126, 131, 141, 217, 252-253, 284, 295 domain support 110 downloading a zone configuration 584 Downloading a zone configuration from a USB device 572.585 DPS 172, 471 dump generation 290 duplicate domain IDs 587, 610 Dynamic Load Sharing. See DLS Dynamic Path 5 Dynamic Path Selection 76, 89, 471 Dynamic Ports On Demand 171

#### Ε

E_D_TOV 282 E_Port 559, 603 E_Port authentication 676 E_Ports 31, 33 edge 22 EEPROM test 45 EFCM 323 effective configuration 515, 617, 709, 720 EGM 182 EGM license 182 elements 17 email address 271 email alerts 120 e-mail configuration 314 email configuration 314 email notification 120 enabling a zone configuration 534–536, 555–556 enabling the switch 506 Enabling Virtual Fabric on the switches 499 Enabling Virtual Fabrics 476 encryption 93, 645-646 encryption enhancements 96 Ending a Web Tools session 199 End-to-end monitoring 739 End-to-end monitoring with DCFM 761 End-to-end monitors 754 end-to-end monitors 173, 759 energy efficiency 12, 26 energy efficient 50, 89 Enhanced Group Management 97, 182, 326 enterprise data centers 25 Enterprise Edition 326 Enterprise Fabric Connectivity Manager 323 supported SAN hardware 470 enterprise-class 325 Environmental classes 301 Error Detect Time Out Value. See E_D_TOV Error log 257, 610, 806 error messages 139, 257 errors 374 Ethernet 126, 132 Ethernet cable 154 Ethernet protocol 7 Event Log 369-370 event type 373 events 144, 349, 369 Excel 803 Exchange Based Routing 591, 601–602 exchange-based load balancing 172 Expansion Port. See E Port Extended Fabric Activation 14–15, 78 Extended Fabric mode 596 Extended Fabric tab 600 Extended Fabric, configuring 596 Extended Fabrics 96, 174 eXtended ISL 471 EZSwitchSetup 118, 152–153, 156, 160, 163, 166-167.194 troubleshooting 167 upgrading 167

#### F

F Ports 559 fabric merging 608, 611 segmented 610 fabric address notification 283 Fabric Assist (FA) 514 Fabric Backbone 11 Fabric Configuration Server 662–663 Fabric Configuration Server policy. See FCS policy fabric core 23 Fabric Detail 365 Fabric Events task 217 fabric health information 124 Fabric ID 474 fabric infrastructure 25 Fabric Log 370 Fabric Login 126 Fabric Manager 17, 140, 145, 264, 323, 521 alias, creating 524–525, 548–549 trace route feature 816 Zone Admin 516–517 zone, adding a member 552 zone, creating 529, 552 fabric mode 770, 774 Fabric Operating System 37, 91 Fabric Operating System v6.2.0 features 92 Fabric OS 16-18, 40, 44-45, 92, 126, 257, 514, 519, 561, 566, 577, 582, 591, 595, 621, 623, 819 Fabric parameters 141, 144, 282 Fabric Port Name 218 Fabric Port WWN 218 fabric routing 603 Fabric Summary Report 364 Fabric Tracking 353 Fabric Watch 14–15, 17, 78, 97, 118–121, 173, 297-298, 301, 310 alarm 120 email notification 120 Port Fencing 173 Port Log Lock 120 RAPI Trap 120 SNMP trap 120 Switch Event log 120 threshold parameters 308 Fabric Watch View Alarm Notifications tab 299 Threshold Configuration tab 300–301, 307 FabricAdmin 280

fabricadmin 199 fabric-connected devices 514 fabricShow command 141 fabric-wide configuration changes 292 failover 147.214 Fan button 212 FAN. See Fabric Address Notification fanShow command 212 fastboot command 144 Fastboot switch 252 FC Ping 812 FC Routing 110 FC4 Type 218 FCoE 7, 26-27, 37 FCoE. See Fibre Channel over Ethernet (FCoE) fcPing command 816 FCR 114 FCR and FCIP Enhancements 93–94 FCR scalability 111 FCS 662-663 FCS Automatic Distribution 115 FCS enforcement 668 FCS policy 291-292, 663 FCS policy distribution 667 FCS policy management 665 FCS policy restrictions 664 FCS switches 293 FDMI host name 218 Federal Information Processing Standards (FIPS) 18 Fibre Channel 50, 171, 218, 561 Arbitrated Loop (FC-AL) 40 over Ethernet (FCoE) 50 Port address 217 Routing 174 Fibre Channel over Ethernet 7 Fibre Channel Routing (FCR) 174 FICON 78, 115, 786 FICON CUP 13, 78, 112, 115, 175, 296 FICON CUP Cascading 115 FICON Enhancements 93 FICON Log 370 FICON Management Server 97, 175 FICON support 112 FID 474 filter 42.373 filter monitors 763 filter type 307 Filter-based monitoring 739

filter-based monitors 173, 754, 763, 766 adding standard filter-based monitors 763 filter-based thresholds 307 filtered view 223 Filtering ports 640 filters 762-763 firewall 158, 295, 686 firmware 92.340 Firmware Download tab 259 firmware files 261 firmware update 145 firmware upgrade 260 firmware validation 284 firmware versions 260 firmwareDownload command 146 firmwareShow command 147 FL_Ports 559 FLOGI. See Fabric Login flow 133 Flow-Based QoS 114 flows 754 FOS 91 frame 43.591 Frame Based ISL Trunking 172 frame buffers 597 frame filtering 42, 76, 173 frame filtering, flow 42 Frame Redirection 95, 113 frame routing 51 frame routing priority 282 frame traffic 45 frames 84 FSPF 605, 709, 807 FSPF cost 95 FSPF Route 605 FSPF routing rules 709 FTP 290, 806 FTP Server 332 FTP server 284, 286, 806-807 back up zone configuration 562-564 downloading a zone configuration 584 full bandwidth 44 Full Fabric license 171

#### G

gateway 588 Gateway links 588 Generate Reports 363 Generating a public and private key 647 GeoTrust 647 GigE ports tab 249 GoldenEye 41, 46 GoldenEye2 6, 88, 725 grace period 193 graph 741, 747 Port Error 751 Port Snapshot Error 752 Port Throughput 745 printing 742 Switch Aggregate Throughput 747 Switch Percent Utilization 751 Switch Throughput Utilization 750

#### Η

HA button 213 hard zone 514 hardware components 8 haShow command 137 Hayes-compatible modem 147, 149 HBA authentication 95 health 212, 311, 785 help command 836 high availability 25, 50, 148, 213 High Availability window 213 High Performance Extension 96, 174 historical performance 374 historical performance data 378 historical performance graph 379-380 historical performance report 380 Home Admin Domain 195, 624 home domain 195 Home Virtual Fabric 624, 640 hop count 605 Host Bus Adapters 122 host ports 559 Hot Code Load 114 HTML 187 HTTPS 636

#### I

IBM Converged Switch B32 7, 172 IBM default settings 310 IBM System Storage and TotalStorage 40 IBM System Storage SAN switch 126 IBM System Storage SAN384B Director 9 IBM System Storage SAN768B 11 ICA 645 ICL 31.471 ICL cable connector 50 ICL Connectivity 314 ICL ports 31, 53 ICLs 97 ingress 701 Ingress Rate Limit 239 Ingress Rate Limiting 97, 172, 699, 701 Ingress Rate Limiting with Web Tools 703 ingress side 97 ingress speed 699 initialization 42, 127, 131, 133 initiate failover 213-214 in-order delivery 44, 590, 603 Insistent Domain ID Mode 282 Installation of DCFM Enterprise Edition 328 Integrated Routing 5–6, 37, 97, 112, 114, 170, 174 Integrated Routing support 111 Inter-Chassis Link 76, 471 Inter-Chassis Link (ICL) 12, 170, 314 cables 172, 317 cabling 317 connectivity 314 license 172 ports 317 internal log 257 Internet Certificate Authority 645 Interoperability 196 interoperability 13, 37 Interoperability mode 224 Interoperability settings 284 InteropMode 110, 112, 622 InteropMode 0 621 InteropMode 1 621 InteropMode 2 519, 621 InteropMode 3 621 InteropMode 2 112 interopmode command 622 inter-switch link (ISL) 13, 76, 173, 254, 592, 607-608 monitoring 769 monitors 173 ports 559 investment protection 73 IP addresses 340 IP Filter policy 291, 295, 662, 688 IP Filter policy distributions 693 IP Filter policy enforcement 691

IP Filter policy restrictions 694 IP Filter policy rules 689 IP Filtering 623 IP management interfaces 686 IP settings 255 IP traffic 739, 781 ipAddrSet command 137 ipAddrShow command 138 IPFilter 662 IPSec with IPv6 95 IPv4 295 IPv4 filter policy 689 IPv6 295 IPv6 Auto-configuration 95 IPv6 filter policy 689 IPv6 support 200 ISL counters 769 ISL monitoring 739 ISL monitors 754 ISL performance monitoring 768 ISL sharing 474 ISL Trunking 13-15, 43-45, 96, 118, 131, 174, 590 administering 592 group 591 license 592 license, enabling 593 long distance 596 trunk group 591–592 trunk master 591–592 trunk ports 592 trunk subordinate links 592

#### J

Java 118, 158, 187–188 Java plug-in 190 JavaScript 187 JRE 189

#### Κ

kernel panic 806 killTelnet command 515

#### L

L_Ports 559 Layer 2 fabrics 110 Layer-2 traffic isolation 471 LDAP 17 LDAP Enhancements 96 LDAPS 636 LEDs 53 Legend button 216 level of access 625 license activation keys 270 license administration 169 License ID 271 license key 92, 170, 179, 268, 274, 590 License tab 268 licenseAdd command 171, 275 licensed features 169 Adaptive Networking 170 Integrated Routing 170 Inter-Chassis Link (ICL) 170 licensed port 175, 237 licenseldShow command 269 licenseShow command 274 licensing 17, 170 8 Gbps 171 Full Fabric 171 Inter-Chassis Link (ICL) 172 Ports on Demand (PoD) 170 Licensing Behavior 113 licensing issues 179 licensing keys 179 lighthouse icon 216 Lightweight Directory Access Protocol. See LDAP limited switch license 193 line speed 701 link cost 607 link reset 589 link speed 41 Linux 92, 257 Listener applications 659 load balancing 89, 591 load distribution 32 load sharing 603 Local database user accounts 626 Local user database 625 logging events 144 Logging in to a Virtual Fabric 196 Logging in to an Admin Domain 196 logical fabric 471, 474, 712 logical grouping 474, 519 logical groups 514 logical ISL 43-44 logical switch 37, 473, 476 logical switch configuration 489

logical switches 470 logically partition 27 login window 195 logs 370 long distance 596, 598 long distance levels 596 Long Distance mode 239 long distance ports 597 loop initialization 283 loop-back function 45 low priority traffic 97 lower provisioning time 44 LSAN tagging 94 LSAN zone names 224 LSAN zones 224 LUN 778 LUN level zoning 42 LUN per port 779

#### Μ

M14 41 management console 390 management functions 17 management information base 638 Management tools 16, 18, 140 managing the Virtual Fabric 509 marching ants 386 mask 131, 256 master port 777 master trunk 595 McDATA 95 McDATA Fabric 470, 622 McDATA Fabric Mode 284 McDATA Fabric mode 621 McDATA interoperability 284 McDATA Open Fabric 470 McDATA Open Fabric Mode 284 McDATA Open Fabric mode 621 Member Selection List 549 members, adding to a zone 552, 578 members, adding to a zone configuration 580 members, removing from a zone 578 members, removing members from a zone configuration 580 memory 778, 806 merging fabrics 587, 608, 611 Merging fabrics example 612 methodologies 22

metric 605 MIB 638 migration 50 MIHPTO 112 Minimap 351 Missed Switches 361 Missing Interrupt Handler Primary Time-out 112 mixed fabrics 112, 514 modem cable 147, 149 connecting 149 connection 148 connection, verifying 151 lamps 151-152 Off Hook (OH) indicator 151 port 149 remote 150 Ring indicator 151 serial ports 147 setup 147, 150 modes 284 Modifying the order of FCS switches 666 modular switching platform 25 monitor 42, 139 monitoring 326, 374 Monitoring Fabrics 360 monitoring switch activity 280 multicast group 42 multicast routing table 42 multiple switch environments 587

#### Ν

N80B 88 name server 43 Name Server lookups 514 Name Server queries 708 Name Server table 217, 219 Name Server task 217 naming convention 670 native connectivity 110 native operating mode 224 Network Config 255 network configuration panel 257 Network tab 257 new messages 257 non-dedicated paths 708 non-disruptive failover 213-214 Nonsecure 637

non-volatile memory 778 number of frames 762 numbering scheme 84–85

#### 0

Object Naming 356 Obtaining certificates 649 one power supply 313 open fabric management 16 Open Fabric mode 621 Opening Web Tools 193 OpenSSH public key 654 operating parameter conflicts 620 operator 198, 280 optimal state 204 optimized behavior 695 Optionally Licensed Software 96 overlap 610 over-subscription 83

#### Ρ

packet filtering firewall 686 panic 290 partition a storage area network 514 partitioning 472 password 134, 137, 140, 151, 156 path selection protocol 709 Pathinfo 95 pathInfo command 816 pay-as-you-grow 17, 170 perfCfgSave command 777 performance 2, 43, 89, 173, 603 Performance class 306 performance counter engine 173 Performance Data 375 Performance Legend 350 performance management 373 performance management features 373 performance measures 375 Performance Monitor 299, 306-307, 740, 755 performance monitoring 42-43, 78 basic 744 Switch Utilization Throughput 741 performance monitoring tasks 739 performance reports 367 Performance Thresholds 381 Per-Frame Routing Priority 282 permissions 625

persistent disable 235, 241 persistent enable 235, 241 PID 621 Pipelining 94 PKI 635, 645 PLOGI activity 528, 551 POD license 6,87 pointers 806 point-to-point E_Port connectivity 588 Port Admin task 231 Port Administration 248 port area numbers 60, 62, 71–72 Port Based Routing 601 port blades 58, 136 port configuration 661 port density 51 Port Error 745 Port Error graph 751 Port Fencing 116, 173, 819 Port Fencing for E_Port class link loss 834 Port Fencing using DCFM 820 Port Identifier (PID) 142–143 port information 231 Port IP Address 218 port level zoning 42 Port Log Lock 120 Port Mirroring 116 Port mode 770 Port Name 218 port number 217, 236 port numbering 88 port position 217 Port Report 364 port selection 745 Port Snapshot Error 745 Port Snapshot Error graph 752 port speeds 172 port states 206 Port Throughput 745 port throughput capability 46 Port Throughput graph 745 port-based routing 602 portCfgIsIMode command 588 portDisable command 593 portEnable command 171, 593 portErrShow 836 porterrshow counters 837 Ports On Demand 17 Ports on Demand 96

Ports on Demand (PoD) enabling 170 license 170 licensing 170 Ports tab 289 POST 45, 126, 128, 136, 151 Power button 212 power consumption 12, 26, 47, 75, 89 power supply 17, 84, 212, 310-311, 313 power-on self tests 45 predefined accounts 626 predefined role 625 Preflight check 798 primary FCS switch 293, 663 principal 319 principal ISL 592 principal switch 126 Prioritization 114 priority 724 priority flows 726 priority traffic 705 problem determination 217 Product List 342 Product Status Log 370 Professional Edition 327 protocol 121 protocol level zoning 42 public key 284 public key infrastructure 635, 645 public loop 218, 283 PuTTY 296

#### Q

QoS Zones 726 QoS zones 730 Quality of Service 97, 172, 770 quick setup 152 Quickloop 550

#### R

R_A_TOV 282 RADIUS 17, 287 RADIUS Enhancements 95 RAPI Trap 120 RASLOG 806–807 rate limit configuration 700 RBAC 198, 625 rcsDisabled command 577 real life example of Virtual Fabrics 495 real time performance 374 Real Time Performance Data 376 real-time monitoring 173 Re-authenticating E_Ports 682 reboot 252 recipient IP address 264 recovery logic 589 Redbooks Web site Contact us xxii redundant control processors 76 Refresh Frequency 188 Registered State Change Notification. See RSCN Reliable Commit Service (RCS) 577 Remote LDAP server 624 Remote RADIUS server 624 Remote Switch 603 Removing devices (members) from a zone 578 Removing Thresholds for Port Fencing 826 replication 50 report window 252, 286 Requirements for Admin Domains 224 Resource Allocation Time Out Value. See R A TOV Restoring the database 393 RLS probing 284 Role 624 Role-Based Access Control 198, 625 Role-Based Access Control (RBAC) 18 role-based permissions 199 root certificates 651 round trip time 816 routes 44 routing 42, 84 Routing icons 342 routing information 816 routing table 126, 605 multicast 42 routing tables 42, 126 unicast 42 RSCN 42, 118, 283 RX Power 303

#### S

S 653 SAN design 22 SAN Director 14–15 SAN Health 785–787, 791, 799, 804 SAN Layout 803 SAN04B-R Upgrade 98 SAN16B 171 SAN24B-4 3, 170, 173 SAN256B 14-15, 45, 78, 85, 90, 133, 136, 147, 213, 235, 251 SAN256B architecture 80 SAN32B-2 133, 171 SAN32B-3 152 SAN348B 92 SAN384B 9.76 SAN40B-4 4, 87, 170, 173–174 SAN64B 171 SAN768B 11-13, 50, 131, 140-141, 143, 172-174, 213, 314 SAN768B architecture 64.66 SAN80-B4 6 SAN80B-4 170, 173–174 save the configuration 286 save the configuration changes 532 Saved Configuration 515 Saving an IP Filter policy 688 scalability 110 scalability limits 111 scalable 3 SCC 662 SCC policies 673 SCC policy 291, 294 SCP 636-637 SCSI 739, 762 SCSI commands monitors 778 SCSI commands rate 739 SCSI INQUIRY 218 SCSI traffic 781 SCSI versus IP Traffic monitor 780 SDRAM 45 secret key pair 677, 683 Secret key pairs 683 Secure 637 secure access 645 Secure Fabric OS 18, 623 Secure file 637 secure file copy 637 secure login channel 654 secure network 654 secure protocols 635 secure shell 653 Secure Shell protocol 653 Secure Sockets Layer protocol 645

security 16-17 external 17 frame filtering 17 physical access 17 policies 280 software based 17 within SAN 17 zoning 17 Security Activation 14-15 Security Enhancements 93, 95 security features 623 Security level 641 Security Log 371 security policies 291, 662 security problems 819 security protocols 635 SecurityAdmin 280 securityadmin 198 Seed Switch 356 seed switch 360 SEEPROM 48 segmented fabric 610 Sequence Level Switching 282 serial cable 132-133, 135-137 serial communication programs 133, 136, 150 serial connection 134, 136, 139 serial numbers 331, 340 serial port 126, 133, 135 SerialLink 45 Server Application Optimization 98 service level agreements 121, 124 Session management 199 Setting a secret key pair 684 setting the domain id 506 Setting up SCP 637 settings 131, 144 setup 126 SFP 46.142 SFP classes 303 sharing 44 shipping plug 133, 135, 140-141 shortest path 710 SID/DID 306 SID/DID pairs 759, 770 SID/DID Performance monitor 755 SID/DID prioritization 172 Simple Network Management Protocol 121, 638 sions 198 SLA 121

SMC 390 SNMP 17, 43, 121, 265-266, 636, 638 trap 304 SNMP access control list 638 SNMP and Virtual Fabrics 640 SNMP tab 263, 265 SNMP trap 120 snmpConfig 641 snmpConfig command 266-267 SNMPv1 636 SNMPv1 trap 264 SNMPv2 636 SNMPv3 636 SNMPv3 trap 265-266 soft zone 514 SoTCP Enhancements 95 speed 40, 42, 45, 239 splicing 596 SSH 636, 653 SSH client 296 SSH public key authentication 654 SSHv2 636 SSL 636.645 SSL configuration overview 646 stabilization period 770 standby CP blade 136, 139-140, 148, 151-152 static route 606 statistics gathering 766 status 352 Status Bar 352 Status button 205, 310 Status Icons 342 status information 806 subordinate 320 subordinate port 777 summary information 252 SupportSave 807 supportShow 806 suspend discovery 360 switch health 205 Switch Admin task 250 switch administration 280 Switch Administration window 251 Switch Aggregate Throughput 745 Switch Aggregate Throughput graph 747 switch authentication 675 Switch Availability Monitoring Report 209 switch configuration 259, 280

Switch connection control 662 Switch Details 365 Switch Event log 120 switch functionality 45 switch information for support 398 Switch Manager utility 166 switch model types 40 switch name 131, 140, 201, 252-253 Switch Percent Utilization 745 Switch Percent Utilization graph 751 Switch tab 252 Switch Throughput Utilization 745 Switch Throughput Utilization graph 750 switch user database 475 Switch Utilization Throughput 741 switch WWN 271 switchadmin 198 SwitchAdmin access level 280 switchDisable command 141, 144, 593, 610, 619, 622 switchEnable command 141, 144, 593, 619 switches modify settings 310 Switch-level attributes 640 switchName command 131, 141 switchShow command 142, 610 switchStatusPolicySet command 311, 313 switchStatusShow command 208, 311 Synchronize Services 214 Syslog Log 371 syslogd 257 system memory 290

#### Т

Technical Support Information 396 Telco wiring 149 Telnet 136, 140, 142–143, 145, 208, 211–212, 266, 274, 296, 311, 313, 577, 584, 590, 592, 596, 763 alias, creating 576 zone configuration, adding members 580 zone configuration, clearing changes 581 zone configuration, creating 579 zone configuration, creating 579 zone configuration, removing members 580 zone, adding members 578 zone, creating 577 zone, deleting 579 zone, removing members 578 Telnet protocol 658 Temp button 210 temperature 17 temperature information 210 temporary internet files 188 Temporary License Support 98 temporary licenses 93 temporary use 98 tempShow command 211 terminal emulator application 132-134, 136, 150 threshold 314 threshold configuration 299 Threshold Configuration tab, Fabric Watch View 300-301, 307 threshold parameters 308 Thresholds for the Environmental classes 301 throttle 172 throughput 43, 46 TI zone failover 707 TI zones 706 TI zones with DCFM 721 tight bends 596 timeout value 145, 289, 603 time-saving tools 123 toolbar 339 Toolbox 345 Top Talker monitors 769 Top Talkers 695 Top Talkers monitoring 173, 739 Top Talkers monitors 754, 770, 776 adding 771, 774 deleting 771, 775 displaying 775 displaying information 771 fabric mode 774 top-of-rack 7.27 topology 42, 142 topology changes 603, 606 TopTalkers feature 96 trace buffer 290 trace dump 290-291, 806-807 trace route 812, 816 Trace Route Summary 818 Trace tab 290 traceDump command 290 traceTrig command 290 tracing 290 Tracking Icons 342 traffic 172, 374, 728

traffic control 172 traffic flow 726 Traffic Isolation 114-115, 705 Traffic Isolation zones 706 traffic load 42 Traffic Management 696, 705 traffic patterns 81-82 Traffic Prioritization 725 Traffic prioritization 729 traffic prioritization 724 transaction 693 transaction key 179, 271 transmission 592 transmitter negotiation 126 trap level 263, 265-266 trap recipients 263 troubleshooting 326, 785, 835 Troubleshooting device connectivity 813 troubleshooting ports 751 trunk aroup 591–592 trunk master 591-592 trunk master link 44 trunk monitoring 777 trunk ports 592, 595 trunk speeds 89 trunk subordinate links 592 trunking group 141 Trunking tab 296 trunks monitoring 777 trusted key agent 645 TX Power 303

#### U

Unblocking a Fenced port 827 Unblocking Telnet 659 unicast 126 unicast routing table 42 unidirectional 172 unmonitor fabrics 363 updating a zone configuration 553–554 upgrades 109 upload 259 USB 4, 11, 52, 259, 284 USB drive 561, 566, 582 USB memory key 259 USB port 7, 259 user 199 User access level 280 user accounts 475, 625 User accounts overview 624 user administration tasks 278 User authentication 624 User tab 276

#### V

Value line licenses 193 vendor company 218 Verisign 647 version command 147 VF 94 VF-capable switches 499 View Report button 254 Viewing technical support information 400 Viewing the list of secret key pairs 683 virtual channel ID 282 Virtual Channels 725 virtual channels (VC) 172, 282-283 virtual channels parameters 283 Virtual Fabric 5-6, 10, 37, 640 Virtual Fabric configuration 712 Virtual Fabric is disabled 499 Virtual Fabric list 624 Virtual Fabrics 92, 94, 110, 113, 196, 700, 753 Virtual Fabrics introduction 470 virtualization 11, 50 Visio 786. 803-804 Visio Viewer 805 VxWorks 92

#### W

watchdog 806
watchdog timer 290
Web browser 201
Web Tools 14–15, 17, 78, 118, 140, 145, 170–171, 175, 260, 262, 284, 310, 314–315, 555, 566, 590, 594, 596, 598, 610
Beacon button 215
buttons 204
EZ error message 167
Fabric Tree panel 202
Fan button 212
features 118
HA button 213

High Availability window 213 Legend button 216 Performance Monitor 740 Power button 212 Status button 205 Switch Events, Information panel 202 Switch View panel 202 Tasks panel 202 Temp button 210 Zone Admin 516-517, 521 Web Tools license 182 Web Tools to create a zone 551 workload peaks 43 world wide name 48 worldwide name. See WWN WWN 48, 76, 179, 340 zoning WWN cards 74 WWN Display 355 **WWNN 218** WWPN 217-218

#### Х

XISL 471, 474 XISLs 492

#### Ζ

Zone Admin 516-517 Zone Admin task 220 zone configurations 515, 534 zone database 519 zoneAdd command 578 ZoneAdmin 280 zoneadmin 199 zoneCreate command 577 zoneDelete command 579 zoneRemove command 578 zones 217-218 zoning 41-42, 172, 514, 516, 609 adding a member 552 adding members 578 adding members to a configuration 580 administrative privileges 517 Advanced 161 analyzing a configuration 557 analyzing a zone configuration 559 back up a configuration 561-564, 566-567, 569-570, 581-582

check 816 clearing changes from a configuration 581 configuration 161, 517, 611 conflicts 559 creating 577 creating a configuration 553-554, 579 creating a zone 528–529, 550, 552 Custom 161 deleting 579 deleting a configuration 580 downloading a configuration 584 enabling a configuration 535–536, 555–556 hard zone 514 icon 220 implementing 521 information 611 license 170, 517 managing 521 removing members 578 removing members from a configuration 580 segmentation 612 soft zone 514 Typical 161 updating a zone configuration 553–554 Zoning Activation 521 zoning configuration 706 zoning configuration conflicts 587 Zoning Consideration 709 zoning elements 518 Zoning Offline 521 Zoning Online 521 zoning reports 367



(1.5" spine) 1.5"<-> 1.998" 789 <->1051 pages

# Implementing an IBM b-type SAN with 8 Gbps Directors and Switches



Learn about the latest additions to the IBM b-type portfolio

Refresh and enhance your skills and awareness

# Increase your SAN knowledge

"Do everything that is necessary and absolutely nothing that is not."

This IBM Redbooks publication, written at a Data Center Fabric Manager v10.1.4 and Fabric Operating System v6.4 level, consolidates critical information while also covering procedures and tasks that you are likely to encounter on a daily basis when implementing an IBM b-type SAN.

The products that we describe in this book have more functionality than we can possibly cover in a single book. A storage area network (SAN) is a powerful infrastructure for consolidation, distance solutions, and data sharing. The quality applications that the IBM SAN portfolio provides can help you take full advantage of the benefits of the SAN.

In this book, we cover the latest additions to the IBM b-type SAN family and show how you can implement them in an open systems environment. In particular, we focus on the Fibre Channel Protocol (FCP) environment. We address the key concepts that these products bring to the market and, in each case, we provide an overview of the functions that are essential to building a robust SAN environment.

#### INTERNATIONAL TECHNICAL SUPPORT ORGANIZATION

#### BUILDING TECHNICAL INFORMATION BASED ON PRACTICAL EXPERIENCE

IBM Redbooks are developed by the IBM International Technical Support Organization. Experts from IBM, Customers and Partners from around the world create timely technical information based on realistic scenarios. Specific recommendations are provided to help you implement IT solutions more effectively in your environment.

For more information: ibm.com/redbooks

SG24-6116-10

ISBN 0738435376